


Use the GPIO pins of the ESP32

ESP32 Wroom DevKit Full Pinout




(Updated at 08/18/2022)

Find all the relevant information about the ESP32 pinout on a single page to use these GPIO pins for your DIY electronics project correctly. Even though there are many variations of ESP32 boards, the function of the pins remains the same. However, some pins may not be available, depending on your model.

There are plenty of ESP32 boards out there with different pin arrangements. Here is a detailed pin diagram of 2 different ESP32 boards. It will be beneficial to know the specific functions of each pin:

- **ESP32 WROOM Generic DevKit**


ESP32 Wroom DevKit Full Pinout



Pinout of an ESP32 board

- **uPesy ESP32 WROOM DevKit**

ESP32 Wroom DevKit Rev2 Full Pinout




Pinout of the uPesy ESP32 Wroom DevKit board

The particular behavior of some pins of the ESP32

Note

The goal is to inform you about the limitations of some GPIO pins of the ESP32 to avoid unpleasant surprises during your projects or having an incomprehensible bug in your code. A significant difference between the two boards that are not necessarily obvious is their width: The uPesy ESP32 board can be put on a breadboard, and you can access the pins on both sides, unlike most other ESP32 boards that are too "big" to be used on a breadboard. ESP32-based development boards typically have 33 pins except those for the power supply. Some GPIO pins have a little bit particular functionings:

- If your ESP32 board has the GPIO6, GPIO7, GPIO8, GPIO9, GPIO10, and GPIO11 pins, **you must not use them** because they are connected to the flash memory of the ESP32: if you use them, the ESP32 will not work.



Pins connected to the Flash memory of the ESP32

GPIO Possible name

- 6 SCK/CLK
- 7 SDO/SD0
- 8 SDI/SD1
- 9 SHD/SD2
- 10 SWP/SD3
- 11 CSC/CMD

Note The GPIO1 (TX0) and GPIO3 (RX0) pins are used to communicate with the computer in UART via USB. If you use them, you will not be able to upload programs to the board or use the serial monitor via the USB port. They are not available on uPesy ESP32 boards. For this reason, these pins are not available on uPesy ESP32 boards. You can use an external programmer instead. Fortunately, there are other UART interfaces available.

- Pins GPIO36 (VP), GPIO39 (VN), GPIO34, and GPIO35 can only be used as input. They also do not have internal pull-up and pull-down resistors (`pinMode(36, INPUT_PULLUP)` or `pinMode(36,`

INPUT_PULLDOWN) cannot be used).

- Some pins have a unique function when starting the ESP32. These are called **ESP32 Strapping Pins**.

Voltage of Internal LDO (VDD_SDIO)					
Pin	Default	3.3 V	1.8 V		
MTDI	Pull-down	0	1		
Bootling Mode					
Pin	Default	SPI Boot	Download Boot		
GPIO0	Pull-up	1	0		
GPIO2	Pull-down	Don't-care	0		
Enabling/Disabling Debugging Log Print over U0TXD During Bootling					
Pin	Default	U0TXD Active	U0TXD Silent		
MTDO	Pull-up	1	0		
Timing of SDIO Slave					
Pin	Default	FE Sampling FE Output	FE Sampling RE Output	RE Sampling FE Output	RE Sampling RE Output
MTDO	Pull-up	0	0	1	1
GPIO5	Pull-up	0	1	0	1

Strapping pins of the ESP32

They are used to put the ESP32 in **BOOT** mode (to run the program written in the flash memory) or in **FLASH** mode (to upload the program to the flash memory). Depending on the voltage available on these pins, the ESP32 will start either in **BOOT** mode or in **FLASH** mode.

The strapping pins are the **GPIO0**, **GPIO2**, **GPIO12 (MTDI)** and **GPIO15 (MTDO)**. You can use them, but you must be careful when setting a logic state (3.3V or 0V) with an external pull-up or pull-down resistor.

Tip

If your ESP32 board works correctly, but when you add a sensor, nothing works anymore (it is impossible to upload a program or launch it), it is most likely related to these famous strapping pins.

- When booting the ESP32, during a short period, some pins quickly change their logic states (0V → 3.3V). You may have weird bugs with these pins: for example, a relay that temporarily activates. The faulty pins are the following:
 - GPIO 1** : Sends the ESP32 boot logs via the UART
 - GPIO 3** : 3.3V voltage at boot time
 - GPIO 5** : Sends a PWM signal at boot time
 - GPIO 14** : Sends a PWM signal at boot time
 - GPIO 15** : Sends the ESP32 boot logs via the UART
- The EN pin can activate or deactivate the ESP32 via an external wire. It is connected to the board's EN button. When the ESP32 is on, it is at 3.3V. If you put this pin to the ground, the ESP32 is off. This can be used when the ESP32 is in a box and you want to be able to turn it on/off with a switch.
Note that we can use these pins. If you encounter a strange behavior when starting the ESP32 by using one of these pins that will probably have to choose another one.
- On some pins that will probably have to choose another one more RAM (for example, on the [uPesy ESP32 Wrover DevKit board](#)), then the GPIO16 and GPIO17 pins are not available because they are used internally by the PSRAM.
- Others GPIO pins have no particular restrictions.

Summary of all ESP32 GPIO pins

Summary of all ESP32 GPIO pins			
GPIO	INPUT	OUTPUT	Comments
0	YES (Internal pull-up)	YES	Must be at 0V during the FLASH
1 (TX0)	NO	YES	UART communication with the PC
2	YES (Internal pull-down)	YES	Must be at 0V during the FLASH
3 (RX0)	YES	NO	UART communication with the PC
4	YES	YES	
5	YES	YES	
6	NO	NO	Connected to the internal flash
7	NO	NO	Connected to the internal flash
8	NO	NO	Connected to the internal flash
9	NO	NO	Connected to the internal flash
10	NO	NO	Connected to the internal flash
11	NO	NO	Connected to the internal flash
12 (MTDI)	YES (Internal pull-down)	YES	Must be at 0V during the BOOT
13	YES	YES	
14	YES	YES	
15 (MTDO)	YES (Internal pull-up)	YES	Startup log if at 3.3V
16	YES	YES	Not available on WROVER
17	YES	YES	Not available on WROVER
18	YES	YES	
19	YES	YES	
21	YES	YES	
22	YES	YES	
23	YES	YES	
25	YES	YES	
26	YES	YES	
27	YES	YES	
32	YES	YES	
33	YES	YES	
34	YES	NO	No internal pull-up/pull-down
35	YES	NO	No internal pull-up/pull-down
36 (VP)	YES	NO	No internal pull-up/pull-down
39 (VN)	YES	NO	No internal pull-up/pull-down
EN	NO	NO	Connected to the EN button (ESP32 Reset)

ESP32 Peripherals

To interact with the modules, sensors or electronic circuits, the ESP32, like any microcontroller, has a multitude of peripherals. They are much more numerous than on a classic Arduino Uno board.

The ESP32 has the following peripherals:

- [3 UART interfaces](#)
- [2 I2C interfaces](#)
- [3 SPI interfaces](#)
- [16 PWM outputs](#)
- [10 capacitive sensors](#)

- 18 ADC channels
- 2 DAC outputs

The ESP32 already uses some peripherals in its essential operation. So, in reality, there are fewer possible interfaces for each device.

Tip

The pins of the ESP32 are much more modular than those of the Arduino: **You can “ attach “ a UART, I2C, SPI, and PWM peripheral on the pins you want.** The SPI, I2C, UART, PWM, and DAC are no longer associated with specific pins. For example, on the Arduino Uno, you could only have SPI on pins 10, 11, 12, and 13. With the ESP32, you can choose the ones you want. Only the ADC and the capacitive sensors are assigned to fixed pins. ESP32 Pinouts available on the Internet show the default association (if you do not specify the pins used). It remains a good practice to use the pins by default to keep good compatibility with external libraries as long as this does not limit the connection of your wires.


UART on ESP32

The UART is the serial protocol that allows easy data exchange between 2 devices. On the ESP32, 3 UART buses are available: UART0, UART1 and UART2. We can use them to communicate with a sensor, an Arduino, a Raspberry Pi, a computer ...

- The UART0 is by default on pins GPIO1(TX0) and GPIO3(RX0) of the ESP32. It is used to communicate with the computer through the serial monitor. It is also the one used to flash the ESP32 board when uploading a new program. It generally displays messages in the console with `Serial.println()` .
- To use the UART2, simply add `Serial2.begin()` in the function `setup()` and to use the `Serial2.println()` to send messages. By default, the UART2 bus is on pins GPIO16(RX2) and GPIO17(TX2), but you can change them (useful with a Wrover module) during setup. This simple code allows you to use the UART2 bus:

```
void setup() {
  Serial2.begin(115200);
}

void loop() {
  Serial2.println("Hello from UART2");
  delay(100);
}
```



Message sent via UART2 from pin GPIO17

- The UART1 is by default on the pins used by the ESP32 flash. However, We can use it by choosing the pins you want, thanks to the “GPIO matrix” of the ESP32. Thus this code allows having a serial interface on the pins GPIO14 and GPIO12 by using the UART1 bus.

```
void setup() {
  /*
  * UART1 -> Serial1
  * RX Pin -> GPIO 14
  * TX Pin -> GPIO 12
```


```

* UART Configuration -> SERIAL_8N1
*/
Serial1.begin(115200,SERIAL_8N1,14,12);

}

void loop() {
  Serial1.println("Hello from UART1");
  delay(100);
}

```



Message sent via UART1 from pin GPIO12

I2C on ESP32

The ESP32 has **2 I2C buses** :

- The I2C0 bus is the one used by default by Arduino libraries. It is connected to the pins **GPIO22 (SCL)** and **GPIO21 (SDA)** of the ESP32. It can be used on any pin of the ESP32 when you use the `Wire.h` library by specifying the pins with the function `Wire.begin(SDA_PIN, SCL_PIN)` .
- The I2C1 bus can also be used on any pin (pay attention to the “limited pins” described previously). Here is an example that uses the second I2C bus:

```

#include <Wire.h>

TwoWire I2C1 = TwoWire(1);

void setup() {
  I2C1.begin(14,12,400000); // SDA pin 14, SCL pin 12, 400kHz frequency
}

void loop() {
  I2C1.beginTransmission(0x42);
  I2C1.write(140);
  I2C1.endTransmission();
  delay(100);
}

```

SPI on ESP32

Even if the ESP32 has 3 SPI buses, we can use only two because the internal flash memory uses one. The two available SPI buses are called VSPI and HSPI.

By default, the pin mapping is as follows:

Note

SPI MOSI MISO SCK/CLK CS/SS

VSPI GPIO 25 GPIO 19 GPIO 18 GPIO 5

HSPI GPIO 13 GPIO 12 GPIO 14 GPIO 15

As for the I2C, it is possible to manually choose the pins you want to use for the SPI by specifying the pins during the initialization of the SPI `bus.begin(CLK_PIN, MISO_PIN, MOSI_PIN, SS_PIN);`

PWM on ESP32

The ESP32 has 16 channels that can be used to generate PWM signals: you can have up to 16 different PWM outputs. All the pins configured as output can be used to output a PWM signal. The use of PWM differs from Arduino's, and you can configure more parameters. I suggest you check [the usage of PWM on ESP32 with Arduino code](#) to use it in your projects.

Capacitive sensors on the ESP32

The ESP32 has ten capacitive sensors (9 if the GPIO0 pin is unavailable). They can be used as touch buttons. They are the famous *TOUCH* pins that can be found on some ESP32 pinouts. They can also be used to wake it up when the ESP32 is in DeepSleep mode (a power-saving mode). I invite you to read [the use of capacitive sensors on the ESP32 with the Arduino code](#) for more details.

The internal capacitive sensors are connected to the following GPIO pins:

TOUCH0 TOUCH1 TOUCH2 TOUCH3 TOUCH4

GPIO 4 GPIO 0 GPIO 2 GPIO 15 GPIO 13

TOUCH5 TOUCH6 TOUCH7 TOUCH8 TOUCH9

GPIO 12 GPIO 14 GPIO 27 GPIO 33 GPIO 32

ADC on ESP32

The ESP32 has two separate ADC: ADC1 with eight channels and ADC2 with ten channels for a total of 18 analog inputs. For example, on the GPIO34, you will find channel number 6 of the ADC1 (ADC1_CH6). But in practice, there are far fewer available because of Wi-Fi.

Warning

The ADC2 cannot be used when Wi-Fi is enabled: The ESP32 Wi-Fi driver uses it to work.

Mapping for ADC1

ADC1_CH0 ADC1_CH1 ADC1_CH2 ADC1_CH3

GPIO 36 GPIO 37 GPIO 38 GPIO 39

ADC1_CH4 ADC1_CH5 ADC1_CH6 ADC1_CH7

GPIO 32 GPIO 33 GPIO 34 GPIO 35

Mapping for ADC2 (rarely used)

ADC2_CH0 ADC2_CH1 ADC2_CH2 ADC2_CH3 ADC2_CH4

GPIO 4 GPIO 0 GPIO 2 GPIO 15 GPIO 13

ADC2_CH5 ADC2_CH6 ADC2_CH7 ADC2_CH8 ADC2_CH9

GPIO 12 GPIO 14 GPIO 27 GPIO 25 GPIO 26

Generally, the GPIO37 and GPIO38 pins are not available if your board has a WROOM or WROVER module. These modules do not expose these pins. Only boards that use the ESP32 board directly (without a module) may expose them.

In general, the ESP32 ADC is not very reliable despite its 12-bit resolution. I invite you [to read the article on the use and limitations of the ESP32 ADC](#) for more information.

DAC on ESP32

The ESP32 has two 8-bit DAC outputs to convert a digital signal into an analog signal (generate a sine signal, for example). The pins used are the following:

DAC1 DAC2

GPIO 25 GPIO 26

Note

The DAC only has a resolution of eight bits. It is insufficient for audio applications without deterioration. It is better to use an external DAC with a higher resolution (12-24 bits) with the I2S bus of the ESP32.