

NAME

foo2xqx-wrapper – Convert Postscript into a XQX printer stream

SYNOPSIS

foo2xqx-wrapper [*options*] [*ps-file*]

DESCRIPTION

foo2xqx-wrapper is a Foomatic compatible printer wrapper for the **foo2xqx** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to XQX printer format for driving the HP LaserJet P1005/P1006/P1007/P1008, the HP LaserJet P1505, the HP LaserJet P2014, the HP LaserJet M1005 MFP, the HP LaserJet M1120 MFP, the HP LaserJet Pro M1132s MFP, the HP LaserJet Pro M1212nf MFP, and other XQX-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-d duplex

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
---	-----	---	-----------	---	------------

-m media

Media code to send to printer [1].

Media	M1005
standard	1
transparency	2
envelope	257
letterhead	259
thick	261
postcard	262
labels	263

-p paper

Paper size code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch	257	16k 197x273
263	16k 184x260	263	16k 195x270

-n copies

Number of copies [1].

-r xresxyres

Set device resolution in pixels/inch [1200x600].

-s source

Source (Input Slot) code to send to printer [7].

1	upper	4	manual
2	lower	7	auto

-t Draft mode. Every other pixel is white.

-T *density*

Print density (1-5). The default is 3 (medium).

-2 -3 -4 -5 -6 -8 -9 -10 -12 -14 -15 -16 -18

Print in N-up. Requires the **psutils** package.

-o *orient*

Orientation used for N-up.

Portrait -op (normal)

Landscape -ol (rotated 90 degrees anticlockwise)

Seascape -os (rotated 90 degrees clockwise)

Printer Tweaking Options

These are the options used to customize the operation of **foo2xqx** for a particular printer.

-u *xoff yoff*

Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

-l *xoff yoff*

Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

-L *mask*

Send the logical clipping values from -u/-l in the ZjStream. **foo2xqx-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.

0 don't send any logical clipping amounts

1 only send Y clipping amount

2 only send X clipping amount

3 send both X and Y clipping amounts

Debugging Options

These options are used for debugging **foo2xqx** and its wrapper.

-D *level*

Set Debug level [0].

EXAMPLES

Create a monochrome ZjStream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2xqx-wrapper testpage.ps > testpage.xqx
xqxdcode < testpage.xqx
lpr -P raw testpage.xqx
```

FILES

/usr/bin/foo2xqx-wrapper

SEE ALSO

foo2xqx(1), xqxdecode(1)

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2xqx.rkkda.com/>