

Note: Vsup, Isn+/- power board connections are not used in the non-PFC version. Also, a number of components are not populated for that version. See detailed build manuals

