



MPLAB[®] IPE
(Integrated Programming Environment)
User's Guide

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Trademarks

The Microchip name and logo, the Microchip logo, dsPIC, FlashFlex, flexPWR, JukeBlox, KEELOQ, KEELOQ logo, Klear, LANCheck, MediaLB, MOST, MOST logo, MPLAB, OptoLyzer, PIC, PICSTART, PIC³² logo, RightTouch, SpyNIC, SST, SST Logo, SuperFlash and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

The Embedded Control Solutions Company and mTouch are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, BodyCom, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, ECAN, In-Circuit Serial Programming, ICSP, Inter-Chip Connectivity, KlearNet, KlearNet logo, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, RightTouch logo, REAL ICE, SQI, Serial Quad I/O, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2013-2015, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-63277-593-1

**QUALITY MANAGEMENT SYSTEM
CERTIFIED BY DNV
= ISO/TS 16949 =**

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

Table of Contents

Preface	5
Chapter 1. IPE Application Overview	
1.1 IPE Defined	9
1.2 Software Installation Requirements	9
1.3 Programming Tools Supported	10
1.4 IPE Modes	10
Chapter 2. General Setup	
2.1 Introduction	13
2.2 Launching the IPE Application	13
2.3 Setting Up the Programmer	14
2.4 Advanced Mode Login	17
2.5 Advanced Mode Settings	18
2.6 Creating Desktop Shortcuts	28
Chapter 3. IPE Reference	
3.1 IPE Main Window	31
3.2 File Menu	33
3.3 View Menu	34
3.4 Settings Menu	39
3.5 Help Menu	40
Appendix A. Revision History	
Support	43
Index	45
Worldwide Sales and Service	48

MPLAB® IPE USER'S GUIDE

NOTES:

Preface

NOTICE TO CUSTOMERS

All documentation becomes dated, and this manual is no exception. Microchip tools and documentation are constantly evolving to meet customer needs, so some actual dialogs and/or tool descriptions may differ from those in this document. Please refer to our web site (www.microchip.com) to obtain the latest documentation available.

Documents are identified with a “DS” number. This number is located on the bottom of each page, in front of the page number. The numbering convention for the DS number is “DSXXXXXXXXA”, where “XXXXXXXX” is the document number and “A” is the revision level of the document.

For the most up-to-date information on development tools, see the MPLAB® X IDE online help. Select the Help menu, and then Topics to open a list of available online help files.

INTRODUCTION

This chapter contains general information that will be useful to know before using the MPLAB® Integrated Production Environment (IPE). Items discussed in this chapter include:

- [Document Layout](#)
- [Conventions Used in this Guide](#)
- [Recommended Reading](#)

DOCUMENT LAYOUT

This document describes how to use the IPE as a programming tool to program devices. The document is organized as follows:

- **Chapter 1. IPE Application Overview** – Defines the IPE, provides software installation requirements and upgrade procedures, lists the supported tools, and provides a feature matrix.
- **Chapter 2. General Setup** – Discusses launching and setting up the application, and provides Advanced Mode login and options information.
- **Chapter 3. IPE Reference** – Provides reference information for the menu items.

CONVENTIONS USED IN THIS GUIDE

This manual uses the following documentation conventions:

DOCUMENTATION CONVENTIONS

Description	Represents	Examples
Arial font:		
Italic characters	Referenced books	<i>MPLAB X IDE User's Guide</i>
	Emphasized text	...is the <i>only</i> compiler...
Initial caps	A window	the Output window
	A dialog	the Settings dialog
	A menu selection	select Enable Programmer
Quotes	A field name in a window or dialog	"Save project before build"
Underlined, italic text with right angle bracket	A menu path	<u><i>File>Save</i></u>
Bold characters	A dialog button	Click OK
	A tab	Click the Power tab
N'Rnnnn	A number in verilog format, where N is the total number of digits, R is the radix and n is a digit.	4'b0010, 2'hF1
Text in angle brackets < >	A key on the keyboard	Press <Enter>, <F1>
Courier New font:		
Plain Courier New	Sample source code	#define START
	Filenames	autoexec.bat
	File paths	c:\mcc18\h
	Keywords	_asm, _endasm, static
	Command-line options	-Opa+, -Opa-
	Bit values	0, 1
	Constants	0xFF, 'A'
Italic Courier New	A variable argument	<i>file.o</i> , where <i>file</i> can be any valid filename
Square brackets []	Optional arguments	mcc18 [options] <i>file</i> [options]
Curly brackets and pipe character: { }	Choice of mutually exclusive arguments; an OR selection	errorlevel {0 1}
Ellipses...	Replaces repeated text	var_name [, var_name...]
	Represents code supplied by user	void main (void) { ... }

RECOMMENDED READING

This user's guide describes how to use IPE. Other useful documents are listed below. The following Microchip documents are available and recommended as supplemental reference resources.

Processor Extension Pak and Header Specification (DS51292)

This booklet describes how to install and use headers. Headers are used to better debug selected devices using special -ICE device versions, without the loss of pins or resources. See also the Header online help file.

Transition Socket Specification (DS51194)

Consult this document for information on transition sockets available for use with headers.

NOTES:

Chapter 1. IPE Application Overview

1.1 IPE DEFINED


The MPLAB® Integrated Production Environment (IPE) is a software application that provides a simple interface to quickly access key programmer features. IPE provides a secure programming environment for production programming.

The IPE uses the MPLAB X IDE framework, Microchip Debugger (MDB) database, hardware tool interfaces and respective drivers to provide programming capabilities for all Microchip programmers.

1.2 SOFTWARE INSTALLATION REQUIREMENTS

The IPE application must be installed on your PC. It is available during the MPLAB X IDE installation process if the check box is selected (see [Figure 1-1](#)). You do not need to install the MPLAB X IDE in order to use the IPE application, however, you may want to refer to the online help for the MPLAB X IDE for additional information.

FIGURE 1-1: SELECT PROGRAMS DIALOG



See the IPE Release Notes for up-to-date version compatibility information.

Once you've installed the software, the IPE application can be accessed through the MPLAB IPE icon on your desktop or startup menu.

Note: The IPE must be run as **ADMINISTRATOR** for all features to be fully functional.

1.3 PROGRAMMING TOOLS SUPPORTED

The following programming tools work with the IPE:

- MPLAB ICD 3 In-Circuit Debugger – recommended for production programming
- MPLAB PICKit™ 3 Debugger/Programmer – for development programming only
- MPLAB PM3 Programmer – recommended for production programming
- MPLAB REAL ICE™ Emulator – recommended for production programming
- Licensed PKOB Starter Kits – recommended for development programming only

1.4 IPE MODES

1.4.1 Modes

The IPE application operates in two modes:

1. Production Mode – in which you can perform production programming operations. By default, the IPE is in production mode when it is launched. The Production mode capabilities are set from the Advanced mode menu discussed in **Section 2.5.6 “Production Mode”** of this document.
2. Advanced Mode – a feature-rich GUI interface in which you can view and change the settings for programming operations, and set up secure environments for production programming. To enable Advanced Mode, see **Section 2.3 “Setting Up the Programmer”**.

1.4.2 Feature Matrix

The following matrix shows the default features that are accessible in Production mode.

However, in Advanced mode, the default behavior of Production mode can be changed, and features can be added or removed as per the authorized personnel's discretion.

Note: The IPE must be run as ADMINISTRATOR for all features to be fully functional.

TABLE 1-1: FEATURE MATRIX

Feature	Description	Production Mode Defaults
Import Hex file	loads the Hex file	On
Import Environment	loads the Environment file	Off
Import SQTP file	loads the pre-built SQTP file	Off
Export Hex file	saves the all memory contents into a hex file	Off
Program	connects to hardware tool and performs program operation	On
Erase	erases the device	On
Verify	verifies the device against the memory contents of IPE	On
Blank Check	checks that the device is blank	On
Read	reads the device and fills the read content in memory	On
Memory View		
Program Memory	displays the program memory contents	Off
Auxiliary Memory	displays the auxiliary memory contents	Off
Config Memory	displays the configuration memory contents	Off
Flash Data	displays the Flash data memory contents	Off

IPE Application Overview

TABLE 1-1: FEATURE MATRIX (CONTINUED)

Feature	Description	Production Mode Defaults
User IDs	displays the User ID memory contents	Off
EEPROM	displays the data memory contents	Off
Memory Edit		
Program Memory	program memory contents can be edited	Off
Auxiliary Memory	auxiliary memory contents can be edited	Off
Flash Data Memory	Flash data memory contents can be edited	Off
Config Memory	configuration memory contents can be edited	Off
EEPROM	data memory contents can be edited	Off
User IDs	User ID memory contents can be edited	Off
Save Environment	creates or overwrites the environment	Off
View Memory Settings	views the memory ranges	On
Edit Memory Settings	changes the memory ranges	Off
View Voltage Settings	views the voltage values	On
Edit Voltage Settings	changes the voltage values	Off
Create SQTP	generates the SQTP file	Off
Manual Download Firmware	to select and download the firmware into the Hardware tool	On
Auto Download Firmware	when a tool is connected, the latest firmware (available in the system) will be downloaded	On
Erase All Before Program	erases the device before programming	Off

NOTES:

Chapter 2. General Setup

2.1 INTRODUCTION

Getting started using the IPE is discussed.


- [Launching the IPE Application](#)
- [Setting Up the Programmer](#)
- [Advanced Mode Login](#)
- [Advanced Mode Settings](#)
- [Creating Desktop Shortcuts](#)

2.2 LAUNCHING THE IPE APPLICATION

2.2.1 Launching the IPE

After installing the software, double-click on the MPLAB IPE application icon located on the desktop. The IPE main window opens.

FIGURE 2-1: IPE MAIN WINDOW



2.2.2 Multiple Instances of IPE

If you need to have multiple instances of the IPE available, refer to the MPLAB X IDE help. Open MPLAB X IDE, go to *Help>Tool Help Contents>MPLAB X IDE Help* and navigate to the “Before You Begin” section, then “Launch Multiple Instances of the IDE.” Follow the instructions and apply to the IPE.


2.3 SETTING UP THE PROGRAMMER

Note: The IPE must be run as **ADMINISTRATOR** for all features to be fully functional.

For programming devices, you can use any of the supported tools (see **Section 1.3 “Programming Tools Supported”**). Refer to the online help of the selected tool (e.g., MPLAB ICD 3, PICKit 3, etc.) for information on programming a device.


1. Using the Family drop-down menu, select the family of the device you wish to program and use the Device drop-down menu to select the device. Or, use the Device drop-down menu to directly select the device.

Note: Selecting the Recently Used option from the Family menu lists the latest 10 devices used in the Device menu.




2. Click **Apply** to configure the IPE to the current device (e.g., Memory View, checksum).
3. Connect the development tool to the PC. Attach the appropriate target board, device, and power. Refer to the tool's online help for additional instructions and information on connecting to target boards, etc.
4. Use the Tool drop-down menu to select the tool you want to use. If more than one development tool is connected to the PC, select the one you wish to use (see the figure below).

Note: An exclamation point before the tool name (as shown below) indicates that the USB drivers need to be updated. This will not occur with the PICKit 3. However, the USB drivers may need to be updated for the MPLAB ICD 3, MPLAB PM3, and REAL ICE.




For information on installing the correct USB drivers for Microsoft Windows®, launch MPLAB X IDE and click on the **MPLAB IDE v8 Users - IMPORTANT** link, which is located on the Start Page of the Learn & Discover tab. Follow the instructions to install the driver; then, return to the IPE.

FIGURE 2-2: SELECT TOOL




5. Click on the **Connect** button (next to the Tool name) to establish a connection between the IPE and the tool.

FIGURE 2-3: CONNECTING THE TOOL



6. When the tool is connected, any messages or errors related to this tool will be displayed in the Output window, see [Figure 2-4](#).

FIGURE 2-4: OUTPUT WINDOW



7. After the tool is successfully connected, proceed to **Chapter 3. "IPE Reference"** to program the device with the IPE.


2.4 ADVANCED MODE LOGIN

Note: The IPE must be run as **ADMINISTRATOR** for all features to be fully functional.

Typically, someone has been authorized to establish the settings that production will use for the device and tool. To input those settings, log in to the Advanced mode.

1. Select Settings>Advanced Mode to open the Advanced Mode login dialog. The password is case sensitive. Type in the default password `microchip` and click **Log on**.


FIGURE 2-5: ADVANCED MODE LOGIN



To change the password after the initial log on, click on **Change Password**.

If you forget the new password, you must uninstall the IPE, delete the `ipe.key` file (located in the IPE install directory) to remove any settings made previously in IPE, then reinstall the IPE to begin with the default password `microchip`.

FIGURE 2-6: CHANGE PASSWORD DIALOG




2.5 ADVANCED MODE SETTINGS

Advanced mode settings must be set by someone authorized to do so. Some settings that are selected in these dialogs will allow a production specialist to view and control certain commands from the IPE Menu bar, Settings menu.

2.5.1 Operate

After validating the password to log in to the Advanced Mode, the dialog opens in the Operate view. This display is similar to the main display, with the addition of option buttons located along the left side of the window.

FIGURE 2-7: ADVANCED MODE, OPERATE DIALOG



2.5.2 Power

The Power option is only available when a tool is connected. From the Advanced Mode dialog, click on **Power** to display the available settings.

TABLE 2-1: POWER SETTINGS

Setting	Description
Voltage Settings: Voltage settings will vary for different device families. All of the settings and parameters are similar to MPLAB X IDE.	
VDD	This voltage is used by the programmer to verify memory. The value should be the maximum voltage for the designated circuit. The default is the device's maximum voltage value.
VPP	This is the voltage used to bring the device into a programming mode. Although this is dependent on the device's programming specification, it may be changed.
VDD Nom	The default value depends on the device. For example, PIC32 has 3.3V as default VDD Nom.
VDD APP	This is the voltage used by the programmer to verify Flash memory. The default is the device's nominal voltage value.
Reset Voltages	returns voltages to their default settings
ICSP Options:	
Low voltage program	The tool allows low voltage programming (LVP) with certain PICXXFXXX Flash devices. The Flash device selected must be capable of low voltage and programming must be performed in ICSP™ mode.
Power Target Circuit from tool	This setting enables the connected tool to power the target.
High Voltage on MCLR	This setting enables high voltage to be used on a Master Clear Reset (MCLR).

2.5.3 Memory

From the Advanced Mode dialog, click on **Memory** to display the available settings. You can control the memory address and other parameters related to a programming operation. Some of the options in this window are also available on the main screen, for viewing and to provide easy access to these settings.

TABLE 2-2: MEMORY SETTINGS

Setting	Description
Allow Tool to select memories and ranges	When the check box is selected, the programmer tool sets the memory types and ranges. If selected, the Program Memory fields are disabled.
Manual select:	
• Program Memory	allows the tool to program the program memory
• Auxiliary Memory	allows the tool to program the auxiliary memory
• Flash Data	allows the tool to program the Flash data
• EEPROM	allows the tool to program the EEPROM
• User IDs	allows the tool to program the User IDs
• Boot Flash	allows the tool to program the Boot Flash
• Configuration Memory	allows the tool to program the configuration memory
Program Memory - define the addresses to be used to preserve memory for range programming of the program memory.	
Start Address:	the starting address in Hex of the program space that will be programmed
End Address:	the ending address in Hex of the program space that will be programmed
Reset Addresses	returns addresses to default settings
Preserve Memory ¹ - define the addresses to be used for EEPROM or Flash memory.	
Preserve EEPROM on Program ²	When the check box is selected, the device will not be programmed with any new data that is present in the memory (shown in the EEPROM window). The data in the EEPROM memory area on the device will not be erased.
Preserve Flash on Program ²	When the check box is selected, the program memory range specified in the following Program Memory (Start and End Address) fields will not be programmed with any new data.
Preserve Start Address ²	the starting address in Hex of the program space that will be preserved
Preserve End Address ²	the ending address in Hex of the program space that will be preserved
Preserve Auxiliary Memory	When the check box is selected, the auxiliary memory will not be programmed with any new data that is present in the auxiliary memory.
Preserve ID Memory	When the check box is selected, the ID memory will not be programmed with any new data that is present in the ID memory. Only available if device has user ID memory.

Note 1: The MPLAB PM3 programmer does not support the preserve memory options in the environment .pm3 files.

- 2:** If you wish to use any of the Preserve Memory options, first ensure that your code is **not** code-protected. For memory to be preserved, the programmer reads the section it needs to save, performs a bulk erase of the device, reprograms the device and then rewrites the area that is preserved with what was saved. Therefore, this area cannot be code protected.

2.5.4 Environment

Environments allow you to save settings, so that all of the same settings can be reloaded in another programming session. Environments are supported, under all tools, as either .pen files or .pm3 files.

Note: MPLAB PM3 programmer does not support the preserve memory options in the environment .pm3 files.

From the Advanced Mode dialog, click on **Environment** to display the available settings.

TABLE 2-3: ENVIRONMENT SETTINGS

Setting	Description
Environment Name	the environment name you specify
.pm3 file	for MPLAB PM3, select this type of file
.pen file	for MPLAB ICD 3, PICKit 3 and REAL ICE tools, select this type of file
Description	the description you use for the environment
SQTP File	the SQTP file name used in the environment
Misc Files	other files used in the environment, e.g., data sheets, instructions, etc. Multiple files can be selected.
Properties	Click this button to display the properties of the SD card in the MPLAB PM3.
Format	Click this button to format the SD card in the MPLAB PM3, erasing all of the contents.
Delete	opens the Delete Environment window
Copy	opens a dialog to select source and destination for copying environment
View	opens the View Environment window
Save to PM3 SD Card	saves the file to a MPLAB PM3 SD card destination
Save to PC	saves file to a destination on the PC

2.5.5 SQTP

SQTP (serial quick turn programming) is used to program a unique serial number into each device. This number can be used as an entry code, password or ID number.

From the Advanced Mode dialog, click on **SQTP** to display the available settings.

TABLE 2-4: SQTP SETTINGS

Setting	Description
Generation Method:	
Random	Select this option to generate unique, random numbers for each part. Also enter the start address, number of bytes and number of parts in the corresponding fields.
Pseudo Random Seed Value (Hex):	Select this option to generate a pseudo-random set of non-repeating numbers based on the Hex value you enter in the Seed Value field. Also enter the start address, number of bytes and number of parts in the corresponding fields.
Sequential Start Value (Hex): Increment (Hex):	Select this option to generate sequential numbers based on the starting value specified and incrementing each number by the amount specified. Also enter the start address, number of bytes and number of parts in the corresponding fields.
Start Address (Hex)	Enter the starting address (in Hex) for the serial number.
Number of bytes (Dec)	Enter the size of the serial number (in decimal). Make sure a large enough serial number is specified for the number of parts planned to program using this file.
Number or parts (Dec)	Enter the number of parts to be programmed using this file.
Generate	Click Generate to create the SQTP (.num) file.
Location:	
Program Memory	Select this option to load the SQTP number in program memory.
EEPROM	Select this option to load the SQTP number in EEPROM.
Access Method:	
RETLW	Select this option to use a series of RETLW (Return Literal W) instructions with the serial number bytes as the literal data.
Raw Data	Select this option to use the raw data.
Format for PSV	If the Raw Data option is selected, selecting Format for PSV formats SQTP data to make it compatible with PSV (Program Space Visibility).

2.5.6 Production Mode

From the Advanced Mode dialog, click on **Production Mode** to display the available Production Mode Settings.

The Production Mode Settings dialog enables authorized personnel to select the options that are available during production programming. The options that are selected in the Production Mode Settings determine which commands will be available under the File, View, and Settings menus in Production Mode.

Select the appropriate settings for your production programming project by checking or unchecking the settings. Selecting a check box in the Production Mode Settings dialog causes a check mark to display in front of that option under the IPE Settings menu.

A check mark indicates that an option has been set in the Advanced Mode. If the item is available and has a check mark, then the production specialist can control this item by toggling it on or off.

TABLE 2-5: PRODUCTION MODE SETTINGS

Setting	Description
Production Mode Settings	
Allow Export Hex	enables a production specialist to export Hex files. If checked, this option displays under the <i>File>Export</i> menu.
Allow Import Hex file	enables a production specialist to import Hex files. If checked, this option displays under the <i>File>Import</i> menu. Note: If using a Hex file in the IPE and the file is modified using Notepad, MPLAB X IDE, etc., outside the IPE, a message displays: <i>"File modified. The loaded hex file has been modified externally. Would you like to reload the hex file?"</i>
Allow Import Environment	enables a production specialist to import environments. If checked, this option displays under the <i>File>Import</i> menu.
Allow Import SQTP file	enables a production specialist to import SQTP files. If checked, this option displays under the <i>File>Import</i> menu.
Generate Reports	enables reports to be generated. If Generate Reports is checked, click on Browse to set the location where the reports will be placed.
Limit the Program Count to	If selected, this option limits the pass, fail, and total counts to the value that is entered into the associated field. This actually halts further programming operations from occurring. To clear the counts on the main window, click Reset Counters .
Allow "Verify Device ID before Program" under the Settings menu	activates this option in the Settings menu and enables a production specialist to control this option. This setting is valid only for tools that are capable of performing this function, e.g., MPLAB PM3.
Allow "Auto Download Firmware" under the Settings menu	If selected, this option displays in the Settings menu and can be controlled by a production specialist. If it is not selected, the IPE automatically downloads the latest firmware for the tool, if needed.
Allow "Erase All before Program" under the Settings menu	If selected, this option displays in the Settings menu and can be controlled by a production specialist. If it is not selected, the production specialist cannot control this option from the Settings menu.

TABLE 2-5: PRODUCTION MODE SETTINGS (CONTINUED)

Allow "Communication" under the Settings menu	If selected, this option is enabled (Section 3.4 "Settings Menu") and can be controlled by a production specialist. If using the MPLAB PM3 programmer COM port (RS-232), you must select this option in order to set the appropriate COM port.
Remove Read button from main window	If this option is selected, the Read button is removed from the main window.
Audible notification on successful program completion	If selected, this option generates a sound when programming successfully completes.
Allow memory editing and filling	Enables memory editing and filling of memory. If enabled, this option is accessed in Production Mode from the <u>View>Fill Memory</u> option.
Display EEPROM checksum in the output window	If selected, the EEPROM checksum is displayed in the output window.
Display imported hex checksum with CP=OFF	If selected, the non-code protected checksum is displayed in the Results area.
Enable programming operations only if hex file is loaded	If selected, a) If Hex file is not loaded: All the programming buttons (Program, Read, Erase, Verify, Blank Check) will be disabled. b) If Hex file is loaded, all the programming buttons will be enabled.
Allow Memory View	
Program Memory	If this option is selected, program memory can be displayed in the Memory View pane on the main window.
Auxiliary Memory	If this option is selected, auxiliary memory can be displayed in the Memory View pane on the main window.
Config Memory	If this option is selected, configuration memory can be displayed in the Memory View pane on the main window.
Flash Data	If this option is selected, Flash memory can be displayed in the Memory View pane on the main window.
User IDs	If this option is selected, user IDs can be displayed in the Memory View pane on the main window. This is only applicable if user IDs are supported by the tool.
EEPROM	If this option is selected, EEPROM memory can be displayed in the Memory View pane on the main window.

2.5.7 Settings

From the Advanced Mode dialog, click on **Settings** to display the available options (Figure 2-8).

FIGURE 2-8: GENERAL SETTINGS OPTIONS

General Settings

Min Max

PICKit 3 Programmer To Go

Secure Segment

Segments to Program: Full Chip Programming

SQTP

☐ Disable operations if SQTP values are exhausted

Programming Method

☒ Apply Vpp before Vdd (Recommended) ☐ Apply Vdd before Vpp

Diagnostics

Logging Level: OFF

Log File: C:\Users\C11393

Special Memory Regions

☐ Program Calibration Memory ☐ Program User OTP

TABLE 2-6: GENERAL SETTINGS

Settings	Description
PICkit 3 programming speed	Use the slider to adjust the programming speed (see Figure 2-9). This option can be used to help troubleshoot problems by slowing down the speed to allow sufficient time for signal levels. The PICkit 3 slider will slow down ICSP programming which may help communication problems created by heavy loading on the ICSP lines. Microchip recommends that these lines are clear of any components. The programming speed control may help to program boards that already have existing components on these lines.
PICkit 3 Programmer To Go	Opens the PICkit 3 Programmer To Go dialog (see Figure 2-10) showing the settings that will be applied the next time the Programmer-To-Go feature is used. Enter an Image Name that will be used for the image on the PICkit 3. Click Programmer To Go to activate. Refer to the PICkit 3 In-Circuit Debugger/Programmer User's Guide, DS52116, for information on the Programmer-To-Go feature. This feature may not be supported on all devices. Note: Programmer To Go does not support the preserve memories options.
Secure Segments	
Segments to Program	Available only for devices with CodeGuard, e.g., dsPIC33FJ12GP202, etc. Supported by REAL ICE, MPLAB ICD 3 and PICkit 3. Select the segments to program: <ul style="list-style-type: none"> • Full Chip Programming • Boot, Secure and General Segments • Secure and General Segments • General Segment Only
SQTP	
Disable operations if SQTP values are exhausted	Selecting the check box prohibits further programming if all SQTP values from the specified .num file have been exhausted.
Program Method	This option allows you to choose the test mode entry method for devices. This feature is supported by the tools which can power the target (except for PM3). This setting refers to the order in which the VPP and VDD voltages will be applied when programming/reading the target device.
Apply VPP before VDD (Recommended)	This is the default setting.
Apply VDD before VPP	Caution is recommended when using this setting as it may have adverse side effects. This options is available only when powering the device from the debug tool.
Diagnostics	
Logging Level	Set the message logging level. OFF: No logging SEVERE: Log severe (error) messages only. WARNING: Log warning messages only. INFO: Log informational messages only. CONFIG: Log configuration information only. FINE: Log some module-to-module communication. FINER: Log more module-to-module communication. FINEST: Log all module-to-module communication.
Log File	Path and name of log file.

TABLE 2-6: GENERAL SETTINGS (CONTINUED)

Settings	Description
Special Memory Regions	
Program Calibration Memory	Enables programming of registers used to hold calibration values for a device.
Program User OTP	Enables programming of a serial user ID that is OTP (one time programmable). Once programmed, it cannot be changed.

FIGURE 2-9: PICKIT 3 SETTINGS OPTIONS





FIGURE 2-10: PICKIT 3 PROGRAMMER TO GO DIALOG



2.5.8 Log out

After the settings are selected, click **Log out** to save your settings, exit the Advanced Mode, and return to the main window.


2.6 CREATING DESKTOP SHORTCUTS

Desktop shortcuts can be created for devices, Hex files, or environments.

To do this:

1. Create a copy of the MPLAB IPE desktop icon.
2. Right click on the new shortcut icon and click **Properties**.


FIGURE 2-11: RIGHT CLICK MENU



3. The Properties dialog opens. Click the **Shortcut** tab.
4. In the Target field (see [Figure 2-12](#)), add additional commands that will load a specified device, Hex file or environment. Place the command in the Target field at the end of the string after the "...jar". You must add a space before the command. Command are preceded by a dash. Commands are not case sensitive. Paths must be in quotations.

Switch	Command	Description
-P	-P18f1220	Select the specified device when IPE is launched.
-P,-F	-P12f1501 -F"E:\12f1501.hex"	Load the specified device for the specified Hex file when IPE is launched.
-BL	-BL"E:\18f1220.pm3"	Load the specified environment when IPE is launched.

FIGURE 2-12: SHORTCUT TAB



5. Click **OK**.
6. Right click on the new shortcut icon and click **Rename**. Type a new name for the shortcut.
7. Double click the new shortcut icon to launch IPE. The specified target (environment, device, etc.) automatically loads when the IPE opens.

NOTES:

Chapter 3. IPE Reference

3.1 IPE MAIN WINDOW

Note: The IPE must be run as ADMINISTRATOR for all features to be fully functional.

The following figure shows the main window of the IPE. The IPE Menu bar contains the following menus, with commands:

- [File Menu](#)
- [View Menu](#)
- [Settings Menu](#)
- [Help Menu](#)

Commands are available or not depending on the settings selected in Advanced Mode.

FIGURE 3-1: IPE MAIN WINDOW




TABLE 3-1: IPE MAIN WINDOW FIELDS

Item	Description
Select Device and Tool:	
• Family	filters devices by family or recently used
• Device	specifies the device; click Apply to select
• Tool	specified the tool; click Connect or Disconnect as appropriate
Results:	
• Checksum	checksum value for the device with current memory contents
• Pass Count	details the programming operations that passed
• Fail Count	details the programming operations that failed
• Total Count	the total amount of programming operations
Command Buttons:	
• Program (Alt+F5)	programs the device
• Erase(Alt+F6)	erases the device
• Read(Alt+F7)	reads the device
• Verify(Alt+F8)	performs a verify operation on the device
• Blank Check(Alt+F9)	checks whether the device is blank
Other:	
Source	the Hex file location— Browse to locate the file
SQTP	the SQTP file location— Browse to locate the file
More/Less	display more or less information
Output Tab	display of output data. Right-click in the Output window to split the view and show the tools
Tool Tab	display of specific tool data, i.e., PM3, ICD 3, PICkit 3 If a tool is connected, right-click in the Output area and select <i>Split View</i> to display the tool tab.
Memory View	displays only if the <i>View>Show Memory</i> is selected This option displays memory addresses, device ID, configuration memory, etc.

3.2 FILE MENU


The IPE Menu bar, File menu provides three commands: Import, Export, and Exit.

3.2.1 File>Import

The Import menu item allows you to import files into the IPE:

1. File->Import->Hex – select to import the hexadecimal file (*.hex).

Note: If using a Hex file in the IPE and the file is modified using Notepad, MPLAB X IDE, etc., outside the IPE, the following message displays:



2. File->Import->Environment – select to import the environment (*.pen or .pm3 file).
3. File->Import->SQTP – select to load the SQTP file (*.num file).

3.2.2 File>Export

The Export menu item allows you to export data from IPE to storage media. By default, these commands are not available in Production Mode. However, in Advanced Mode, an authorized user can change the default states of this feature for the Production Mode.

File->Export->Hex – this command allows you to export all the memory contents into Intel® Hex file format.

3.2.3 File>Exit

This command closes the IPE application.

3.3 VIEW MENU


The View menu commands are described below:

- [Show Memory](#)
- [Clear All Memory](#)
- [Fill Memory](#)
- [Memory Settings](#)
- [Power Settings](#)

3.3.1 Show Memory


The specific kinds of memory that are shown are determined by Advanced or Production Mode settings. This command toggles between showing and not showing the memory. A check mark before the command indicates it is enabled (showing) in the Memory View pane that is located near the bottom of the window; unchecked indicates that the memory is not showing.

FIGURE 3-2: MEMORY VIEW PANE



The viewable memory types are determined by the Production settings that are selected in the Advanced Mode.


FIGURE 3-3: MEMORY TYPES



If enabled, the configuration settings can be edited. Select Config Memory from the drop-down list in Memory View. Use the scroll bar to view the Setting column. Click the setting you want to edit and a list displays that shows the options that are available for that setting. Click on your selection.

This is shown in the following figure.

FIGURE 3-4: EDITING A CONFIGURATION SETTING



3.3.1.1 RIGHT-CLICK MENU COMMANDS


Undock/Dock – when viewing the memory window, a right-click menu is available with commands to undock/dock, fill memory and print.

The memory window can be undocked to view a larger area in a separate window.

Right-click on any value in the Memory View and select *Undock* (see following figure).

To return the undocked window to the IPE window, either close the memory window or right-click and select *Dock*.

FIGURE 3-5: UNDOCKED MEMORY VIEW



Fill Memory – you can also access this dialog by right-clicking on any value in the Memory View window and select *Fill Memory*.

Print – to print the memory window, right-click on any value in the Memory View window and select *Print*.

Note: this command will print the entire contents of the memory. So, if you have a large device, such as a PIC32, the printout will probably be quite large. You might consider printing to a file, rather than to a printer, in some cases.

3.3.2 Clear All Memory

Clears all of the memory views.

3.3.3 Fill Memory

If enabled in Advanced Mode, the Fill Memory command is available in Production Mode under the View menu.

FIGURE 3-6: FILL MEMORY DIALOG




TABLE 3-2: FILL MENU OPTIONS

Setting	Description
Start Address	start address of the fill operation
End Address	end address of the fill operation
Data	the value used for the fill operation
Use Data as	Fill Value – fills each address with the Data value Sequence Start – fills each address with incrementing Data value Randomize – fills each address with a random value
Write	writes addresses to the memory view
Close	exits the dialog

3.3.4 Memory Settings

Displays the current memory settings. The Memory Settings are view-only and cannot be changed from this window.

3.3.5 Power Settings

Displays the current power settings.

3.4 SETTINGS MENU

3.4.1 Understanding the Settings Menu Commands

The Settings menu on the IPE Menu bar (see [Table 3-3](#)) contains commands available for production personnel. Many of these commands are made available through the Advanced Mode, Production Mode dialog.

Menu commands are shown as active (black) or unavailable (grayed out).

Active commands with a check mark indicate that the production personnel can control these settings.

Active commands without a check mark indicate that only authorized personnel can access them.

Unavailable commands with or without a check mark indicate that production personnel cannot control these settings.

TABLE 3-3: SETTINGS MENU COMMANDS

Setting	Description
Advanced Mode	This command opens the Advanced Mode login dialog. Once the login is validated, additional settings can be set by authorized personnel. Refer to “Setting Up the Programmer” and “Advanced Mode Settings” for more information.
Verify Device ID Before Program	This command is only appropriate when using devices that have device IDs.
Erase All Before Program	This command is used to control whether or not the contents of the device will be erased before it is programmed. It is not applicable to One-Time-Programmable (OTP). When the “Erase All Before Program” command is enabled (check box is checked), the device will be erased before it is programmed. If it is disabled (unchecked), the device will not be erased before it is programmed
Auto Download Firmware*	If this command is selected, the application verifies that the firmware is the latest available; and, if needed, downloads the newer firmware automatically.
Manual Download Firmware*	This command enables manual download of firmware.
Hold on Reset	prevents the code from running after programming
Release from Reset	removes the Reset and allows the code to run
Communication	only for use with the MPLAB PM3 programmer This command opens the PM3 Communication Setting dialog. Use this dialog to set communications for COM or USB ports. See “PM3 Communication Setting Dialog” for more information.

* The download of firmware will not occur until the connect/disconnect button is clicked or a programming operation is performed.

PM3 Communication Setting Dialog

The PM3 Communication Setting dialog is available under the IPE Menu bar, Settings menu only when the associated check box for *Allow "Communication" under Settings menu* is selected in the Advanced Mode, Production Mode dialog.

The MPLAB PM3 must be connected to the PC, using the appropriate cable, prior to using the PM3 Communication Setting dialog.

This dialog enables selecting the communication port for the MPLAB PM3 programmer through the IPE.

To use the RS-232 port on the MPLAB PM3, select the COM port option button and use the drop list to select the available port. Click the refresh button if necessary to view available ports. Click the **Test** button to check communication between the IPE and the MPLAB PM3.

To use USB for the communication port, select the USB option button.

Setting up the COM Port Manually

On some systems, you may need to set up the communications port manually.

On Windows, from the **Start** menu, select **Control Panel**, then **System and Security**. Under the **System** settings, click **Device Manager**. Expand the Ports drop-down list and double-click on the port you are trying to use. Click the **Port Settings** tab, and select the following:

Bits per second: **19200** (baud rate)

Data bits: **8**

Parity: **None**

Stop bits: **1**

Flow control: **Hardware**

Click **Advanced**. Uncheck the Use FIFO buffers check box.

Reboot the PC to implement the change.

3.5 HELP MENU

The Help menu provides access to the online user's guide and information about the program.

Appendix A. Revision History

Revision A (December 2013)

This is the initial release of this document.

Revision B (August 2015)

Modified [Section 1.2 “Software Installation Requirements”](#). The IPE is now a separate installation than the MPLAB X IDE.

Modified the description of Production Mode.

In [Chapter 2. “General Setup”](#):

- Added information on new features: Recently Used option in the Family list of devices and Creating Desktop Shortcuts.
- Added information on Preserve Memory options.
- Added notes regarding MPLAB PM3 programmer environment files.
- Added a note in the description of the Allow Import Hex file option in [Table 2-5](#).
- Added information regarding using the MPLAB PM3 programmer with the option Allow “Communication” under the Settings menu in [Table 2-5](#).
- Added Special Memory Regions information to [Table 2-6](#).

In [Chapter 3. “IPE Reference”](#):

- Added a note regarding the [File>Import>Hex](#) option.

NOTES:

Support

INTRODUCTION

Please refer to the items discussed here for support issues.

- [Warranty Registration](#)
- [The Microchip Web Site](#)
- [myMicrochip Personalized Notification Service](#)
- [Customer Support](#)

WARRANTY REGISTRATION

If your development tool package includes a Warranty Registration Card, please complete the card and mail it in promptly. Sending in your Warranty Registration Card entitles you to receive new product updates. Interim software releases are available at the Microchip web site.

THE MICROCHIP WEB SITE

Microchip provides online support via our web site at <http://www.microchip.com>. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- **Product Support** – Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** – Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip consultant program member listing
- **Business of Microchip** – Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

myMICROCHIP PERSONALIZED NOTIFICATION SERVICE

Microchip's personal notification service helps keep customers current on their Microchip products of interest. Subscribers will receive e-mail notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool.

Please visit <http://www.microchip.com/pcn> to begin the registration process and select your preferences to receive personalized notifications. A FAQ and registration details are available on the page, which can be opened by selecting the link above.

When you are selecting your preferences, choosing “Development Systems” will populate the list with available development tools. The main categories of tools are listed below:

- **Compilers** – The latest information on Microchip C compilers, assemblers, linkers and other language tools. These include all MPLAB C compilers; all MPLAB assemblers (including MPASM™ assembler); all MPLAB linkers (including MPLINK™ object linker); and all MPLAB librarians (including MPLIB™ object librarian).
- **Emulators** – The latest information on Microchip in-circuit emulators. These include the MPLAB REAL ICE in-circuit emulators
- **In-Circuit Debuggers** – The latest information on Microchip in-circuit debuggers. These include the MPLAB ICD 3 in-circuit debuggers and PICKit 3 debug express.
- **MPLAB X IDE** – The latest information on Microchip MPLAB X IDE, the Windows® Integrated Development Environment for development systems tools.
- **Programmers** – The latest information on Microchip programmers. These include the device (production) programmers MPLAB REAL ICE in-circuit emulator, MPLAB ICD 3 in-circuit debugger, MPLAB PM3, and PICKit 3 development (nonproduction) programmer.
- **Starter/Demo Boards** – These include MPLAB Starter Kit boards, PICDEM demo boards, and various other evaluation boards.

CUSTOMER SUPPORT

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or field application engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document. See our web site for a complete, up-to-date listing of sales offices.

Technical support is available through the web site at <http://support.microchip.com>.

Documentation errors or comments may be emailed to docerrors@microchip.com.

Index

A

Access Method	22
Advanced Mode	17, 18, 39
Allow "Auto Download Firmware"	23
Allow "Communication"	24
Allow "Erase All before Program"	23
Allow "Verify Device ID before Program"	23
Allow Export Hex	23
Allow Import Environment	23
Allow Import Hex File	23
Allow Import SQTP File	23
Allow Memory Editing and Filling	24
Allow Memory View	24
Apply Vdd Before Vpp	26
Apply Vpp Before Vdd	26
Audible Notification	24
Auto Download Firmware	11, 39
Auxiliary Memory	10

B

Blank Check	10
-------------------	----

C

Change Password	17
Change the Password	17
Clear All Memory	37
COM Port	
Manual Settings	40
Communication	39
Config Memory	10
Create SQTP	11
Customer Support	44

D

Default Password	17
Desktop shortcuts	28
Diagnostics	26
Disable Operations if SQTP Values are Exhausted ..	26
Display EEPROM checksum in the output window ..	24
Display imported hex checksum with CP=OFF	24
Dock Memory View	37
Documentation	
Layout	5

E

Edit Memory Settings	11
Edit Voltage Settings	11
EEPROM	11
Enable programming operations only if hex file is load- ed	24
Environment	21
Erase	10

Erase All Before Program	11, 39
Exit	33
Export	33
Export Hex File	10

F

Feature Matrix	10
Features	10
File Menu	33
Exit	33
Export	33
Import	33
Fill Memory	37, 38
Flash Data	10
Forget New Password?	17

G

General Settings	
Apply Vdd Before Vpp	26
Apply Vpp Before Vdd	26
Diagnostics	26
Disable Operations if SQTP Values are Exhausted ..	2
Log File	6
Logging Level	26
PICKit 3 Programmer To Go	26
PICKit 3 Programming Speed	26
Program Calibration Memory	27
Program Method	26
Program User OTP	27
Secure Segments	26
Segments to Program	26
Special Memory Regions	27
SQTP	26
Generate	22
Generate Reports	23
Generation Method	22

H

Header Board	
Specification	7
Hold on Reset	39

I

Import	33
Import Environment	10
Import Hex File	10
Import SQTP File	10
Internet Address, Microchip	43
IPE Feature Matrix	10

MPLAB® IPE User's Guide

L

Launching the IPE Application	13
Limit the Program Count to	23
Location	22
Log File	26
Logging Level	26

M

Manual Download Firmware.....	11, 39
Memory Settings	38
Modes	10
Advanced.....	10
Production.....	10
myMicrochip Personalized Notification Service.....	43

N

Number of Bytes	22
Number or Parts.....	22

P

PICkit 3 Programmer To Go	26
PICkit 3 Programming Speed.....	26
Power	19
Power Settings	38
Print.....	37
Processor Extension Pak and Header Specification ..	7
Production Mode	23, 25
Production Mode Settings	23, 24, 25
Allow "Auto Download Firmware"	23
Allow "Communication"	24
Allow "Erase All before Program"	23
Allow "Verify Device ID before Program"	23
Allow Export Hex	23
Allow Import Environment.....	23
Allow Import Hex File	23
Allow Import SQTP File	23
Allow Memory Editing and Filling.....	24
Allow Memory View	24
Audible Notification	24
Auxiliary Memory	24
Config Memory	24
Display EEPROM checksum in the output window ..	2
.....	4
Display imported hex checksum with CP=OFF	24
EEPROM	24
Flash Data	24
Generate Reports	23
Limit the Program Count to	23
Program Memory	24
User IDs	24
Program	10
Program Calibration Memory	27
Program Memory.....	10
Program Method	26
Program User OTP.....	27
Pseudo Random	22

R

Random.....	22
Read.....	10

Reading, Recommended.....	7
Release from Reset.....	39
Remove Read Button	24
Right-Click Menu	37
Dock.....	37
Fill Memory	37
Print.....	37
Undock.....	37
Run as Administrator.....	9, 10, 14, 17, 31

S

Save Environment	11
Secure Segments.....	26
Segments to Program	26
Sequential	22
Setting Up the Programmer.....	14
Settings	25
Settings Menu	39
Advanced Mode.....	39
Auto Download Firmware.....	39
Communication	39
Erase All Before Program	39
Hold on Reset	39
Manual Download Firmware	39
Release from Reset	39
Verify Device ID Before Program.....	39
Show Memory	34
Software Installation Requirements.....	9
Special Memory Regions	27
SQTP.....	22, 26
Access Method	22
Generation Method	22
Location	22
SQTP Settings	22
EEPROM	22
Format for PSV	22
Generate	22
Number of Bytes	22
Number of Parts.....	22
Program Memory	22
Pseudo Random	22
Random	22
Raw Data	22
RETLW	22
Sequential	22
Start Address	22
Start Address.....	22

T

Transition Socket	7
-------------------------	---

U

Undock Memory View	37
User IDs	11

V

Verify	10
Verify Device ID Before Program	39
View Memory Settings.....	11
View Menu.....	34

Clear All Memory	37
Fill Memory	38
Memory Settings.....	38
Power Settings	38
Right-Click Menu	37
Show Memory.....	34
View Voltage Settings	11

W

Web Site, Microchip	43
---------------------------	----



Worldwide Sales and Service

AMERICAS

Corporate Office

2355 West Chandler Blvd.
Chandler, AZ 85224-6199

Tel: 480-792-7200

Fax: 480-792-7277

Technical Support:

[http://www.microchip.com/
support](http://www.microchip.com/support)

Web Address:

www.microchip.com

Atlanta

Duluth, GA

Tel: 678-957-9614

Fax: 678-957-1455

Austin, TX

Tel: 512-257-3370

Boston

Westborough, MA

Tel: 774-760-0087

Fax: 774-760-0088

Chicago

Itasca, IL

Tel: 630-285-0071

Fax: 630-285-0075

Cleveland

Independence, OH

Tel: 216-447-0464

Fax: 216-447-0643

Dallas

Addison, TX

Tel: 972-818-7423

Fax: 972-818-2924

Detroit

Novi, MI

Tel: 248-848-4000

Houston, TX

Tel: 281-894-5983

Indianapolis

Noblesville, IN

Tel: 317-773-8323

Fax: 317-773-5453

Los Angeles

Mission Viejo, CA

Tel: 949-462-9523

Fax: 949-462-9608

New York, NY

Tel: 631-435-6000

San Jose, CA

Tel: 408-735-9110

Canada - Toronto

Tel: 905-673-0699

Fax: 905-673-6509

ASIA/PACIFIC

Asia Pacific Office

Suites 3707-14, 37th Floor

Tower 6, The Gateway

Harbour City, Kowloon

Hong Kong

Tel: 852-2943-5100

Fax: 852-2401-3431

Australia - Sydney

Tel: 61-2-9868-6733

Fax: 61-2-9868-6755

China - Beijing

Tel: 86-10-8569-7000

Fax: 86-10-8528-2104

China - Chengdu

Tel: 86-28-8665-5511

Fax: 86-28-8665-7889

China - Chongqing

Tel: 86-23-8980-9588

Fax: 86-23-8980-9500

China - Dongguan

Tel: 86-769-8702-9880

China - Hangzhou

Tel: 86-571-8792-8115

Fax: 86-571-8792-8116

China - Hong Kong SAR

Tel: 852-2943-5100

Fax: 852-2401-3431

China - Nanjing

Tel: 86-25-8473-2460

Fax: 86-25-8473-2470

China - Qingdao

Tel: 86-532-8502-7355

Fax: 86-532-8502-7205

China - Shanghai

Tel: 86-21-5407-5533

Fax: 86-21-5407-5066

China - Shenyang

Tel: 86-24-2334-2829

Fax: 86-24-2334-2393

China - Shenzhen

Tel: 86-755-8864-2200

Fax: 86-755-8203-1760

China - Wuhan

Tel: 86-27-5980-5300

Fax: 86-27-5980-5118

China - Xian

Tel: 86-29-8833-7252

Fax: 86-29-8833-7256

ASIA/PACIFIC

China - Xiamen

Tel: 86-592-2388138

Fax: 86-592-2388130

China - Zhuhai

Tel: 86-756-3210040

Fax: 86-756-3210049

India - Bangalore

Tel: 91-80-3090-4444

Fax: 91-80-3090-4123

India - New Delhi

Tel: 91-11-4160-8631

Fax: 91-11-4160-8632

India - Pune

Tel: 91-20-3019-1500

Japan - Osaka

Tel: 81-6-6152-7160

Fax: 81-6-6152-9310

Japan - Tokyo

Tel: 81-3-6880-3770

Fax: 81-3-6880-3771

Korea - Daegu

Tel: 82-53-744-4301

Fax: 82-53-744-4302

Korea - Seoul

Tel: 82-2-554-7200

Fax: 82-2-558-5932 or

82-2-558-5934

Malaysia - Kuala Lumpur

Tel: 60-3-6201-9857

Fax: 60-3-6201-9859

Malaysia - Penang

Tel: 60-4-227-8870

Fax: 60-4-227-4068

Philippines - Manila

Tel: 63-2-634-9065

Fax: 63-2-634-9069

Singapore

Tel: 65-6334-8870

Fax: 65-6334-8850

Taiwan - Hsin Chu

Tel: 886-3-5778-366

Fax: 886-3-5770-955

Taiwan - Kaohsiung

Tel: 886-7-213-7828

Taiwan - Taipei

Tel: 886-2-2508-8600

Fax: 886-2-2508-0102

Thailand - Bangkok

Tel: 66-2-694-1351

Fax: 66-2-694-1350

EUROPE

Austria - Wels

Tel: 43-7242-2244-39

Fax: 43-7242-2244-393

Denmark - Copenhagen

Tel: 45-4450-2828

Fax: 45-4485-2829

France - Paris

Tel: 33-1-69-53-63-20

Fax: 33-1-69-30-90-79

Germany - Dusseldorf

Tel: 49-2129-3766400

Germany - Karlsruhe

Tel: 49-721-625370

Germany - Munich

Tel: 49-89-627-144-0

Fax: 49-89-627-144-44

Italy - Milan

Tel: 39-0331-742611

Fax: 39-0331-466781

Italy - Venice

Tel: 39-049-7625286

Netherlands - Drunen

Tel: 31-416-690399

Fax: 31-416-690340

Poland - Warsaw

Tel: 48-22-3325737

Spain - Madrid

Tel: 34-91-708-08-90

Fax: 34-91-708-08-91

Sweden - Stockholm

Tel: 46-8-5090-4654

UK - Wokingham

Tel: 44-118-921-5800

Fax: 44-118-921-5820

07/14/15