

To start using your Dyson V11 Cord-Free Vacuum Cleaner, remove it from the box and attach the wand to the main body by aligning the connections and pressing until you hear a click. Insert your preferred cleaning head, such as the High Torque cleaner head, into the wand and ensure it is firmly attached. Power on the vacuum by pressing the power button on the handle. The Dyson V11 features three cleaning modes: Eco, Auto, and Boost. Select the mode that best suits your cleaning needs by pressing the mode button on the handle. Once powered on, the vacuum will automatically adjust the suction power based on your cleaning mode. After use, store the vacuum on its charging dock to ensure it's always ready for the next cleaning session. The charging dock ensures that your vacuum remains powered for continuous use.