

# **UTC Series**

## **UtcPanel+ QUICK SETUP GUIDE**



***Micro Trend Automation Co., Ltd***

3F, No.78, Cheng Kung Road, Sec. 1  
Nan Kang, Taipei, Taiwan  
TEL:(02)27882162 FAX:(02)27857173

# Contents

Chapter 1. Service Level Guide .....	02
1.1 Setup UTCPanel+_Eng On A Computer.....	02
1.1.1 Download UTC System Setup Software From Micro Trend Website.	02
1.1.2 Install the Application Software UTC_Setup+_Eng On the Computer .....	05
1.1.3 Connecting RS232 Cable From the Computer to UTC Controller .....	06
1.1.4 Run the UtcPane+ On the Computer.....	06
1.1.5 Communication Failure between Computer and UTC .....	07
1.2 Using UtcPanel+ To Do the UTC Control Setup or Maintenance .....	09
1.2.0 Get some information from the controller through “Online Commands” window .....	09
1.2.1 Download the UTC Default Setup File.....	11
1.2.2 Download the User Program File or Backup File.....	13
1.2.3 To Activate the Control System .....	13
1.2.4 Saving All the Control Programs And Variables In the Flash ROM ...	14
1.2.5 Saving All the Control Programs And Variables In a File to the Computer .....	15
1.2.6 Restore the Data saved in Flash ROM to the SRAM.....	17
1.2.7 UTC Firmware Update.....	17
1.2.8 Introduction of all kinds of UTCPanel+ functions.....	19
1.2.9 Some More Online Commands On Service Propose .....	23
1.3.0 Some Parameters Regarding Control Setup .....	24
Chapter 2. Designing With UTC Control .....	32
2.1 A cut to length with timer cut tool output control.....	32
2.1.1 The details of project requirement .....	32
2.1.1.1 Parameter Settings.....	32
2.1.1.2 Control System Consideration.....	33
2.1.2 Start the Design.....	33
2.1.2.1 Hardware Assignments .....	33
2.1.2.2 Internal Variable Assignments.....	33
2.1.2.3 PLC programs planning example .....	34
2.1.2.4 PLC and motion programs coding example .....	34
2.2 A cut to length with two sensors cut tool output control, mark signal capture and Hitech ADP3 as HMI .....	35
2.2.1 The details of project requirement.....	35
2.2.1.1 Parameter Settings.....	35
2.2.1.2 Control System Consideration .....	36
2.2.2 Start the Design.....	36
2.2.2.1 Hardware Assignments .....	36
2.2.2.2 Internal Variable Assignments.....	36
2.2.2.3 PLC programs planning example .....	37
2.3 A single axis motion program example for drilling cycle and Hitech ADP3 as HMI.....	38
Chapter 3. Appendix .....	39
3.1 PROJECT_1 .....	39
3.2 PROJECT_2.....	49

# A Step-By-Step Setup Guide For UTC Series

Revision: 2008/11/25

## **Chapter 1. Service Level Guide**

This is a step-by-step quick reference for an uninitiated user to setup a UTC system. It is essential to have a computer with RS232 communication port for UTC system setup. For some latest model notebook computers, which have a few USB ports but no RS232 port, please purchase a USB-to-RS232 adaptor and setup the adaptor prior to start the UTC system setup. As well, a panel software running with Windows Operating System, Windows 95 or higher version, is needed for the setup. Please contact Micro Trend to get an application disk or visit Micro Trend website to download the panel software.



### **1.1 Setup UTCPanel+\_Eng On A Computer**

In this section, we will show the novice how to connect a computer to the UTC control. If you have already successfully connected please skip this section.

#### **1.1.1 Download UTC System Setup Software From Micro Trend Website.**

Please visit: <http://www.utrend.com.tw> and click "SERVICES" from any page of the site. Then enter name: **utrend** and password: **7173**. In the service page, two different versions of the UTC operation manual and the setup software will be found. Please download the execution software – UTCPanel+\_Eng from this page.

1. From Micro Trend Website, click “SERVICES”




Fig1.1

2. Then enter name: **utrend** and password: **7173**




Fig1.2

3. Download the execution software – **UTCPanel+\_Eng**



Fig1.3

#### 4. Save UTC-Setup+\_Eng.exe






Fig1.4

### 1.1.2 Install the Application Software UTC\_Setup+\_Eng On the Computer

From Micro Trend application disk or downloaded resource, we get a file named UTC\_Setup+Eng.zip. Unpack this file, we will get two files, UTCPanel+.exe and UTCPanel+.lng. File UTCPanel+.lng is used for multi-language, it's a text file. Anyone can modify the contents with his own characters.

The related solution of unpacking step please refer to Fig 1.6.

Unpack UTC\_Setup+\_Eng.zip to his own hard driver. We can make a short-cut of UTCPanel+.exe to the desktop, an icon named UTCPanel+.exe will be shown on the desktop screen. Please connect the RS232 cable and turn the UTC control power on before clicking the UtcPanel+.exe icon as Fig1.5.





Fig1.5




Fig1.6

### 1.1.3 Connecting RS232 Cable From the Computer to UTC Controller


The connection cable for computer to UTC controller is a one-to-one 9 pin D-connector with pin 9 cut off. Please make the connection when control power is turned off. The default protocol for UTC COM1 is 38400, N, 8, 1 with RTS/CTS flow control. It can be changed by setting the dipswitch 2 and 3 on the control board. The default protocol for UTC COM2 is 19200, N, 8, 1 without flow control. It can be changed by I-Parameter 2 and 3 settings.



### 1.1.4 Run the UtcPanel+ On the Computer



With the RS232 cable connected, computer serial COM port properly installed and control power turned on, click the UtcPanel+ icon on the desktop. If UtcPanel+ is used in this computer for the first time, it can't be connected to the control. The information will be shown on the screen.



*Setup window.*


*\*\*The port number should be set to match the computer serial port, not the UTC port.*

Please setup, under the message, the RS232 connection protocol, including COM port number, BAUD rate, delay time and flow control handshake (CTS/RTS). Please correctly set the **computer COM port number**, BAUD rate 38400, delay time 50000 and select CTS/RTS to non-activate flow control. Then click "OK" to approach again



communicating with the UTC control. The information “Card found on Comx” will be shown on the screen to indicate that the software setup process has been finished and the communication between computer and UTC control is successful. If still “No control card found”, please follow section 1.1.5 to do the diagnostic process.

1. The information “Card found on Comx” the communication between computer and UTC control is successful



*If this screen shows up, it indicates that the connection is successful;  
Click “OK” to enter the panel page*

### 1.1.5 Communication Failure between Computer and UTC

The communication failure problem could be at computer side, controller side or the connection. Please re-check the one-to-one connection cable, pin 9 should not be connected, and verify the computer serial port settings. At UTC controller side, please take the following steps to identify the problem.

1. If the message shows “Can’t open communication port!”  
It indicates that the problem is at the computer communication port; either set to a non-exist port number or this port has been occupied by other application software. Please check the computer property and then set it to right port number or turn off other application software that occupies this communication port.




**\*\***Sometimes this problem could happen by double clicking the icon twice to cause the second approach failure.

2. Check the dipswitch 2 and 3 settings.  
Please turn both the dipswitch 2 and 3 off if any of them not been turned off. Then re-turn-on the control power and try again to do the connection. The dipswitch 2 and 3 decide the COM1 BAUD rate. When both of them turned



off, the COM1 BAUD rate is 38400. Please use the following table for other BAUD rate settings.



NO.2	NO.3	COM1 baud rate
OFF	OFF	38400
ON	OFF	19200
OFF	ON	9600
ON	ON	115200

3. Check the “W. Dog” LED.

This LED should turn on for a few seconds then turn off after power up. When “W. Dog” LED turns on, the control does not do any communication or run any user programs; it indicates that the control is in an abnormal situation.

4. What to do if the “W. Dog” LED does not turn off after power up?

Please turn the dipswitch 1, on the control board, to on position then power up. This action reset the all the UTC parameters to the default values and clear all the preloaded motion programs and PLC programs. If the LED still keeps turned on all the time after this process, the control board or the firmware chip should be replaced. Please contact Micro Trend to request for service.

5. Try using COM2 instead of COM1.

If the “W. Dog” LED turns off after the reset process but still unable to communicate with COM1, please turn off the control power and switch the connection to COM2. Then try COM2 with BAUD rate 19200 and no CTS/RTS flow control.

6. If the computer still cannot find the UTC control after all these approaches, please contact local service people or Micro Trend for help.

## 1.2 Using UTCPanel+ To Do the UTC Control Setup or Maintenance

In this section, we will explain the setup and program update procedure using a computer running UTCPanel+ software. These procedures are normally for a service engineer who would like to setup or update software to a new machine with a fully tested user program.

### 1.2.0 Get some information from the controller through “Online Commands” window.

Once the computer successfully finds the control card by running “UTCPanel+”, we can start the service level actions from the computer. We can download the basic setup file for different versions, change parameter or variable settings, monitor the system status, download motion programs or PLC programs, issue the Online-Commands, backup system configurations or update firmware. Now, we first get some information from the controller through “Online Commands” window. Also, we will request the controller to take some actions upon our Online Commands.

If the control is well connected to the computer, the following page will be on the screen.

The screenshot shows the UTCPanel+ software interface. The main window displays various motor control parameters and status indicators. The interface is divided into several sections:

- Motor JOG:** Parameters include Acc. Time (100), OutSlewRate (1), and Speed (10000).
- Motor HOME:** Parameters include Speed and Dir (-1000) and Offset (2000).
- Motor Control Flag:** Parameters include Flag Control (220) and Adv.
- Motor PID:** Parameters include Proportional Gain (15000), Derivative Gain (200), Velocity Feedforward Gain (230), Integral Gain (500), Integral Mode (1), and Acceleration Feedforward Gain (500).
- Motor Control Flag:** Parameters include CaptureControl (Rising edge of CHC) and Capture Flag (Negative Flag).
- Motor Control Flag:** Parameters include #1, #2, #3, #4, #1J, #2J, #3J, #4J.
- Motor Control Flag:** Parameters include #1, #2, #3, #4, #1J, #2J, #3J, #4J.

Annotations point to specific areas of the interface:

- Information district of “Online Commands”**: Points to the top right area of the interface.
- Commonly used parameter areas**: Points to the Motor PID and Motor Control Flag sections.
- “Online Commands” command area.**: Points to the bottom right area of the interface.
- Choosing area of the function**: Points to the bottom status bar.

Choosing area of the function

1. Systematic parameter area
2. #1- #8 motor parameter area
3. I/O Status area
4. Coordinate parameter area
5. Simple & easy program editor

Fig 1.2.0.1

1. You can see window. Fig 1.2.0.1 including the Online Commands

```
>>type
UTC-400V
>>date
20071123
>>ver
V3.042
>>listprog
1000 1433 2052
1001 2053 2181
1 2182 2194
6 2195 2216
>>listplc
1 0 179 NO
2 180 206 YES
3 207 437 NO
4 438 929 NO
5 930 1379 NO
15 1380 1424 YES
10 1425 1432 YES
>>^k
>>^a
>>#1j+
>>#1j/
>>#1j:20000
>>#1j:-2000
>>m161
126709
>>
```

The control takes action or report information to this screen upon issuing "Online Commands" from this window.  
\*\*The "Online Commands" can also be issued from other HMI units or from PLC software running in the controller.

Information reported

The controller takes action upon these Online Commands.

Variable data reported

Fig 1.2.0.3

As shown in the Fig 1.2.0.3, we can see that the control reports information or takes action upon the online commands we issue from the window. Actually, the control report to any serial port, which sent commands to request information. Also, it takes action upon receiving any online command from any serial port even from a PLC program, which is enabled. A full set of "Online Commands" explanation can be found in the UTC control manual "Online Commands" section.

### 1.2.1 Download the UTC Default Setup File.

For each different model or version of UTC, Micro Trend preloads in the controller before shipment a dedicated default setup file bases on customers' orders. This basic setup file is a set of default M-Variable-definitions. These M variables are generally used in most of the PLC programs or motion programs. If the control firmware version has been changed or a hardware or software reset process has been performed, we should re-download the basic setup file. The following table shows the files for various models and versions.

Model	Version	M-Definition File
UTC400P/200P/100P	2.2x/2.1x	400P220.UTC
UTC400V/200V/100V	2.2x/2.1x	400V220.UTC

However, each of these M-Variable-Definitions can be redirected to different memory location for different purposes.

Please follow these procedures to download the default setup file to the controller.

1. For first time setup, before the downloading, please use the online command “\$\$\$\*\*\*” to clear all the memory in the controller.



Fig 1.2.1.1

2. Click “File” the “Download to UTC” then “File” as shown in Fig 1.2.1.2




Fig 1.2.1.2

3. Select the right file type and then a target default setup file from the computer and then click “Open”




Fig 1.2.1.3

4. It takes a few seconds to minutes for the downloading depends on the file size. There is a blue bar to show the percentage of completed portion during download process, as Fig 1.2.1.4.




Fig 1.2.1.4

### 1.2.2 Download the User Program File or Backup File

To activate a UTC control system, there must be some PLC programs and/or some motion programs pre-loaded in the controller and activated. We call them user application programs or user programs. Normally, the user programs are put in a file; we call it user program file; with extension UTC. After a control system is fully tested, we may upload all the parameter and variable settings as well as all the user programs then store these items in a file. We call it backup file, with extension DAT. Please be aware that these UTC or DAT files are with simple ASCII text format. The process is the same as downloading the default setup file only choosing different file. Normally, the user program file should be loaded after the setup file. Otherwise, it is possible that some parameters, which have been set to match an individual application, will be reset to the default value and cause mal-function.

### 1.2.3 To Activate the Control System

After we go through the process 1.2.0 to 1.2.2, we have a well-tested user program loaded in the UTC controller. We may activate the control system at this moment if the initial variables and parameters are included in the user program. Otherwise, we might need to set some parameters or variables for an individual system before activating the control. For example, the unit ratio between the encoder counts and the customer define unit. It could be various for each individual machine and leave for the machine setup engineer to finish the settings.

There are some possible ways to activate the system control after first time the software is loaded in the UTC. It is flexible to allow the users to choose their own way to activate the control system. The following is some typical ways to activate a UTC control system.

1. Activates by setting PLC control parameter I6.  
Set the I6 to 1, 2 or 3 to activate the PLC control programs.  
In most situations, we write PLC programs to control the whole system, including starting a motion program. Set I6 to a suitable value can activate all the system PLC programs immediately.
2. Activate an individual PLC program by the PLC enable command.  
We may use the command “enaplc x” (x=0 to 15) to test an individual PLC program.
3. To run a motion program by the motion program enable command.  
We may use the command “BxR” (x= program number) to start a motion program running.

#### 1.2.4 Saving All the Control Programs And Variables In the Flash ROM.

It is very important for a working control system to save all the content in the working space, SRAM with backup battery, to the Flash ROM space. In case someday the data in the SRAM are destroyed by low battery or any other reason, we can restore all the content back to the SRAM from the Flash ROM.

The saving process should be done whenever:

- The machine setup is first time finished.
- The PLC programs or motion programs are modified.
- The compensation data is changed.
- The EEPROM (Flash ROM) is replaced.
- The UTC system firmware is updated
- Any other variables settings are changed



Fig 1.2.4.1



1. Before processing the saving process, please type from the online commands window to disable currently running motors and PLC programs.

>>^A ;Abort currently running motion program.

>>^D ;Disable currently running PLC program.

>>^K ;Disable currently enabled motors

2. To do the saving process, we simply type "Save" in the online commands window.

>>Save ;To start the saving process




Fig 1.2.4.2

3. The saving process will take a few seconds; please do not turn the control power off during the saving process.
4. After the saving process, we may re-turn-on the control to get the controller back to normal operations.

### 1.2.5 Saving All the Control Programs And Variables In a File to the Computer.

Besides saving the control data in the Flash ROM, we can also save a copy of all the control variable settings and user programs in a computer. For the next identical UTC control setup, we may download this backup file instead of the default setup file and the user program files. Please see section 1.2.2 for the download process.

The backup process is as follows.

1. Select "Backup Configurations" from the tools menu or directly from the tool bar.




Fig 1.2.5.1

2. Give a file name for this backup file and save it in a selected directory.

The default extension of the backup file is XXXX.dat.



Fig 1.2.5.2

4. The backup process could take a few seconds to minutes. There is a blue bar to show each data group processing. (Fig 1.2.5.3)





Fig 1.2.5.3

### 1.2.6 Restore the Data saved in Flash ROM to the SRAM

No matter what reason causes the control working space data losses, we may restore all the data back from the Flash ROM. There are two ways to get the data back from the Flash ROM.

1. If the RS232 communications still works fine when the control data losses happens, we may simply type “\$\$\$” in the online commands window to get the data back from the Flash ROM.
2. If the RS232 communication no longer works, please turn the control power off. And then, turn the control power on with the dipswitch 7 ON. The dipswitch location is described in section 1.1.5.



### 1.2.7 UTC Firmware Update

The UTC control system software handles all the control behaviors including decoding the PLC and motion program, communicating with HMI through RS232, servo controls and other protection features. Micro Trend keeps updating this software to provide better features or improve the control performances. To update the UTC control system software for the hardware in the customer site, we can also use the UTC\_Setup+\_Eng setup software.

This is the procedure to do the system software update.

The same as the saving process, before doing the firmware upgrade, please type from the online commands window to disable currently running motors and PLC programs.

>>^A	;Abort currently running motion program.
>>^D	;Disable currently running PLC program.
>>^K	;Disable currently enabled motors

1. From the tool bar, click “Tools” then select “Firmware Upgrade”




Fig 1.2.7.1

2. Select the target BIN file that stored in the computer






Fig 1.2.7.2

3. The firmware upgrades process. All over the new firmware downloading process, please do not turn of the control power. Otherwise, the system firmware will be permanently destroyed. And, the control will no longer works unless we replace the Flash ROM.
  - i. The flash erases process; the erasing message shows on the screen for a few seconds. Then, turn to process b to write the new bin code to the flash ROM.
  - ii. Write the new bin code to the flash ROM; there will be a blue bar to show the downloading progress on the screen.



- iii. After the Flash Writing completed, there will be following message shows on the screen.




- iv. Now, we can turn off and re-turn-on the control power to run the new system software.
4. If the major firmware version code is changed, it indicates that there are major changes have been made in the new version. We may need to re-setup the system. In this case, please turn the control power on with dipswitch 1 in the “ON” position to re-initiate the control. And then, follow section 1.2.1 to 1.2.5 to re-setup the control. **Please don't forget to turn the dipswitch 1 back to off position each time after we turn it on at power up.** Otherwise, the data in the SRAM area will be cleared at next power up. In that case, we will have to process 1.2.1 to 1.2.5 one more time.

## 1.2.8 Introduction of all kinds of UTCPanel+ functions

### 1. Systematic function display


It is a system parameter setting area, like the setting of COM2, the setting of PLC etc. There is also relevant explanation about the connection of the computer on the left-top of the display. This version can understand the COM port status of the computer and is helpful on the connection to the computer.

(This future, because of the administration authority of Vista, is not able to use under Vista)




## 2. I/O Status display

It is used for measuring and setting up the status of I/O, also support the extension card like, MT-0118C / MT-0192 / MT-0170.




### 3. Coordinate systematic parameter display

Used for setting up the parameter of all kinds of the coordinate systems.




### 4. Display of the simple and easy editor

Offer a simple and easy editor to write or revise programs.






< Can alter the color of the base or the character of the editor >



< Download the file to the editor >



< Upload the program or the plc of the controller to the editor >



### 1.2.9 Some More Online Commands On Service Propose

There are many online commands that are dedicated for service proposes. Please read the “UTC Motion Controller Manual” for the detail. The following are some of the examples.

>>Type --- The control will report a short description of this firmware version

>>Ver ---

>>Date

>>

## 1.3.0 Some Parameters Regarding Control Setup

### 1. Online Command Summary

#### Notes

<b>spaces</b>	: Spaces are not important unless special noted
<b>{ }</b>	: Item in { } can be replaced by anything fitting definition
<b>[ ]</b>	: Item in [ ] is an option
<b>[{item}...]</b>	: Repeated syntax
<b>[..{item}]</b>	: The periods are used to specify a range

#### Definitions

<b>constant</b>	: Number that is non-changeable
<b>variable</b>	: Variable like <b>I</b> , <b>M</b> , <b>P</b> , <b>Q</b>
<b>expression</b>	: combination of constant, variable, function and operator
<b>data</b>	: constant without parentheses or expression with parentheses
<b>axis</b>	: element of coordinate system. It can be X, Y, Z, U, V, W, A, B, C

### 2. Global Online Command

---

#### <CONTROL-A>

---

<b>Function</b>	Abort all Program Execution and motor moves
<b>Syntax</b>	ASCII Value 1

---

#### <CONTROL-D>

---

<b>Function</b>	Disable all PLC programs
<b>Syntax</b>	ASCII Value 4

---

#### <CONTROL-K>

---

<b>Function</b>	Disable all drivers
<b>Syntax</b>	ASCII Value 11

---

## \$\$\$

---

<b>Function</b>	Card Flash Reload
<b>Syntax</b>	\$\$\$

---

## \$\$\$\*\*\*

---

<b>Function</b>	Card reset and re-initialization
<b>Syntax</b>	\$\$\$***

---

## CLEAR

---

<b>Function</b>	Clear currently opened buffer
<b>Syntax</b>	CLEAR CLEARALL

---

## CLOSE

---

<b>Function</b>	Close the currently opened program buffer
<b>Syntax</b>	CLOSE

---

## DATE

---

<b>Function</b>	Report the controller firmware date.
<b>Syntax</b>	DATE

---

## DISPLC

---

<b>Function</b>	Disable the specified PLC(s)
<b>Syntax</b>	DISPLC{constant}[,{constant}. . .] {constant} is a positive integer representing PLC number, ranging 0~15

---

## ENAPLC

---

<b>Function</b>	Enable the specified PLC program.
<b>Syntax</b>	ENAPLC{constant}[,{constant}. . .] {constant} is a positive integer representing PLC number, ranging 0~15

---

## HM

---

**Function** Motor home searching  
**Syntax** HM

---

## HMZ

---

**Function** Do a Zero-Move Homing  
**Syntax** HMZ

---

## I{constant}

---

**Function** Report the specified I-variable value  
**Syntax** I{constant}[..{constant}]  
{constant} is an integer representing I variable number, ranging 0~1023

---

## I{constant}={expression}[:;]

---

**Function** Assign The specified I-variable value.  
**Syntax** I{constant}[..{constant}]= {expression}  
{constant} is an integer representing I variable number, ranging 0~1023  
The second {constant} should be greater than the first one; it represents the ending I-variable number.  
{expression} is an expression  
[:;] means to report the value of this I-variable value.

---

## J+

---

**Function** Jog to positive direction.  
**Syntax** J+

---

## J-

---

**Function** Jog to negative direction.  
**Syntax** J-

---

---

## J/

---

**Function** Jog stop.

**Syntax** J/

---

## J:

---

**Function** Jog a variable specified distance

**Syntax** J:

---

## J:{constant}

---

**Function** Jog a distance specified by {constant}

**Syntax** J:{constant}

{constant} is a floating point value representing the distance to jog in count..

---

## J=

---

**Function** Jog to a variable specified absolute position.

**Syntax** J=

---

## J={constant}

---

**Function** Jog a motor to a specified position

**Syntax** J={constant}

{constant} is a floating point value representing the absolute position to jog in count..

---

## J\*

---

**Function** Jog the addressed motor back to the motion program stop

**Syntax** J\*

---

---

## LIST PLC

---

**Function** Report the existed PLC program number or specified PLC Program contents

**Syntax** LIST PLC {constant}  
{constant} is positive integer representing the number of the PLC Program to reported, ranging 0~15.

---

## LISTPROG

---

**Function** Report the existed motion program numbers or specified motion program contents

**Syntax** LIST PROG{constant}  
{constant} is positive integer representing the number of the motion program to be reported.

---

## M{constant}

---

**Function** Report the specified M variable value

**Syntax** M{constant}[..{constant}]  
{constant} is an integer representing the variable number to be specified or the starting variable number, ranging 0 ~ 1023.  
The 2<sup>nd</sup> {constant} representing the end number of variable to be reported, its value should be larger than the 1<sup>st</sup> one.

---

## M{constant}={expression}[;]

---

**Function** Set the specified M variable value

**Syntax** M{constant}[..{constant}]= {expression}  
{constant} is an integer representing the variable number to be specified or the starting variable number, ranging 0 ~ 1023.  
The 2<sup>nd</sup> {constant} representing the end number of variable to be set, its value should be larger than the 1<sup>st</sup> one.  
{expression} Representing the value to be set.  
[;] means to report the value of this M variable.



---

### **M{constant}->**

---

**Function** Report M variable definition

**Syntax** M{constant}[..{constant}]->

{constant} is an integer representing the variable number to be specified or the starting variable number, ranging 0 ~ 1023.

The 2<sup>nd</sup> {constant} representing the end number of variable to be reported, its value should be larger than the 1<sup>st</sup> one.

---

### **M{constant}->\***

---

**Function** Assign M{const} as a normal variable.

**Syntax** M{constant}[..{constant}]->\*

{constant} is an integer representing the variable number to be specified or the starting variable number, ranging 0 ~ 1023.

The 2<sup>nd</sup> {constant} representing the end number of variable to be assigned, its value should be larger than the 1<sup>st</sup> one.

---

### **O{constant} For Pulse Command (UTCx00P)**

---

**Function** Set the output pulse frequency in the unit Pulses/msec

**Syntax** O{constant}

{constant} is an integer representing the pulse number per msec, ranging -250~250.

---

### **OUT{constant} For Voltage Command (UTCx00V)**

---

**Function** Set the output voltage

**Syntax** OUT{constant}

{constant} is an integer representing the ratio of **Ix30** voltage, ranging -100~100.

---

## **P{constant}**

---

**Function** Report specified P variable value

**Syntax** P{constant}[..{constant}]

{constant} is a positive integer representing the P variable, ranging 0~1023

The 2<sup>nd</sup> {constant} representing the end number of variable to be assigned, its value should be larger than the 1<sup>st</sup> one.

---

## **P{constant}={expression}[:,]**

---

**Function** Set the specified P variable value

**Syntax** P{constant}[..{constant}]= {expression}

{constant} is a positive integer representing the P variable, ranging 0~1023

The 2<sup>nd</sup> {constant} representing the end number of variable to be assigned, its value should be larger than the 1<sup>st</sup> one.

{expression} is the value to be assigned.

[:,] means to report the value of this P variable.

---

## **Q{constant}**

---

**Function** Report specified Q variable value

**Syntax** Q{constant}[..{constant}]

{constant} is a positive integer representing the Q variable, ranging 0~1023

The 2<sup>nd</sup> {constant} representing the end number of variable to be assigned, its value should be larger than the 1<sup>st</sup> one.

---

## **Q{constant}={expression}[:,]**

---

**Function** Set the specified Q variable value

**Syntax** Q{constant}[..{constant}]= {expression}

{constant} is a positive integer representing the Q variable, ranging 0~1023

The 2<sup>nd</sup> {constant} representing the end number of variable to be assigned, its value should be larger than the 1<sup>st</sup> one.

{expression} is the value to be assigned.

[:,] means to report the value of this Q variable.

---

## **RD{address}[,{length}]**

---

**Function** Report the contents of the addressed buffer memory.

**Syntax** RD(D(dec)/H(hex) /L(float){address}[,{length}]  
{address} points to the buffer memory you want to list. It should be 16 bit, ranging from \$0~FFFF  
{length} means the length of the buffer memory you want to list.

---

## **SAVE**

---

**Function** Save all the contents from static RAM to FLASH ROM.

**Syntax** SAVE

---

## **SIZE**

---

**Function** Report the available buffer size.

**Syntax** SIZE

---

## **TYPE**

---

**Function** Return UTC module number, and version description.

**Syntax** TYPE

---

## **VER**

---

**Function** Report the controller firmware version.

**Syntax** VER

## ***Chapter 2. Designing With UTC Control***

In this chapter, we will study how to start a project design with UTC control. We will start with some simple application projects that are ready for applying to a customer's machine. All the sample projects include a series of illustrations of the design procedures. Before going through with this chapter, please at least have a rough review on "UTC Motion Controller Manual" to get the basic idea of all the variables, parameters, online commands and buffer commands.

### ***2.1 A cut to length with timer cut tool output control***

This is a single axis servo control system project. When the system auto-cycle stops, some manual control is allowed. When the system auto-cycle starts, the control will go over the sequences described as following. The auto cycle can be terminated by a stop button.

1. The cut tool output turns on for the 1st pre-set timing.
2. When the 1<sup>st</sup> setting timer is over, the cut tool turns off and starts the 2<sup>nd</sup> pre-set timer.
3. When the 2<sup>nd</sup> timer timeout, servomotor feed a pre-set length.
4. When the servomotor finishes the feed length, the cutting counter increase by one and the control go back to sequence 1.
5. If the cutting count over a pre-set limit, the control stops feeding.

#### **2.1.1 The details of project requirement**

##### **2.1.1.1 Parameter Settings**

1. Length setting --- ---  
Basic unit: 0.1 mm  
Setting range: 0 to 99999.9 mm
2. Speed setting ---  
Setting range: 1 mm/second to 999mm/second
3. Count limit setting ---  
Setting range: 0 to 999999; zero setting indicates unlimited cutting.
4. Cut tool on time setting (timer1): 0.1 seconds to 99.9 seconds
5. Cut tool off time setting (timer2): 0.1 seconds to 9.9 seconds
6. Machine gear ratio: encoder counts per basic unit (0.1 mm)
7. Acceleration/deceleration time setting. 100msec to 999 msec

### 2.1.1.2 Control System Consideration

1. Parameter settings will be done with a customer-designed panel to run with UTC\_Setup+\_Eng application software. Please read the “PMWIN Manual” to get the idea of the user panel design.
2. The manual control keys.  
The manual control buttons are placed on the computer screen.  
As well, there are some digital inputs are ready for external control connections.
3. Cut tool output.  
One digital output to drive a solid-state relay as an interface to the control valve.
4. Servomotor control  
Use UTC controller Driver1 port to connect with a servo driver.

## 2.1.2 Start the Design

### 2.1.2.1 Hardware Assignments

1. Digital inputs assignments  
M11: START --- This input signal (M11=0) to trigger the system to start auto cycle.  
M12: STOP --- This input signal (M12=0) to stop the auto cycle.  
M13: JOG + --- This input signal to jog the motor in positive direction at stop cycle.  
M14: JOG- --- This input signal to jog the motor in negative direction at stop cycle.  
M15: Clear --- This input signal to clear the current cutting counter to zero.
2. Digital output assignments  
M01: Cut Tool --- M01=0 (LED lit) to turn on the cut tool.

### 2.1.2.2 Internal Variable Assignments

1. Setting parameters variable assignments  
Cutting length: P400  
Speed setting: P401  
Count limit: P402  
Tool on time (timer1): P403  
Tool off time (timer2): P404
2. Display and control information variable assignments  
Accumulated cut counts: P410  
Current servo position: P411  
Current status: P412

3. System configure and protection variables  
Gear ratio: P420 (Encoder counts per basic unit, 0.1mm)  
Maximum speed: P421 counts/second  
Minimum acceleration time: P422 msec  
Error message: P423

### 2.1.2.3 PLC programs planning example

1. PLC0 foreground (not used)
2. PLC1: Power up initial settings
3. PLC2: PLC enable/disable management
4. PLC3: Individual key/push-button handling
5. PLC4: Calculations
6. PLC5: Auto cycle handling
7. PLC6: Alarm/protection handling
8. PLC7: External inputs handling

### 2.1.2.4 PLC and motion programs coding example

1. PLC program  
Open plc1 clear           ;open a buffer area for plc1 and clear that area  
.....                   ;the program content  
close                    ;close plc1 area
2. Motion program  
Open prog1 clear        ;open a buffer area for motion program1  
                          ;and clear that area  
.....                   ;the program content  
close                    ;close program 1 area

## ***2.2 A cut to length with two sensors cut tool output control, mark signal capture and Hitech ADP3 as HMI***

This project is similar to the first project in section 2.1. We add a signal capture option and also change the HMI design to fit Hitech ADP3. We can learn how to fit the Hitech HMI to UTC control.

The following portion is different from the project in section 2.1.

- When the cut tool output turns on, a lower limit sensor to trigger the cut tool off.
  - When the cut tool output turns off, an upper limit sensor to trigger next feeding.
  - Before the setting length feeding, the servomotor speed up and catch a mark signal to determine the feeding length. The total length will be as length before mark plus setting length.
  - The Hitech ADP3 will be the target HMI.
- 1 The cut tool output turns on until a lower limit switch on. If the 1st pre-set timer timeout, the control generate an error message, cutter on timeout.
  - 2 When the lower sensor turns on, the cut tool turns off and looks for the upper sensor turns on. If the sensor does not turn on before timer2 timeout, the control generate an error message, cutter off timeout.
  - 3 When the upper sensor turns on, the servomotor keeps feeding and looks for a mark signal to continue to feed the pre-set length.
  - 4 When the servomotor finishes the pre-set feed length, the cutting counter increase by one and the control go back to sequence 1.
  - 5 If the cutting count over a pre-set limit, the control stops feeding.

### **2.2.1 The details of project requirement**

#### **2.2.1.1 Parameter Settings**

1. Length setting --- ---  
Basic unit: 0.1 mm  
Setting range: 0 to 99999.9 mm
2. Speed setting ---  
Setting range: 1 mm/second to 999mm/second
3. Count limit setting ---  
Setting range: 0 to 999999; zero setting indicates unlimited cutting.
4. Cut tool on limit timer (timer1): 0.1 seconds to 99.9 seconds
5. Cut tool off limit timer (timer2): 0.1 seconds to 9.9 seconds
6. Machine gear ratio: encoder counts per basic unit (0.1 mm)
7. Acceleration/deceleration time setting. 100msec to 999 msec



### 2.2.1.2 Control System Consideration

1. Parameter settings will be done with Hitech ADP3 HMI.
2. The panel control keys and push-buttons are on Hitech touch panel.  
As well, there are some digital inputs ready for external control connections.
3. Cut tool output.  
One digital output is assigned to drive a solid-state relay as an interface to the control valve.
4. Servomotor control  
Use UTC controller Driver1 port to connect with a servo driver.

## 2.2.2 Start the Design

### 2.2.2.1 Hardware Assignments

1. Digital inputs assignments  
M11: START --- This input signal (M11=0) to trigger the system to start auto cycle.  
M12: STOP --- This input signal (M12=0) to stop the auto cycle.  
M13: JOG + --- This input signal to jog the motor in positive direction at stop cycle.  
M14: JOG- --- This input signal to jog the motor in negative direction at stop cycle.  
M15: Clear --- This input signal to clear the current cutting counter to zero.  
M21: Lower limit sensor  
M22: Upper limit sensor  
M23: Mark signal to trigger the pre-set length.
2. Digital output assignments  
M01: Cut Tool --- M01=0 (LED lit) to turn on the cut tool.

### 2.2.2.2 Internal Variable Assignments

1. Setting parameters variable assignments  
Cutting length: P400  
Speed setting: P401  
Count limit: P402  
Tool on timer (timer1): P403  
Tool off timer (timer2): P404
2. Display and control information variable assignments  
Accumulated cut counts: P410  
Current servo position: P411  
Current status: P412

3. System configure and protection variables
    - Gear ratio: P420 (Encoder counts per basic unit, 0.1mm)
    - Maximum speed: P421 counts/second
    - Minimum acceleration time: P422 msec
    - Error message: P423
  4. Hitech interface parameters
    - Cutting length: P500, P501
    - Speed setting: P502
    - Count limit: P503, P504
    - Tool on timer (timer1): P505
    - Tool off timer (timer2): P506
    - Accumulated cut counts: P507, P508
    - Current servo position: P509, P510
    - Current status: P511
- Gear ratio: P512
- Maximum speed: P513, P514
- Error message: P423

### 2.2.2.3 PLC programs planning example

1. PLC0: Mark capture handling
2. PLC1: Power up initial settings
3. PLC2: PLC enable/disable management
4. PLC3: Individual key/push-button handling
5. PLC4: Calculations
6. PLC5: Auto cycle handling
7. PLC6: Alarm/protection handling
8. PLC7: External inputs handling

## ***2.3 A single axis motion program example for drilling cycle and Hitech ADP3 as HMI***

(Home finding // limit switches // motion program for the drilling // hand wheel for master following setting // AD1 for federate override // AD2 and DA1 for spindle speed control)

## Chapter 3. Appendix

### 3.1 PROJECT\_1

CLOSE

```
;=====EXTERNAL INPUT=====
;STATUS =0      (TRUE)
;      =1      (FALSE)
;M11   ;START
;M12   ;STOP
;M13   ;+JOG
;M14   ;-JOG
;M15   ;CLEAR
;=====EXTERNAL INPUT=====
;STATUS =0      (TRUE)
;      =1      (FALSE)
;M21   ;NO MATERIAL
;=====OUTPUT=====
;STATUS =0      (TRUE)
;      =1      (FALSE)
;M01   ;CUT TOOL
;M02   ;ALARM LAMP
;=====SETTING PARAMETERS=====
;P400   ;CUTTING LENGTH SETTING
;P401   ;SPEED SETTING
;P402   ;COUNT LIMIT SETTING
;P403   ;TOOL ON TIME SETTING
;P404   ;TOOL OFF TIME SETTING
;P405   ;ACC/DEC TIME SETTING
;=====DISPLAY=====
;P410   ;ACCUMULATED CUT COUNTS
;P411   ;CURRENT SERVO POSITION
;=====SYSTEM CONFIGURE=====
;P420   ;GEAR RATIO
;P421   ;MAXIMUM SPEED
;P422   ;MINIMUM ACCELERATION TIME
;P423   ;ERROR MESSAGE
;P424   ;ACTION CODE
```

```
;P425    ;AUTO RUN STATUS
;P426    ;FEEDING FLAG
;P427    ;COUNT OVER FLAG
```

```
;=====PLC0=====
OPEN PLC0 CLEAR
CLOSE
```

```
;=====PLC1=====
OPEN PLC1 CLEAR          ;POWER UP INITIAL SETTINGS
DISPLC2,3,4,5,6,7
M71=2000
WHILE(M71>0)              ;DELAY 2 SECOND
ENDW
P11=M11                   ;START FLAG
P12=M12                   ;STOP FLAG
P13=M13                   ;+JOG FLAG
P14=M14                   ;-JOG FLAG
P15=M15                   ;CLEAR FLAG
P424=0                    ;NO ACTIONS AT POWER ON
P425=0                    ;NOT IN AUTO RUN STATUS
P426=0                    ;NOT IN AUTO FEEDING
P427=0                    ;NO COUNT OVER
P2=0                      ;P2=1 WHEN AUTO RUNNING
CMD"#1J/"                ;ENABLE #1 SEVRO ON
ENAPLC2,4,6,7
DISPLC1
CLOSE
```

```
;=====PLC2=====
OPEN PLC2 CLEAR          ;PLC ENABLE/DISABLE MANAGEMENT
IF(P424!=0)              ;ANY ACTIONS?
    ENAPLC3              ;IF YES, ENABLE PLC3.
ENDIF
IF(P425!=0)              ;AUTO CYCLE STARTED?
    ENAPLC5              ;IF YES, ENABLE PLC5.
ENDIF
CLOSE
```

```

;=====PLC3=====
OPEN PLC3 CLEAR          ;INDIVIDUAL KEY/PUSH-BUTTON HANDING
IF(P424=1)                ;JOG+
    P424=0
    IF(P425=0)
        I101=P405        ;ACC/DEC TIME SETTING
        I103=P401*M191    ;JOG SPEED SETTING
        CMD"#1J+"
        P426=0            ;NOT IN AUTO FEEDING
    ENDIF
ENDIF
ENDIF
.....
IF(P424=2)                ;JOG-
    P424=0
    IF(P425=0)
        I101=P405
        I103=P401*M191
        CMD"#1J-"
        P426=0
    ENDIF
ENDIF
ENDIF
.....
IF(P424=3)                ;JOG/
    P424=0
    IF(P425=0 AND M144=0) ;NOT AUTO & NO FOLLOWING ERROR
        CMD"#1J/"        ;STOP JOGGING
    ENDIF
ENDIF
ENDIF
.....
IF(P424=4)                ;CLEAR
    P424=0
    P410=0                ;CLEAR CUT COUNTS
ENDIF
ENDIF
.....
IF(P424=10)               ;START
    P2=1                  ;STARTED FLAG
    P424=0
    IF(P425=0 AND M141=0 AND P423=0)

```

```

                IF(P426=0)
                    P425=1      ;CUT ONCE THEN MOVE
                ELSE
                    P425=3      ;BACK TO UNFINISHED MOVING
                ENDIF
            ENDIF
        ENDIF
    .....
    ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
    IF(P424=11)                ;STOP
        P2=0                  ;STOP AUTO CYCLE
        P424=0
        IF(P425!=0)           ;IF IN AUTO CYCLE.
            P425=10           ;TO STOP PLC5
        ELSE
            CMD"#1J/"         ;STOP JOGGING
        ENDIF
    ENDIF
    .....
    ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
    DISPLC3                    ;DISABLE PLC3
    CLOSE

;=====PLC4=====
OPEN PLC4 CLEAR                ;CALCULATIONS
P411=ROUND(M161/M191)          ;CURRENT SERVO POSITION
IF(P400<0 OR P400>99999.9)      ;LENGTH SETTING RANGE
    IF(P400>99999.9)
        P400=99999.9
    ELSE
        P400=0
    ENDIF
ENDIF
ENDIF
IF(P400!=Q400)                 ;CHECK LENGTH SETTING
    P426=0
    Q400=P400
ENDIF
IF(P401<1 OR P401>P421)        ;SPEED SETTING RANGE
    IF(P401>P421)              ;MAXIMUM SPEED FOR P421
        P401=P421
    ELSE

```

```

                P401=1
            ENDIF
        ENDIF
    IF(P402<0 OR P402>999999)                ;COUNT LIMIT SETTING RANGE
        IF(P402>999999)
            P402=999999
        ELSE
            P402=0
        ENDIF
    ENDIF
    IF(P403<0.1 OR P403>99.9)                ;TOOL ON TIMER RANGE
        IF(P403>99.9)
            P403=99.9
        ELSE
            P403=0.1
        ENDIF
    ENDIF
    IF(P404<0.1 OR P404>99.9)                ;TOOL OFF TIMER RANGE
        IF(P404>99.9)
            P404=99.9
        ELSE
            P404=0.1
        ENDIF
    ENDIF
    IF(P405<P422 OR P405>999)                ;ACCELERATION/DECELERTION
                                            ;TIMER RANGE
                                            ;MINMUM ACC/DEC TIMER FOR P422
        IF(P405>999)
            P405=999
        ELSE
            P405=P422
        ENDIF
    ENDIF
    IF(P420<=0)                            ;GEAR RATIO
        P420=1
    ENDIF
    M191=P420*10
    CLOSE

```



```

;=====PLC5=====
OPEN PLC5 CLEAR ;AUTO CYCLE HANDLING
IF(P425=1) ;FIRST TOOL ON
    M1=0 ;TOOL ON
    M71=P403*1000 ;SET TOOL ON TIME
    WHILE(M71>0)
    ENDW
    P425=2
ENDIF
.....
IF(P425=2) ;FIRST TOOL OFF
    M1=1
    M71=P404*1000 ;SET TOOL OFF TIME BEFORE FEEDING
    WHILE(M71>0 AND P425=2)
    ENDW
    IF(P425=10)
        RET
    ENDIF
    P425=3
ENDIF
.....
IF(P425=3) ;FEEDING
    IF(P426=0)
        CMD"#1HMZ" ;SET CURRENT POSITION = 0
    ENDIF
    M71=10
    WHILE(M71>0) ;WAIT FOR CLEAR POSITION
    ENDW
    M163=M191*P400 ;M163 = TARGET POSITION
    I101=P405 ;ACC/DEC TIME
    I103=P401*M191 ;SPEED
    CMD"#1J=" ;ACTION
    M71=20
    WHILE(M71>0) ;WAIT FOR FIRMWARE PROCESSING
    ENDW
    P426=1 ;FEEDING FLAG = 1
    WHILE(M161!=M163 AND M141!=0 AND P425=3)
    ENDW

```

```

        IF(P425=10)                ;STOP
            RET
        ENDIF
        P426=0                    ;STOP FEEDING
        P425=4                    ;NEXT STEP
    ENDIF
    IF(P425=4)                    ;TOOL ON
        M1=0
        M71=P403*1000
        WHILE(M71>0)
            ENDW
        P425=5
    ENDIF
    IF(P425=5)                    ;TOOL OFF
        M1=1
        M71=P404*1000
        WHILE(M71>0 AND P425=5)
            ENDW
        IF(P425=10)
            RET
        ENDIF
        P410=P410+1                ;COUNT
        IF(P402>P410 OR P402=0)    ;CHECK COUNT LIMIT
            P425=3
        ELSE
            P423=4                ;ALARM MESSAGE FOR P423=3
            P425=10
        ENDIF
    ENDIF
    IF(P425=10)                    ;GET READY FOR STOP
        CMD"#1J/"
        M1=1
        P425=0
    ENDIF
    IF(P425=0)                    ;DISABLE PLC5 TO STOP AUTO CYCLE
        DISPLC5
    ENDIF
CLOSE

```

```

.....
))))))))))))))))))))))))))))))))

```

```

;=====PLC6=====
OPEN PLC6 CLEAR ;ALARM/PROTECTION HANDING
IF(P402>P410 OR P402=0) ;COUNT OVER FLAG
    P427=0
ELSE
    P427=1
ENDIF
IF(M143=1 OR M21=0 OR M144=1) ;DRIVER FAULT OR NO MATERIAL OR
    ;FOLLOWING ERROR
    IF(M143=1)
        P423=1
    ELSE
        IF(M21=0)
            P423=2
        ELSE
            P423=3
        ENDIF
    ENDIF
ELSE
    IF(P427=1) ;COUNT OVER
        P423=4
    ELSE
        P423=0
    ENDIF
ENDIF
;=====
;COUNT OVER
IF(P423!=0)
    M2=P2^1
    P430=P423
ELSE
    M2=1
    IF(P425=0 AND P426=1)
        P430=29
    ELSE
        P430=20+P425
    ENDIF
ENDIF
;=====

```

```

CLOSE
;=====PLC7=====
OPEN PLC7 CLEAR ;EXTERNAL HMI INPUTS
IF(M11=0 AND P11!=0) ;START EXTERNAL INPUTS
    P11=0
    P424=10
ENDIF
IF(M11=1 AND P11!=1)
    P11=1
ENDIF
IF(M12=0 AND P12!=0) ;STOP EXTERNAL INPUTS
    P12=0
    P424=11
ENDIF
IF(M12=1 AND P12!=1)
    P12=1
ENDIF
IF(M13=0 AND P13!=0) ;JOG+ EXTERNAL INPUTS
    P13=0
    P424=1
ENDIF ;JOG/ EXTERNAL INPUTS
IF(M13=1 AND P13!=1)
    P13=1
    P424=3
ENDIF
IF(M14=0 AND P14!=0) ;JOG- EXTERNAL INPUTS
    P14=0
    P424=2
ENDIF
IF(M14=1 AND P14!=1) ;JOG/ EXTERNAL INPUTS
    P14=1
    P424=3
ENDIF
IF(M15=0 AND P15!=0) ;CLEAR EXTERNAL INPUTS
    P15=0
    P424=4
ENDIF
IF(M15=1 AND P15!=1)
    P15=1

```

ENDIF  
CLOSE

;=====PLC8=====

OPEN PLC8 CLEAR

CLOSE

## 3.2 PROJECT\_2

CLOSE

```
;=====EXTERNAL INPUT=====
;STATUS =0      (TRUE)
;      =1      (FALSE)
;M11      ;START
;M12      ;STOP
;M13      ;+JOG
;M14      ;-JOG
;M15      ;CLEAR
```

```
;=====EXTERNAL INPUT=====
;STATUS =0      (TRUE)
;      =1      (FALSE)
;M21      ;NO MATERIAL
;;M22      ;CUT UP LIMIT
;;M23      ;CUT DOWN LIMIT
```

```
;=====PANEL INPUT=====
;STATUS =0      (FALSE)
;      =1      (TRUE)
M501..505->*
;;M501      ;+JOG
;;M502      ;-JOG
```

```
;=====OUTPUT=====
;STATUS =0      (TRUE)
;      =1      (FALSE)
;M01      ;CUT TOOL
;M02      ;ALARM LAMP
```

```
;=====SETTING PARAMETERS=====
;P400      ;CUTTING LENGTH<*****.*>
;P401      ;SPEED SETTING<***>
;P402      ;COUNT LIMIT<*****>
;P403      ;TOOL ON TIME(TIMER1)<**. *>
;P404      ;TOOL OFF TIME<**. *>
```

```
;P405 ;ACC/DEC TIMER<***>
;;P406 ;TOOL TO LIMIT TIME OUT<***>
```

```
;=====DISPLAY=====
```

```
;P410 ;ACCUMULATED CUT COUNTS<*****>
;P411 ;CURRENT SERVO POSITION<*****.*>
;P412 ;CURRENT STATUS
```

```
;=====SYSTEM CONFIGURE=====
```

```
;P420 ;GEAR RATIO<****.*>
;P421 ;MAXIMUM SPEED<***>
;P422 ;MINIMUM ACCELERATION TIME<***>
;P423 ;ERROR MESSAGE<1~60>
;P424 ;ACTION STATUS<1~20>
;P425 ;AUTO RUN STATUS<1~5>
;P426 ;FEEDING FLAG<0,1>
;P427 ;COUNT OVER FLAG<0,1>
;;P428 ;TOOL ON TIME OUT FLAG<0,1>
;;P429 ;TOOL OFF TIME OUT FLAG<0,1>
```

```
;;P430 ;INFORMATION
```

```
;=====HUMAN MACHINE INTERFACE=====
```

```
.....READ UTC-CONTROLLER;.....
,,,,,,,,,
```

```
;P450 ;P400---
;P451 ;P401(SPEED SETTING)
;P452 ;P402---
;P453 ;P403(TOOL ON TIME)
;P454 ;P404(TOOL OFF TIME)
;P455 ;P405(ACC/DEC TIMER)
;P456 ;P406(TOOL TO LIMIT TIME OUT)
```

```
;P460 ;P410---
;P461 ;P411---
```

```
;P470 ;P420---
;P471 ;P421(MAXIMUM SPEED)
;P472 ;P422(MINIMUM ACCELERATION TIME)
```

```

;P480 ;LOW_Word FOR P400(CUTTING LENGTH)
;P481 ;HI_Word FOR P400(CUTTING LENGTH)
;P482 ;LOW_Word FOR P402(COUNT LIMIT)
;P483 ;HI_Word FOR P402(COUNT LIMIT)
;P484 ;LOW_Word FOR P410(ACCUMULATED CUT COUNTS)
;P485 ;HI_Word FOR P410(ACCUMULATED CUT COUNTS)
;P486 ;LOW_Word FOR P411(CURRENT SERVO POSITION)
;P487 ;HI_Word FOR P411(CURRENT SERVO POSITION)
;P488 ;LOW_Word FOR P420(GEAR RATIO)
;P489 ;HI_Word FOR P420(GEAR RATIO)

```

.....WRITE TO UTC-CONTROLLER.....  
,,,,,,,,,,,,,

```

;P550 ;P400---
;P551 ;P401(SPEED SETTING)
;P552 ;P402---
;P553 ;P403(TOOL ON TIME)
;P554 ;P404(TOOL OFF TIME)
;P555 ;P405(ACC/DEC TIMER)
;P556 ;P406(TOOL TO LIMIT TIME OUT)

```

```

;P560 ;P410---
;P561 ;P411---

```

```

;P570 ;P420---
;P571 ;P421(MAXIMUM SPEED)
;P572 ;P422(MINIMUM ACCELERATION TIME)

```

```

;P580 ;LOW_Word FOR P400(CUTTING LENGTH)
;P581 ;HI_Word FOR P400(CUTTING LENGTH)
;P582 ;LOW_Word FOR P402(COUNT LIMIT)
;P583 ;HI_Word FOR P402(COUNT LIMIT)
;P584 ;LOW_Word FOR P410(ACCUMULATED CUT COUNTS)
;P585 ;HI_Word FOR P410(ACCUMULATED CUT COUNTS)
;P586 ;LOW_Word FOR P411(CURRENT SERVO POSITION)
;P587 ;HI_Word FOR P411(CURRENT SERVO POSITION)
;P588 ;LOW_Word FOR P420(GEAR RATIO)
;P589 ;HI_Word FOR P420(GEAR RATIO)

```



;=====PLC0=====

OPEN PLC0 CLEAR

CLOSE

;=====PLC1=====

OPEN PLC1 CLEAR ;POWER UP INITIAL SETTINGS

DISPLC2,3,4,5,6,7,8

M71=2000

WHILE(M71>0) ;DELAY 2 SECOND

ENDW

CMD"#1J/" ;ENABLE #1 SEVRO ON

P11=M11 ;START FLAG

P12=M12 ;STOP FLAG

P13=M13 ;+JOG FLAG

P14=M14 ;-JOG FLAG

P15=M15 ;CLEAR FLAG

P501=M501 ;START FLAG

P502=M502 ;STOP FLAG

P503=M503 ;+JOG FLAG

P504=M504 ;-JOG FLAG

P505=M505 ;CLEAR FLAG

P424=0 ;NO ACTIONS AT POWER ON

P425=0 ;NOT IN AUTO RUN STATUS

P426=0 ;NOT IN AUTO FEEDING

P427=0

P428=0

P429=0

P2=0 ;P2=1 WHEN AUTO RUNNING

CMD"P550..599=0"

ENAPLC2,4,6,7,8

DISPLC1

CLOSE

;=====PLC2=====

OPEN PLC2 CLEAR ;PLC ENABLE/DISABLE MANAGEMENT

IF(P424!=0) ;ANY ACTIONS?

ENAPLC3 ;IF YES, ENABLE PLC3.

ENDIF

```

IF(P425!=0)                                ;AUTO CYCLE STARTED?
    ENAPLC5                                ;IF YES, ENABLE PLC5.
ENDIF
CLOSE

;=====PLC3=====
OPEN PLC3 CLEAR                            ;INDIVIDUAL KEY/PUSH-BUTTON HANDLING
IF(P424=1)                                  ;JOG+
    P424=0
    IF(P425=0)
        I101=P405                        ;ACC/DEC TIME SETTING
        I103=P401*M191                    ;JOG SPEED SETTING
        CMD"#1J+"
        P426=0                            ;NOT IN AUTO FEEDING
    ENDIF
ENDIF
IF(P424=2)                                  ;JOG-
    P424=0
    IF(P425=0)
        I101=P405
        I103=P401*M191
        CMD"#1J-"
        P426=0
    ENDIF
ENDIF
IF(P424=3)                                  ;JOG/
    P424=0
    IF(P425=0)
        CMD"#1J/"                        ;STOP JOGGING
    ENDIF
ENDIF
IF(P424=4)                                  ;CLEAR
    P424=0
    P410=0                                ;CLEAR CUT COUNTS
    P428=0                                ;;
    P429=0                                ;;
ENDIF
IF(P424=10)                                ;START
    P2=1                                  ;STARTED FLAG

```

```

P424=0
IF(P425=0 AND M141=0 AND P423=0)
    IF(P426=0)
        P425=1      ;CUT ONCE THEN MOVE
    ELSE
        P425=3      ;BACK TO UNFINISHED MOVING
    ENDIF
ENDIF
ENDIF
IF(P424=11)          ;STOP
    P2=0              ;STOP AUTO CYCLE
    P424=0
    IF(P425!=0)        ;IF IN AUTO CYCLE.
        P425=10        ;TO STOP PLC5
    ELSE
        P423=0
        P427=0
        P428=0
        P429=0
        CMD"#1J/"      ;STOP JOGGING
    ENDIF
ENDIF
ENDIF

DISPLC3              ;DISABLE PLC3
CLOSE

;=====PLC4=====
OPEN PLC4 CLEAR      ;CALCULATIONS
P411=ROUND(M161/M191) ;CURRENT SERVO POSITION
IF(P400<0 OR P400>99999.9) ;LENGTH SETTING RANGE
    IF(P400>99999.9)
        P400=99999.9
    ELSE
        P400=0
    ENDIF
ENDIF
ENDIF
IF(P400!=Q400)        ;CHECK LENGTH SETTING
    P426=0
    Q400=P400

```

```

ENDIF
IF(P401<1 OR P401>P421)                ;SPEED SETTING RANGE
    IF(P401>P421)                        ;MAXIMUM SPEED FOR P421
        P401=P421
    ELSE
        P401=1
    ENDIF
ENDIF
IF(P402<0 OR P402>999999)                ;COUNT LIMIT SETTING RANGE
    IF(P402>999999)
        P402=999999
    ELSE
        P402=0
    ENDIF
ENDIF
IF(P403<0.1 OR P403>99.9)                ;TOOL ON TIMER RANGE
    IF(P403>99.9)
        P403=99.9
    ELSE
        P403=0.1
    ENDIF
ENDIF
IF(P404<0.1 OR P404>99.9)                ;TOOL OFF TIMER RANGE
    IF(P404>99.9)
        P404=99.9
    ELSE
        P404=0.1
    ENDIF
ENDIF
IF(P405<P422 OR P405>999)                ;ACCELERATION/DECELERATION
                                           ;TIMER RANGE
    IF(P405>999)                          ;MINMUM ACC/DEC TIMER FOR P422
        P405=999
    ELSE
        P405=P422
    ENDIF
ENDIF
IF(P420<1)                               ;GEAR RATIO
    P420=1

```

ENDIF

M191=P420\*10

CLOSE

;=====PLC5=====

OPEN PLC5 CLEAR ;AUTO CYCLE HANDLING

IF(P425=1) ;FIRST TOOL ON

M1=0 ;TOOL ON

M71=P406\*1000 ;TO DOWN LIMIT TIME

WHILE(M71>0 AND P425=1 AND M23=1)

ENDW

IF(M71<0) ;TIME OUT

P428=1

P425=10

RET

ENDIF

IF(P425=10) ;STOP

RET

ENDIF

M71=P403\*1000 ;SET TOOL ON TIME

WHILE(M71>0)

ENDW

IF(P425=10) ;STOP

RET

ENDIF

P425=2

ENDIF

IF(P425=2) ;FIRST TOOL OFF

M1=1

M71=P406\*1000 ;TOOL OFF TO UP LIMIT TIME

WHILE(M71>0 AND P425=2 AND M22=1)

ENDW

IF(M71<0) ;TIME OUT

P429=1

P425=10

RET

ENDIF

IF(P425=10)

RET

```

ENDIF
M71=P404*1000           ;SET TOOL OFF TIME BEFORE FEEDING
WHILE(M71>0 AND P425=2)
ENDW
IF(P425=10)
    RET
ENDIF
P425=3
ENDIF
IF(P425=3)               ;FEEDING
    IF(P426=0)
        CMD"#1HMZ"       ;SET CURRENT POSITION = 0
    ENDIF
    M71=10
    WHILE(M71>0)         ;WAIT FOR CLEAR POSITION
    ENDW
    M163=M191*P400        ;M163 = TARGET POSITION
    I101=P405             ;ACC/DEC TIME
    I103=P401*M191        ;SPEED
    CMD"#1J="            ;ACTION
    M71=20
    WHILE(M71>0)         ;WAIT FOR FIRMWARE PROCESSING
    ENDW
    P426=1               ;FEEDING FLAG = 1
    WHILE(M161!=M163 AND M141!=0 AND P425=3)
    ENDW
    IF(P425=10)          ;STOP
        RET
    ENDIF
    P426=0               ;STOP FEEDING
    P425=4               ;NEXT STEP
ENDIF
IF(P425=4)              ;TOOL ON
    M1=0
    M71=P406*1000
    WHILE(M71>0 AND P425=4 AND M23=1)
    ENDW
    IF(M71<0)            ;TIME OUT
        P428=1

```

```

        P425=10
        RET
    ENDIF
    IF(P425=10)                ;STOP
        RET
    ENDIF
    M71=P403*1000              ;SET TOOL ON TIME
    WHILE(M71>0)
    ENDW
    IF(P425=10)                ;STOP
        RET
    ENDIF
    P425=5
ENDIF
IF(P425=5)                    ;TOOL OFF
    M1=1
    M71=P406*1000
    WHILE(M71>0 AND P425=5 AND M22=1)
    ENDW
    IF(M71<0)                  ;TIME OUT
        P429=1
        P425=10
        RET
    ENDIF
    IF(P425=10)                ;STOP
        RET
    ENDIF
    M71=P404*1000              ;SET TOOL OFF TIME BEFORE FEEDING
    WHILE(M71>0 AND P425=5)
    ENDW
    IF(P425=10)
        RET
    ENDIF
    P410=P410+1                ;COUNT
    IF(P402>P410 OR P402=0)    ;CHECK COUNT LIMIT
        P425=3
    ELSE
        P423=3                ;ALARM MESSAGE FOR P423=3
        P425=10
    
```

```

        ENDIF
ENDIF
IF(P425=10)                                ;GET READY FOR STOP
        IF(M114=0)
                CMD"#1J/"
        ENDIF
        M1=1
        P425=0
ENDIF
IF(P425=0)                                ;DISABLE PLC5 TO STOP AUTO CYCLE
        DISPLC5
ENDIF
CLOSE

;=====PLC6=====
OPEN PLC6 CLEAR                                ;ALARM/PROTECTION HANDING
IF(P402>P410 OR P402=0)                        ;COUNT OVER FLAG
        P427=0
ELSE
        P427=1
ENDIF
IF(M143=1 OR M21=0 OR M144=1)                ;DRIVER FAULT OR NO MATERIAL OR
                                                ;FOLLOWING ERROR
        IF(M143=1)
                P423=1
        ELSE
                IF(M21=0)
                        P423=2
                ELSE
                        P423=3
                ENDIF
        ENDIF
ELSE
        IF(P427=1 OR P428=1 OR P429=1)
                IF(P427=1)
                        P423=4
                ELSE
                        IF(P428=1)
                                P423=5

```



```

                                ELSE
                                P423=6
                                ENDIF
                            ENDIF
                        ENDIF
                    ENDIF
                IF(P423!=0)
                    M2=P2^1
                    P430=P423
                    IF(P2=1)
                        P424=11                ;STOP
                        P426=0
                    ENDIF
                ELSE
                    M2=1
                    IF(P425=0 AND P426=1)
                        P430=29
                    ELSE
                        P430=20+P425
                    ENDIF
                ENDIF
            ENDIF

        CLOSE
        ;=====PLC7=====
        OPEN PLC7 CLEAR                ;EXTERNAL&PANEL INPUTS
        IF(M11=0 AND P11!=0)            ;START EXTERNAL INPUTS
            P11=0
            P424=10
        ENDIF
        IF(M11=1 AND P11!=1)
            P11=1
        ENDIF
        IF(M12=0 AND P12!=0)            ;STOP EXTERNAL INPUTS
            P12=0
            P424=11
        ENDIF
        IF(M12=1 AND P12!=1)
            P12=1
        ENDIF
    
```

IF(M13=0 AND P13!=0)	;JOG+ EXTERNAL INPUTS
P13=0	
P424=1	
ENDIF	;JOG/ EXTERNAL INPUTS
IF(M13=1 AND P13!=1)	
P13=1	
P424=3	
ENDIF	
IF(M14=0 AND P14!=0)	;JOG- EXTERNAL INPUTS
P14=0	
P424=2	
ENDIF	
IF(M14=1 AND P14!=1)	;JOG/ EXTERNAL INPUTS
P14=1	
P424=3	
ENDIF	
IF(M15=0 AND P15!=0)	;CLEAR EXTERNAL INPUTS
P15=0	
P424=4	
ENDIF	
IF(M15=1 AND P15!=1)	
P15=1	
ENDIF	
.....	
IF(M501=1 AND P501!=1)	;JOG+ PANEL INPUTS
P501=1	
P424=1	
ENDIF	;JOG/ PANEL INPUTS
IF(M501=0 AND P501!=0)	
P501=0	
P424=3	
ENDIF	
IF(M502=1 AND P502!=1)	;JOG- PANEL INPUTS
P502=1	
P424=2	
ENDIF	
IF(M502=0 AND P502!=0)	;JOG/ PANEL INPUTS
P502=0	
P424=3	

ENDIF  
CLOSE

;=====PLC8=====

OPEN PLC8 CLEAR

.....READ UTC-CONTROLLER;.....  
,,,,,,,,,

;P450 ;P400---

P451=P401 ;P401(SPEED SETTING)

;P452 ;P402---

P453=P403\*10 ;P403(TOOL ON TIME)

P454=P404\*10 ;P404(TOOL OFF TIME)

P455=P405 ;P405(ACC/DEC TIMER)

P456=P406 ;P406(TOOL TO LIMIT TIME OUT)

;P460 ;P410---

;P461 ;P411---

;P470 ;P420---

P471=P421 ;P421(MAXIMUM SPEED)

P472=P422 ;P422(MINIMUM ACCELERATION TIME)

P481=INT(P400\*10/65536) ;HI\_Word FOR P400(CUTTING LENGTH)

P480=INT(P400\*10)-P481\*65536 ;LOW\_Word FOR P400(CUTTING LENGTH)

P483=INT(P402/65536) ;HI\_Word FOR P402(COUNT LIMIT)

P482=P402-P483\*65536 ;LOW\_Word FOR P402(COUNT LIMIT)

P485=INT(P410/65536) ;HI\_Word FOR P410(ACCUMULATED CUT  
COUNTS)

P484=P410-P485\*65536 ;LOW\_Word FOR P410(ACCUMULATED  
CUT COUNTS)

P487=INT(P411\*10/65536) ;HI\_Word FOR P411(CURRENT SERVO  
POSITION)

P486=INT(P411\*10)-P487\*65536 ;LOW\_Word FOR P411(CURRENT SERVO  
POSITION)

P489=INT(P420\*1000/65536) ;HI\_Word FOR P420(GEAR RATIO)

P488=INT((P420+0.0001)\*1000)-P489\*65536 ;LOW\_Word FOR P420(GEAR RATIO)

.....WRITE TO UTC-CONTROLLER;.....  
,,,,,,,,,

;P550 ;P400---

IF(P551!=0) ;P401(SPEED SETTING)

```

        P401=P551
        P551=0
ENDIF
;P552    ;P402---
IF(P553!=0)                ;P403(TOOL ON TIME)
        P403=P553*0.1
        P553=0
ENDIF
IF(P554!=0)                ;P404(TOOL OFF TIME)
        P404=P554*0.1
        P554=0
ENDIF
IF(P555!=0)                ;P405(ACC/DEC TIMER)
        P405=P555
        P555=0
ENDIF
IF(P556!=0)                ;P406(TOOL TO LIMIT TIME OUT)
        P406=P556
        P556=0
ENDIF

;P560    ;P410---
;P561    ;P411---

;P570    ;P420---
IF(P571!=0)                ;P421(MAXIMUM SPEED)
        P421=P571
        P571=0
ENDIF
IF(P572!=0)                ;P422(MINIMUM ACCELERATION TIME)
        P422=P572
        P572=0
ENDIF

;P580    ;LOW_WORD FOR P400(CUTTING LENGTH)
;P581    ;HI_WORD FOR P400(CUTTING LENGTH)
IF(P580!=0 OR P581!=0)
        P400=(P580+P581*65536)*0.1
        P580=0

```

```

        P581=0
ENDIF
;P582    ;LOW_WORD FOR P402(COUNT LIMIT)
;P583    ;HI_WORD FOR P402(COUNT LIMIT)
IF(P582!=0 OR P583!=0)
        P402=P582+P583*65536
        P582=0
        P583=0
ENDIF
;P584    ;LOW_WORD FOR P410(ACCUMULATED CUT COUNTS)
;P585    ;HI_WORD FOR P410(ACCUMULATED CUT COUNTS)
IF(P584!=0 OR P585!=0)
        P410=P584+P585*65536
        P584=0
        P585=0
ENDIF
;P586    ;LOW_Word FOR P411(CURRENT SERVO POSITION)
;P587    ;HI_Word FOR P411(CURRENT SERVO POSITION)
IF(P586!=0 OR P587!=0)
        P411=(P586+P587*65536)*0.1
        P586=0
        P587=0
ENDIF
;P588    ;LOW_Word FOR P420(GEAR RATIO)
;P589    ;HI_Word FOR P420(GEAR RATIO)
IF(P588!=0 OR P589!=0)
        P420=(P588+P589*65536)*0.001
        P588=0
        P589=0
ENDIF
CLOSE

```