

PM-2 50UA Test Procedure:

1、 Test “Zero” position



2、 The balance test at 45degree, horizontal and vertical



3、Test the scale between Zero and full scale



4、 Test at full scale



