



AB158x Series Earbuds Reference Design User Guide

Version: 1.0

Release date: 12 January 2022

Document revision history

Revision	Date	Description
1.0	12 January 2022	Initial version

Table of contents

1.	Introduction.....	1
1.1.	Platform architecture	1
1.2.	EVK components.....	1
2.	MMI Functionality	3
2.1.	System	3
2.1.1.	Power.....	3
2.2.	Connection.....	4
2.2.1.	Entering pairing mode	4
2.2.2.	Connected.....	4
2.2.3.	Reconnecting automatically	4
2.2.4.	Air pairing	5
2.3.	Calling	5
2.3.1.	Incoming call	5
2.3.2.	Accepting a call	5
2.3.3.	Ending a call	6
2.3.4.	Rejecting a call	6
2.3.5.	Holding a call.....	6
2.3.6.	Three-way calling.....	6
2.4.	Volume	7
2.4.1.	Changing the volume	7
2.5.	Music	8
2.5.1.	Playing music	8
2.5.2.	Pausing music	8
2.5.3.	Skipping forward.....	9
2.5.4.	Skipping back	9
2.5.5.	Fast forward and fast rewind.....	9
2.6.	ANC and pass through	9
2.7.	Voice assistant	10
2.7.1.	Waking up voice assistant.....	10
2.8.	MCSync share	10
2.8.1.	Enter MCSync share.....	10
2.8.2.	Exit MCSync share.....	10
2.9.	Multipoint.....	11
2.9.1.	Connection.....	11
3.	MMI Event	12
3.1.	Connection.....	12
3.2.	Battery	12
3.3.	Time out.....	12
4.	Key Mapping Table	13

Lists of tables and figures

Table 1. Power	3
Table 2. Enable BT	3
Table 3. Enable BT without smart charger case	3
Table 4. Enter pairing mode	4
Table 5. Connected	4
Table 6. Reconnect actively	4
Table 7. Air pairing	5
Table 8. Incoming call	5
Table 9. Accept call	5
Table 10. End call	6
Table 11. Reject call	6
Table 12. Hold call	6
Table 13. Hold and reject	7
Table 14. Hold and accept	7
Table 15. End active call and recover held	7
Table 16. Ending a three-way call	7
Table 17. Speaker volume	7
Table 18. Music play	8
Table 19. Music pause	8
Table 20. Music next	9
Table 21. Music previous	9
Table 22. Music previous	9
Table 23. Music previous	9
Table 24. Wake up voice assistant	10
Table 25. Enter MCSync share	10
Table 26. Exit MCSync share	10
Table 27. Connection event	12
Table 28. Battery event	12
Table 29. Time out event	12
Table 30. Key mapping table	13
 Figure 1. Software architecture	 1
Figure 2. EVK components	2

1. Introduction

The man-machine interface (MMI) layer is intended to offer a well-organized interface that makes control profile services such as HFP, A2DP, and AVRCP more intuitive. The MMI layer also provides a robust system environment which protects users from a negative experience (e.g., crash situation).

This guide is written to help users easily and completely understand MMI layer functionality.

1.1. Platform architecture

Figure 1 shows that the software architecture is made up of several components which are divided into three different groups: Airoha Defined Interface component; Bluetooth Defined Component; and Customer Defined Component. MMI is the only component in the Customer Defined component. It is also the topmost layer and is completely controlled by the user. Moreover, MMI coordinates the interface and allows all profiles to operate together.




Figure 1. Software architecture

1.2. EVK components

When the user starts making use of the AB158x MMI functionality, there are some signals to which they can refer so that they can verify whether the corresponding function is operating correctly. The user must also use some of the EVK components to make use of the MMI functions. This section introduces the components that are used to trigger MMI or show MMI functionality.

There are three different colors to indicate the different EVK component groups, as shown in Figure 2.

- 1) The components shown in green indicate the buttons on the EVK. From bottom to top, these buttons are EINT_KEY0, EINT_KEY1, EINT_KEY2, and EINT_KEY3. The power key and reset key are above the EINT_KEYS.
- 2) The EVK components shown in yellow indicate the LEDs. The LEDs (shown from bottom to top) are LED0 and LED1. These LEDs have different colors.
- 3) The EVK component shown in orange is the earphone jack. The earphone jack is used for listening to the voice prompts that are related to a specific MMI function.




Figure 2. EVK components

2. MMI Functionality

This section shows the MMI layer functionality. Generally speaking, MMI functions can be partitioned into five main fields: system; connection; calling; volume; and music. A more in-depth description of each function field is given in the function field sections.

Furthermore, the actions for the buttons must be defined in advance. The tap action is defined as a press of the button of no more than 500 milliseconds. Pressing the button for more than 500 milliseconds is defined as a “long press”. You can use Config Tool to make changes to the time settings for a tap or long press.

The beep results must also be well defined. The length of the beeps are described as long, median, and short, and the tonality of the beep refers to either rising or falling sounds. Every beep result includes a number which describes the number of times a beep will play.

In the following sections, the components must be used to trigger the functionality. The results indicate that the function is correctly triggered.

2.1. System

Regarding the system function field, the MMI functions related to the functions of the EVK itself are classified in this field, including how to turn the AB158x product on and off.

2.1.1. Power

The user can turn the AB158x product on and off by pressing the key.

Table 1. Power

Functionality	Actions	Results	Requirements
Power on	Long press power key for 3 seconds.	Device powers on.	Power off state.
Power off	Long press power key for 3 seconds.	Device powers off.	Power on state.

When there is support for a smart charger case, earbuds power on and BT is turned off when they are put into the charger case and the cover is closed.

Table 2. Enable BT

Functionality	Actions	Results	Requirements
BT on	Open the cover of charger case.	Device turns on BT.	The earbuds are in the charger case and cover is closed.
BT off	Close the cover of charger case.	Device turns off BT.	The earbuds are in the charger case and the cover is open.

If there is no support for a smart charger case, when the earbuds are put in charger case, it powers on but turns off BT.

Table 3. Enable BT without smart charger case

Functionality	Actions	Results	Requirements
BT on	Take the device out of the charger case.	Device turns on BT.	The earbuds are in the charger case.
BT off	Put the device into the charger case.	Device turns off BT.	The earbuds are out of the charger case.

2.2. Connection

This section describes the MMI functionality related to being discoverable by other devices and connecting to other devices.

2.2.1. Entering pairing mode

This functionality is used to make the AB158x product discoverable by other devices. If the AB158x product is not connected to other devices and Partner is attached to Agent, the Agent device automatically enters pairing mode. If Partner is not attached to Agent, the user can press a key to enter pairing mode. Only Agent can enter pairing mode, so if the key is pressed on Partner, Partner resets its role to Agent and then goes into pairing mode.

Table 4. Enter pairing mode

Functionality	Actions	Results	Requirements
Enter pairing mode	Press the button on the charger case.	LED0 and LED1 on the earbuds are on.	The earbuds are in the charger case and there is only support for smart charger case.
Enter pairing mode	Double-click the power key on right earbud.	LED0 and LED1 on the earbuds are on; a voice prompt says "Enter pairing mode" on Agent side.	The earbuds do not connect to a smart phone if AIR_MULTI_POINT_ENABLE is set to "n".

2.2.2. Connected

This connecting function occurs when first pairing a device or when automatically reconnecting to a paired device.

Table 5. Connected

Functionality	Actions	Results	Requirements
Connected	Smart phone or other devices connect to the earbuds.	LED0 and LED1 are off. And a voice prompt says "Connected".	NA

2.2.3. Reconnecting automatically

When an AB158x product powers on or is disconnected, it tries to reconnect to the previously connected device

Table 6. Reconnect actively

Functionality	Actions	Results	Requirements
Reconnect actively	Automatically reconnect.	NA	Already connected before



Note: The voice prompt immediately says “Connected” when an AB158x product successfully connects to the other device.

2.2.4. Air pairing

When an AB158x product is not connected to a smart phone, press key to trigger air pairing. The air pairing process times out is 30 seconds.

Table 7. Air pairing

Functionality	Actions	Results	Requirements
Start air pairing	Triple-click the power key.	LED0 and LED1 double blink every 0.5 seconds; a voice prompt says “Enter pairing mode”.	The device is not connected to smart phone.
Air pairing is successful	Both of the earbuds are in air pairing status; they scan each other to do air pairing.	LED1 double blinks every 0.5 seconds; a beep plays when the process is successful.	Earbuds are in air pairing status.
Air pairing fails	The earbuds cannot scan for other earbuds before timeout.	LED0 and LED1 are off for three seconds.	Earbuds are in air pairing status.

2.3. Calling

This section shows the MMI functionality related to calling. These functions include how to accept/end/reject/hold a call, cancel an outgoing call, redial the most recently dialed phone number, transfer the sound to a connected device or to the AB158x product, and manage a three-way call.

2.3.1. Incoming call

The identity of an incoming call.

Table 8. Incoming call

Functionality	Actions	Results	Requirements
Incoming call	There is an incoming call from the smart phone.	LED0 blinks.	Connected.

2.3.2. Accepting a call

The user can accept an incoming call.

Table 9. Accept call

Functionality	Actions	Results	Requirements
Accept call	Press the power key on right earbud.	NA	An incoming call is active.



Note: When the call is successfully accepted, LED0 is ON.

2.3.3. Ending a call

The user can end an active call.

Table 10. End call

Functionality	Actions	Results	Requirements
End call	Press the power key on right earbud.	The active call ends.	A call is active.

2.3.4. Rejecting a call

The user can reject an incoming call.

Table 11. Reject call

Functionality	Actions	Results	Requirements
Reject call	Double-click the power key on right earbud.	A voice prompt says "Call rejected".	A call is incoming.

2.3.5. Holding a call

The user can hold an active call.

Table 12. Hold call

Functionality	Actions	Results	Requirements
Hold call	Double-click the power key on right earbud.	NA	A call is active.

2.3.6. Three-way calling

This section shows the functions available to the user when two calls are active at the same time.



Note: The calls here are held, incoming, or active.

2.3.6.1. Holding and rejecting

The user can keep the current call and reject a held or incoming call.

Table 13. Hold and reject

Functionality	Actions	Results	Requirements
Hold and reject	Double-click the power key on right earbud.	A voice prompt says "Call rejected".	There is an incoming at the same time as an active call.

2.3.6.2. Holding and accepting

The user can hold the current calling and accept an incoming call.

Table 14. Hold and accept

Functionality	Actions	Results	Requirements
Hold and accept	Press the power key on right earbud.	N/A	There is an incoming at the same time as an active call.

2.3.6.3. Ending an active call and recovering a held call

The user can end the currently active call and recover the held call.

Table 15. End active call and recover held

Functionality	Actions	Results	Requirements
End and recover	Press the power key on right earbud.	N/A	There is an active call and another held call.

2.3.6.4. Ending a three-way call

The user can end the three-way call.

Table 16. Ending a three-way call

Functionality	Actions	Results	Requirements
End three-way call	Press the power key on right earbud.	N/A	There is an active three-way active call.

2.4. Volume

This section shows the MMI functions related increasing or decreasing the volume of the speaker and microphone, and how to mute or unmute the microphone.

2.4.1. Changing the volume

The user can adjust the sound level of the speaker.

Table 17. Speaker volume

Functionality	Actions	Results	Requirements
Volume up	Press EINT_KEY_0.	One short beep	In connected, incoming/outgoing, call active states or playing music.
Volume down	Press EINT_KEY_1.	One short beep	In connected, incoming/outgoing, call active states or playing music.



Note: The speaker here is applicable to HFP and A2DP, depending on the scenario.



Note: When the volume reaches the maximum level, the user hears two short beeps and the voice prompt says “Volume maximum” through the earphone.

2.5. Music

This section shows the MMI functionality for controlling music, including the method for playing music, pausing music, and setting music forward or backward.



Note: The music referred to here is for A2DP.



Note: A2DP music cannot exist at the same time of HFP calling.

2.5.1. Playing music

The user can play music.

Table 18. Music play

Functionality	Actions	Results	Requirements
Music play	Press the power key.	NA	In a connected state.



Note: The user can immediately hear the song through the earphones when the music successfully plays.

2.5.2. Pausing music

The user can pause the currently playing music.

Table 19. Music pause

Functionality	Actions	Results	Requirements
Music pause	Press the power key.	NA	In playing music state.



Note: The user immediately hears the music pause when the music successfully pauses.

2.5.3. Skipping forward

This functionality provides the ability to play the next audio file.

Table 20. Music next

Functionality	Actions	Results	Requirements
Music forward	Double-click the power key on right earbud.	One short beep.	In playing music state.

2.5.4. Skipping back

The user can play the audio file that is stored before the currently playing audio file.

Table 21. Music previous

Functionality	Actions	Results	Requirements
Music back	Triple-click the power key.	One short beep.	In playing music state.

2.5.5. Fast forward and fast rewind

This functionality provides the ability to fast forward and fast rewind.

Table 22. Music previous

Functionality	Actions	Results	Requirements
Music fast forward	Long press EINT_KEY_0 for 1 second to start fast forward and release the key to stop fast forward.	N/A	In playing music state.
Music fast rewind	Long press EINT_KEY_1 for 1 second to start fast rewind and release the key to stop fast rewind.	N/A	In playing music state.

2.6. ANC and pass through

The user can press a key to switch ANC and pass through.

Table 23. Music previous

Functionality	Actions	Results	Requirements
Switch ANC and pass through	Double click power key on left earbud, switch ANC and pass through. When current state is OFF, next state is pass through. When current state is pass through, next	A short beep	BT on and AWS connected. If AWS is not connected, the beep is fail sound.

Functionality	Actions	Results	Requirements
	state is ANC. When current state is ANC, next state is OFF.		

2.7. Voice assistant

The user can press a key to wake up the voice assistant.

2.7.1. Waking up voice assistant

Table 24. Wake up voice assistant

Functionality	Actions	Results	Requirements
Wake up voice assistant	Long press the power key for 1 second and release the key before 3 seconds.	One short beep.	Connected to smart phone.

2.8. MCSync share

This section shows how users can enter or exit MCSync share.

2.8.1. Enter MCSync share

Table 25. Enter MCSync share

Functionality	Actions	Results	Requirements
Enter MCSync share (Share side)	Double click EINT_KEY_0.	One short beep.	Connected to smart phone and AWS connected. In playing music state or idle state.
Enter MCSync share (Follower side)	Double click EINT_KEY_1.	One short beep.	AWS connected. In playing music state or idle state.

2.8.2. Exit MCSync share

Table 26. Exit MCSync share

Functionality	Actions	Results	Requirements
Exit MCSync share (Share side)	Double click EINT_KEY_0.	One short beep.	The earbuds already in MCSync share.
Exit MCSync share (Follower side)	Double click EINT_KEY_1.	One short beep.	The earbuds already in MCSync share.

2.9. Multipoint

This section shows how users can make multilink at the same time.

2.9.1. Connection

When the device is connected with one smartphone, users can enter pairing mode again by double-clicking the power key on the right earbud. At this time, the second smartphone can find this device and connect.

When the earbuds connect to the second smartphone, a voice prompt says “Connected” on both sides.

3. MMI Event

This section shows the events that are not triggered by pressing the button but are instead triggered by other devices or the AB158x product itself. These events are divided into three types: connection; battery; and time out.

3.1. Connection

This section shows all events related to connections, such as successfully pairing, being connectable, and being connected.

Table 27. Connection event

Event	Results
Connectable	LED0 and LED1 is on.
Connected	LED0 and LED1 is off.



Note: If the AB158x product is connectable, it can only be connected to but it is not discovered.



Note: The connected event here is for situations in which it is both fully connected and not connected.

3.2. Battery

This section shows the battery events including low battery, charging, and charging full.

Table 28. Battery event

Event	Results
Low battery	LED1 flashes every 0.6 seconds.
Charging	LED1 flashes every 4 seconds.
Charging full	LED1 is always on in 5 seconds.

3.3. Time out

There is a time out mechanism for the AB158x product: pairing mode time out. This section shows the time out mechanism.

Table 29. Time out event

Event	Results
Pairing mode time out	The timeout of the pairing mode is infinite.
Power off	The AB158x product powers off if it waits 5 minutes and no other devices are connected.

4. Key Mapping Table

This section shows a mapping table of the keys, actions, LEDs, voice prompts, ring tones and any related comments for a specific function. For example, for the ‘Power on’ function, search for ‘Power on’ in the ‘Functionality’ column in Table 30. Key mapping table. The Key, Action, LED, Voice prompt, Ring tone, and comments that are associated with the ‘Power on’ function (i.e. Press for three seconds; LED0 rapidly flashes three seconds; Say “Power-On”; and ‘In the power off state’) are shown in the adjacent cells on the same row.

Table 30. Key mapping table

Key	Functionality	Action	LED	Voice prompt	Comment
Power Key	Accept call	Press	LED0 is ON	NA	An incoming call is active.
	End call	Press	NA	“Call ended”	A call is active.
	Reject	Double-click	NA	“Call Rejected”	An incoming call is active.
	Hold	Double-click	LED0 blinks slowly	NA	During an active call.
	Hold and reject	Double-click	NA	“Call Rejected”	There is incoming call during an active call.
	Hold and accept	Press	NA	NA	There is another incoming when there is an active call, or there is an active call and another held call.
	End active and recover held	Press	NA	NA	An activity call and another hold call.
	End three-way call	Press	NA	NA	Three-way call is active.
	Music play	Press	NA	NA	In the connected state.
	Music pause	Press	NA	NA	In playing music state.
	Music forward	Double-click	NA	NA	In playing music state. Only right earbud.
	Music backward	Triple-click	NA	NA	In playing music state.
	Power on	Long press for 3 seconds.	LED0 blink quickly; LED1 is OFF	“Power on”	When device is power off.

Key	Functionality	Action	LED	Voice prompt	Comment
	Power off	Long press for 3 seconds.	LED0 blinks quickly; LED1 is OFF	“Power off”	When device is power on. Power off event will not sync to another earbud.
	Wake up voice assistant	Long press for 1 second and release before 3 seconds	NA	A short beep	When the device is connected to a smart phone.
	Enter pairing mode	Double-click	LED0 and LED1 is on	“Enter pairing mode”	When the device is not connected to a smart phone if AIR_MULTI_POINT_ENABLE is set to “n”.
	Start air pairing	Triple-click	LED0 and LED1 double-blink	“Enter pairing mode”	When the device is not connected to a smart phone.
	Switch ANC and pass through	Double-click	NA	A short beep	When the device is connected to another side
EINT_KEY_0	Volume up	Press	NA	NA	In the connected, incoming/outgoing call, call active or playing music states.
EINT_KEY_1	Volume down	Press	NA	NA	In the connected, incoming/outgoing call, call active, or playing music states.
Key on charger case	Enter pairing mode	Press the button on the charger case	LED0 and LED1 is on	“Enter pairing mode”	Both earbuds are in the charger case.