

CONEX-PP

Single-Axis Intelligent Stepper Motor Controller/Driver



Newport®
Experience | Solutions

Command Interface Manual

V1.0.x

Precision Motion – **Guaranteed™**

Table of Contents

1.0	Introduction	1
1.1	Purpose	1
1.2	Overview	1
2.0	Programming	2
2.1	State Diagram	2
2.2	Command Syntax.....	3
2.3	Command Execution Time	3
2.4	Command Set	4
	AC — Set/Get acceleration	6
	BA — Set/Get backlash compensation	7
	BH — Set/Get hysteresis compensation.....	8
	FR — Set/Get stepper motor configuration.....	9
	HT — Set/Get HOME search type.....	10
	ID — Set/Get stage identifier	11
	JR — Set/Get jerk time	12
	MM — Enter/Leave DISABLE state	13
	OH — Set/Get HOME search velocity	14
	OR — Execute HOME search.....	15
	OT — Set/Get HOME search time-out	16
	PA — Move absolute	17
	PR — Move relative.....	18
	PT — Get motion time for a relative move	19
	PW — Enter/Leave CONFIGURATION state	20
	RS — Reset controller.....	21
	RS## — Reset controller's address.....	22
	SA — Set/Get controller's RS422 address.....	23
	SE — Configure/Execute simultaneous started move.....	24
	SL — Set/Get negative software limit.....	26
	SR — Set/Get positive software limit	27
	ST — Stop motion	28
	TB — Get command error string	29
	TE — Get last command error	30
	TH — Get set-point position.....	31
	TP — Get current position	32
	TS — Get positioner error and controller state	33

VA — Set/Get velocity	35
VE — Get controller revision information.....	36
ZT — Get all configuration parameters	37
<hr/>	
Service Form	39

CONEX-PP

Single-Axis Intelligent Stepper Motor Controller/Driver

1.0 Introduction

1.1 Purpose

The purpose of this document is to provide the method syntax of each command to communicate with the CONEX-PP device.

1.2 Overview

The Command Interface is the wrapper class that maintains a list of CONEX-PP instruments. It exposes methods to communicate with any CONEX-PP device.

NOTE


Each function name is defined with the command code “AA”.

For each command function, refer to the CONEX-PP programmer’s manual.

2.0 Programming

2.1 State Diagram

For a safe and consistent operation, the CONEX-PP uses 6 different operational states: Not referenced, Configuration, Homing, Ready, Disable and Moving. In each state, only specific commands are accepted by the CONEX-PP. Therefore, it is important to understand the state diagram below and to know which commands and actions cause transitions between the different states. Also see section 2.4 for command/state information:



Actions in each state when End of Runs is encountered

NOT REFERENCED: No action.

CONFIGURATION: No action.

HOMING: Only check at end of HOMING and then change to NOT REFERENCED state.

MOVING: Abort motion and then changes to NOT REFERENCED state.

READY: Changes to NOT REFERENCED state.

DISABLE: Changes to NOT REFERENCED state.

2.2 Command Syntax

The CONEX-PP is a command-driven controller. The general format of a command is a two-letter ASCII word preceded and followed by parameters specific to the command:

Command format

nn	AA	xx
-----------	-----------	-----------

nn — Controller address, or
nothing if the issued command addresses all controllers.

AA — Command name.

xx — Parameter value, or
“?” to query the current value, or
nothing if the command takes no parameter.

Both upper and lower case characters are accepted. Depending on the command, it can have an optional or required prefix (**nn**) for the controller address and/or a suffix (**xx**) value, a “?” or no suffix at all.

Blank spaces

Blanks are allowed and ignored in any position, including inside a numerical value, unless enclosed within quotes. The following two commands are equivalent, but the first example might be confusing:

2P A1.43 6

2PA1.436

Decimal separator

A dot (“.”) must be used as decimal separator for all numerical values.

Command terminator

Commands are executed as either of the command terminator C_R or L_F (carriage-return, ASCII 13 or line-feed, ASCII 10) is received. The controller will analyze the received string. If the command is valid and its parameters are in the specified range, it will be executed. Otherwise it will memorize an error.

After the command parameters are identified, all remaining characters in the input string until the first command terminator, if any, will be ignored. Commands from the PC to the CONEX-PP may still be concatenated in a single string, but each command must be separated from the next one by a carriage-return or a line-feed.

In case any error occurs, the reported error will be recorded and can be checked using the TE command. Please refer to the command set in section 2.4 for details.

2.3 Command Execution Time

The CONEX-PP controller interprets commands continuously as they are received. The typical execution time for a "tell position command" (nTP?) is about 10 ms. Here, command execution time means the between sending a command and receiving an answer.

It is important to note that a move command, that may lasts for several seconds, will not suspend the controller from further command execution. So for an efficient process flow with many move commands it is recommended to use the PT command (get time for a relative move), and to query the controller status (TS command) or the current position (TP command) before any further motion command is sent.

2.4 Command Set

This section describes the supported two-letter ASCII commands used to configure and operate the CONEX-PP. The general command format is:

Command format

nn	AA	xx
-----------	-----------	-----------

nn — Optional or required controller address.

AA — Command name.

xx — Optional or required value or “?” to query current value.

Most commands can be used to set a value (in that case the command name is followed by the value, represented here as “**xx**”) or to query the current value (in that case the command name is followed by a “?”). When querying a value, the controller responds with the command it received followed by the queried value.

Examples:

1VA10 sets the velocity of the controller #1 to 10 units/second (and sends nothing back).

1VA? sends back the reply "1VA10", which means: "controller #1's velocity is 10 units/second".

Not every command can be executed in all states of the CONEX-PP and some commands have different meaning in different states. It is therefore important to understand the state diagram of the controller, see section 2.1.

	Not Ref.	Config.	Disable	Ready	Motion	Description
AC	–	○	□	□	–	Set/Get acceleration
BA	–	○	–	–	–	Set/Get backlash compensation
BH	–	○	–	–	–	Set/Get hysteresis compensation
FR	–	○	–	–	–	Set/Get stepper motor configuration
HT	–	○	–	–	–	Set/Get HOME search type
ID	–	○	□	□	–	Set/Get stage identifier
JR	–	○	□	□	–	Set/Get jerk time
MM	–	–	●	●	–	Enter/Leave DISABLE state
OH	–	○	–	–	–	Set/Get HOME search velocity
OR	●	–	–	–	–	Execute HOME search
OT	–	○	–	–	–	Set/Get HOME search time-out
PA	–	–	–	●	–	Move absolute
PR	–	–	–	●	–	Move relative
PT	–	–	●	●	●	Get estimated duration of a relative move
PW	●	●	–	–	–	Enter/Leave CONFIGURATION state
QC	–	□	–	–	–	Set/Get idle current coefficient
QD	–	□	–	–	–	Set/Get idle current delay
QI	–	○	–	–	–	Set/Get motor's current limits
RS	●	●	●	●	●	Reset controller
RS##	●	●	●	●	●	Reset controller's address to 1
SA	–	○	–	–	–	Set/Get controller's RS-485 address
SE	–	–	–	●	–	Configure/Execute simultaneous started move
SL	–	○	□	□	–	Set/Get negative software limit
SR	–	○	□	□	–	Set/Get positive software limit
ST	–	–	–	–	●	Stop motion
TB	●	●	●	●	●	Get command error string
TE	●	●	●	●	●	Get last command error
TH	●	●	●	●	●	Get set-point position
TP	●	●	●	●	●	Get current position
TS	●	●	●	●	●	Get positioner error and controller state
VA	–	○	□	□	–	Set/Get velocity
VE	●	●	●	●	●	Get controller revision information
ZT	●	●	●	●	●	Get all axis parameters

Not Ref. Corresponds to the NOT REFERENCED state (for details see state diagram, section 2.1).

Config. Corresponds to the CONFIGURATION state.

Disable Corresponds to the DISABLE state.

Ready Corresponds to the READY state.

Motion Corresponds to the HOMING and MOVING states.

○ Changes configuration parameters. Those changes will be stored in the controller's memory with the PW1 command and remain available after switching off the controller.

□ Changes working parameters only. Those changes will get lost when switching off the controller.

● Accepted command.

– Command is forbidden in this state (will memorize an error).

Grey line Command passed without preceding controller number applies to all controllers (e.g. MM0 disables all controllers).

AC — Set/Get acceleration

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	□	□	—
Syntax	xxACnn or xxAC?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Acceleration value.			
Range	xx	—	1 to 31			
	nn	—	> 10 ⁻⁶ and < 10 ¹²			
Units	xx	—	None			
	nn	—	Preset units/s ²			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	In CONFIGURATION state, this command sets the maximum acceleration value which can then be saved in the controller's non-volatile memory using the PW command. This is the maximum acceleration that can be applied to the mechanical system. It is also the default acceleration that will be used for all moves unless a lower value is set in DISABLE or READY state.					
	In DISABLE or READY state, this command sets the acceleration used for all subsequent moves. Its value can be up to the programmed value in CONFIGURATION state. This value is not saved in the controller's memory and will be lost after reboot.					
Returns	If the sign “?” is used instead of nn, this command returns the current value for the state in which the controller is (either CONFIGURATION or DISABLE/READY).					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	JR	—	Set/Get jerk time.			
	VA	—	Set/Get velocity.			
Example	1AC500		Set controller #1 acceleration to 500 units/s ² .			
	1AC?		Controller returns 1AC500.			

BA — Set/Get backlash compensation

Usage	Not Ref.	Config.	Disable	Ready	Motion
	—	○	—	—	—
Syntax	xxBAnn or xxBA?				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [float]	—	Backlash value.		
Range	xx	—	1 to 31		
	nn	—	≥ 0 and < 10 ¹²		
Units	xx	—	None		
	nn	—	Preset units		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	The BA command sets the backlash compensation value. This is the value that the controller moves the motor in addition to the commanded distance with any move that reverses the direction of motion without changing the current position value (TP command).				
	The BA command helps compensating for repeatable mechanical defects that appear when reversing the direction of motion, for instance mechanical wear. The value 0 disables this function. This feature can be only used when the hysteresis compensation (BH) is disabled.				
	When a value different from 0 is set, the travel range of the stage is decreased by the same amount.				
Returns	If the sign “?” is used instead of nn, this command returns the current programmed value.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	C	—	Parameter missing or out of range.		
	D	—	Execution not allowed.		
	H	—	Execution not allowed in NOT REFERENCED state.		
	J	—	Execution not allowed in DISABLE state.		
	K	—	Execution not allowed in READY state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Rel. Commands	BH	—	Set hysteresis compensation.		
Example	1BA0.005		Set controller #1 backlash compensation to 0.005 units.		

BH — Set/Get hysteresis compensation

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	—	—	—
Syntax	xxBHnn or xxBH?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Hysteresis value.			
Range	xx	—	1 to 31			
	nn	—	≥ 0 and < 10 ¹²			
Units	xx	—	None			
	nn	—	Preset units			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
		Floating point:	Error A.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	The BH command sets the hysteresis compensation value. When set to a value different than zero, the controller will issue for each move in the positive direction a move of the commanded distance plus the hysteresis compensation value, and then a second move of the hysteresis compensation value in the negative direction. This motion ensures that a final position gets always approached from the same direction and distance and helps compensating for non-repeatable mechanical defects like hysteresis or mechanical stiffness variations.					
	The value 0 disables this function. The BH command can not be used when the backlash compensation is enabled (BA command).					
	When a value different from 0 is set, the travel range of the stage is decreased by the same amount in the positive direction.					
NOTE						
The homing set on the positive end of run and hysteresis compensation are not compatible. Any attempt to use both features together will make the stage fail.						
Returns	If the sign “?” is used instead of nn, this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	J	—	Execution not allowed in DISABLE state.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	BA	—	Set backlash compensation.			
Example	1BH0.015		Set controller #1 backlash compensation to 0.015 units.			

FR — Set/Get stepper motor configuration

Usage	Not Ref.	Config.	Disable	Ready	Motion
	—	○	—	—	—
Syntax	xxFRSnn, xxFRM? or xxFRS?				
Parameters					
Description	xx [int]	—	Controller address.		
	Mmm [int]	—	Amount of micro-steps per full step.		
	Snn [float]	—	Full step displacement length in 1/1000 of unit.		
Range	xx	—	1 to 31		
	mm	—	> 0 and ≤ 2000		
	nn	—	> 10 ⁻⁶ and < 10 ¹²		
Units	xx	—	None.		
	Mmm	—	None.		
	Snn	—	1/1000 of unit.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
	mm	Missing:	Error C.		
		Out of range:	Error C.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	FRM: For compatibility. No effect. Always 128 μsteps.				
	FRS: This command sets the displacement length per full step in 1/1000 of unit.				
Returns	If the sign “?” is used instead of mm or nn, this command returns the current programmed value.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	C	—	Parameter missing or out of range.		
	D	—	Execution not allowed.		
	H	—	Execution not allowed in NOT REFERENCED state.		
	J	—	Execution not allowed in DISABLE state.		
	K	—	Execution not allowed in READY state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Example	1FRS10		Set controller #1 full step value to 10 milli-units.		

HT — Set/Get HOME search type

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	—	—	—
Syntax	xxHTnn or xxHT?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [int]	—	Home search type identifier.			
Range	xx	—	1 to 31			
	nn	—	1 use current position as HOME.			
			2 use MZ switch (mechanical zero) to detect HOME position.			
			4 use EoR- switch (negative end of range) to detect HOME position.			
Units	xx	—	None.			
	nn	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	This command sets the type of HOME search used with the OR command.					
<hr/>						
NOTE						
The homing set on the positive end of run and hysteresis compensation are not compatible. Any attempt to use both features together will make the stage fail.						
<hr/>						
Returns	If the sign “?” is used instead of nn, this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	J	—	Execution not allowed in DISABLE state.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	OH	—	Set/Get HOME search velocity.			
	OR	—	Execute HOME search.			
	OT	—	Set HOME search time-out.			
Example	1HT1		Set controller #1 HOME sequence to use current position.			

ID — Set/Get stage identifier

Usage	Not Ref.	Config.	Disable	Ready	Motion
	—	○	□	□	—
Syntax	xxIDnn or xxID?				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [string]	—	Stage identifier string.		
Range	xx	—	1 to 31		
	nn	—	1 to 31 ASCII characters.		
Units	xx	—	None		
	nn	—	None		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	The ID command sets the stage identifier in the form of a character string. Any printable character can be used ; spaces are admissible only if the string is enclosed in quotes, "like this". If not, spaces and tabs are ignored.				
	In CONFIGURATION state, this command sets a new value for the stage identifier which can then be saved in the device's non-volatile memory with the PW command. It is also the default value that will be used unless a different value is set in DISABLE or READY state.				
	In DISABLE or READY state, this command allows setting a new working parameter for the stage identifier. This value is not saved in the controller's memory and will be lost after reboot.				
Returns	If the sign “?” is used instead of nn, this command returns the current identifier string for the state in which the controller is (either CONFIGURATION or DISABLE/READY).				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	C	—	Parameter missing or out of range.		
	D	—	Execution not allowed.		
	H	—	Execution not allowed in NOT REFERENCED state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Example	1ID?		Get stage identifier for controller #1.		
	1ID URS100CC		Set controller #1's stage identifier to: URS100CC.		

JR — Set/Get jerk time

Usage	Not Ref.	Config.	Disable	Ready	Motion
	—	○	□	□	—
Syntax	xxJRnn or xxJR?				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [float]	—	Jerk time value.		
Range	xx	—	1 to 31		
	nn	—	> 0.001 and < 10 ¹²		
Units	xx	—	None.		
	nn	—	Seconds.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	Jerk is the derivative of acceleration. The jerk time defines the time to reach the needed acceleration. A longer jerk time reduces stress to the mechanics and smoothes motion.				
	In CONFIGURATION state, this command sets the value for the maximum jerk time which can then be saved in the controller’s non-volatile memory using the PW command. It is also the default value that will be used unless a different value is set in DISABLE or READY state.				
	In DISABLE or READY state, this command allows setting a new working parameter for the maximum jerk time. This value is not saved in the controller’s memory and will be lost after reboot.				
Returns	If the sign “?” is used instead of nn, this command returns the current programmed value for the state in which the controller is (either CONFIGURATION or DISABLE/READY).				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	C	—	Parameter missing or out of range.		
	D	—	Execution impossible (axis in movement).		
	H	—	Execution not allowed in NOT REFERENCED state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Rel. Commands	AC	—	Set/Get acceleration.		
	VA	—	Set/Get velocity.		
Example	1JR0.05		Set controller #1 jerk time to 0.05 seconds.		

MM — Enter/Leave DISABLE state

Usage	Not Ref.	Config.	Disable	Ready	Motion
	—	—	●	●	—
Syntax	xxMMnn or xxMM?				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [int]	—	Whether to enter (1) or leave (0) the DISABLE state.		
Range	xx	—	0 to 31		
	nn	—	0 changes state from READY to DISABLE. 1 changes state from DISABLE to READY.		
Units	xx	—	None.		
	nn	—	None.		
Defaults	xx	Missing:	Change to 0 (will forward this command to all controllers).		
		Out of range:	Error B.		
	nn	Missing:	Error C.		
		Out of range:	Error C.		
Description	When the MM command is sent without preceding controller number or the controller number is 0, the MM command is executed on all controllers.				
	MM0 changes the controller's state from READY to DISABLE. In DISABLE state the control loop is open and the motor is not powered.				
	MM1 changes the controller's state from DISABLE to READY. The controller's set point position is set equal to its current position and the control loop gets closed (depending on the closed-loop state). Any residual error is cleared and the motor is powered.				
Returns	If the sign “?” is used instead of nn, this command returns the current state. Refer to the TS command section for the list of controller states.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	C	—	Parameter missing or out of range.		
	D	—	Execution not allowed.		
	H	—	Execution not allowed in NOT REFERENCED state.		
	I	—	Execution not allowed in CONFIGURATION state.		
	L	—	Execution not allowed in HOMING state.		
	M	—	Execution not allowed in MOVING state.		
Rel. Commands	PW	—	Enter/leave CONFIGURATION state.		
Example	MM0		All controllers go to DISABLE state.		

OH — Set/Get HOME search velocity

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	—	—	—
	Syntax	xxOHnn or xxOH?				
	Parameters					
Description	xx [int]	—	Controller address.			
	nn [float]	—	HOME search velocity.			
Range	xx	—	1 to 31			
	nn	—	> 10⁻⁶ and < 10¹²			
Units	xx	—	None.			
	nn	—	Preset units/s.			
Defaults	xx Missing:	Error B.				
	Out of range:	Error B.				
	nn Missing:	Error C.				
	Out of range:	Error C.				
Description	This command sets the maximum velocity used by the controller for the HOME search.					
Returns	If the sign “?” is used instead of nn , this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	J	—	Execution not allowed in DISABLE state.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
	Rel. Commands	HT	—	Set/Get HOME search type.		
OR		—	Execute HOME search.			
OT		—	Set HOME search time-out.			
Example	1OH50		Set controller #1 HOME search velocity to 50 units/s.			

OR — Execute HOME search

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	—	—	—	—
	Syntax	xxOR				
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	1 to 31			
Units	xx	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	This command starts the execution of the HOME search according to the algorithm defined by the HT command.					
	When in NOT REFERENCED state, for instance after system start, any positioner must first be homed with the OR command before further motion commands can be executed.					
	The OR command is accepted only in NOT REFERENCED state and only when no hardware error is present (except end-of-runs). Refer to the TS command to get more information on the possible hardware errors.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	E	—	home sequence already started.			
	I	—	Execution not allowed in CONFIGURATION state.			
	J	—	Execution not allowed in DISABLE state.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	HT	—	Set HOME search type.			
	OH	—	Set HOME search velocity.			
	OT	—	Set HOME search time-out.			
Example	1OR		Execute HOME search with controller #1.			

OT — Set/Get HOME search time-out

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	—	—	—
Syntax	xxOTnn or xxOT?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	HOME time-out.			
Range	xx	—	1 to 31			
	nn	—	> 1 and < 1000			
Units	xx	—	None.			
	nn	—	Seconds			
Defaults	xx Missing:	Error B.				
	Out of range:	Error B.				
	nn Missing:	Error C.				
	Out of range:	Error C.				
Description	This command sets the time-out value for the HOME search. When the HOME search does not finish successfully before this delay elapses, the HOME search is aborted and an error is recorded.					
Returns	If the sign “?” is used instead of nn , this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	J	—	Execution not allowed in DISABLE state.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
	Rel. Commands	HT	—	Set HOME search type.		
OH		—	Set HOME search velocity.			
OR		—	Execute HOME search.			
Example	1OT2.2		Set controller #1 HOME time-out to 2.2 seconds.			

PA — Move absolute

	Usage	Not Ref.	Config.	Disable	Ready	Motion	
		—	—	—	●	—	
Syntax	xxPAnn or xxPA?						
Parameters							
Description	xx [int]	—	Controller address.				
	nn [float]	—	New absolute position.				
Range	xx	—	1 to 31				
	nn	—	≥ SL and ≤ SR				
Units	xx	—	None.				
	nn	—	Preset units.				
Defaults	xx Missing:	Error B.					
	Out of range:	Error B.					
	nn Missing:	Error C.					
	Out of range:	Error C.					
Description	The PA command initiates an absolute move. When received, the positioner will move, with the predefined acceleration and velocity, to the new absolute position specified by nn .						
	The PA command is only accepted in READY state, AND when the new absolute position is higher or equal to the negative software limit (SL), AND lower or equal to the positive software limit (SR).						
	The controller always rounds the new target position to the closest micro-step position.						
Returns	If the sign “?” is used instead of nn , this command returns the target absolute position value.						
Errors	A	—	Unknown message code or floating point controller address.				
	B	—	Controller address not correct.				
	C	—	Parameter missing or out of range.				
	D	—	Execution not allowed.				
	G	—	Target position out of limits.				
	H	—	Execution not allowed in NOT REFERENCED state.				
	I	—	Execution not allowed in CONFIGURATION state.				
	J	—	Execution not allowed in DISABLE state.				
	L	—	Execution not allowed in HOMING state.				
	M	—	Execution not allowed in MOVING state.				
	Rel. Commands	PR	—	Move relative.			
		PT	—	Get motion time for a relative move.			
TH		—	Get set-point position.				
TP		—	Get current position.				
Example	1PA2.2		Move positioner on controller #1 to absolute position 2.2 units.				

PR — Move relative

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	—	—	●	—
	Syntax	xxPRnn or xxPR?				
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Displacement.			
Range	xx	—	1 to 31			
	nn	—	≥ (SL - TP) and ≤ (SR - TP)			
Units	xx	—	None.			
	nn	—	Preset units.			
Defaults	xx Missing:	Error B.				
	Out of range:	Error B.				
	nn Missing:	Error C.				
	Out of range:	Error C.				
Description	The PR command initiates a relative move. When received, the positioner will move, with the predefined acceleration and velocity, to a new absolute position nn units away from the current absolute position.					
	The PR command gets only accepted in READY state, AND when the distance of the positioner to the software limit in the same direction is longer than the commanded displacement.					
	The controller always rounds the new target position to the closest micro-step position.					
Returns	If the sign “?” is used instead of nn , this command returns the target absolute position value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	G	—	Displacement out of limits.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	I	—	Execution not allowed in CONFIGURATION state.			
	J	—	Execution not allowed in DISABLE state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
	Rel. Commands	PA	—	Move absolute.		
PT		—	Get motion time for a relative move.			
TH		—	Get set-point position.			
TP		—	Get current position.			
Example	1PR2.2		Move positioner on controller #1 to a new position 2.2 units away from the current position.			

PT — Get motion time for a relative move

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	—	●	●	●
	Syntax	xxPTnn				
	Parameters					
	Description	xx [int]	—	Controller address.		
		nn [float]	—	Displacement.		
	Range	xx	—	1 to 31		
		nn	—	> 10 ⁻⁶ and < 10 ¹²		
	Units	xx	—	None.		
		nn	—	Preset units.		
	Defaults	xx	Missing:	Error B.		
			Out of range:	Error B.		
		nn	Missing:	Error C.		
			Out of range:	Error C.		
	Description	The PT commands helps evaluating move times for an efficient program flow.				
		When receiving the PT command, the controller computes and returns the time, in seconds, necessary to execute a relative move of displacement nn with the current working parameters (velocity, acceleration, etc.). The controller does not execute any displacement.				
	Errors	A	—	Unknown message code or floating point controller address.		
		B	—	Controller address not correct.		
		C	—	Parameter missing or out of range.		
		D	—	Execution not allowed.		
		H	—	Execution not allowed in NOT REFERENCED state.		
		I	—	Execution not allowed in CONFIGURATION state.		
Rel. Commands	PA	—	Move absolute.			
	PR	—	Move relative.			
	TH	—	Get set-point position.			
	TP	—	Get current position.			
Example	1PT2.2		Get time to move positioner on controller #1 by 2.2 units.			
	1PT0.25		Controller returns: 0.25 seconds.			

PW — Enter/Leave CONFIGURATION state

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	●	—	—	—
	Syntax	xxPWnn or xxPW?				
Parameters						
Description	xx [int]	—	Controller address.			
	nn [int]	—	Whether to enter (1) or leave (0) the CONFIGURATION state.			
Range	xx	—	1 to 31			
	nn	—	1: Go from NOT REFERENCED state to CONFIGURATION state. 0: Go from CONFIGURATION state to NOT REFERENCED state.			
Units	xx	—	None.			
	nn	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	PW1 changes the controller's state from NOT REFERENCED to CONFIGURATION. In CONFIGURATION state, all parameter settings are saved in the controller's memory upon exiting this state and remain available after switching off the controller. In addition, some settings are only possible in CONFIGURATION state (e.g. set drive voltage, set Backlash compensation, etc.).					
	PW0 checks all stage parameters, and if they are acceptable, saves them in the flash memory of the controller. After that, it changes the controller's state from CONFIGURATION to NOT REFERENCED.					
	The execution of a PW0 command may take up to 5 seconds. During that time the controller will not respond to any other command.					
Returns	If the sign “?” is used instead of nn, this command returns whether we are or not in the CONFIGURATION state.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	J	—	Execution not allowed in DISABLE state.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	MM	—	Enter/Leave DISABLE state.			
Example						
	1PW1		Changes controller #1 to CONFIGURATION state.			

NOTE

The PW command is limited to 100 writes. Unit failure due to excessive use of the PW command is not covered by the warranty.

The PW command is used to change the default configuration parameters that are stored in memory, and not working parameters that may be changed on the fly.

RS — Reset controller

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	●	●	●	●
	Syntax	xxRS				
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	1 to 31			
Units	xx	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
Description	The RS command issues a hardware reset of the controller, equivalent to a power cycle.					
	To go from DISABLE or READY state to CONFIGURATION state, it is also needed to reset the controller with the RS command, and then to change the controller's state with the PW1 command from NOT REFERENCED to CONFIGURATION.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	D	—	Execution not allowed.			
Example	1RS		Reset controller #1.			

RS## — Reset controller's address

Usage	Not Ref.	Config.	Disable	Ready	Motion
	○	○	○	○	○
Syntax	xxRS## or RS##				
Parameters					
Description	xx [int]	—	Controller address.		
Range	xx	—	0 to 31		
Units	xx	—	None.		
Defaults	xx	Missing:	Change to 0 (will forward this command to all controllers).		
		Out of range:	Error B.		
Description	The RS## command resets the controller's address to 1. This address needs to be different for each CONEX-PP when connected on a RS-485 communication network.				
Returns					
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	D	—	Execution not allowed.		
Rel. Commands	SA	—	Set/Get controller's RS-485 address.		
Example	RS##		Reset all controllers' addresses to 1.		

SA — Set/Get controller's RS422 address

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	—	—	—
Syntax	xxSAnn or xxSA?					
Parameters						
Description	xx [int]	—	Current controller address.			
	nn [int]	—	New controller address (a.k.a. RS422 address).			
Range	xx	—	1			
	nn	—	1 to 31			
Units	xx	—	None.			
	nn	—	None.			
Defaults	xx Missing:	Error B.				
	Out of range:	Error B.				
	nn Missing:	Error C.				
	Out of range:	Error C.				
Description	The SA command sets the controller’s RS422 address, also known as the axis number. This address needs to be different for each CONEX-PP when connected on a RS422 communication network.					
Returns	If the sign “?” is used instead of nn , this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	J	—	Execution not allowed in DISABLE state.			
	K	—	Execution not allowed in READY state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	RS##	—	Reset controller's address.			
Example	1SA3		Set controller’s RS422 address to 3.			

SE — Configure/Execute simultaneous started move

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	—	—	●	—
Syntax	xxSEnn, xxSE? or SE					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	New target position.			
Range	xx	—	0 to 31			
	nn	—	≥ SL and ≤ SR			
Units	xx	—	None.			
	nn	—	Preset units.			
Defaults	xx Missing:	Change to 0 (will forward this command to all controllers).				
	Out of range:	Error B.				
	nn Missing:	Error C.				
	Out of range:	Error C.				
Description	The SE command allows starting a move on different controllers at the same time.					
	The command xxSEnn sets a new target position for the controller nn . But contrarily to the PA/PR commands, the move is not executed immediately, but only after receipt of an SE command without preceding controller number nor position value. When receiving the 2nd SE command, all controllers start moving to their target position.					
	The xxSEnn command is only accepted in READY state, AND when the new target position is higher or equal to the negative software limit (SL), AND lower or equal to the positive software limit (SR). The controller always rounds the new target position to the closest micro-step position.					
	The SE command should not be confused with a synchronized move. With a synchronized move, all positioners start moving simultaneously AND complete their moves at the same time. The SE command starts a move on all controllers at the same time, but each positioner moves with its individually defined velocity and acceleration. Consequently, the different positioners do NOT complete their moves at the same time.					
Returns	If the sign “?” is used instead of nn , this command returns the target position value set by the SE command, which may not be the target position set by the PA/PR commands.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	I	—	Execution not allowed in CONFIGURATION state.			
	J	—	Execution not allowed in DISABLE state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	PA / PR	—	Move absolute / relative.			
	TH	—	Get set-point position.			
	TP	—	Get current position.			
Example	1SE2.2		Prepare controller #1 to move to absolute position 2.2 units.			

- 2SE3.3 | *Prepare controller #2 to move to absolute position 3.3 units.*
- SE | *All controllers start their programmed move, if any.*

SL — Set/Get negative software limit

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	□	□	—
Syntax	xxSLnn or xxSL?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Negative software limit.			
Range	xx	—	1 to 31			
	nn	—	> -10¹² and ≤ 0			
Units	xx	—	None.			
	nn	—	Preset units.			
Defaults	xx Missing:	Error B.				
	Out of range:	Error B.				
	nn Missing:	Error C.				
	Out of range:	Error C.				
Description	In CONFIGURATION state, this command sets the negative software limit which can then be saved in the controller’s non-volatile memory using the PW command. It is also the default value that will be used unless a different value is set in DISABLE or READY state.					
	In DISABLE or READY state, this command allows setting a new working parameter for the negative software limit. It must be lower than or equal to the set-point position. This value is not saved in the controller’s memory and will be lost after reboot.					
	The software limits are useful to limit the travel range of a positioner. There is no possibility to disable software limits. For an almost infinite motion, for instance with a rotative stage, set the lowest possible value, which is -999999930400.					
Returns	If the sign “?” is used instead of nn , this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	SR	—	Set positive software limit.			
Example	1SL-100 Set controller #1 negative software limit to -100 units.					

SR — Set/Get positive software limit

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	□	□	—
Syntax	xxSRnn or xxSR?					
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Positive software limit.			
Range	xx	—	1 to 31			
	nn	—	≥ 0 and < 10¹²			
Units	xx	—	None.			
	nn	—	Preset units.			
Defaults	xx Missing:	Error B.				
	Out of range:	Error B.				
	nn Missing:	Error C.				
	Out of range:	Error C.				
Description	In CONFIGURATION state, this command sets the positive software limit which can than be saved in the controller’s non-volatile memory using the PW command. It is also the default value that will be used unless a different value is set in DISABLE or READY state.					
	In DISABLE or READY state, this command allows setting a new working parameter for the positive software limit. It must be greater or equal to the set-point position. This value is not saved in the controller’s memory and will be lost after reboot.					
	The software limits are useful to limit the travel range of a positioner. There is no possibility to disable software limits. For an almost infinite motion, for instance with a rotative stage, set the highest possible value, which is 999999930400.					
Returns	If the sign “?” is used instead of nn , this command returns the current programmed value.					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
Rel. Commands	SL	—	Set negative software limit.			
Example	1SR100 Set controller #1 positive software positive to 100 units.					

ST — Stop motion

Usage	Not Ref.	Config.	Disable	Ready	Motion
	—	—	—	—	●
Syntax	[xx]ST				
Parameters					
Description	xx [int]	—	Controller address.		
Range	xx	—	0 to 31		
Units	xx	—	None.		
Defaults	xx	Missing:	Change to 0 (will forward this command to all controllers).		
		Out of range:	Error B.		
Description	The ST command is a safety feature. It stops a move in progress by decelerating the positioner immediately with the acceleration defined by the AC command until it stops.				
	The xxST command with a preceding controller address stops a move in progress on controller xx. The ST command without any preceding controller address stops the moves on ALL controllers.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	D	—	Execution not allowed.		
	H	—	Execution not allowed in NOT REFERENCED state.		
	I	—	Execution not allowed in CONFIGURATION state.		
	J	—	Execution not allowed in DISABLE state.		
	K	—	Execution not allowed in READY state.		
Example	ST		Stop moves on all controllers.		

TB — Get command error string

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	●	●	●	●
Syntax	xxTBnn					
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	1 to 31			
	nn [char]	—	Error code (refer to TE command).			
Units	xx	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
	nn	Missing:	Returns explanation of current error as a literal string.			
		Out of range:	Error C.			
Description	The TB command returns a literal character string that explains the meaning of the error code nn (see TE command for complete list).					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
Rel. Commands	TE	—	Get last command error.			
Example	1TB@ Get explanation to error code @.					
	1TB@ No error Controller returns: @ = means no error.					

TE — Get last command error

Usage	Not Ref.	Config.	Disable	Ready	Motion
	●	●	●	●	●
Syntax	xxTE				
Parameters					
Description	xx [int]	—	Controller address.		
Range	xx	—	1 to 31		
Units	xx	—	None.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
Description	<p>The TE command returns the currently recorded error. When a command is not executable or fails, an error is recorded. This error can be read with the TE command. After the execution of a TE command, the error buffer is erased and another TE command will return @, which means "No error". When a new command error is generated before the previous command error is read, the new command's error will overwrite the currently memorized error.</p> <p>For a safe program flow it is recommended to always query the command error after each command execution.</p>				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	D	—	Execution not allowed.		
Rel. Commands	TB	—	Get command error string.		
Example	1TE		Get last error memorized on controller #1.		
			Controller returns: 1TE@, means no error.		

List of errors and corresponding strings (see TB command):

@	—	No error.
A	—	Unknown message code or floating point controller address.
B	—	Controller address not correct.
C	—	Parameter missing or out of range.
D	—	Command not allowed.
E	—	Home sequence already started.
G	—	Displacement out of limits.
H	—	Command not allowed in NOT REFERENCED state.
I	—	Command not allowed in CONFIGURATION state.
J	—	Command not allowed in DISABLE state.
K	—	Command not allowed in READY state.
L	—	Command not allowed in HOMING state.
M	—	Command not allowed in MOVING state.
N	—	Current position out of software limit.
S	—	Communication Time Out.
U	—	Error during EEPROM access.
V	—	Error during command execution.

TH — Get set-point position

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	●	●	●	●
	Syntax	xxTH				
	Parameters					
	Description	xx [int]	—	Controller address.		
	Range	xx	—	1 to 31		
	Units	xx	—	None.		
	Defaults	xx	Missing:	Error B.		
			Out of range:	Error B.		
	Description	The TH command returns the value of the set-point or theoretical position. This is the position where the positioner should be. In MOVING state, the set-point position changes according to the calculation of the motion profiler. In READY state, the set-point position is equal to the target position.				
	Errors	A	—	Unknown message code or floating point controller address.		
		B	—	Controller address not correct.		
		D	—	Execution not allowed.		
	Rel. Commands	TP	—	Get current position.		
	Example	1TH		Get set-point position of controller #1.		
		1TH0		Controller returns: set-point position = 0 units.		

TP — Get current position

Usage	Not Ref.	Config.	Disable	Ready	Motion
	●	●	●	●	●
Syntax	xxTP				
Parameters					
Description	xx [int]	—	Controller address.		
Range	xx	—	1 to 31		
Units	xx	—	None.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
Description	The TP command returns the value of the current position. This is the position where the positioner actually is. In MOVING state, this value always changes. In READY state, this value should be equal or very close to the set-point and target position. Together with the TS command, the TP command helps evaluating whether a motion has completed.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
	D	—	Execution not allowed		
Rel. Commands	TH	—	Get set-point position.		
	TS	—	Get positioner error and controller state.		
Example	1TP		Get current position of controller #1.		
	1TP0		Controller returns: actual position = 0 units.		

TS — Get positioner error and controller state

Usage	Not Ref.	Config.	Disable	Ready	Motion
	●	●	●	●	●
Syntax	xxTS				
Parameters					
Description	xx [int]	—	Controller address.		
Range	xx	—	1 to 31		
Units	xx	—	None.		
	nn	—	None.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
Description	The TS command returns the positioner error and the current controller state.				
Returns	The TS command returns six characters (1TSabcdef). The first 4 characters (abcd) represent the positioner error as hexadecimal number. The last two characters (ef) represent the controller state as hexadecimal number.				

Error code (abcd): Convert each hexadecimal to a binary:

F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
1111	1110	1101	1100	1011	1010	1001	1000	0111	0110	0101	0100	0011	0010	0001	0000

E

each bit represents one possible error (exception made of bit C1):

A				B				C				D			
1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
Not used	Not used	Not used	Not used	Driver overheating	Driver fault	Not used	Not used	No parameters in memory	Homing time out	Not used	Newport reserved (MZ status)	RMS current limit	Not used	Positive end of run	Negative end of run

NOTE

Bit C1 (MZ status) is not an error. It is reserved for Newport technicians to diagnose the mechanical zero sensor status during customer support and servicing.

Examples:

- Error map 0000 = No errors
- Error map 0002 = Positive end of run
- Error map 0048 = Homing time out, RMS current limit

Controller states (ef):

- **0A:** NOT REFERENCED from RESET.
- **0B:** NOT REFERENCED from HOMING.
- **0C:** NOT REFERENCED from CONFIGURATION.
- **0D:** NOT REFERENCED from DISABLE.
- **0E:** NOT REFERENCED from READY.
- **0F:** NOT REFERENCED from MOVING.
- **10:** NOT REFERENCED - NO PARAMETERS IN MEMORY.
- **14:** CONFIGURATION.
- **1E:** HOMING.
- **28:** MOVING.
- **32:** READY from HOMING.
- **33:** READY from MOVING.
- **34:** READY from DISABLE.
- **3C:** DISABLE from READY.
- **3D:** DISABLE from MOVING.

NOTE

The positioner error gets updated periodically, approx. every 1 ms.
The TS command reads the positioner error and clears it at the same time (same as what the command TE does with command errors). So when launching the TS command, it is important to process the TS feedback accordingly.

Errors	A	—	Unknown message code or floating point controller address.
	B	—	Controller address not correct.
Rel. Commands	TE	—	Get last command error.
Example	1TS		<i>Get error and state of controller #1.</i>
	1TS00000A		<i>Controller returns: no errors and state is NOT REFERENCED from reset.</i>

VA — Set/Get velocity

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		—	○	□	□	—
	Syntax	xxVAnn or xxVA?				
Parameters						
Description	xx [int]	—	Controller address.			
	nn [float]	—	Velocity value.			
Range	xx	—	1 to 31			
	nn	—	> 10 ⁻⁶ and < 10 ¹²			
Units	xx	—	None.			
	nn	—	Preset units/s.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
	nn	Missing:	Error C.			
		Out of range:	Error C.			
Description	In CONFIGURATION state, this command sets the maximum (i.e. cruise) velocity value which can then be saved in the controller's non-volatile memory using the PW command. This should be the maximum velocity that can be applied to the mechanical system. It is also the default velocity that will be used for all moves unless a lower value is set in DISABLE or READY state.					
	In DISABLE or READY state, this command sets the velocity used for all subsequent moves. Its value can be up to the programmed value set in the CONFIGURATION state. This value is not saved in the controller's memory and will be lost after reboot.					
Returns	If the sign “?” is used instead of nn, this command returns the current value for the state in which the controller is (either CONFIGURATION or DISABLE/READY).					
Errors	A	—	Unknown message code or floating point controller address.			
	B	—	Controller address not correct.			
	C	—	Parameter missing or out of range.			
	D	—	Execution not allowed.			
	H	—	Execution not allowed in NOT REFERENCED state.			
	L	—	Execution not allowed in HOMING state.			
	M	—	Execution not allowed in MOVING state.			
		—				
Rel. Commands	AC	—	Set/Get acceleration.			
	JR	—	Set/Get jerk time.			
Example	1VA50		Set controller #1 maximum velocity to 50 units/s.			

VE — Get controller revision information

Usage	Not Ref.	Config.	Disable	Ready	Motion
	●	●	●	●	●
Syntax	xxVE				
Parameters					
Description	xx [int]	—	Controller address.		
	nn [string]	—	Action.		
Range	xx	—	1 to 31		
Units	xx	—	None.		
Defaults	xx	Missing:	Error B.		
		Out of range:	Error B.		
Description	This command returns the controller's firmware revision information.				
Errors	A	—	Unknown message code or floating point controller address.		
	B	—	Controller address not correct.		
Example	1VE Get controller #1 revision information.				
	1VE FC family controller 2.0.0 Controller returns revision number				

ZT — Get all configuration parameters

	Usage	Not Ref.	Config.	Disable	Ready	Motion
		●	●	●	●	●
	Syntax	xxZT				
Parameters						
Description	xx [int]	—	Controller address.			
Range	xx	—	1 to 31			
Units	xx	—	None.			
Defaults	xx	Missing:	Error B.			
		Out of range:	Error B.			
Description	The ZT command returns the list of all current configuration parameters.					
	The ZT command allows a quick review of all current stage parameter and simplifies the configuration of Newport stages, for instance by copying all the returned values into a configuration file which can be later fed back to the stage by simply pasting its contents in the terminal emulator when the stage needs to be quickly reconfigured.					
Errors	A	—	Unknown message code or floating point controller address			
	B	—	Controller address not correct			
Example	1ZT		Get controller #1 configuration data.			
	1PW1					
	1AC320.000000					
	1BA0.000000					
	...					
	1VA80.000000					
	1PW0					

Your Local Representative

Fax: _____

Return authorization #: _____

(Please obtain prior to return of item)

Date: _____


Phone Number: _____

Fax Number: _____

Serial #: _____

Reasons of return of goods (please list any specific problems): _____

Reasons of return of goods (please list any specific problems): _____



Newport®

Experience | Solutions

Visit Newport Online at:
www.newport.com

North America & Asia

Newport Corporation
1791 Deere Ave.
Irvine, CA 92606, USA

Sales

Tel.: (800) 222-6440
e-mail: sales@newport.com

Technical Support

Tel.: (800) 222-6440
e-mail: tech@newport.com

Service, RMAs & Returns

Tel.: (800) 222-6440
e-mail: service@newport.com

Europe

MICRO-CONTROLE Spectra-Physics S.A.S
9, rue du Bois Sauvage
91055 Évry CEDEX
France

Sales

Tel.: +33 (0)1.60.91.68.68
e-mail: france@newport.com

Technical Support

e-mail: tech_europe@newport.com

Service & Returns

Tel.: +33 (0)2.38.40.51.55