

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Video Conference
Manufacturer: Poly
Firmware Version: 4.0.2-384012
Model(s): G7500

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.17.0000-b002	2.20.0.16

Version History

Module Version	Date	Notes
1_5_1_0	8/24/2023	Added Content Navigation, Results, Result Set, and Update. Added Module Notes regarding Version command.
1_5_0_0	1/7/2022	Added Number of Meeting Results parameter. Increased Meeting parameter maximum value from 5 to 10 for all Meeting status. Added Meeting Navigation, Provider Lock, and Provider Mode. Fixed Meeting commands.
1_3_0_0	11/10/2021	Added Sleep Mode query protection. Added authentication support for serial control. Added Keypad, Menu Navigation, and Selfview commands. Fixed Hangup issue. <ul style="list-style-type: none">Updated Call History, Call Info, Meeting, Phonebook, and Phonebook Group logicCall History Results and Results Set<ul style="list-style-type: none">Position<ul style="list-style-type: none">Changed type to Decimal from EnumRenamed to CallCall Info

Global Scriptor Module Communication Sheet

		<ul style="list-style-type: none"> ○ Renamed to Call Info State ○ Added Opened, Ringing, Disconnecting, and Disconnected states • Call Info Name, Number, and State <ul style="list-style-type: none"> ○ Call <ul style="list-style-type: none"> ▪ Changed type to Decimal from Enum ○ Updated status to be based off unsolicited data • Call State <ul style="list-style-type: none"> ○ This command is removed • Call Sate Incoming Call ID <ul style="list-style-type: none"> ○ Updated status behavior to only show incoming caller ○ Renamed to Call Info Caller ID • Camera Near Tracking Mode <ul style="list-style-type: none"> ○ Fixed status • Config Display <ul style="list-style-type: none"> ○ Renamed to Config Display 1 • Hook <ul style="list-style-type: none"> ○ Added Dial 256Kbps, 384Kbps, 768Kbps, 1.4Mbps, 1.9Mbps, and 3.8Mbps ○ Removed Dial 832Kbps and 1.7Mbps ○ Renamed Dial 6Mbps → Dial 6.1Mbps • LAN Port <ul style="list-style-type: none"> ○ Added status • Meeting End, Location, Number, Organizer, Start, Subject, and Time Combined <ul style="list-style-type: none"> ○ Label <ul style="list-style-type: none"> ▪ Changed type to Decimal from Enum ▪ Renamed to Meeting • Mute Far Status <ul style="list-style-type: none"> ○ Added Unknown • Phonebook Navigation and Group Navigation <ul style="list-style-type: none"> ○ Removed Phonebook Type qualifier • Phonebook Results, Results Set, Group Results, and Group Results Set <ul style="list-style-type: none"> ○ Position <ul style="list-style-type: none"> ▪ Changed type to Decimal from Enum ▪ Renamed to Entry • Phonebook Update <ul style="list-style-type: none"> ○ Changed Phonebook Type qualifier to Value • Selfview <ul style="list-style-type: none"> ○ Fixed status • Sleep Time <ul style="list-style-type: none"> ○ Added 45 state. • Transmit Mute <ul style="list-style-type: none"> ○ Fixed status
--	--	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Global Scripter Module
Communication Sheet**

		<ul style="list-style-type: none">• Version Added status
1_1_4_0	12/10/2020	Added Meeting commands and logic.
1_1_3_0	10/14/2020	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- If login credentials are required, devicePassword and deviceUsername must be set accordingly. deviceUsername default value is admin respectively.
Example: `InterfaceName.deviceUsername = 'extron'`
- MeetingsTimeFormat variable must be set accordingly. Default value is '12 Hour'.
Example: `InterfaceName.MeetingsTimeFormat = '12 Hour'`
- MeetingsTimeInterval variable must be set accordingly. Default value is 'One Day'.
Example: `InterfaceName.MeetingsTimeInterval = 'One Day'`
- NumberofPhonebookResults variable must be set accordingly. Default value is '5'.
NumberofPhonebookResults ranges from 1 to 15.
Example: `InterfaceName.NumberofPhonebookResults = '5'`
- NumberofCallHistoryResults variable must be set accordingly. Default value is '5'.
NumberofCallHistoryResults ranges from 1 to 10.
Example: `InterfaceName.NumberofCallHistoryResults = '5'`
- NumberofMeetingResults variable must be set accordingly. Default value is '5'.
NumberofMeetingResults ranges from 1 to 10.
Example: `InterfaceName.NumberofMeetingResults = '5'`
- It is recommended to have a 0.2 second pacing between commands.
- When Sleep Mode is Sleep or Unknown, the following queries will not be sent to the device as it causes it to wake up:
 - Camera Near Tracking
 - Camera Near Tracking Mode
 - Camera Source
 - Video Content Source
- If authentication is required for serial control, the module must be programmed for bidirectional communication to authenticate with the device.

- Version command will need to be updated and polled at least 4 times upon initialization for the following statuses to update:
 - Sleep Mode
 - Call Info Caller ID
 - Call Info Name
 - Call Info Number
 - Call Info State

Call History Commands

- Call History Update
 - This command is used to query the Call History in which the device will respond with a list of results which will be populated in Call History Results.
- Call History Results
 - This is where the results will be saved to when Call History is updated. The number of results is set by a module parameter Number of Call History Results which is set to 5 results by default. Use text feedback to display the search results.
- Call History Navigation
 - This command is used for navigating through the search results. When there are more search results from the Call History Update than the Number of Call History Results, the user can scroll through these results one entry or page at a time.
- Call History Result Set
 - This command obtains the result from Call History Results and sends to the Dial String status to be used for dialing functionality.

Content Commands

- Content Update
 - This command is used to query the content by type in which the device will respond with a list of results which will be populated in Content Results.
- Content Results
 - This is where the results will be saved to when the content is updated. The number of results is set by a driver parameter Number of Content Results which is set to 5 results by default. Use text feedback to display the search results.
- Content Navigation
 - This command is used for navigating through the search results. When there are more search results from the Content Update than the Number of Content Results, the user can scroll through these results one entry or page at a time.
- Content Result Set
 - This command obtains the result from Content Results to show, hide, or close the content.

Meeting Commands

- Meetings will be automatically updated every 120 seconds.
- Number of Meeting Results
 - Module parameter that determines the number of results to display. Use text feedback to display the search results.
 - Default value is set to 5 and ranges from 1 – 10.
- Meetings Time Interval
 - Module parameter that determines the time range of Meetings to query.
 - Default value is set to 'One Day'.
- Meeting Navigation
 - This command is used for navigating through the search results. When there are more search results from the Meeting Refresh than the Number of Meeting Results, the user can scroll through these results one entry or page at a time.
- Meeting Refresh
 - This command will refresh the meetings list, based on the time range defined by the Meetings Time Interval driver parameter.
- Calendar Status
 - Returns status if the calendar server has been Established or if it is Unavailable.
- Meeting Number
 - Returns the meeting number when configured or if the meeting room is not dialable.
- Meeting Number Set
 - When the number selected, it will copy the number over to Dial String command for dialing.
- Meeting Organizer
 - Returns the meeting organizer name.
- Meeting Start
 - Returns the meeting start time.
- Meeting End
 - Returns the meeting end time.
- Meeting Time Combined
 - Returns the meeting Day, Start and End time i.e. "Mon 11:00AM – 12:00PM".
- Meeting Subject
 - Returns the Meeting subject.
- Meeting Location
 - Returns the Meeting location.

Phonebook Commands

- Phonebook Update
 - This command updates the phonebook statuses depending on which value is used:
 - Local: Retrieves local directory entries for groups and contacts using Phonebook Search and Phonebook Group Search as filters.
 - Global: Retrieves global directory entries using Phonebook Search and Phonebook Group Search as filters.
 - Global Grouplist: Returns the top tier group list. This does not use Phonebook Search and Phonebook Group Search as filters.
- Phonebook Group Results
 - This is where the search results (group entries) will be saved to when phonebook is searched. The number of results is set by a module parameter Number of Phonebook Results which is set to 5 result by default. Use text feedback to display the search results.
- Phonebook Group Navigation
 - This command is used for navigating through the group search results. When there are more search results from the Phonebook Update than the Number of Phonebook Results, the user can scroll through these results one entry or page at a time.
- Phonebook Group Result Set
 - This command obtains the result from Phonebook Group Results and sends the group's UID to Phonebook Group Search to be used for updating the phonebook for that specific group.
- Phonebook Group Search
 - This command determines if there is a specific group UID to be used for updating the phonebook.
- Phonebook Results
 - This is where the search results will be saved to when phonebook is searched. The number of results is set by a module parameter Number of Phonebook Results which is set to 5 result by default. Use text feedback to display the search results.
- Phonebook Navigation
 - This command is used for navigating through the search results. When there are more search results from the Phonebook Update than the Number of Phonebook Results, the user can scroll through these results one entry or page at a time.
- Phonebook Result Set
 - This command obtains the result from Phonebook Results and sends to the Dial String status to be used for dialing functionality.
- Phonebook Search
 - This command takes in a search phrase and is used during Phonebook Update to filter the results.

Query Commands

The following commands trigger a query command and should not be sent at a faster rate than the Command Timeout Duration specified.

Command Name	Command Timeout Duration
Call History Update	5 seconds
Content Update	5 seconds
Meeting Refresh	5 seconds
Phonebook Update	5 seconds

Supported Classes and Examples

SerialClass

```
InterfaceName = ModuleName.SerialClass(ProcessorName, 'COM1', Model='G7500')
```

SerialOverEthernetClass

```
InterfaceName = ModuleName.SerialOverEthernetClass('192.168.254.254', 2001, Model='G7500')
```

SSHClass

#Password Required

```
InterfaceName = ModuleName.SSHClass('192.168.254.254', 22, Credentials=('admin', 'extron'),  
Model='G7500')
```

#No Password Required

```
InterfaceName = ModuleName.SSHClass('192.168.254.254', 22, Credentials=('admin', ''),  
Model='G7500')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command AutoAnswer	Value 'Yes'	Value 'No'	Value 'Do Not Disturb'
# AutoAnswer example InterfaceName.Set('AutoAnswer', 'Yes')			
Command CallHistoryNavigation	Value 'Up' 'Page Down'	Value 'Down'	Value 'Page Up'
# CallHistoryNavigation example InterfaceName.Set('CallHistoryNavigation', 'Up')			
Command CallHistoryResultSet	Value None		
Qualifier Key 'Call'	Qualifier Value 1 – 10		
# CallHistoryResultSet example InterfaceName.Set('CallHistoryResultSet', None, {'Call': 10})			
Command CallHistoryUpdate	Value None		
# CallHistoryUpdate example InterfaceName.Set('CallHistoryUpdate', None)			
Command CameraNearTracking	Value 'On'	Value 'Off'	
# CameraNearTracking example InterfaceName.Set('CameraNearTracking', 'On')			
Command CameraNearTrackingMode	Value 'Speaker' 'Off'	Value 'Group'	Value 'Group with Transition'
# CameraNearTrackingMode example InterfaceName.Set('CameraNearTrackingMode', 'Speaker')			
Command CameraPTZ	Value 'Up' 'Right' 'Zoom-'	Value 'Down' 'Stop'	Value 'Left' 'Zoom+'
Qualifier Key 'Mode'	Qualifier Value 'Near'	Qualifier Value 'Far'	
# CameraPTZ example InterfaceName.Set('CameraPTZ', 'Up', {'Mode': 'Near'})			
Command CameraSource	Value '1' – '4'		
Qualifier Key 'Mode'	Qualifier Value 'Near'	Qualifier Value 'Far'	
# CameraSource example InterfaceName.Set('CameraSource', '1', {'Mode': 'Near'})			

Global Scripter Module Communication Sheet

Command	Value	Value	Value
ConfigDisplay1	'Auto' '3840x2160p @ 25Hz' '3840x2160p @ 60Hz'	'1920x1080p @ 50Hz' '3840x2160p @ 30Hz'	'1920x1080p @ 60Hz' '3840x2160p @ 50Hz'
# ConfigDisplay1 example InterfaceName.Set('ConfigDisplay1', 'Auto')			
Command	Value	Value	Value
ConfigDisplay2	'Off' '1920x1080p @ 60Hz'	'Auto'	'1920x1080p @ 50Hz'
# ConfigDisplay2 example InterfaceName.Set('ConfigDisplay2', 'Off')			
Command	Value	Value	
ConfigPresentationContent	'Single'	'Dual'	
# ConfigPresentationContent example InterfaceName.Set('ConfigPresentationContent', 'Single')			
Command	Value	Value	
ConfigPresentationSelfView	'Corner'	'Full Screen'	
# ConfigPresentationSelfView example InterfaceName.Set('ConfigPresentationSelfView', 'Corner')			
Command	Value	Value	
ContentAuto	'On'	'Off'	
# ContentAuto example InterfaceName.Set('ContentAuto', 'On')			
Command	Value	Value	Value
ContentNavigation	'Up'	'Down'	'Page Up'
# ContentAuto example InterfaceName.Set('ContentAuto', 'On')			
Command	Value	Value	Value
ContentResultSet	'Show'	'Hide'	'Close'
Qualifier Key	Qualifier Value		
'Content'	1 – 10		
# ContentResultSet example InterfaceName.Set('ContentResultSet', 'Show', {'Content': 10})			
Command	Value	Value	Value
ContentUpdate	'All' 'PPCIP' 'Drawing Board'	'Unknown' 'Miracast'	'Content Cam' 'AirPlay'
# ContentUpdate example InterfaceName.Set('ContentUpdate', 'All')			
Command	Value		
DialString	String		
# DialString example InterfaceName.Set('DialString', 'Dial String')			
Command	Value	Value	Value
DTMF	'0' – '9'	'*'	'#'
# DTMF example InterfaceName.Set('DTMF', '0')			
Command	Value	Value	Value
Hook	'Answer' 'Dial 384Kbps' 'Dial 1Mbps' 'Dial 2Mbps' 'Dial 4Mbps' 'Dial Name'	'Dial 128Kbps' 'Dial 512Kbps' 'Dial 1.4Mbps' 'Dial 3Mbps' 'Dial 6.1Mbps' 'Dial UID'	'Dial 256Kbps' 'Dial 768Kbps' 'Dial 1.9Mbps' 'Dial 3.8Mbps' 'Dial Auto' 'Dial H323'

Global Scripter Module Communication Sheet

	'Dial IP' 'Hangup 2' 'Hangup 5'	'Dial SIP' 'Hangup 3' 'Hangup All'	'Hangup 1' 'Hangup 4'
# Hook example InterfaceName.Set('Hook', 'Answer')			
Command Keypad	Value '0' – '9' '*'	Value '.'	Value '#'
# Keypad example InterfaceName.Set('Keypad', '0')			
Command MeetingNavigation	Value 'Up' 'Page Down'	Value 'Down'	Value 'Page Up'
# MeetingNavigation example InterfaceName.Set('MeetingNavigation', 'Up')			
Command MeetingNumberSet	Value None		
Qualifier Key 'Meeting'	Qualifier Value 1 – 10		
# MeetingNumberSet example InterfaceName.Set('MeetingNumberSet', None, {'Meeting': 10})			
Command MeetingRefresh	Value None		
# MeetingRefresh example InterfaceName.Set('MeetingRefresh', None)			
Command MenuNavigation	Value 'Up' 'Right' 'Keyboard' 'Delete'	Value 'Down' 'Menu' 'Select'	Value 'Left' 'Call Screen' 'Back'
# MenuNavigation example InterfaceName.Set('MenuNavigation', 'Up')			
Command PhonebookGroupNavigation	Value 'Up' 'Page Down'	Value 'Down'	Value 'Page Up'
# PhonebookGroupNavigation example InterfaceName.Set('PhonebookGroupNavigation', 'Up')			
Command PhonebookGroupResultSet	Value None		
Qualifier Key 'Group'	Qualifier Value 1 – 15		
# PhonebookGroupResultSet example InterfaceName.Set('PhonebookGroupResultSet', None, {'Group': 15})			
Command PhonebookGroupSearch	Value 'String'		
# PhonebookGroupSearch example InterfaceName.Set('PhonebookGroupSearch', 'String')			
Command PhonebookNavigation	Value 'Up' 'Page Down'	Value 'Down'	Value 'Page Up'
# PhonebookNavigation example InterfaceName.Set('PhonebookNavigation', 'Up')			

Global Scripter Module Communication Sheet

Command PhonebookResultSet	Value None		
Qualifier Key 'Entry'	Qualifier Value 1 – 15		
Qualifier Key 'Type'	Qualifier Value 'Name' 'H323 Extension'	Qualifier Value 'UID' 'SIP Number'	Qualifier Value 'H323 Number'
# PhonebookResultSet example InterfaceName.Set('PhonebookResultSet', None, {'Entry': 15, 'Type': 'Name'})			
Command PhonebookSearch	Value 'String'		
# PhonebookSearch example InterfaceName.Set('PhonebookSearch', 'String')			
Command PhonebookUpdate	Value 'Local'	Value 'Global'	Value 'Global Grouplist'
# PhonebookUpdate example InterfaceName.Set('PhonebookUpdate', 'Local')			
Command PresetFar	Value '0' – '15'		
Qualifier Key 'Mode'	Qualifier Value 'Recall'	Qualifier Value 'Save'	
# PresetFar example InterfaceName.Set('PresetFar', '0', {'Mode': 'Recall'})			
Command PresetNear	Value '0' – '99'		
Qualifier Key 'Mode'	Qualifier Value 'Recall'	Qualifier Value 'Save'	
# PresetNear example InterfaceName.Set('PresetNear', '0', {'Mode': 'Recall'})			
Command ProviderMode	Value 'Poly' 'GoToRoom' 'Device Mode'	Value 'Zoom Rooms' 'BlueJeans Rooms' 'StarLeaf'	Value 'Microsoft Teams' 'RingCentral Rooms' 'Dialpad Conference Room'
# ProviderMode example InterfaceName.Set('ProviderMode', 'Poly')			
Command Reboot	Value None		
# Reboot example InterfaceName.Set('Reboot', None)			
Command Selfview	Value 'On'	Value 'Off'	Value 'Auto'
# Selfview example InterfaceName.Set('Selfview', 'On')			
Command SleepMode	Value 'Sleep'	Value 'Wake'	
# SleepMode example InterfaceName.Set('SleepMode', 'Sleep')			
Command SleepTime	Value '0' – '480'		
# SleepTime example InterfaceName.Set('SleepTime', '0')			

Global Scripter Module Communication Sheet

Command TransmitLevel	Value -6 to 18 in steps of 1 dB	
# TransmitLevel example InterfaceName.Set('TransmitLevel', 18)		
Command TransmitMute	Value 'On'	Value 'Off'
# TransmitMute example InterfaceName.Set('TransmitMute', 'On')		
Command VideoContentSource	Value '1' – '6'	Value 'Stop'
# VideoContentSource example InterfaceName.Set('VideoContentSource', '1')		
Command VideoMute	Value 'On'	Value 'Off'
# VideoMute example InterfaceName.Set('VideoMute', 'On')		
Command Volume	Value 0 to 50 in steps of 1	
# Volume example InterfaceName.Set('Volume', 50)		

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus, CallHistoryResults, CallInfoCallerID, CallInfoName, CallInfoNumber, CallInfoState, MeetingEnd, MeetingLocation, MeetingNumber, MeetingOrganizer, MeetingStart, MeetingSubject, MeetingTimeCombined, PhonebookGroupResults, PhonebookResults, and SleepMode do not support the Update function. ConnectionStatus is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value	Value
AutoAnswer	'Yes'	'No'	'Do Not Disturb'
# AutoAnswer example InterfaceName.Update('AutoAnswer') Value = InterfaceName.ReadStatus('AutoAnswer') InterfaceName.SubscribeStatus('AutoAnswer', None, FeedbackHandler)			
Command	Value	Value	
CalendarStatus	'Established'	'Unavailable'	
# CalendarStatus example InterfaceName.Update('CalendarStatus') Value = InterfaceName.ReadStatus('CalendarStatus') InterfaceName.SubscribeStatus('CalendarStatus', None, FeedbackHandler)			
Command	Value		
CallHistoryResults	'String'		
Qualifier Key	Qualifier Value		
'Call'	1 – 10		
# CallHistoryResults example Value = InterfaceName.ReadStatus('CallHistoryResults', {'Call': 10}) InterfaceName.SubscribeStatus('CallHistoryResults', None, FeedbackHandler)			
Command	Value		
CallInfoCallerID ¹	'String'		
# CallInfoCallerID example Value = InterfaceName.ReadStatus('CallInfoCallerID') InterfaceName.SubscribeStatus('CallInfoCallerID', None, FeedbackHandler)			
Command	Value		
CallInfoName ¹	'String'		
Qualifier Key	Qualifier Value		
'Call'	1 – 5		
# CallInfoName example Value = InterfaceName.ReadStatus('CallInfoName', {'Call': 5}) InterfaceName.SubscribeStatus('CallInfoName', None, FeedbackHandler)			

Global Scripter Module Communication Sheet

Command CallInfoNumber ¹	Value 'String'		
Qualifier Key 'Call'	Qualifier Value 1 – 5		
# CallInfoNumber example Value = InterfaceName.ReadStatus('CallInfoNumber', {'Call': 5}) InterfaceName.SubscribeStatus('CallInfoNumber', None, FeedbackHandler)			
Command CallInfoState ¹	Value 'Opened' 'Connected' 'Inactive'	Value 'Ringing' 'Disconnecting'	Value 'Connecting' 'Disconnected'
Qualifier Key 'Call'	Qualifier Value 1 – 5		
# CallInfoState example Value = InterfaceName.ReadStatus('CallInfoState', {'Call': 5}) InterfaceName.SubscribeStatus('CallInfoState', None, FeedbackHandler)			
Command CameraNearTracking	Value 'On'	Value 'Off'	
# CameraNearTracking example InterfaceName.Update('CameraNearTracking') Value = InterfaceName.ReadStatus('CameraNearTracking') InterfaceName.SubscribeStatus('CameraNearTracking', None, FeedbackHandler)			
Command CameraNearTrackingMode	Value 'Speaker' 'Off'	Value 'Group'	Value 'Group with Transition'
# CameraNearTrackingMode example InterfaceName.Update('CameraNearTrackingMode') Value = InterfaceName.ReadStatus('CameraNearTrackingMode') InterfaceName.SubscribeStatus('CameraNearTrackingMode', None, FeedbackHandler)			
Command CameraSource	Value '1' – '4'	Value 'Unavailable'	
Qualifier Key 'Mode'	Qualifier Value 'Near'	Qualifier Value 'Far'	
# CameraSource example InterfaceName.Update('CameraSource', {'Mode': 'Near'}) Value = InterfaceName.ReadStatus('CameraSource', {'Mode': 'Near'}) InterfaceName.SubscribeStatus('CameraSource', None, FeedbackHandler)			
Command ConfigDisplay1	Value 'Auto' '3840x2160p @ 25Hz' '3840x2160p @ 60Hz'	Value '1920x1080p @ 50Hz' '3840x2160p @ 30Hz'	Value '1920x1080p @ 60Hz' '3840x2160p @ 50Hz'
# ConfigDisplay1 example InterfaceName.Update('ConfigDisplay1') Value = InterfaceName.ReadStatus('ConfigDisplay1') InterfaceName.SubscribeStatus('ConfigDisplay1', None, FeedbackHandler)			
Command ConfigDisplay2	Value 'Off' '1920x1080p @ 60Hz'	Value 'Auto'	Value '1920x1080p @ 50Hz'
# ConfigDisplay2 example InterfaceName.Update('ConfigDisplay2') Value = InterfaceName.ReadStatus('ConfigDisplay2') InterfaceName.SubscribeStatus('ConfigDisplay2', None, FeedbackHandler)			

Global Scriptor Module Communication Sheet

Command ConfigPresentationContent	Value 'Single'	Value 'Dual'
# ConfigPresentationContent example InterfaceName.Update('ConfigPresentationContent') Value = InterfaceName.ReadStatus('ConfigPresentationContent') InterfaceName.SubscribeStatus('ConfigPresentationContent', None, FeedbackHandler)		
Command ConfigPresentationSelfView	Value 'Corner'	Value 'Full Screen'
# ConfigPresentationSelfView example InterfaceName.Update('ConfigPresentationSelfView') Value = InterfaceName.ReadStatus('ConfigPresentationSelfView') InterfaceName.SubscribeStatus('ConfigPresentationSelfView', None, FeedbackHandler)		
Command ConnectionStatus	Value 'Connected'	Value 'Disconnected'
# ConnectionStatus example Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command ContentAuto	Value 'On'	Value 'Off'
# ContentAuto example InterfaceName.Update('ContentAuto') Value = InterfaceName.ReadStatus('ContentAuto') InterfaceName.SubscribeStatus('ContentAuto', None, FeedbackHandler)		
Command ContentResults	Value 'String'	
Qualifier Key 'Content'	Qualifier Value 1 – 10	
# ContentResults example Value = InterfaceName.ReadStatus('ContentResults', {'Content': 10}) InterfaceName.SubscribeStatus('ContentResults', None, FeedbackHandler)		
Command LANPort	Value 'Auto' '100 Mbps Half Duplex' '1000 Mbps Full Duplex'	Value '10 Mbps Half Duplex' '100 Mbps Full Duplex' '1000 Mbps Half Duplex'
# LANPort example InterfaceName.Update('LANPort') Value = InterfaceName.ReadStatus('LANPort') InterfaceName.SubscribeStatus('LANPort', None, FeedbackHandler)		
Command MeetingEnd	Value 'String'	
Qualifier Key 'Meeting'	Qualifier Value 1 – 10	
# MeetingEnd example Value = InterfaceName.ReadStatus('MeetingEnd', {'Meeting': 10}) InterfaceName.SubscribeStatus('MeetingEnd', None, FeedbackHandler)		
Command MeetingLocation	Value 'String'	
Qualifier Key 'Meeting'	Qualifier Value 1 – 10	
# MeetingLocation example Value = InterfaceName.ReadStatus('MeetingLocation', {'Meeting': 10}) InterfaceName.SubscribeStatus('MeetingLocation', None, FeedbackHandler)		

Global Scripter Module Communication Sheet

Command MeetingNumber	Value 'String'
Qualifier Key 'Meeting'	Qualifier Value 1 – 10
# MeetingNumber example Value = InterfaceName.ReadStatus('MeetingNumber', {'Meeting': 10}) InterfaceName.SubscribeStatus('MeetingNumber', None, FeedbackHandler)	
Command MeetingOrganizer	Value 'String'
Qualifier Key 'Meeting'	Qualifier Value 1 – 10
# MeetingOrganizer example Value = InterfaceName.ReadStatus('MeetingOrganizer', {'Meeting': 10}) InterfaceName.SubscribeStatus('MeetingOrganizer', None, FeedbackHandler)	
Command MeetingStart	Value 'String'
Qualifier Key 'Meeting'	Qualifier Value 1 – 10
# MeetingStart example Value = InterfaceName.ReadStatus('MeetingStart', {'Meeting': 10}) InterfaceName.SubscribeStatus('MeetingStart', None, FeedbackHandler)	
Command MeetingSubject	Value 'String'
Qualifier Key 'Meeting'	Qualifier Value 1 – 10
# MeetingSubject example Value = InterfaceName.ReadStatus('MeetingSubject', {'Meeting': 10}) InterfaceName.SubscribeStatus('MeetingSubject', None, FeedbackHandler)	
Command MeetingTimeCombined	Value 'String'
Qualifier Key 'Meeting'	Qualifier Value 1 – 10
# MeetingTimeCombined example Value = InterfaceName.ReadStatus('MeetingTimeCombined', {'Meeting': 10}) InterfaceName.SubscribeStatus('MeetingTimeCombined', None, FeedbackHandler)	
Command MuteFarStatus	Value 'On' Value 'Off' Value 'Unknown'
# MuteFarStatus example InterfaceName.Update('MuteFarStatus') Value = InterfaceName.ReadStatus('MuteFarStatus') InterfaceName.SubscribeStatus('MuteFarStatus', None, FeedbackHandler)	
Command PhonebookGroupResults	Value 'String'
Qualifier Key 'Group'	Qualifier Value 1 – 15
# PhonebookGroupResults example Value = InterfaceName.ReadStatus('PhonebookGroupResults', {'Group': 15}) InterfaceName.SubscribeStatus('PhonebookGroupResults', None, FeedbackHandler)	
Command PhonebookResults	Value 'String'
Qualifier Key 'Entry'	Qualifier Value 1 – 15
# PhonebookResults example Value = InterfaceName.ReadStatus('PhonebookResults', {'Entry': 15}) InterfaceName.SubscribeStatus('PhonebookResults', None, FeedbackHandler)	

Global Scripter Module Communication Sheet

Command PresentationStatus	Value 'Play' 'Unknown'	Value 'Far Site Play'	Value 'Stop'
<pre># PresentationStatus example InterfaceName.Update('PresentationStatus') Value = InterfaceName.ReadStatus('PresentationStatus') InterfaceName.SubscribeStatus('PresentationStatus', None, FeedbackHandler)</pre>			
Command ProviderLock	Value 'Locked'	Value 'Unlocked'	
<pre># ProviderLock example InterfaceName.Update('ProviderLock') Value = InterfaceName.ReadStatus('ProviderLock') InterfaceName.SubscribeStatus('ProviderLock', None, FeedbackHandler)</pre>			
Command ProviderMode	Value 'Poly' 'GoToRoom' 'Device Mode'	Value 'Zoom Rooms' 'BlueJeans Rooms' 'StarLeaf'	Value 'Microsoft Teams' 'RingCentral Rooms' 'Dialpad Conference Room'
<pre># ProviderMode example InterfaceName.Update('ProviderMode') Value = InterfaceName.ReadStatus('ProviderMode') InterfaceName.SubscribeStatus('ProviderMode', None, FeedbackHandler)</pre>			
Command Selfview	Value 'On'	Value 'Off'	Value 'Auto'
<pre># Selfview example InterfaceName.Update('Selfview') Value = InterfaceName.ReadStatus('Selfview') InterfaceName.SubscribeStatus('Selfview', None, FeedbackHandler)</pre>			
Command SleepMode ¹	Value 'Sleep'	Value 'Wake'	Value 'Unknown'
<pre># SleepMode example Value = InterfaceName.ReadStatus('SleepMode') InterfaceName.SubscribeStatus('SleepMode', None, FeedbackHandler)</pre>			
Command SleepTime	Value '0' – '480'		
<pre># SleepTime example InterfaceName.Update('SleepTime') Value = InterfaceName.ReadStatus('SleepTime') InterfaceName.SubscribeStatus('SleepTime', None, FeedbackHandler)</pre>			
Command TransmitLevel	Value -6 to 18 in steps of 1 dB		
<pre># TransmitLevel example InterfaceName.Update('TransmitLevel') Value = InterfaceName.ReadStatus('TransmitLevel') InterfaceName.SubscribeStatus('TransmitLevel', None, FeedbackHandler)</pre>			
Command TransmitMute	Value 'On'	Value 'Off'	
<pre># TransmitMute example InterfaceName.Update('TransmitMute') Value = InterfaceName.ReadStatus('TransmitMute') InterfaceName.SubscribeStatus('TransmitMute', None, FeedbackHandler)</pre>			
Command Version	Value 'String'		
<pre># Version example InterfaceName.Update('Version') Value = InterfaceName.ReadStatus('Version') InterfaceName.SubscribeStatus('Version', None, FeedbackHandler)</pre>			

Global Scripter Module Communication Sheet

Command VideoContentSource	Value '1' – '6'	Value 'Stop'
<pre># VideoContentSource example InterfaceName.Update('VideoContentSource') Value = InterfaceName.ReadStatus('VideoContentSource') InterfaceName.SubscribeStatus('VideoContentSource', None, FeedbackHandler)</pre>		
Command VideoMute	Value 'On'	Value 'Off'
<pre># VideoMute example InterfaceName.Update('VideoMute') Value = InterfaceName.ReadStatus('VideoMute') InterfaceName.SubscribeStatus('VideoMute', None, FeedbackHandler)</pre>		
Command Volume	Value 0 to 50 in steps of 1	
<pre># Volume example InterfaceName.Update('Volume') Value = InterfaceName.ReadStatus('Volume') InterfaceName.SubscribeStatus('Volume', None, FeedbackHandler)</pre>		

¹ Refer to the note regarding Version command on Page 5 of 26 for status functionality.

Cable and Adapter Requirements

Captive Screw to Male Mini DIN 8 Pin RS-232 Serial Cable

Notes for the Device

To ensure the functionality of the module, please set Web UI → General Settings → Serial Ports → Mode → **RS-232 Mode to Control**.

Additionally, please set Serial Port Options → Baud Rate to the highest possible rate. If authentication is required, the module must be configured for bidirectional communication to authenticate with the device.

Serial communication

Port Type: RS-232

Baud Rate: 9600


Data Bits: 8

Parity: None

Stop Bits: One

Flow Control: None

Pin Assignments Diagram



Please contact the manufacturer for pin assignment diagram.



Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface.

Port Type: Ethernet (SSH)

Default Port: 22

Logon Credentials Supported: Yes

Default Username: admin

Default Password:

Multi-Connection: Yes

Capabilities:

Port Changeability: No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

To ensure the functionality of the module, please enable Web UI → Security → Access → **Enable Legacy API Over SSH**.

Appendix A. Set Commands

Auto Answer Do Not Disturb	autoanswer donotdisturb\x0D
Auto Answer No	autoanswer no\x0D
Auto Answer Yes	autoanswer yes\x0D
Camera Near Tracking Mode Group	cameratracking near mode group\x0D
Camera Near Tracking Mode Group with Transition	cameratracking near mode groupwithtransition\x0D
Camera Near Tracking Mode Off	cameratracking near mode off\x0D
Camera Near Tracking Mode Speaker	cameratracking near mode speaker\x0D
Camera Near Tracking Off	camera near tracking off\x0D
Camera Near Tracking On	camera near tracking on\x0D
Camera Source 1 Mode Far	camera far 1\x0D
Camera Source 1 Mode Near	camera near 1\x0D
Camera Source 4 Mode Far	camera far 4\x0D
Camera Source 4 Mode Near	camera near 4\x0D
Config Display 1 1920x1080p @ 50Hz	configdisplay monitor1 50hz1920x1080p\x0D
Config Display 1 1920x1080p @ 60Hz	configdisplay monitor1 60hz1920x1080p\x0D
Config Display 1 3840x2160p @ 25Hz	configdisplay monitor1 25hz3840x2160p\x0D
Config Display 1 3840x2160p @ 30Hz	configdisplay monitor1 30hz3840x2160p\x0D
Config Display 1 3840x2160p @ 50Hz	configdisplay monitor1 50hz3840x2160p\x0D
Config Display 1 3840x2160p @ 60Hz	configdisplay monitor1 60hz3840x2160p\x0D
Config Display 1 Auto	configdisplay monitor1 auto\x0D
Config Display 2 1920x1080p @ 50Hz	configdisplay monitor2 50hz1920x1080p\x0D
Config Display 2 1920x1080p @ 60Hz	configdisplay monitor2 60hz1920x1080p\x0D
Config Display 2 Auto	configdisplay monitor2 auto\x0D
Config Display 2 Off	configdisplay monitor2 off\x0D
Config Presentation Content Dual	configpresentation content dual\x0D
Config Presentation Content Single	configpresentation content single\x0D
Config Presentation Self View Corner	configpresentation self-view corner\x0D
Config Presentation Self View Full Screen	configpresentation self-view full-screen\x0D
Content Auto Off	contentauto off\x0D
Content Auto On	contentauto on\x0D
Content Result Set Close Content 1	content close *\x0D
Content Result Set Hide Content 1	content hide *\x0D
Content Result Set Show Content 1	content show *\x0D
Preset Far 0 Mode Recall	preset far go 0\x0D
Preset Far 0 Mode Save	preset far set 0\x0D
Preset Far 15 Mode Recall	preset far go 15\x0D
Preset Far 15 Mode Save	preset far set 15\x0D
Reboot None	reboot now\x0D
Selfview Auto	systemsetting selfview auto\x0D
Selfview Off	systemsetting selfview off\x0D
Selfview On	systemsetting selfview on\x0D
Sleep Mode Sleep	sleep\x0D

Global Scriptor Module Communication Sheet

Sleep Mode Wake	wake\x0D
Sleep Time 0	sleeptime 0\x0D
Sleep Time 1	sleeptime 1\x0D
Sleep Time 120	sleeptime 120\x0D
Sleep Time 15	sleeptime 15\x0D
Sleep Time 240	sleeptime 240\x0D
Sleep Time 3	sleeptime 3\x0D
Sleep Time 30	sleeptime 30\x0D
Sleep Time 45	sleeptime 45\x0D
Sleep Time 480	sleeptime 480\x0D
Sleep Time 60	sleeptime 60\x0D
Transmit Level 18	audiotransmitlevel set 18\x0D
Transmit Level -6	audiotransmitlevel set -6\x0D
Transmit Mute Off	mute near off\x0D
Transmit Mute On	mute near on\x0D
Video Content Source 1	vcbutton play 1\x0D
Video Content Source 4	vcbutton play 4\x0D
Video Content Source 6	vcbutton play 6\x0D
Video Content Source Stop	vcbutton stop\x0D
Video Mute Off	videomute near off\x0D
Video Mute On	videomute near on\x0D
Volume 0	volume set 0\x0D
Volume 50	volume set 50\x0D

Appendix B. Update Commands

Auto Answer	autoanswer get\x0D
Calendar Status	calendarstatus get\x0D
Camera Near Tracking	camera near tracking get\x0D
Camera Near Tracking Mode	cameratracking near mode get\x0D
Camera Source Mode Far	camera far source\x0D
Camera Source Mode Near	camera near source\x0D
Config Display 1	configdisplay monitor1 get\x0D
Config Display 2	configdisplay monitor2 get\x0D
Config Presentation Content	configpresentation content get\x0D
Config Presentation Self View	configpresentation self-view get\x0D
Content Auto	contentauto get\x0D
LAN Port	lanport get\x0D
Mute Far Status	mute far get\x0D
Presentation Status	vcbutton register\x0D
Selfview	systemsetting get selfview\x0D
Sleep Time	sleeptime get\x0D
Transmit Level	audiotransmitlevel register\x0D
Transmit Mute	mute register\x0D
Video Content Source	vcbutton source get\x0D
Video Mute	videomute near get\x0D
Volume	volume register\x0D