



## TA682-W

### Chronostat with Indoor Humidity Control

Operating Voltage	240V <sub>AC</sub> ± 20%
Relay contact	240V <sub>AC</sub> 50/60 Hz 5(1)A max
Wi-Fi	2.4GHz 802.11b/g/n

#### Features

- Valve / actuator control
- Summer / Winter (Cool / Heat) pre-programmed mode
- Temperature measurement and control
- Humidity measurement and control
  - deactivates relay when R.H.>80%. Valid for summer mode
- Output: digital type x 5
- 3.4" high-contrast VA TN with backlit
- Touch keys x 4
- Flush-mount installation in European electrical wall-box
- Super-cap retains clock and user schedule for 60 mins maximum


#### Technical Specification

Measuring temperature	0 ~ 40°C
Controlling temperature	5 ~ 35°C
Measuring accuracy/resolution	±0.5°C
Temperature control differential	±0.4°C
Humidity measurable range	5% ~ 95%, non-condensing
Humidity accuracy	±5%
Sensing elements	103AT NTC thermistor Digital humidity sensor
Operating Temperature	0 ~ 40 °C
Operating Humidity	5 ~ 95%R.H. non-condensing
Storage conditions	-5 ~ 60 °C, 5 ~ 95%R.H. non-condensing
Terminals	NC NO COM. 2mm <sup>2</sup> cable


#### Wi-Fi and Smartphone App

Avan-Stat 


**Dimensions and Line Drawing**



**Special Requirement of Wall Box Fitting**



**Output Diagram**



Display Content



Touch Keys


#	Description
	Mode / Menu
	Accessing clock
	Adjust settings

#	Description
	Cold
	Heat
	Wi-Fi connectivity
	Touch key lock
<b>SET</b>	Setting mode
<b>EXT</b>	External Temp Sensor
<b>P18</b>	Program Number
	Heating
	Cooling
	Output
	Comfort Mode
	Economy Mode
	Anti-freeze
	Window Opened

## On/Off Control


### (A) Heating

- The thermostat flips the relay on or off according to the following diagram.
- Switching differential for heat mode is 0.4°C as default.
- Relay protection time is 5 seconds. See **Relay Protection** on the next page.



### (B) Cooling





- The thermostat flips the relay on or off according to the following diagram.
- Switching differential for cool mode is 0.4°C as default.
- Compressor protection is 4-minute. See **Compressor Protection** on the next page.



### (C) Humidity Control

- Valid for Summer Mode i.e. Cooling only.
- R.H. overrides relay control.
- Relay is turned off when the R.H. in the environment exceeds user-preset threshold.
- TA682-W must allow the shutdown R.H.% to be adjusted in a range between 40% and 80%, adjustable by users.

## Internal Parameter Menu







- Press-n-hold on  key
- Press  to advance to the next item
- Press [] / [] to adjust the value
- Press [blank key] in the middle to confirm and exit

#	Items	Values	Default
P0	Screen Saver setting(^)	Black-out ("0") / Temp only ("1") / Clock, Time Slot, Temp ("2") / All icons on ("3")	2
P1	Screen Saver Countdown	5 ~120(^)	20
P2	Limited Mode	Enabled / Disabled	En
P3	---	---	
P4	Time Display format	24 / 12	12
P5	Temperature Offset	-5°C ~ 5°C	0°C
P6	Switching Differential in Heat mode	0.4°C / 1.0°C / 2.0°C	0.4°C
P7	Switching Differential in Cool mode	0.4°C / 1.0°C / 2.0°C	0.4°C
P8	Duration of T & RH on Display	30 sec / 60 sec / 90 sec	30
P9	Humidity setpoint(*)	60 ~ 90% R.H.	80

(^) P0 and P1 stored in RAM. Restored to default after a power surge



(\*) valid only for Summer Mode

## Advanced Parameter Menu


- Press-n-hold onto  and  keys together
- Press  to advance to the next item
- Press [] / [] to adjust the value
- Press  in the middle to confirm and exit

#	Items	Values	Default
P10	Clear Wi-Fi pairing data	Enable ("en") / Disable ("dis")	dis
P11	Restore Default	Enable ("en") / Disable ("dis")	dis
P12	Wi-Fi Pairing	Enable ("en") / Disable ("dis")	dis
P13	MAC address	5 hexadecimal data	-





### Compressor / Relay Protection

- A predetermined off-time is observed after turning off the relay in heating / cooling
- If there is a call of Heat / Cool during the minimum-off delay,  flashes on LCD.
- After the minimum-off delay expires,  stays visible and the output is on.
- Duration of off-time for cooling is 4 minutes.
- Duration of off-time for heating is 5 seconds.





### Defrost function

- Icon  appears when ambient temperature drops below 5°C
- Output turns on regardless of setpoint temperature in Winter Mode
- Output turns off regardless of setpoint temperature in Summer Mode

### Touch Key Lock

- In order to prevent undesirable manipulation on TA682-W when installed in public places, locking the four touch keys is recommended
- Simply press-n-hold on   together for 3 seconds
- While locked, the four touch keys on TA682-W do not respond to presses
- To unlock, press-n-hold on   together for 3 seconds again

### External Temperature Sensor readings

- Press-n-hold   together
- The temperature reading on the screen switches to external temperature sensor
- Release   and the reading on the screen switches back to ambient temperature

### Humidity readings

- Display toggles humidity readings and ambient temp readings in duration of 1 min
- Toggle duration adjustable in Internal Parameter Menu
- Measurable range: 10 ~ 95% R.H.
- Humidity Accuracy: ±5%

Product (rear view)

