

Singer 127-1

HISTORICAL COPY

DO NOT REMOVE

LIST OF PARTS COMPLETE



Machine No. 127-1

THE SINGER MANUFACTURING COMPANY

HISTORICAL COPY

NUMBERING DEPARTMENT

MAY 9, 1912

DO NOT REMOVE

LIST OF PARTS COMPLETE

FOR

MACHINE NO. 127-1

For family use, vibrating shuttle with shuttle ejector.

*55501	Arm with 443A and 8206.....	
2002	" Dowel Pin.....	
8203	" Rock Shaft with 122E.....	
122E	" " " Adjusting Screw.....	
8204	" " " Centre (upper).....	
301A	" " " Screw Centre.....	
1508E	" " " " Nut.....	
649E	" Screw.....	
8341	" Shaft.....	
8206	" " Bushing.....	
443A	" " " Set Screw.....	
8300	" Side Cover.....	
286D	" " " Thumb Screw.....	
2007	" Spool Pin.....	
8879	" " " Washer (cloth).....	
15282	Balance Wheel, 2½ in. pulley.....	
*8328	Bed.....	
256B	Clamp Stop Motion Clamp Screw.....	
248A	" " " " Stop Screw.....	
2020	" " " " Washer.....	
*15312	" " " " Flanged Bushing.....	
15313	" " " " " 15312 with	
	two 462C.....	
2022	Clamp Stop Motion Flanged Bushing Pin.....	
462C	" " " " " Set Screw.....	
15314	Clamp Stop Motion complete, Nos. 248A, 256B, 2020	
	and 15313.....	
8210	Face Plate with 2827.....	
219A	" " " Screw.....	
2827	" " " Thread Guard with 8505.....	
8505	" " " " Rivet.....	
32562	Feed Cam with 1285C.....	
1285C	" " " Set Screw.....	
8321	" Dog, four teeth at right of needle (square	
	corners).....	

8437	Feed Dog Carrier.....
1833	" " " Roller and Screw Stud.....
315C	" " " Screw Centre.....
1519E	" " " " " Nut.....
191C	" " " Screw.....
8348	" Forked Connection (cast iron) with 175B.....
175B	" " " Adjusting Screw.....
1381C	" " " Hinge Screw.....
1520E	" " " " " Nut.....
1832	" " " Roller and Screw Stud.....
253B	" Regulating Thumb Screw.....
8216	" Regulator.....
8217	" " Friction Washer.....
42D	" " Hinge Screw.....
8334	" Rock Shaft.....
307C	" " " Screw Centre.....
1513E	" " " " " Nut.....
25825	Feller.....
25527B	Guide.....
237B	" Thumb Screw.....
35857	Hemmer (foot) $\frac{1}{8}$ in. hem.....
26170	" " $\frac{5}{64}$ " ".....
35996	" " $\frac{5}{64}$ " ".....
6267	" Folder.....
25888	" Tongue.....

NOTE. When ordering Nos. 6267 or 25888, give width of hem and No. of Hemmer for which it is required.

55502	Needle Bar (hollow).....
8222	" " Cam with 175E and 400C.....
175E	" " " Clamping Screw.....
400C	" " " Guide Adjusting Screw.....
233B	" " " Position Screw.....
1836	" " " Roller and Screw Stud.....
8338	" " Thread Guard.....
249A	" " " and Needle Stop Screw.....
2054	" Clamp with 552C.....
552C	" " Thumb Screw.....
8224	Presser Bar.....
55507	" " Guide Bracket with 400F and 453C.....
400F	" " " Adjusting Screw.....
453C	" " " Set Screw.....
54503	" " Lifter.....
97E	" " " Screw.....
8225	" " Spring.....
2070	" " Washer.....
8337	" Foot for 8321.....

50053B	Presser Foot Thumb Screw.....
263B	Pressure Regulating Thumb Screw.....
8444	Shuttle Bell Crank.....
50036D	" " " Hinge Screw.....
54517	" Bobbin.....
*54504	" Body.....
215H	" Tension Regulating Screw.....
8326	" " Spring.....
54505	Shuttle complete, Nos. 215H, 8326, 54504 and 54517
54506	" Carrier.....
54507	Shuttle Carrier complete, Nos. 50126E, 54506, 54508, 54510, 54511 and two 54509.....
54508	Shuttle Carrier Cushion Spring.....
54509	" " " Rivet.....
231C	" " Screw.....
54510	" Ejector.....
50126E	" " Hinge Screw.....
54511	" " Spring.....
8232	" Pitman with two 175B.....
175B	" " Adjusting Screw.....
44A	" " Screw Stud.....
520C	" " " (eccentric).....
1520E	" " " " " Nut.....
216A	" " " " " Screw.....
55503	" Slide (back).....
55504	" " (front).....
2102	Tension Disc.....
1560B	" Regulating Thumb Nut.....
1274B	" Screw Stud.....
8238	" Spring.....
32572	" Releasing Disc.....
55505	" " Lever.....
55506	" " " Hinge Pin.....
12329	" " " Spring.....
54515	" " " Pin.....
26076	Thread Cutter.....
8241	" Take-up Cam with 448C.....
2117	" " " Pin.....
448C	" " " Set Screw.....
8242	" " " Lever with 1822.....
8243	" " " Cover.....
8401	" " " " with 8422.....
107B	" " " Hinge Screw.....
8422	" " " Thread Guard.....
79C	" " " Hinge Screw.....
1822	" " " Roller and Stud.....
8244	" " " Spring.....
54516	" " " Regulator Plate.....
233B	" " " " Adjusting Screw.....
8323	Throat Plate for 8321.....
219A	" " " Screw.....

BOBBIN WINDER (Automatic)

8342	Bobbin Winder Back Centre.....
8256	" " " " Head.....
8343	" " " " Spring.....
8344	" " Bracket (belt cover).....
158B	" " " " Screw.....
8257	" " Cam.....
219A	" " " " Screw.....
8345	" " Frame.....
80272	" " " " Friction Washer.....
50101B	" " " " Hinge Screw.....
1718H	" " " " " " Nut.....
15287	" " " " Friction Ring (rubber).....
50102A	" " " " Spindle.....
15288	" " " " Pulley.....
8346	" " " " Thread Guide.....
92B	" " " " " " Hinge Screw.....
8260	" " " " " " Spring.....
8261	" " " " Worm Wheel.....
2749	" " " " " " Friction Washer.....
50104B	" " " " " " Screw Stud (eccentric).....
1718H	" " " " " " Nut.....
8347	Bobbin Winder (automatic) complete, Nos. 92B, 219A, 2749, 8256, 8257, 8260, 8261, 8342 to 8346, 15287, 15288, 50101B, 50102A, 50104B, 80272 and two 1718H.....

HAND ATTACHMENT

8377	Body.....
33647	" Bracket.....
183D	" " " " Screw.....
8380	Crank Handle (wood).....
8433	" " " " Spindle.....
8434	" " " " 8433 with 8382.....
8382	" " " " Washer.....
8280	" " Hinge Pin.....
8435	" " Lever.....
8281	" " Lock Pin.....
8282	" " " " Spring.....
8436	Crank complete, Nos. 8380, 8434 and 8435.....
33642	Driver.....
33643	" " " " Finger.....
33644	" " " " 33643 with 8390, 8391 and 33645.....
8386	" " " " Hinge Pin.....

8387	Driver Finger Lock Pin.....
8388	" " " " " " Spring.....
33645	" " " " Sheath (leather).....
8390	" " " " Plate.....
8391	" " " " Staple.....
8392	Gear with 8281 and 8282.....
8393	" " Cover.....
399A	" " " " Screw.....
659D	" " " " Screw Stud.....
8394	Pinion.....
2532	" " Dowel Pin.....
660D	" " " " Screw Stud.....
33646	Hand Attachment complete, Nos. 137E, 659D, 660D, 2532, 8280, 8377, 8386 to 8388, 8392 to 8394, 8436, 33642, 33644, 33647 and two each 183D and 399A.....
137E	Hand Attachment Screw.....