

# **Detailed Design of External interrupt Driver**

**Team X**

## Contents

Introduction and functional overview: .....	2
File structure: .....	2
Requirement's traceability: .....	3
API specification: .....	3
Type definitions: .....	3
Function definitions: .....	4


## Introduction and functional overview:

This document specifies requirements on the module External interrupt Driver.

The external interrupt driver initializes External interrupt0 , initializes External interrupt1, and initializes External interrupt2

## File structure:

The LCD module shall comply with the following file structure:



## Requirement's traceability:

Requirement	Description	Satisfied by
[SRS_External interrupt_1001]	The External interrupt driver shall provide a service that initializes the External interrupt 0.	[DD_External interrupt_1002] [DD_External interrupt_1003]
[SRS_External interrupt_1002]	The External interrupt driver shall provide a service that initializes External interrupt 1	[DD_External interrupt_1002] [DD_External interrupt_1004]
[SRS_External interrupt_1003]	The External interrupt driver shall provide a service that initializes the External interrupt 2	[DD_External interrupt_1005] [DD_External interrupt_1002]
[SRS_External interrupt_1004]	The External interrupt driver shall provide a service that set call back function	[DD_External interrupt_1001] [DD_External interrupt_1006]

## API specification:

### Type definitions:

#### 1. [DD\_External interrupt\_1001]

<b>Name:</b>	EN_interrupt_sense_t
<b>Type</b>	Enum
<b>Range:</b>	____
<b>Description:</b>	interrupt sense
<b>Covered requirements:</b>	[SRS_External interrupt_1004]

#### 2. [DD\_External interrupt\_1002]

<b>Name:</b>	E_Error_state
<b>Type</b>	unsigned char
<b>Range:</b>	0...<number of ports>
<b>Description:</b>	check if there error in code or not

<b>Covered requirements:</b>	[SRS_External interrupt_1001], [SRS_External interrupt_1002], [SRS_External interrupt_1003],[SRS_External interrupt_1004]
------------------------------	---

## Function definitions:

### 1- [DD\_External interrupt\_1003]

<b>Service name:</b>	External interrupt 0 initialization
<b>Syntax:</b>	E_Error_state MCAL_EXT_INT_0_init(EN_interrupt_sense_t sense)
<b>Sync/Async:</b>	Synchronous
<b>Re-entrancy:</b>	Re-entrant
<b>Parameters (in):</b>	sense.   input interrupt sense
<b>Parameters (out):</b>	none
<b>Parameters (inout):</b>	none
<b>Return type:</b>	E_Error_state
<b>Description:</b>	Function that initializes the External interrupt
<b>Covered requirements:</b>	[SRS_External interrupt_1001]

### 2- [DD\_External interrupt\_1004]

<b>Service name:</b>	External interrupt 1 initialization
<b>Syntax:</b>	E_Error_state MCAL_EXT_INT_1_init(EN_interrupt_sense_t sense)
<b>Sync/Async:</b>	Synchronous
<b>Re-entrancy:</b>	Re-entrant
<b>Parameters (in):</b>	sense.   input interrupt sense
<b>Parameters (out):</b>	none
<b>Parameters (inout):</b>	none
<b>Return type:</b>	E_Error_state
<b>Description:</b>	Function that initializes the External interrupt
<b>Covered requirements:</b>	[SRS_External interrupt_1002]

**3- [DD\_External interrupt\_1005]**

<b>Service name:</b>	External interrupt 0 initialization
<b>Syntax:</b>	E_Error_state MCAL_EXT_INT_2_init(EN_interrupt_sense_t sense)
<b>Sync/Async:</b>	Synchronous
<b>Re-entrancy:</b>	Re-entrant
<b>Parameters (in):</b>	sense.   input interrupt sense
<b>Parameters (out):</b>	none
<b>Parameters (inout):</b>	none
<b>Return type:</b>	E_Error_state
<b>Description:</b>	Function that initializes the External interrupt
<b>Covered requirements:</b>	[SRS_External interrupt_1003]

**4- [DD\_External interrupt\_1006]**

<b>Service name:</b>	Set call back
<b>Syntax:</b>	E_Error_state MCAL_Ext_INT_setCallBack(void(* ptr_to_ISR_Ext_INT_)(void),ext_int interrupt);
<b>Sync/Async:</b>	Synchronous
<b>Re-entrancy:</b>	Re-entrant
<b>Parameters (in):</b>	void(* ptr_to_ISR_Ext_INT_)(void)  pointer to function , interrupt   to external interrupt
<b>Parameters (out):</b>	none
<b>Parameters (inout):</b>	none
<b>Return type:</b>	E_Error_state
<b>Description:</b>	Function that takes address of the function and sends this function to ISR
<b>Covered requirements:</b>	[SRS_External interrupt_1004]