

Synchronous FIFO

Parameters

- FIFO_WIDTH: DATA in/out and memory word width (default: 16)
- FIFO_DEPTH: Memory depth (default: 8)

Ports

Port	Direction	Function
data_in	Input	Write Data: The input data bus used when writing the FIFO.
wr_en		Write Enable: If the FIFO is not full, asserting this signal causes data (on data_in) to be written into the FIFO
rd_en		Read Enable: If the FIFO is not empty, asserting this signal causes data (on data_out) to be read from the FIFO
clk		Clock signal
rst_n		Active low asynchronous reset (if rst_n is asserted, the FIFO will be empty and empty flag will be asserted)
data_out	Output	Read Data: The sequential output data bus used when reading from the FIFO.
full		Full Flag: When asserted, this combinational output signal indicates that the FIFO is full. Write requests are ignored when the FIFO is full, initiating a write when the FIFO is full is not destructive to the contents of the FIFO.
almostfull		Almost Full: When asserted, this combinational output signal indicates that only one more write can be performed before the FIFO is full.
empty		Empty Flag: When asserted, this combinational output signal indicates that the FIFO is empty. Read requests are ignored when the FIFO is empty, initiating a read while empty is not destructive to the FIFO.
almostempty		Almost Empty: When asserted, this output combinational signal indicates that only one more read can be performed before the FIFO goes to empty.
overflow		Overflow: This sequential output signal indicates that a write request (wr_en) was rejected because the FIFO is full. Overflowing the FIFO is not destructive to the contents of the FIFO.
underflow		Underflow: This sequential output signal Indicates that the read request (rd_en) was rejected because the FIFO is empty. Under flowing the FIFO is not destructive to the FIFO.
wr_ack		Write Acknowledge: This sequential output signal indicates that a write request (wr_en) has succeeded.