



User Manual

Vector Logger Configurator

Version 2.9
English

Imprint

Vector Informatik GmbH
Ingersheimer Straße 24
D-70499 Stuttgart

Vector reserves the right to modify any information and/or data in this user documentation without notice. This documentation nor any of its parts may be reproduced in any form or by any means without the prior written consent of Vector. To the maximum extent permitted under law, all technical data, texts, graphics, images and their design are protected by copyright law, various international treaties and other applicable law. Any unauthorized use may violate copyright and other applicable laws or regulations.

© Copyright 2018, Vector Informatik GmbH. Printed in Germany.
All rights reserved.

Contents

1	Introduction	3
1.1	Vector Logger Configurator Overview	4
1.2	About this User Manual	5
1.2.1	Certification	6
1.2.2	Warranty	6
1.2.3	Support	6
1.2.4	Trademarks	6
2	Overview	7
2.1	General Information	8
2.2	LED Display and Keys	8
2.3	Ring Buffer	9
2.4	Triggered Logging	10
2.4.1	GL Logger	10
2.4.2	VN1630 log	11
2.5	Classification	12
2.6	Long-Term Logging	12
2.7	Operating Mode	15
2.7.1	GL Logger	15
2.7.2	VN1630 log	15
2.8	Data Compression	16
2.9	Filter	16
2.10	Memory Media	16
2.11	Download and Upload	17
2.11.1	GL1000/GL2000 Series	17
2.11.2	GL3000/GL4000/GL5000 Series	17
2.11.3	VN1630 log	18
2.11.4	Logging Formats	18
2.11.5	Automated Sequences	19
2.12	Navigator versus Classic View	19
2.13	Pack&Go	19
2.14	CCP/XCP	20
2.15	Diagnostics	23
2.16	Monitoring Interface	25
2.16.1	Monitoring Mode	25
2.16.2	Signal Sampling Mode	27
3	Vector Logger Configurator	29
3.1	Installation Instructions	30
3.2	Overview	31
3.3	Tree View	31
3.3.1	Hardware	31
3.3.2	General	32
3.3.3	Logging Memory	32
3.3.4	Classification	33
3.3.5	CCP/XCP	33

3.3.6	Diagnostics	33
3.3.7	Output	33
3.3.8	File Manager	34
3.4	Property Panel	35
3.5	Toolbar	35
3.5.1	Real-Time Clock	35
3.5.2	Refresh	36
3.5.3	Representation Dec/Hex	36
3.5.4	Conversion Profiles	36
3.6	General Settings	36
3.7	Support Assistant	36
4	Tutorial	37
4.1	Overview	38
4.2	Tutorial 1: Create a Configuration	38
4.3	Tutorial 2: Download Configuration (GL1000/GL2000 Series)	39
4.4	Tutorial 3: Upload and Convert Logged Data (GL1000/GL2000 Series)	40
4.5	Tutorial 4: Download Configuration (GL3000/GL4000 Series)	40
4.6	Tutorial 5: Upload and Convert Logged Data (GL3000/GL4000 Series)	41
4.7	Tutorial 6: Read out and Download via USB (GL3000/GL4000 Series)	41
4.8	Tutorial 7: Download Configuration (GL5000 Series)	43
4.9	Tutorial 8: Upload and Convert Logged Data (GL5000 Series)	43
4.10	Tutorial 9: Download Configuration (VN 1630 log)	44
4.11	Tutorial 10: Upload and Convert Logged Data (VN1630 log)	44
4.12	Tutorial 11: Configuration with Simple Filter	45
4.13	Tutorial 12: Configuration with Simple Trigger	45
4.14	Tutorial 13: CCP/XCP und Seed & Key (GL Logger)	46
4.14.1	Creation of Configuration	46
4.14.2	Generation of an SKB File	47
4.14.3	Installation of a CCP/XCP License	49
4.15	Tutorial 14: CCP/XCP and Seed & Key with CANape (GL Logger)	50
4.15.1	Generation of a DBC File	50
4.15.2	Generation of a FIBEX File	51
4.15.3	Creation of the Logger Configuration	52
4.16	Tutorial 15: Usage as Interface (GL2000/GL3000/GL4000 Series)	53
4.16.1	Configuration of the Logger	53
4.16.2	Configuration in CANoe/CANalyzer	53
4.17	Tutorial 16: Logging of Diagnostic Data (GL Logger)	55
4.18	Tutorial 17: Configuration of the 3G Data Transmission (GL2000 Series)	56
4.18.1	Configuration of the Logger	56
4.18.2	Connections and Displays of the Sierra Wireless AirLink LS300	56
4.18.3	Configuration of the 3G Router	58
4.19	Tutorial 18: Record images with a HostCAM (GL3000/GL4000/GL5000 Series)	60
4.19.1	Setting up the HostCAM	60
4.19.2	Configuration of a Triggered Capturing	62
4.19.3	Configuration of a Long-term Capturing	64
5	Index	67

1 Introduction

In this chapter you find the following information:

1.1	Vector Logger Configurator Overview	page 4
1.2	About this User Manual	page 5
	Certification	
	Warranty	
	Support	
	Trademarks	

1.1 Vector Logger Configurator Overview


Vector Logger Configurator

The **Vector Logger Configurator** is a tool to create easy configurations for the compact loggers of the **GL1000/GL2000** series and the multibus logger of the **GL3000/GL4000/GL5000** series. Additionally it is already prepared for the logging functionality of the **VN1630 log** interface when operating in standalone mode.

With the **Vector Logger Configurator** hardware settings for CAN, CAN FD, LIN, FlexRay and MOST150 channels can be set. Filter and trigger conditions, logging of analog and digital inputs, diagnostic data and CCP/XCP measurements can be configured. Additionally LEDs can be set to visualize certain events. The settings depend on the device type.

Readout of the logging data is supported as well as conversion to several logging formats.

Screenshot



1.2 About this User Manual

To find information quickly








The user manual provides you the following access helps:

- > At the beginning of each chapter you will find a summary of the contents,
- > In the header you can see the current chapter and section,
- > In the footer you can see to which version the user manual replies,
- > At the end of the user manual you will find an index.

Conventions

In the two following charts you will find the conventions used in the user manual regarding utilized spellings and symbols.

Style	Utilization
bold	Blocks, surface elements, window- and dialog names of the software. Accentuation of warnings and advices. [OK] Push buttons in brackets File Save Notation for menus and menu entries
Windows	Legally protected proper names and side notes.
Source code	File name and source code.
Hyperlink	Hyperlinks and references.
<STRG>+<S>	Notation for shortcuts.

Symbol	Utilization
	Here you can obtain supplemental information.
	This symbol calls your attention to warnings.
	Here you can find additional information.
	Here is an example that has been prepared for you.
	Step-by-step instructions provide assistance at these points.
	Instructions on editing files are found at these points.
	This symbol warns you not to edit the specified file.

1.2.1 Certification

Certified Quality Management System Vector Informatik GmbH has ISO 9001:2008 certification. The ISO standard is a globally recognized standard.

1.2.2 Warranty

Restriction of warranty We reserve the right to modify the contents of the documentation or the software without notice. Vector disclaims all liabilities for the completeness or correctness of the contents and for damages which may result from the use of this documentation.

1.2.3 Support

You need support? You can get through to our hotline at the phone number +49 711 80670-200 or you write an email to support@vector.com.

1.2.4 Trademarks

Protected trademarks All brand names in this documentation are either registered or non registered trademarks of their respective owners.

2 Overview

In this chapter you find the following information:

2.1	General Information	page 8
2.2	LED Display and Keys	page 8
2.3	Ring Buffer	page 9
2.4	Triggered Logging	page 10
	GL Logger	
	VN1630 log	
2.5	Classification	page 12
2.6	Long-Term Logging	page 12
2.7	Operating Mode	page 15
	GL Logger	
	VN1630 log	
2.8	Data Compression	page 16
2.9	Filter	page 16
2.10	Memory Media	page 16
2.11	Download and Upload	page 17
	GL1000/GL2000 Series	
	GL3000/GL4000/GL5000 Series	
	VN1630 log	
	Logging Formats	
	Automated Sequences	
2.12	Navigator versus Classic View	page 19
2.13	Pack&Go	page 19
2.14	CCP/XCP	page 20
2.15	Diagnostics	page 23
2.16	Monitoring Interface	page 25
	Monitoring Mode	
	Signal Sampling Mode	

2.1 General Information

Logger The **Vector Logger Configurator** allows the configuration of the loggers of the **GL1000/GL2000/GL3000/GL4000/GL5000** series and for the logging functionality of the **VN1630 log** interface. The following sections describe the hardware specific features of the loggers.

2.2 LED Display and Keys

LED display GL1000 series The logger has five LEDs. LED 1 to LED 4 are freely programmable. The LEDs can be assigned to different events like trigger active or CAN/LIN errors. LED **USB** indicates the connection to the PC and is not programmable. Please refer to the **User Manual GL1000/GL1010** for more details about the meaning of this LED.

LED display GL2000 series The logger has six LEDs. LED 1 to LED 4 are freely programmable. The LEDs can be assigned to different events like trigger active or CAN/LIN errors. LED **USB** indicates the connection to the PC, and LED **Power** the status of the power supply. These two LEDs are not programmable. Please refer to the **User Manual GL2000** for more details about the meaning of this LED.

LED display GL3000/GL4000/GL5000 series The logger has five red LEDs that are freely programmable. The LEDs can be assigned to different events like trigger active or CAN/LIN/FlexRay errors.

LED display VN1630 log The VN1630 log has five LEDs indicating bus activities and status as well as one LED for the logging mode. The LEDs are not configurable.
Please refer to the user manual of the **VN16000** interface family for more details about the meaning of the LEDs.

Event keys GL3000/GL4000/GL5000 series The **GL3100/GL3200** and the **GL4000/GL5000** series loggers feature four programmable event buttons on the front panel. These buttons can be used as triggers, for example.

2.3 Ring Buffer

Concept

A ring buffer is a certain memory area where logging data is stored. If the end of this memory area is reached, the oldest data from the beginning of the area is overwritten. Thus, the ring buffer contains always the latest logged data.




GL1000/GL2000 series

The ring buffer sizes can be configured between 2 MB and 2 GB. The ring buffer is directly written on the SD card, not in the RAM of the logger.

GL3000/GL4000/GL5000 series

The **GL3000/GL4000/GL5000** series contains two ring buffers (memory 1 and memory 2) in the RAM that can be configured independently. The size of each ring buffer can be set between 1 MB and 117 MB (**GL3000** series) or 234 MB (**GL4000** series) or 390 MB (**GL5000** series). The sum of the two ring buffers (Memory1_Block1 + Memory2_Block1) must not exceed 117 MB or 234 MB or 390 MB. The ring buffer is created in the RAM of the logger and written to the memory medium when a trigger occurs.

Every ring buffer is installed twice, that means in block 1 and block 2. While the saving process of the data of one ring buffer block to the memory medium the new data is written to the other ring buffer block. With this procedure no data loss occurs while saving the data of a ring buffer block.



VN1630 log

The ring buffer is installed on the RAM of the device with the size of 32 MB. The maximum size of the logging file is configurable.

Data is written to the memory when a trigger occurs. At a permanent long-term logging data are buffered shortly and afterwards written to the memory card.

2.4 Triggered Logging


2.4.1 GL Logger

Concept

If a certain event occurs, writing to the ring buffer is stopped. This event is called a trigger. When a trigger event occurs the ring buffer is closed, i.e. data storage to the ring buffer is stopped and the data in the ring buffer is stored as a triggered file. New logging data is stored to a new empty ring buffer.

The ring buffer can be configured to continue logging for a defined post-trigger time after the trigger event. In this case, the ring buffer is not closed when the trigger event occurs, but after the post-trigger time.

This trigger behavior applies to the **Triggered Logging** mode. With the **Conditioned long-term logging** mode trigger types are used which directly start and stop the data logging.



If a trigger event occurs after just a brief time and the end of the ring buffer has not yet been reached, the logging file will be smaller than the specified ring buffer size. If a trigger event occurs after a longer time, i.e. the data in the ring buffer have been overwritten one or more times, the size of the logging file corresponds to that of the ring buffer.

Various trigger events can be defined and parameterized in the **Vector Logger Configurator**, e.g. on receiving a certain message or if a certain value in a signal is reached.

The trigger concept saves a lot of memory space, since data doesn't need to be recorded over all of the time, but only on events of interest.

Triggered logging


In order to use triggers for logging the logging mode must be set to **Triggered logging**. Closed (also called "triggered") ring buffers are stored as a log file. At the end of the logging session an open ring buffer may remain. This open ring buffer is stored to a log file, too.

Pre-trigger time

The pre-trigger time describes the time to be recorded before a trigger event.

Post-trigger time

The post-trigger time describes the time to be recorded after a trigger event. After the post-trigger time elapses the current ring buffer is closed and a new ring buffer is started.



The **Vector Logger Configurator** supports the configuration of the post-trigger time only. The pre-trigger time results from the rest of the ring buffer which is recorded before the trigger occurred. A calculator is available for the estimation of the needed ring buffer size.

2.4.2 VN1630 log**Concept**

If a certain trigger event occurs, data from the ring buffer is written to the memory card according to the set pre-trigger-time. Afterwards data is written for the duration of the post-trigger time to the same file. Data is stored as a triggered file. New logging data is stored to ring buffer until the next trigger.

Various trigger events can be defined and parameterized in the **Vector Logger Configurator**, e.g. on receiving a certain message or if a certain value in a signal is reached.

The trigger concept saves a lot of memory space, since data doesn't need to be recorded over all of the time, but only on events of interest.

Triggered logging

In order to use triggers for recording the logging mode must be set to **Triggered logging**. Triggered ring buffers are stored as a log file. At the end of the logging session an open ring buffer may remain. This open ring buffer is not stored to a log file.

Pre-trigger time

The pre-trigger time describes the time to be recorded before a trigger event. If a trigger event occurs after just a brief time and the pre-trigger time has not been reached, the logging file therefore contains less data accordingly.

Post-trigger time

The post-trigger time describes the time to be recorded after a trigger event. After the post-trigger time elapses the current logging file ring buffer is closed. New data is written to the ring buffer again.

The **Vector Logger Configurator** supports the configuration of the post-trigger time only. The pre-trigger time is limited by the size of the RAM. A calculator is available for the estimation whether the RAM size is big enough for the wanted pre-trigger time. If during the recording the RAM is faster filled up than expected, e.g. the bus load is higher than expected, the oldest data is deleted and thus the pre-trigger time shortened.

2.5 Classification

Concept

Loggers of the **GL2000/GL3000/GL4000/GL5000** series support the recording of classifications.

With classifications you can define statistic evaluations of signals and signal conditions which are executed during the complete measurement time. The results are stored in a compact form and therefore require little memory space. The memory requirement is constant, i.e. it is independent of the measurement duration. When reading out the data, a separate text file is generated for each configured classification task. The text file displays the results in tabular form, and can, for example, be read directly into **Microsoft Excel** and displayed immediately.

2.6 Long-Term Logging

Permanent long-term logging


Alternative to recordings with triggers you can record the complete data traffic from measurement start continuously in a permanent long-term logging without gaps. Therefore the logging mode is set to **Permanent long-term logging**. In this mode all configured triggers are switched off.

GL Logger

In order to record the data traffic without gaps, ring buffers are still used internally. As soon as the ring buffer is completely filled, it is triggered and the recording is immediately continued to the next ring buffer without gaps. For **permanent long-term logging** the **Vector Logger Configurator** uses the configured ring buffer size. The post-trigger time is not used. Permanent long-term logging is a chain of ring buffers without gap. Due to this the **File Manager** of the **Vector Logger Configurator** displays the logging data not as one big file per test-drive but as many single files each of the same ring buffer size.

If the logger changes to sleep mode, the current ring buffer will be triggered in advance even if the buffer was not completely full. The file is marked as end of test-drive and will be stored. At the next logger start, a new ring buffer is started.

At read out and conversion in the **File Manager** the **Vector Logger Configurator** identifies that a **permanent long-term logging** was done and assembles all single files of a test-drive that were logged between switching on and off of the logger (or sleep/wake up) to one big file for that test-drive.



With the **Separate files for each ring buffer** option it is possible to read out the logged data in single files per ring buffer. This option makes it easier to analyze the logging data if needed.

VN1630 log

Data traffic is recorded continuously. As soon as the defined maximum size of the file is reached the recording is immediately continued to the next logging file without gaps. The **Vector Logger Configurator** displays in the **File Manager** the individual logging files.

Conditioned long-term logging

Alternatively the permanent long-term logging of the data traffic can be started with a start condition (**logging on**) and stopped with a stop condition (**logging off**). For that the logging mode is switched to **Conditioned long-term logging**.


For each memory only one start trigger and one stop trigger can be configured. After one of these triggers occurred it is inactive until its counterpart is activated.

GL Logger

As for the **permanent long-term logging**, for the logging ring buffers are still used internally. As soon as the ring buffer is completely filled, it is triggered and the recording is immediately continued to the next ring buffer without gaps. For this the **Vector Logger Configurator** uses the configured ring buffer size. The post-trigger time is not used. The **File Manager** of the **Vector Logger Configurator** displays the logging data not as one big file per logging block but as many single files each of the same ring buffer size.

If the logger changes to sleep mode while logging (after **logging on**), the current ring buffer is triggered even if the buffer was not completely full and the **logging off** condition was not fulfilled. The file is marked as end of the logging (same as for **logging off**) and will be stored. At the next logger start the **logging on** condition must be fulfilled before a new logging will be started.

At read out and conversion in the **File Manager** the **Vector Logger Configurator** identifies that a permanent long-term logging (**conditioned long-term logging**) was done and assembles all single files of each logging block between **logging on** and **logging off** to one big file per logging block.



With the **Separate files for each ring buffer** option it is possible to read out the data in single files per ring buffer. This option makes it easier to analyze the logging data if needed.

VN1630 log

As for the **permanent long-term logging**, data is recorded continuously in single files. Recording is started with the condition **logging on** and stopped with the condition **logging off**.



Note for GL1000: The logger writes the data directly to the memory card. When the logger is disconnected from power during recording, the last ring buffer is not lost, but the marker for the end of logging (**permanent long-term logging** or **conditioned long-term logging**) gets lost. The logger will identify the power interruption at the next start and will add the marker. Thus in spite of the power interruption, the assembly of the single ring buffers per test-drive/logging block is possible because the **Vector Logger Configurator** requires the end markers to identify and separate the test drives/logging blocks on conversion.



Note for GL2000: The logger writes the data directly to the memory card. When the logger is disconnected from power during recording, the USV provides for a few seconds that the data of the last ring buffer is logged completely. The marker for the end of logging (**permanent long-term logging** or **conditioned long-term logging**) is also stored. So the assembly of the single ring buffers per test-drive/logging block is possible in the **Vector Logger Configurator**.



Note for GL3000/GL4000/GL5000: When the logger is disconnected from power during recording, the last ring buffer is not saved from the RAM to the memory card. Thus the data from the last ring buffer is lost.

At a permanent long-term logging (**permanent long-term logging** or **conditioned long-term logging**) the marker for the end of logging gets lost too. The assembly of the single ring buffers per test-drive/logging block is no longer possible because the **Vector Logger Configurator** requires the end markers to identify and separate the test drives/logging blocks on conversion.

Please make sure that the **GL3000/GL4000/GL5000** went to sleep before disconnecting power. Alternatively you can open the front panel while the logger is still supplied by power to force a regular shutdown and writing of the last ring buffer to the memory card.

Marker

Markers are available for GL Loggers (**GL1000** series excluded). Like triggers, markers are defined for certain events when the logger is configured. However, they do not trigger a new recording (trigger file) but merely mark a point in time within a long-term logging. As a result, you have more flexibility in the selection of pre- and post-trigger time for the readout. However, the long-term logging causes more memory space to be occupied on the memory card.

Markers are only available in the Navigator and help you to quickly locate for the conversion the time areas of interest.

2.7 Operating Mode

2.7.1 GL Logger

Operating mode The loggers have two operating modes for handling the situation of a full memory medium:


- > **Stop logging** mode
- > **Overwrite** mode

The operating modes apply to all logging modes (**Triggered logging**, **Conditioned long-term logging** and **Permanent long-term logging**).

Stop Logging mode With the setting **Stop logging** the logger records data until the memory medium is full. On full memory medium, no further trigger and no logging condition will be considered. This avoids overwriting recorded triggered files on the memory medium.

Overwrite mode With the setting **Overwrite oldest** the logger records data in ring buffers until the memory medium is full. On full memory card, the oldest triggered file is deleted and the new data is stored. This mode allows keeping always the newest log files on the memory medium while oldest log files are overwritten. Overwrite mode is the default setting for a new configuration in the **Vector Logger Configurator**.

Logging modes The following figure visualizes the differences between the logging modes:



2.7.2 VN1630 log

Operating mode The **VN1630 log** records data until the memory card is full. This avoids overwriting recorded files.

This operating mode applies to all logging modes (**Triggered logging**, **Conditioned long-term logging** and **Permanent long-term logging**).

2.8 Data Compression

GL3000/GL4000/ GL5000 series

The **GL3000/GL4000/GL5000** series supports the optional compression of the logging files to save space on the memory card. In the same way the transmission time at the read out via WLAN/LTE can be reduced. After the read out of the memory card with the **File Manager** the files will be decompressed automatically.

2.9 Filter

Concept

With the **Vector Logger Configurator** you can use filter on CAN messages, LIN messages and FlexRay frames/PDUs to reduce the amount of logged data. Due to this the possible logging time is extended. The different filters influence the recording of messages only. Messages with **Stop** filter are not recorded. Messages with **Limit** filter (GL Logger only) are logged with reduced rate. All other messages are completely stored.

The filters do not influence the trigger, because the logger receives all messages. After reception of a message the trigger conditions are checked. A message can cause a trigger even if it is not recorded due to a **Stop** filter.

2.10 Memory Media

GL1000/GL1010

The **GL1000/GL1010** uses an SD/SDHC card for storing logging data. For more information about supported SD/SDHC cards please see the user manual of the **GL1000/GL1010**.



Info: Please do not remove or exchange the SD/SDHC card in the **GL1000/GL1010** during operation in the logging mode. This may cause loss of data!

GL2000/GL2010

The **GL2000/GL2010** uses an SD/SDHC card for storing logging data. For more information about supported SD/SDHC cards please see the user manual of the **GL2000**.

GL3000/GL3100/ GL4000

The **GL3000/GL3100/GL4000** saves the logging data to a Compact Flash card (CF card). The slot for the Compact Flash card is located behind the front access panel. Alternatively an USB memory medium can be connected.

GL3200/GL4200/ GL5350

The **GL3200/GL4200/GL5350** saves the logging data on a removable disk (SSD). The slot therefore is located behind the front access panel.

VN1630 log

The **VN1630 log** uses an SD/SDHC card for storing logging data. For more information about supported SD/SDHC cards please see the user manual of the **VN1600** interface family.

Memory size

Please note that the listed capacity of the CF/SD cards (e.g. 2 GB) may not match the actual available memory size. Some parts of the memory card are used for administration and other functions.

The listed capacity printed on the memory medium is calculated with 1 GB = 1 billion bytes, 1 MB = 1 million bytes. This calculation differs from the common calculation in **Windows** with 1 GB = 1024 MB, 1 MB = 1024 KB, 1 KB = 1024 Byte. This formula known from **Windows** is also used in the **Vector Logger Configurator** for the calculation of the available card memory.

2.11 Download and Upload

2.11.1 GL1000/GL2000 Series

Download

The configuration can be loaded to the logger of the **GL1000/GL2000** series by USB interface. Therefore the logger must be connected to the USB port of the PC. Alternatively the configuration can be stored to an SD card in a card reader. In both cases the configuration is stored to the SD card first and will be updated in the logger on the next start in logging mode. If the configuration is updated on start of the logger, the effective start-up time (the time from power-up until recording of the first data frame) is extended.

Upload

The **Vector Logger Configurator** allows the upload of recorded logging data from the logger or SD card of the PC.

For uploading the logging data from the logger, the logger must be connected to the USB port of the PC. The data is uploaded in a raw format first, and automatically converted to the desired logging format afterwards.

For more information about the upload of logging data please see section **3.3.7 File Manager**.

2.11.2 GL3000/GL4000/GL5000 Series

**Download
GL3000/GL3100/
GL4000**

The configuration is saved for the **GL3000/GL3100/GL4000** to a Compact Flash card in the card reader. This card is then inserted into the logger.

The logger supports a download also via USB (USB port located behind the front access panel). Therefore the logger has to be switched on.

The front access panel must then be closed. The next time the logger is started in logging mode, the configuration is checked and updated if it is okay.

Please refer to

Tutorial 5: Upload and Convert Logged Data (GL3000/GL4000 Series) in section **4.6** and the online help for more information about configuration download.

**Upload
GL3000/GL3100/
GL4000**

The **Vector Logger Configurator** supports the readout of the recorded data from the Compact Flash card in the card reader. The data is read out in raw format and then converted automatically to the desired logging format.

The logger supports the data read out also via USB (USB port located behind the front access panel). Therefore the logger has to be switched on.

**Download
GL3200/GL4200/
GL5000**

The configuration for the **GL3200/GL4200/GL5000** is saved to a removable disk (SSD) that is connected to the **eSATA** interface (with external power supply) on the PC. It is then inserted into the logger. The front access panel must then be closed. The next time the logger is started in logging mode, the configuration will be checked and, if okay, updated.

**Upload
GL3200/GL4200/
GL5000**

The **Vector Logger Configurator** supports readout of recorded data from the SSD connected to the PC. The data are read out in raw format and then converted automatically to the desired logging format.

2.11.3 VN1630 log**Download**

The configuration can be loaded to the SD card in the **VN1630 log** by USB interface. Therefore the device must be connected to the USB port of the PC. Alternatively the configuration can be stored to an SD card in a card reader. In both cases the configuration is stored to the SD card. On each start of the device in logging mode, the configuration is read from the SD card. Please note, that recording can only be started with a configuration on the inserted SD card.

Upload

The **Vector Logger Configurator** allows the configuration of the device and the upload of recorded data from the device or memory card to the PC.

For uploading the logging data from the **VN1630 log**, it must be connected to the USB port of the PC. The data is uploaded in a raw format first, and automatically converted to the desired logging format afterwards.

For more information about the upload of logging data please see section **3.3.7 File Manager**.

2.11.4 Logging Formats**Overview**

The logged data can be converted to the following formats.

Formats	GL1000	GL2000	GL3000/GL4000/ GL5000	VN1630 log
ASC	Yes	Yes	Yes	Yes
BLF	Yes	Yes	Yes	Yes
MDF	MDF versions 2.0 to 4.1 ¹			MDF 4.1 ²
IMG	No	No	Yes	No
TXT	Yes	Yes	Yes	No
CLF	Yes	Yes	Yes	No
MAT ³	Yes	Yes	Yes	No
HDF5	Yes	Yes	Yes	No
ADTF	Yes	Yes	Yes	No

¹ signal-oriented, with version 4 also message-oriented

² message-oriented

³ MALTLAB® v7.3

2.11.5 Automated Sequences

GL Logger

The option exists for all GL Loggers to use the Win32 console program **CLexport**, for example, to convert the recorded raw data for automated sequences. This program is included in the installation directory of the **Vector Logger Configurator**. **CLexport** and other Win32 console programs are described in detail in the user manual of the G.i.N. Configuration Program.

2.12 Navigator versus Classic View

Overview

The **File Manager** enables logging files on memory cards and the SSD to be displayed, transferred to the PC, and converted to the various formats with the selected settings. The settings can be stored in conversion profiles.

The classic view is available for all GL Loggers and **VN1630 log**. For the **GL2000/GL3000/GL4000/GL5000** series, the Navigator is additionally available.

Classic View

When conversion is carried out in this view, all logging files are always transferred from the memory medium to the PC and then converted to the selected format. The logging files can be additionally saved as a raw file on the PC. This gives you the option of converting data from this format to other formats at a later time.

Navigator

With the Navigator, you can have more information on the recorded logging data displayed before the conversion is carried out. You thus get a quick overview of the number of messages that were recorded over a particular time period.

In addition, you can use the Navigator to make a targeted selection of the data to be read out. You do not have to read out the entire memory card but can limit the readout to the areas of interest. Markers will help you to quickly locate the time ranges of interest. By including less data, the readout and conversion are completed much faster.

In order to convert the logging files to other formats at a later time, you must copy all original files from the memory medium to the hard disk.

2.13 Pack&Go

Overview

With Pack&Go, you can export your logger project, consisting of the configuration (GLC) and all its referenced project files (e.g. databases), as a Pack&Go file and then load it together with the compiled configuration to the logger during configuring. Thus, on a test drive you will have with you on the logger all the files that are needed to view the configuration, change the configuration, or analyze the log data with the appropriate databases.

You can also save the Pack&Go file on your hard disk in order to forward your logger project along with its associated files in a compact form to a colleague.

To protect the data on the logger from unauthorized access, you can assign a password to the Pack&Go file. Likewise, you can exclude certain file types from the export if their export is not desired for safety reasons. For example, it is possible to save only the configuration (GLC) and not the databases on the logger. Please note for changing the configuration all files must be available.



Note: When the Pack&Go file is written to the logger, it is stored on the memory card. When a memory card is replaced, the Pack&Go file is not automatically copied to the new memory card! That is, the Pack&Go file is not present on the new memory card. Please note this in particular, when you are using multiple memory cards in your loggers.

2.14 CCP/XCP

Overview

The GL Loggers (except **GL1020FTE**) support reading out of ECU-internal data via CCP/XCP.

The CAN Calibration Protocol (CCP) supports reading of internal ECU process or measurement variables and writing of control parameters to the ECU memory via CAN.

XCP (Universal Measurement and Calibration Protocol) is an extension and advanced development of CCP for further bus systems.

The Vector loggers support reading data from the ECU using DAQ and polling mode.

Configuration

With the **Vector Logger Configurator** you can configure the loggers for the measurement of ECU-related data using the CCP or XCP protocol.

You have the following options for this:

1. Direct use of an ECU description (ASAP2 file)

The ECU that is addressed via CCP/XCP is defined by inserting the ASAP2 file (A2L) into the **Vector Logger Configurator**. For every ECU the important protocol and ECU settings can be made here. Afterwards the signals to be measured will be selected and displayed in a measurement list. With this configuration procedure you can change the measurement list at any time.

2. CCP/XCP measurement configuration with **CANape**

The setting of the CCP/XCP protocol parameters and the assembling of the measurement list is carried out in **CANape**. The A2L file of an ECU is loaded in **CANape** and the signals to be measured are selected. **CANape** generates afterwards for CCP/XCP on CAN a DBC file with special attributes to initialize the ECU with the logger. This DBC file is added in the **Vector Logger Configurator**. With this configuration procedure you can only change the measurement list in **CANape**.

The DBC file reflects the current configuration of the measurement data to exactly one control unit, which the user has configured in **CANape**. This means that the DBC file will change if the **CANape** configuration changes. Please note that the DBC file doesn't contain the complete description of this control unit. You have to create one DBC file for each control unit to read data from several control units. The names of the DBC files have to be renamed if necessary.

At both configuration procedures for XCP on FlexRay additional information will be added to the FIBEX file.

Seed & Key

To prevent access to controller data by unauthorized persons, some controllers (ECUs) have access protection, which can be activated via a Seed & Key procedure. This procedure provides for the measurement and calibration system first to query a value from the controller (Get Seed For Key) in order to calculate a key from it, which is then sent back to the controller (Unlock Protection). The controller then only allows access to its data when the key calculated by the measurement and calibration system matches the self-calculated key, i.e. when the measurement and calibration system knows the procedure for calculating the key.

The CCP/XCP communication between Vector loggers and ECUs can be protected by Seed & Key algorithms. In **CANape** a DLL with Seed & Key is required for encryption. The logger cannot use this DLL which is designed for the PC for calculating the necessary key. An SKB file is used instead which has to be programmed in **CANape**. Therefore the Seed & Key algorithm must be known.



Cross reference: You can find further information about CCP/XCP and Seed & Key in the Tutorial 13: CCP/XCP und Seed & Key in chapter 4.14.

VX measurement hardware

With the **GL3000/GL4000/GL5000** series and the VX measurement hardware from Vector, you can record internal ECU signals (variables, parameters) in parallel with bus communication. The ECU signals are measured using a POD (plug-on device), which for its part uses microcontroller-specific data trace or debug interfaces of the ECU. The connection of the logger to the VX module is by means of Ethernet and uses the XCP on UDP protocol.

When you paste the A2L file in the **Vector Logger Configurator** you can select if the VX measurement hardware should be used.

Execution

On its start the logger automatically establishes a CCP/XCP connection – for protected ECUs the Seed & Key algorithm is used.

With DAQ mode the control unit sends the requested data as DTO messages (**Data Transmit Object**) with the given cycle time. The DTO messages are logged or processed as defined in the logger configuration.

The logger requests from the ECU the measurement data in polling mode with the specified cycle time. After the request the ECU will send the requested data. Minimum one measurement value has to be configured in DAQ mode.

FAQ

Measurement mode	DAQ (d ata a cquisition) mode: for all transport types Polling mode: for CCP and XCP on CAN
Supported CCP version	CCP 2.0 und CCP 2.1
Supported XCP version	XCP 1.0 and higher
File format	A2L: This file in ASAP2 format describes signals and CCP/XCP interfaces of the ECU. FIBEX: Description of the bus communication for XCP on FlexRay and XCP on Ethernet in XML format.
Number of ECUs	Multiple ECUs possible

Supported logger

The Vector loggers support CCP/XCP and Seed & Key as follows:

Logger	CCP	XCP on CAN	XCP on FR	XCP on Ethernet
GL1000 series	Yes	Yes	No	No
GL2000 series	Yes	Yes	No	No
GL3000 series	Yes	Yes	No	Yes
GL4000 series	Yes	Yes	Yes	Yes
GL5000 series	Yes	Yes	Yes	Yes

Logger	Seed & Key	VX Measurement Hardware
GL1000 series	Yes	No
GL2000 series	Yes	No
GL3000 series	Yes	Yes
GL4000 series	Yes	Yes
GL5000 series	Yes	Yes



Note: Please note, that for support of CCP/XCP a license must be obtained separately to the logger itself.

Requirements without Seed & Key

For the configuration of CCP/XCP without Seed & Key the following items are required for the direct use of an ECU description:

- > Logger that supports CCP/XCP
- > CCP/XCP license for this logger
- > **Vector Logger Configurator**
- > A2L file describing the not protected ECU

Requirements with Seed & Key

For the configuration of CCP/XCP with Seed & Key the following items are required for the direct use of an ECU description:

- > Logger that supports CCP/XCP and Seed & Key
- > CCP/XCP license for this logger
- > **Vector Logger Configurator**
- > Vector **CANape** 8.0 or higher for the creation of an SKB file
- > A2L file describing the Seed & Key protected ECU
- > ECU (hardware) with Seed & Key protection, for access by **CANape**
- > Seed & Key algorithm must be known

2.15 Diagnostics

Concept

The GL Loggers (except **GL1020FTE**) support reading out of control unit-internal data by means of diagnostic services via the CAN bus. To prevent inadvertent write accesses to control units and resulting changes in the control unit software, the **Vector Logger Configurator** provides only **reading diagnostic services**. The following diagnostic data can be read out:

- > Identification data
- > Measurement values
- > Fault memory (without environment data)

The **diagnostic descriptions** contain information regarding the diagnostic services, i.e. the diagnostic requests to be supported, possible responses, and their interpretation. They also usually contain the communication parameters, such as CAN identifiers and Timings. The diagnostic descriptions are loaded in the **Vector Logger Configurator** in either CANdela (CDD) format, ODX/PDX or MDX format. While only one control unit is usually described in **CDD** and **ODX** files, several control units can be described in a **PDX** or **MDX** file, e.g. all control units within a vehicle. In this case, the control units to which the logger is to send diagnostic services can be selected.

If present, the **Vector Logger Configurator** adopts the **communication parameters** automatically from the diagnostic description. If these parameters are incomplete, the preset values of the missing parameters must be checked and changed, if required. Alternatively, the parameters can also be entered completely manually. In either case, it is recommended that the values of the communication parameters should be checked for completeness and correctness after a new diagnostic description is added.

The GL Loggers also support On-Board Diagnostics (OBD II). This has the advantage that no diagnostic description is required for the configuration of the available diagnostic requests.

Diagnostic request lists are then configured. A list contains those diagnostic requests that are to be sent when a particular event occurs. You can define which data the logger requests either through the response parameter (signal request) directly or through specification of the diagnostic service (service request). The list may contain diagnostic requests for various control units on different CAN buses. Examples of events include the start of the logger (if necessary, with a time delay), a cyclic timer, the receipt of a certain message, or the fulfillment of a signal condition. As soon as an event occurs, the requests in the list are sent one after the other. The logger always waits for the response of a service before it sends the next request in the list. If a response is missing, the logger waits for a timeout. Likewise, a new list is only begun after the current list has been completely processed.

The **diagnostic data** are saved in the logging files as raw messages synchronously with the other messages.

Diagnostic protocol

The control units can be read out using the supported diagnostic protocols

- > KWP2000 (Keyword Protocol 2000) and
- > UDS (Unified Diagnostic Services)
- > OBD II

The diagnostic protocol is usually contained in the diagnostic description. It can be manually set, if required.

For OBD II no diagnostic description is required.

Transport protocol The loggers support diagnostics using the ISO-TP transport protocol.

The following addressing modes are supported for this:

- > Normal
- > Normal fixed
- > Extended

Session type Diagnostic services are supported in the following sessions:

- > Default
- > Extended

A session is generally already assigned to each diagnostic service in the diagnostic description. The **Vector Logger Configurator** automatically adopts the session from there. It can also be manually set, if required.

The logger assumes the complete session management. Prior to communication with a control unit, it automatically starts the required session and changes it if necessary.

External diagnostic tester For the case that another node on the CAN bus sends diagnostic services to the control units in parallel with the logger, the logger immediately stops sending all of its diagnostic requests. If after a specified timeout the logger no longer receives diagnostic communication between the other node and the control units, it starts processing the appropriate diagnostic service lists again after the configured events occur.

Offline analysis The **Vector Logger Configurator** converts the log files to the message-oriented formats ASC, BLF and TXT and via virtual CAN messages signal-oriented to MDF and TXT.

The symbolic interpretation of the diagnostic data from the log files takes place, e.g. in **CANoe/CANalyzer**. **CANoe/CANalyzer** also requires the diagnostic descriptions for this.

For signal based recordings of diagnostic data no diagnostic description is required, but only the analysis package created by the **Vector Logger Configurator**.

Diagnostic descriptions The following diagnostic descriptions are supported:

Diagnostic descriptions	Version number	Remarks
CDD	up to V7.1	CANdela
ODX	V2.0.1, V2.2.0	
MDX	V3.0	

Requirements The loggers support diagnostics as of the following firmware versions:

Component	Version number	Remarks
GL1000 Firmware	V1.26	GL1000_126.COD
GL2000 Firmware	V1.00	GL2000_100.COD
GL3000 Firmware	V1.66	GL3000_166.COD
GL4000 Firmware	V1.66	GL4000_166.COD
GL5000 Firmware	V0.52	GL5000_052.COD

2.16 Monitoring Interface

Logger as bus interface	<p>Loggers of the GL2000/GL3000/GL4000 series support a monitoring mode that makes it possible to use the loggers in CANoe/CANalyzer as bus interface for monitoring mode. The GL3000/GL4000/GL5000 series support the signal sampling mode.</p> <p>The logger is connected via Ethernet to the CANoe/CANalyzer PC and sends after measurement start the bus data to CANoe/CANalyzer, where the data can be analyzed in the measurement setup. Sending messages with CANoe/CANalyzer is not possible.</p>
Supported bus systems and licenses	<p>Depending on the mode the bus systems CAN, LIN, FlexRay and MOST150 are supported. The relevant CANoe/CANalyzer licenses must be provided by a connected hardware interface on the PC or by a license dongle. A combined operation of loggers and other hardware interfaces in CANoe/CANalyzer is not possible.</p>

2.16.1 Monitoring Mode

Monitoring mode	<p>In monitoring mode, the logger transfers all incoming data such as messages and Error Frames. The bus systems CAN, LIN, FlexRay and MOST150 are supported.</p> <p>During the measurement, the logger does not record any data in the ring buffer. Classifications are also continued during the measurement. The following sections describe which logger functions are limited, or will not run or will run with different behavior to normal logger operation.</p>
Logger functions	<p>The following functions do not work or work with restrictions:</p> <ul style="list-style-type: none"> > Logging in Memory 1 and Memory 2 > Logging of virtual CAN messages (e.g. analog inputs or date/time) > Logging of error frames > Tachograph > Sleep mode > VoCAN, CASM2T3L <p>The following functions have unrestricted functionality:</p> <ul style="list-style-type: none"> > Classification > CCP/XCP > Diagnostics > Sending of CAN messages (by the Logger, not by CANoe/CANalyzer) > Gateway configurations > Camera (HostCAM/F44/CAMlog2) > LOGview
Logging	<p>In monitoring mode logging in Memory 1 and Memory 2 is stopped. In this time the logger doesn't control the trigger condition.</p> <p>However classifications are continued. In the logging file begin and end of a monitoring mode is marked by the logger with a specific, virtual CAN message. The message ID and channel of this virtual can be set with the Vector Logger Configurator.</p>

Filter	Filters defined for CAN, LIN and FlexRay in the logger configuration have no effect on the data that are sent to CANoe/CANalyzer . So CANoe/CANalyzer displays unfiltered all available messages on the connected CAN, LIN and FlexRay busses.
Virtual messages	Data from internal CAN messages (e.g. signals of the analog and digital inputs) are visible in CANoe/CANalyzer if the corresponding Tx event is activated in the Vector Logger Configurator .
Send messages	<p>Messages that are sent by the logger in logging mode are also sent in monitoring mode. In the Trace window of CANoe/CANalyzer these messages are displayed as Tx messages (if configured).</p> <p>Virtual messages that are not sent on the real bus by the logger but logged only in the ring buffer in logging mode are also displayed (if configured) in CANoe/CANalyzer as Tx messages (e.g. logging of date/time or analog inputs). Since the logger can send virtual messages also on the virtual channels CAN10 - CAN16, these channels are also completely displayed in CANoe/CANalyzer.</p> <p>Since the logger can also send messages in monitoring mode, gateway configurations will remain running.</p>
Options	CCP/XCP measurements continue also in monitoring mode on the logger. Pictures of the camera (HostCAM (P1214_E), F44 , CAMlog2) are also logged and the LOGview is actuated.
WLAN/LTE	If the logger configuration triggers a WLAN/LTE connection while the logger is in monitoring interface mode, after a successful connection the monitoring interface mode will be stopped. As consequence the CANoe/CANalyzer measurement is also stopped.
Sleep mode	The timeout for the sleep mode is not available in monitoring mode. The logger remains awake as long as the CANoe/CANalyzer measurement is running even when the bus is sleeping and the timeout time for sleep mode is passed.
Configuration	The configuration of the logger and of CANoe/CANalyzer is described in Tutorial 15: Usage as Interface (GL2000/GL3000/GL4000 Series) in chapter 4.16 and in the online help.

Requirements The monitoring mode is supported since the following software versions:

GL2000	Component	Version number	Remarks
	CANoe/CANalyzer	8.2	CAN, LIN
	GL2000 Firmware	V1.14 (GL2000_114.COD)	CAN, LIN
GL3000/GL4000 series	Component	Version number	Remarks
	CANoe/CANalyzer	7.6 SP3 8.0 SP4	CAN, LIN, FlexRay additionally MOST150
	GL3x00/GL4x00 Firmware	V1.47 (GL3000_147.COD) V1.97 (GL3000_197.COD)	CAN, LIN, FlexRay additionally MOST150

2.16.2 Signal Sampling Mode

Signal sampling mode

In signal sampling mode, the logger transfers sampled signal values of predefined signals. The smallest sampling rate is 50 ms. CAN-, LIN-, CCP/XCP- and diagnostic signals are supported as well as system information. Each signal is mapped in **CANoe/CANalyzer** onto a system variable.

During the measurement, the logger continues to record data in the ring buffer. All logger functions have unrestricted functionality.

Requirements

The signal sampling mode is supported since the following software versions:

GL3000/GL4000 series

Component	Version number	Remarks
CANoe/CANalyzer	8.5 SP3	CAN, LIN
GL3x00/GL4x00 Firmware	V2.74 (GLx000_274.COD)	CAN, LIN

GL5000 series


Component	Version number	Remarks
CANoe/CANalyzer	11.0 SP3	CAN, LIN
GL5000 Firmware	V0.55 (GL5000_055.COD)	CAN, LIN

3 Vector Logger Configurator

In this chapter you find the following information:

3.1	Installation Instructions	page 30
3.2	Overview	page 31
3.3	Tree View	page 31
	Hardware	
	General	
	Logging Memory	
	Classification	
	CCP/XCP	
	Diagnostics	
	Output	
	File Manager	
3.4	Property Panel	page 35
3.5	Toolbar	page 35
	Real-Time Clock	
	Refresh	
	Representation Dec/Hex	
	Conversion Profiles	
3.6	General Settings	page 36
3.7	Support Assistant	page 36

3.1 Installation Instructions

Using this installation instruction	<p>This instruction describes the installation of the software package for the Vector Logger Configurator containing:</p> <ul style="list-style-type: none">> Vector Logger Configurator Logging configuration of the GL1000/GL2000/GL3000/GL4000/GL5000 series and VN1630 log> Online help for the configuration tool> This user manual> User manual for GL1000 series> User manual for GL2000 series> User manual for GL3000/GL4000 series> User manual for GL5000 series
Operating system	<p>The following software requirements must be fulfilled to run the Vector Logger Configurator:</p> <ul style="list-style-type: none">> Windows 7 / Windows 8.1 (32/64 Bit)> Windows 10 (64 Bit) <p>Restriction Windows 8.1: AUTOSAR databases are not supported.</p>
Program variants	<p>The Vector Logger Configurator can be installed as a 32-bit or 64-bit program. Due to the larger address space, the 64-bit variant can process very extensive databases. 32-bit and 64-bit variants are otherwise functionally identical.</p> <p>The 64-bit version can only be installed on 64-bit operating systems.</p> <p>The 32-bit version can be installed on 32-bit and 64-bit operating systems.</p>
Setup	<div></div> <p>Follow the instructions below to install the Vector Logger Configurator.</p> <ol style="list-style-type: none">1. Execute the setup, which is found on the<ul style="list-style-type: none">> Vector Logger Configurator CD: .\VLConfig\Setup_64Bit.exe or .\VLConfig\Setup_32Bit.exe> Vector Driver Disk: .\Tools\VN1630_log\Setup.exe.2. Please, follow the instructions found there to complete the installation.3. After successfully installation, Vector Logger Configurator can be found (if chosen during installation) in the start menu.

3.2 Overview

About Vector Logger Configurator

The **Vector Logger Configurator** enables the configuration of the loggers of the **GL1000/GL2000/GL3000/GL4000/GL5000** series and the recording function of the **VN1630 log** interface with a wide range of settings. You may set baud rates, logging triggers and filters and manage log files on the memory card. It also supports trigger and filter access by symbolic names defined in the databases. Depending on the logger type the main features are:

- > Customizable filters for CAN messages, LIN messages and FlexRay frames/PDUs
- > Customizable triggers and markers
- > Support of databases
- > CCP/XCP configuration
- > Diagnostics
- > Customizable analog and digital inputs
- > File management

The Vector Logger Configurator window

The window of **Vector Logger Configurator** is divided into five parts that are all described in the online help:

- > Main menu
- > Toolbar
- > Tree view
- > Property panel
- > Status bar

3.3 Tree View

3.3.1 Hardware

Hardware

The **Hardware** lets you configure and check the channel settings, analog and digital inputs, and LEDs.

Comment

Here a comment and a version number can be added to the configuration.

Settings

When this tree node is selected hardware settings like the ring buffer and the timeout for the sleep mode status are displayed in the property panel (for GL Loggers only).

CAN Channels

When this tree node is selected, settings for the CAN channels can be made in the property panel.

LIN Channels

When this tree node is selected, settings for the LIN channels can be made in the property panel.

FlexRay Channels

When this tree node is selected, settings for the FlexRay channels can be made in the property panel (only for the **GL4000/GL5000** series).

MOST150 Channels

When this tree node is selected, settings for the MOST150 channels can be made in the property panel (only for the **GL3000/GL4000/GL5000** series).

Channels

For the **VN1630 log** with this tree node settings for the CAN/CAN FD/LIN channels can be made in the property panel.

Analog Inputs

When this tree node is selected, the analog input logging settings can be set in the property panel.

Digital Inputs	When this tree node is selected, the digital input loggings can be set in the property panel.
Measurement Modules	For the CAN measurement modules of CSM the database and channel assignment is configured here.
GPS	The GL2000 series supports the logging of GPS data from a serial GPS mouse. The settings for this GPS logging (CAN messages and/or system channel) are configured here.
CANgps	The loggers support the logging of GPS data via CANgps. For the loggers of the GL3000/GL4000/GL5000 series the settings for logging GPS data via system channel are configured here.
HostCAM	The cameras for the loggers of the GL3000/GL4000/GL5000 series are activated here, the first settings are also configured. The events for the start of the recording are configured on the Tigger page.
Monitoring	Loggers of the GL2000/GL3000/GL4000/GL5000 series support a monitoring interface mode that allows the use of loggers as bus interface for monitoring in CANoe/CANalyzer (see chapter 2.15 Monitoring Interface).
LTE/Wi-Fi/LAN	When this tree node is selected, you can set which events should trigger the LTE/Wi-Fi/LAN connection and which logged data should be transferred from the logger to the destination system (GL2000/GL3000/GL4000/GL5000 series only, depending on the transfer type).

3.3.2 General

General	At the General node the following settings can be made for the logger.
Databases	When this tree node is selected, the property panel displays a list of all databases (DBC, LDF, XML, ARXML) which are assigned to the current project. Databases can be added, edited or removed. They are required in order to configure filters or triggers by symbolic message or signal.
Special Features	When this tree node is selected, special features for the logger can be selected in the property panel.
Include Files	When this node is selected, include files with LTL code can be added in the main window in order to extend the current configuration (GL Logger only).

3.3.3 Logging Memory

Logging Memory	Logging Memory is the main node of Vector Logger Configurator and specifies miscellaneous logging conditions.
Triggers	When this tree node is selected, markers and triggers can be specified in the property panel. Markers are used in long-term loggings to mark special events. Triggers are used to log data when a defined event occurs. For additional information on the logging concept based on ring buffers and trigger, see sections 2.3 Ring Buffer and 2.4 Trigger .
Filters	When this tree node is selected, record filters on CAN messages, LIN messages and FlexRay frames/PDUs can be configured in the property panel.

3.3.4 Classification

Classifications For the GL Loggers (except **GL1000** series) the classification can be configured. With classifications you can define statistic evaluations of signals and signal conditions which are executed during the complete measurement time.

3.3.5 CCP/XCP

CCP/XCP The GL Loggers (except **GL1020FTE**) support CCP/XCP.

Descriptions When this tree node is selected, a list of all A2L files that are assigned to the project will be displayed in the main window. These files can be added or removed. Additionally protocol and ECU settings can be made. The A2L files are required to define lists with CCP/XCP signals.

Signal Requests When this tree node is selected, lists with CCP/XCP signals can be configured.

3.3.6 Diagnostics

Diagnostics The GL Loggers (except **GL1020FTE**) support diagnostics on CAN.

Diagnostic Descriptions When this tree node is selected, a list of all diagnostic descriptions (CDD, ODX, PDX, MDX) that are assigned to the project will be displayed in the main window. These files can be added or removed. Additionally single ECUs can be selected and their communication parameters can be set. The diagnostic description files are required to define lists with **diagnostic requests**. For OBD II no diagnostic description is required.

Requests When this tree node is selected, you can configure the logger for the request of diagnostic data of the ECUs.

You can define which data the logger requests either through the response parameter (signal request) directly or through specification of the diagnostic service (service request).

3.3.7 Output

Output For the GL Loggers this tree node specifies the settings for the output functionality of the logger.

LEDs When this tree node is selected, the programmable LEDs can be configured.

Display Devices When this tree node is selected, you can configure the display of events and signals on the **LOGview** and the display of events for the Front Panel display of the **GL3000/GL4000/GL5000** series.

Transmit Message When this tree node is selected, CAN messages can be configured that will be sent onto the CAN bus by the logger at a configured event. Alternatively this CAN message can be logged as virtual message in the logging file.

Set Digital Output When this tree node is selected, the SET and RESET conditions of the digital outputs can be configured.

Gateway When this tree node is selected, a simple gateway between CAN channels can be configured. The complete CAN messages are transferred 1:1.


3.3.8 File Manager

File Manager	The File Manager displays log files on memory cards and on the SSD, and allows transferring them to the PC. Furthermore the conversion to different formats is possible. The converted files can be displayed in CANoe , CANalyzer , CANape , vSignalizer or 3 rd party tools.
Device Information	When this tree node is selected miscellaneous details about the selected logger are displayed in the property panel.
Logger Device: Classic View	When this tree node is selected, all log files on the memory medium in a connected logging device are accessed. Select this view if you want to read out and convert all logging files.
Logger Device: Navigator	For the GL2000/GL3000/GL4000/GL5000 series, all logging files on the memory media on the connected logger are also displayed in this view. Select this view if the data have been logged via long-term logging with markers. More information (e.g., regarding the markers) is displayed for the logging data. Specific files can be selected for the conversion.
Card Reader: Classic View	When this tree node is selected, all log files on the memory card in a connected card reader or on a connected SSD are displayed. If there are several cards in the system, you can select a card by its drive letter via Card reader drive . Select this view if you want to read out and convert all logging files.
Card Reader: Navigator	For the GL2000/GL3000/GL4000/GL5000 series, all logging files on the memory card in the card reader or on the connected SSD are also displayed in this view. Select this view if the data have been logged via long-term logging with markers. More information (e.g., regarding the markers) is displayed for the logging data. Specific files can be selected for the conversion.
CLF Export	The GL Loggers support the CLF export. When this tree node is selected, all logged files in raw format (CLF) on a local directory are displayed. These log files can be converted into different formats.

3.4 Property Panel

Displayed details


The property panel displays miscellaneous information and details and allows several settings depending on the selection in the tree view.



3.5 Toolbar

3.5.1 Real-Time Clock

Real-time clock

With the  icon a dialog is opened, where the internal system clock of the logger can be set.

The loggers of the **GL1000/GL2000** series must be connected via USB to the PC. The real-time clock of the logger is set to the current system time of the PC.


The loggers of the **GL3000/GL4000** series can be connected either via USB or via the CONSOLE cable to a COM port of the PC. With the CONSOLE cable the real-time clock can be set either to the current system time of the PC or to a manually set time.

The loggers of the **GL5000** series can be connected via a COM port of the PC. The real-time clock can be set either to the current system time of the PC or to a manually set time.

The **VN1630 log** must be connected via USB to the PC. The real-time clock of the device is set to the current system time of the PC.

3.5.2 Refresh

Refresh

With the  icon in the toolbar the display for **Card Reader** and **CLF Export** in the File Manager is updated. Additionally the list of the drives with connected card reader (**Card reader drive** setting) is updated.

3.5.3 Representation Dec/Hex

Dec/Hex

With the **hex** icon in the toolbar the current representation of value is displayed. Values from the definition of filters and triggers can be displayed as decimal (Dec) or hexadecimal (Hex) values.

3.5.4 Conversion Profiles

Conversion profiles

With the   icons in the toolbar conversion profiles can be stored and loaded. The icons are only available within the **File Manager** node.

Conversion profiles contain all settings for the conversion of logging files that can be set on the corresponding pages of the **File Manager**. They provide a quick and comfortable access to different conversion settings.

3.6 General Settings

Vector Logger Configurator

The **Options** dialog provides the following general settings:

- > Language
- > Logger type at program start
- > Additional local drives
- > Pack&Go export
- > Conversion profiles
- > Analysis package
- > Generated files
- > Quick view
- > Diagnostics

3.7 Support Assistant

Vector Support Assistant

In order for our Support Team to optimally assist you in resolving your problem, additional information is needed. The **Vector Support Assistant** compresses the necessary files and send them password-protected to the Vector Support. You can deactivate files that should not be sent. You can also save the report without sending it to check the file assembly.

4 Tutorial

In this chapter you find the following information:

4.1	Overview	page 38
4.2	Tutorial 1: Create a Configuration	page 38
4.3	Tutorial 2: Download Configuration (GL1000/GL2000 Series)	page 39
4.4	Tutorial 3: Upload and Convert Logged Data (GL1000/GL2000 Series)	page 40
4.5	Tutorial 4: Download Configuration (GL3000/GL4000 Series)	page 40
4.6	Tutorial 5: Upload and Convert Logged Data (GL3000/GL4000 Series)	page 41
4.7	Tutorial 6: Read out and Download via USB (GL3000/GL4000 Series)	page 41
4.8	Tutorial 7: Download Configuration (GL5000 Series)	page 43
4.9	Tutorial 8: Upload and Convert Logged Data (GL5000 Series)	page 43
4.10	Tutorial 9: Download Configuration (VN 1630 log)	page 44
4.11	Tutorial 10: Upload and Convert Logged Data (VN1630 log)	page 44
4.12	Tutorial 11: Configuration with Simple Filter	page 45
4.13	Tutorial 12: Configuration with Simple Trigger	page 45
4.14	Tutorial 13: CCP/XCP und Seed & Key (GL Logger)	page 46
	Creation of Configuration	
	Generation of an SKB File	
	Installation of a CCP/XCP License	
4.15	Tutorial 14: CCP/XCP and Seed & Key with CANape (GL Logger)	page 50
	Generation of a DBC File	
	Generation of a FIBEX File	
	Creation of the Logger Configuration	
4.16	Tutorial 15: Usage as Interface (GL2000/GL3000/GL4000 Series)	page 53
	Configuration of the Logger	
	Configuration in CANoe/CANalyzer	
4.17	Tutorial 16: Logging of Diagnostic Data (GL Logger)	page 55
4.18	Tutorial 17: Configuration of the 3G Data Transmission (GL2000 Series)	page 56
	Configuration of the Logger	
	Connections and Displays of the Sierra Wireless AirLink LS300	
	Configuration of the 3G Router	
4.19	Tutorial 18: Record images with a HostCAM (GL3000/GL4000/GL5000 Series)	page 60
	Setting up the HostCAM/F44	
	Configuration of a Triggered Capturing	
	Configuration of a Long-term Capturing	

4.1 Overview

Overview

This tutorial is intended to make users who are using the **Vector Logger Configurator** for the first time familiar with how to operate it and to briefly describe the most important features.

To illustrate the basic principle, a simple configuration will first be created, generated and then loaded into the logger. Then additional features will be integrated into this basic configuration.

Configurations of any type can then be created based on this basic principle. In the following sections, more features will be added to those already shown and will be explained in turn.

The examples for the **GL3000/GL4000** series are prepared for Compact Flash cards. Logger configuration and data readout for the SSD are performed analogously.

4.2 Tutorial 1: Create a Configuration



Example: The following example describes for the GL Loggers the creation of a configuration that records all data of the defined CAN buses as long-term logging. The baudrate for the two CAN buses CAN1 and CAN2 (for **GL1000/GL2000/GL5000** series) or CAN5 and CAN6 (for **GL3000/GL4000** series) is set and a LED is configured.



1. Start the **Vector Logger Configurator**.
2. Open a new project and select the logger type. The logger type is displayed in the status bar.
3. Open the node **Hardware** in the tree view.
4. Click on **CAN Channels**.
5. Select the baudrate **500,000 bd** in the combo box for CAN1 or CAN5.
6. Select the baudrate **125,000 bd** in the combo box for CAN2 or CAN6.
7. Click on LEDs.
8. Select **Always blinking** in the LED 1 combo box.
9. Open the node **Logging Memory** in the tree view.
10. Click on **Triggers**.
11. Select the **Permanent long-term logging** mode.
12. Save the configuration on your PC.



Example: The following example describes the creation of a configuration for **VN1630 log** that records all data of the defined CAN buses as long-term logging. The baudrate for the two CAN buses on channel 1 and 2 is set.




1. Start the **Vector Logger Configurator**.
2. Open a new project and select the logger type **VN1630 log**. The logger type is displayed in the status bar.
3. Open the node **Hardware** in the tree view.
4. Click on **Channels**.
5. Select the **Mode** CAN or CAN FD.
6. Select the baudrate **500,000 bd** in the combo box for channel 1.
7. Select the baudrate **125,000 bd** in the combo box for channel 2.
8. For CAN FD also select the data rate.
9. Open the node **Logging** in the tree view.
10. Click on **Triggers**.
11. Select the **Permanent long-term logging** mode.
12. Save the configuration on your PC.

4.3 Tutorial 2: Download Configuration (GL1000/GL2000 Series)



Example: This example describes how to download the configuration of Tutorial 1, created with the **Vector Logger Configurator**, to a logger of the **GL1000/GL2000** series.



1. Open the project of **Tutorial 1** for the logger. The logger type is displayed in the status bar.
2. Connect the logger via USB to your PC.
3. Write the current configuration to the connected logger by selecting the menu item **Configuration|Write to Device** or by clicking the  button in the tool bar.
4. Disconnect the logger from USB and connect the logger to your test system. The logger now starts in logging mode. LED1 is blinking – as configured in **Tutorial 1**.

4.4 Tutorial 3: Upload and Convert Logged Data (GL1000/GL2000 Series)



Example: This example explains how to upload and convert logged data from the **GL1000/GL2000** series.



1. Disconnect the logger from the test system und connect it via USB to your PC.
2. Open a project for the **GL1000** series or the **GL2000**.
3. Open the node **File Manager** in the tree view.
4. Click on **Logger Device**. The logged files are displayed in the property window.
5. Select in the **General Settings** the target directory and the file format (e.g. BLF logging file).
6. Select in the **Advanced Settings** the conversion options.
7. Click on **[Convert]** to start upload of logged data and automatic conversion to the selected file format. The files will be stored in a new subfolder (**Destination Subdirectory**) of the target directory.
8. Open the new subfolder with a double click on any entry of the **Destination Subdirectory** column. Analyze the converted file (e.g. BLF file with **CANoe/CANalyzer**, TXT file with **MS Excel**).

4.5 Tutorial 4: Download Configuration (GL3000/GL4000 Series)



Example: This example describes how to download a configuration (e.g. of Tutorial 1) created with the **Vector Logger Configurator** to a logger of the **GL3000/GL4000** series.



Caution: The logger must always be switched off before the Compact Flash card (CF card) can be inserted or removed.



1. Insert the CF card into the card reader on the PC.
2. Open a project for the **GL3000/GL4000** series, e.g. the project of **Tutorial 1**. The logger type is displayed in the status bar.
3. Select the **Configuration|Write to Memory Card...** menu command to load the configuration on the CF card. In addition, select the drive of the card reader in the displayed dialog.
4. Eject the CF card.
5. Open the front access panel of the logger and insert the CF card to the logger. After that close the front access panel.
6. Start the logger and make sure that the logger is kept awake by bus activity or the KL15/Wake-pin. Now the configuration is loaded to the logger. This process takes about one minute. This can take up to five minutes for a firmware update. During the configuration update the logger first boots up and displays first about 30 s **Record** and then about 30 s **FLASHING**. As soon as the logger displays **Record** again the new configuration is active.
7. The logger then initiates the configuration and recording of data.

4.6 Tutorial 5: Upload and Convert Logged Data (GL3000/GL4000 Series)



Example: This example explains how to upload and convert logged data from the GL3000/GL4000 series via the card reader on the PC.



1. Open the front access panel of the logger. Wait until the LEDs in the CF card slot disappear. Then, you can remove the CF card.
2. Open a project for the GL3000/GL4000 series.
3. Insert the CF card into the card reader on the PC.
4. Open the **File Manager** node in the tree view.
5. Click on **Card Reader|Classic View** and select in **Card reader drive** the drive of the CF card. Now all files on the card are displayed.
6. Select in the **General Settings** the target directory and the file format (e.g. BLF logging file).
7. Select in the **Advanced Settings** the conversion options.
8. Click on **[Convert]** to initiate the readout of the logging data and the automatic conversion to the selected file format. The files will be stored in a new subfolder (**Destination Subdirectory**) of the target directory.
9. Open the new subfolder with a double click on any entry of the **Destination Subdirectory** column. Analyze the converted file (e.g. BLF file with CANoe/CANalyzer, TXT file with MS Excel).

4.7 Tutorial 6: Read out and Download via USB (GL3000/GL4000 Series)



Example: This example explains how to read out and convert logged data from the GL3000/GL4000 series and how to download a configuration via USB.



1. Start the logger in **logging mode** or check if the logger is already in logging mode.
The display shows **Record** and the LEDs lit as configured.
2. First connect the USB cable to the PC (USB connector **type A**).
3. Open the front access panel.
4. Quickly connect the USB cable with the USB device connector (USB connector **type B**).

After opening the front access panel the logger will stop logging and will wait minimum 6 seconds for the USB connection. If logging data are still written to the memory medium the waiting time will be extended respectively. During this time the display shows **Stop Rec** or **Save XX%** and the LEDs show a running light from the right to the left. If the USB cable is not connected during this waiting time, the logger will switch off.

If the USB cable is connected during this waiting time, the logger will switch to USB mode and the display shows **USB Mode**. The LEDs still show the running light from the right to the left, and on the memory medium green and red LEDs lit (at the compact flash card behind the card, at the SSD on the front of the cartridge).

Do not remove the memory medium while the logger is in USB mode!

5. Open in the **Vector Logger Configurator** a project for the **GL3000** or **GL4000** series. The series must be equal to the connected logger.
6. Open the node **File Manager** in the tree view.
7. Click on **Logger Device|Classic View**. Now all data on the logger memory media is displayed.
8. Select in the **General Settings** the target directory and the file format (e.g. BLF logging file).
9. Select in the **Advanced Settings** the conversion options.
10. Click on **[Convert]** to initiate the readout of the logging data and the automatic conversion to the selected file format. The files will be stored in a new subfolder (**Destination Subdirectory**) of the target directory.
11. Open the new subfolder with a double click on any entry of the **Destination Subdirectory** column. Analyze the converted file (e.g. BLF file with **CANoe/CANalyzer**, TXT file with **MS Excel**).
12. Open a project for the **GL3000/GL4000** series, e.g. the project of **Tutorial 1**. The logger type is displayed in the status bar.
13. Write the configuration to the memory medium of the logger via the menu item **Configuration|Write to Device**.
14. A message confirms the successful writing of the configuration.

Make sure that the **Eject logger/memory card** option is activated and close the message.
15. Close the message with **[OK]**.
16. Disconnect the USB cable from the logger and close the front access panel. The logger will switch off.
17. Start the logger and make sure that the logger is kept awake by bus activity or the KL15/Wake-pin. Now the configuration is loaded to the logger. This process takes about one minute. This can take up to five minutes for a firmware update. During the configuration update the logger first boots up and displays first about 30 s **Record** and then about 30 s **FLASHING**. As soon as the logger displays **Record** again the new configuration is active.



The logger starts the configuration and the logging of the data.

4.8 Tutorial 7: Download Configuration (GL5000 Series)



Example: This example describes how to download a configuration (e.g. of Tutorial 1) created with the **Vector Logger Configurator** to a logger of the **GL5000** series.




1. Open the project of **Tutorial 1** for the **GL5000** series. The logger type is displayed in the status bar.
2. Connect the logger via USB to your PC, power it up and wait until the display shows **USB Mode**.
3. Write the current configuration to the connected logger by selecting the menu item **Configuration|Write to Device** or by clicking the  button in the tool bar.
4. Eject the logger with the  button in the **File Manager**. Disconnect the logger from USB.
5. Connect the logger to your test system. Now the configuration is loaded to the logger. This task takes about one minute.
During the configuration update the logger first boots up and displays first about 30 s **Record** and then about 30 s **Update in progress**. As soon as the logger displays **Record** again the new configuration is active.
6. The logger then initiates the configuration and recording of data.

4.9 Tutorial 8: Upload and Convert Logged Data (GL5000 Series)



Example: This example explains how to upload and convert logged data from the **GL5000** series via the card reader on the PC.




1. Connect the logger via USB to your PC, power it up and wait until the display shows **USB Mode**.
2. Open a project for the **GL5000** series.
3. Open the node **File Manager** in the tree view.
4. Click on **Logger Device|Classic View**. The logging files are displayed.
5. Select in the **General Settings** the target directory and the file format (e.g. BLF logging file).
6. Select in the **Advanced Settings** the conversion options.
7. Click on **[Convert]** to initiate the readout of the logging data and the automatic conversion to the selected file format. The files will be stored in a new subfolder (**Destination Subdirectory**) of the target directory
8. Open the new subfolder with a click on the blue underlined **Destination Subdirectory** link. Analyze the converted file (e.g. BLF file with **CANoe/CANalyzer**).
9. Eject the logger with the  button in the **File Manager**. Disconnect the logger from USB.

4.10 Tutorial 9: Download Configuration (VN 1630 log)



Example: This example describes how to download a configuration of **Tutorial 1**, created with the **Vector Logger Configurator**, to a **VN1630 log**.



1. Open the project of **Tutorial 1** for the **VN1630 log**. The logger type is displayed in the status bar.
2. Connect the **VN1630 log** via USB to your PC.
3. Select the **Configuration|Write to Device...** menu command to load the configuration on the connected **VN1630 log**. Alternatively you can use  in the toolbar.
4. Disconnect the **VN1630 log** from USB and connect it to your test system. The **VN1630 log** now starts in logging mode. The Log-LED lights green, if data is written to the memory card.

4.11 Tutorial 10: Upload and Convert Logged Data (VN1630 log)



Example: This example explains how to upload and convert logged data from the **VN1630 log**.



1. Disconnect the **VN1630 log** from the test system und connect it via USB to your PC. The device must be connected to the external power supply until the Log-LED is off and the LED push button lights green.
2. Open a project for the **VN1630 log**.
3. Open the **File Manager** node in the tree view.
4. Click on **Logger**. The logging files are displayed.
5. Select in the **General Settings** the target directory and the file format (e.g. BLF logging file).
6. Select in the **Advanced Settings** the conversion options.
7. Click on **[Convert]** to initiate the readout of the logging data and the automatic conversion to the selected file format. The files will be stored in a new subfolder (**Destination Subdirectory**) of the target directory.
8. Open the new subfolder with a double click on any entry of the **Destination Subdirectory** column. Analyze the converted file (e.g. BLF file with **CANoe/CANalyzer**).



Note: You can read also read data from the memory card in the card reader. To securely remove the SD card, press the LED push button at least for three seconds. Remaining data in the ring buffer is copied to the SD card which can take approx. 15 seconds. During this time, the LED flashes yellow. Remove the SD card only if the LED lights green. During this sequence the **VN1630 log** must not be disconnected from the power supply.

4.12 Tutorial 11: Configuration with Simple Filter



Example: The following example describes how to insert a simple filter which is used in the logger. The filter settings block all received messages of one channel except for the messages with ID between 100 and 200 which are logged.



1. Start the **Vector Logger Configurator**.
2. Open the project of **Tutorial 1** for the corresponding logger type.
3. Open the node **Logging Memory** in the tree view.
4. Click on **Filters**.
5. Now change the status of the **Default** filters in the **Action** column from **Pass** to **Stop** in order to block all incoming CAN and LIN messages.
6. Select **CAN ID** in the filter combo box.
The filter setting dialog pops up.
7. Set **Relational operator** to **ID Range**, below enter the **ID** value 100 (0x64) and **Last ID** value 200 (0xC8).
8. Click on **[OK]**. The filter is listed in the list view now.
9. Now change the just added filter action to **Pass**.
This makes sure that only CAN messages with ID between 100 and 200 are logged. Select the corresponding CAN channel under **Channel**.
10. Save the configuration.
11. Download the configuration as already described on the logger.

4.13 Tutorial 12: Configuration with Simple Trigger



Example: The following example describes how to insert a simple trigger which is used in the logger.



1. Start the **Vector Logger Configurator**.
2. Open the project of **Tutorial 1** for corresponding logger type.
3. Open the node **Logging Memory** in the tree view.
4. Click on **Triggers**.
5. Select the mode **Triggered logging**.
6. Select **On CAN ID** as trigger event.
7. Click on **[Add...]**. The trigger setting dialog is opened.
8. Set **Relational operator** to **==**.
9. Enter the **ID** value 100. This setting will trigger to every received CAN message with ID 100. **Extended ID** must be deactivated.
10. Click on **[OK]**. The trigger is listed in the list view now.
11. Save the configuration.
12. Download the configuration as already described on the logger.

4.14 Tutorial 13: CCP/XCP und Seed & Key (GL Logger)



Example: The following example describes the procedure of the creation of a logger configuration with CCP/XCP and Seed & Key with direct use of an ECU description file (A2L) in **Vector Logger Configurator**.

Overview

Section 4.10.1 **Creation of Configuration** explains the basic configuration for CCP/XCP.

If the ECU has a Seed & Key protection, section 4.10.2 **Generation of an SKB File** explains how to generate a SKB file required by the logger to unlock the ECU. If the ECU has no Seed & Key protection, this section can be skipped.

Section 4.10.3 **Installation of a CCP/XCP License** finally describes how to install a CCP/XCP license to a logger hardware.



Reference: You can find an example for CCP/XCP with Seed & Key with **CANape** in section 4.11.

4.14.1 Creation of Configuration



1. Open the **Vector Logger Configurator**.
2. Create a new project via **File|New Project...** or load via **File|Open Project...** an existing one which shall be extended by the CCP/XCP measurement.
3. Include the A2L file to the project via **[Add...]** on the **CCP/XCP|Descriptions** page and assign the channel.

For A2L files with Seed & Key a second dialog is opened for including the SKB file.
If no SKB file is selected and the dialog is closed with **[OK]**, a warning symbol is automatically disabled.
The column **Settings** displays whether the A2L file includes Seed & Key.
The SKB file can be added later.
4. Open via **[Settings...]** the dialog for the ECU and protocol settings.
5. Check the setting and edit them if necessary.
6. Close the dialog with **[OK]**.
7. Open the node **CCP/XCP|Signal Requests** in the tree view.
8. Open via **[Add...]** the selection dialog for the CCP/XCP signals.
9. Select in this dialog the signals to be measured. You can apply several signals consecutively via **[Apply]**.
10. Close the dialog with **[OK]**.
11. If necessary edit the measurement mode (DAQ or Polling) and the cycle time in the measurement list.
12. For XCP on FlexRay add the ECU adequate FIBEX file on the page **General|Databases**.
13. Load the configuration via the menu **Configuration|Write to Device...** in the logger or create a COD file via menu **Configuration|Export to COD File...**

In this process the **Vector Logger Configurator** creates DBC/FIBEX files in the **Analysis** subdirectory. For a later export, these files must be added to the configuration.

Alternatively the DBC/FIBEX files can be generated via the menu **Configuration|Create Analysis Package...**

14. Start the logger in logging mode.

The CCP/XCP connection is automatically established, if an SKB file is available additionally with Seed & Key. In this case the logger automatically calculates and transmits the correct key for the seed received from the ECU.

After the connection is established, the ECU transmits CCP/XCP data to the logger according to the configured DAQ or polling mode. This data is logged as normal CAN or FlexRay data. In case of a connection break (i.e. the logger does no longer receive CCP/XCP data from the ECU) the connection is automatically initiated again.

4.14.2 Generation of an SKB File



Note: The following steps are explained for **CANape** 8.0 to 14.0. Other versions may have slightly different menu names, etc.

If data from a Seed & Key protected ECU is to be logged, an SKB file containing the Seed & Key algorithm information is necessary in addition.



1. Start **CANape**:
 - > If a **CANape** project for the connected ECU exists, open this project.
 - > If no **CANape** project exists yet, create a new project based on the ECU's A2L file.
2. Open the Functions Editor via **Tools|Functions and Scripts...** or the appropriate button from the toolbar.
3. Create a new function in the section **Seed & Key algorithm**; select **New...** from the shortcut menu. The function is stored to an SKS file.

When the function is created, the following four parameters are automatically included:

 - > **var seed[]**
Key from ECU
 - > **var seedLength**
Length of the key from ECU
 - > **var key[]**
Response key to ECU
 - > **var keyLength**
Length of response key to ECU
4. Insert the ECU specific Seed & Key algorithm.
5. Select **Export...** from the shortcut menu of the SKS file.
6. Click on **[SeedKey Binary (.skb)]**.
7. Select an export directory, where the SKB file is created.



Note: The SKS files contain the encryption algorithms in plain text and will always be saved in the sub-folder **SeedAndKey** in the **CANape** working directory. After the SKB file was created the respective SKS file can be deleted or moved for safety reasons. Otherwise it will be exported, too, when the project is exported by the project manager.

Test of SKB file

The generated SKB file can be integrated into the CCP/XCP device in **CANape** instead of a Seed & Key DLL. This allows testing the SKB file with **CANape** first before including it to the logger configuration. The testing procedure is as follows:

Test procedure

1. Connect the ECU to the CAN interface for **CANape**.
2. Start **CANape**.
3. Include the SKB file to the project:

Applies to CANape 8.0:

> **CCP devices:**

On the **General** page of the **Driver settings** dialog search for the entry SEED_KEY_NAME_DAQ in the **[Extended settings]**. Here you can enter the name of the SKB file.

> **XCP devices:**

In the **Driver Settings** dialog, **General** tab, **Seed&Key** section, use **[Browse]** to find the generated SKB file and enter it.

Applies to CANape 9.0 to 11.0:

> **CCP and XCP devices:**

Open the dialog **Device configuration** from **Device|Device configuration....**. Select in the tree under the node **Devices** the connected CCP respectively XCP device and under it the node **General**. In the **General** tab, **Seed&Key** section, use **[Browse...]** to find the generated SKB file and enter it. The setting **Enable** must be selected.

Applies to CANape 12.0 to 14.0:

> **CCP and XCP devices:**

Open the dialog **Device configuration** from **Device|Device configuration....**. Select in the tree under the node **Devices** the connected CCP respectively XCP device and under it the node **Protocol**. In the **General** tab, **Seed&Key** section, use **[Browse...]** to find the generated SKB file and enter it. The setting **Enable** must be selected.

4. Start the measurement for at least some seconds, and check for correct connection setup, i.e. no error messages are displayed and data from the ECU is displayed.



Note: When **CANape** starts a Seed & Key procedure in the working directory a log file **SeednKey_<devicename>.log** is created that contains information about the process. Here **<devicename>** stands for the current device. When the next Seed & Key procedure is started the file is overwritten by its latest version.



Cross reference: You can find examples for the Seed & Key functions in the online help.

4.14.3 Installation of a CCP/XCP License



Example: The following example describes how to subsequently install the CCP/XCP license for the **GL1000/GL2000** series. An activated LIC file for the logger is required.



1. Connect the logger via USB with the PC. Only the logger must be connected on which the license should be installed.
2. Open the **Vector Logger Configurator**.
3. Select **Device|Install License...** in the menu to open the selection dialog. Select the license file (LIC) for your logger there. If the menu item **Install License...** is not available check the connection between logger and PC. Update your view with <F5>.
4. Click **[Open]**. The license file will be copied on the memory card of the logger. After that the logger will be ejected from the system automatically.
5. Start the logger in logging mode. The license will be checked by the firmware and after that it will be copied from the memory card to the internal memory of the logger. The license installation is finished afterwards. After a reconnection of the logger to the PC the installed license will be displayed in the **Vector Logger Configurator** under **File Manager|Logger Device|Device Information**.



Example: The following example describes how to subsequently install the CCP/XCP license for the **GL3000/GL4000** series. An activated LIC file for the logger is required. The example is for a Compact Flash card (CF card). The installation occurs analogously for the SSD.



1. Insert a CF card into the card reader.
2. Open the **Vector Logger Configurator**.
3. Select **Device|Write License to Memory Card...** in the menu to open the selection dialog. Select the license file (LIC) for your logger there.
4. Click **[Open]**.
5. In the next dialog, select the drive of the CF card.
6. Click **[OK]**. The license file is written to the CF card. Optionally you can use **Configuration|Write to Memory Card...** to write a new configuration to the CF card.
7. Eject the CF card.
8. Open the front access panel of the logger, insert the CF card into the logger, and then close the front access panel again.
9. Switch on the logger. The logger checks and installs the license file if it matches with the logger's serial number and type.

4.15 Tutorial 14: CCP/XCP and Seed & Key with CANape (GL Logger)



Example: The following example describes the procedure of the creation of a logger configuration with CCP/XCP and Seed & Key.

Overview

Section 4.11.1 Generation of a DBC File explains how to generate a DBC file with **CANape** for CCP and XCP on CAN. For XCP on FlexRay section 4.11.2 Generation of a FIBEX File explains how to create a FIBEX file with **CANape** instead.

Section 4.11.3 Creation of the Logger Configuration explains how to import the DBC/FIBEX and SKB file in the actual logger configuration.



Reference: If the ECU has a Seed & Key protection, section 4.10.2 Generation of an SKB File explains how to generate a SKB file required by the logger to unlock the ECU. If the ECU has no Seed & Key protection, this section can be skipped.

Section 4.10.3 Installation of a CCP/XCP License finally describes how to install a CCP/XCP license to a logger hardware.

4.15.1 Generation of a DBC File



Note: The following steps are explained for **CANape** 8.0 to 14.0. Other versions may have slightly different menu names, etc.



1. Connect the ECU to the CAN interface for **CANape**.
2. Start **CANape**:
 - > If a **CANape** project for the connected ECU exists, open this project.
 - > If no **CANape** project exists yet, create a new project based on the ECUs A2L file.

With **CANape 7.0**:

3. Go to menu **Device|Driver Settings...**, select the desired ECU.
4. Click on **[OK]**.
5. Go to **General** tab and activate the option **Generate a CANalyzer database**.
6. Click on button **[Extended Settings]**.
7. Set the parameter **CANDB_CCP_CONF** to **Yes**.
8. Select the signals to be logged via menu **Measurement|Measurement Configuration...** or press **<F4>**.
9. Start the measurement for a few seconds via menu **Measurement|Start** or press **<F9>**.

With **CANape 8.0 and higher**:

3. Select the signals to be logged via menu **Measurement|Measurement Configuration...** or press **<F4>**.

4. Use the **Tools|Logger configuration ...** menu command to select the desired ECU, and click on **[Create File]**.

CANape records all information from the current connection establishment and saves it into a new created DBC file, which is stored to the **CANape** working directory. This DBC file contains exactly the same CCP/XCP connection setup as it was done by **CANape** at the start of the measurement, i.e. the logger will later setup exactly the same measurement.

4.15.2 Generation of a FIBEX File

For XCP on FlexRay a FIBEX file containing the XCP information must be generated with **CANape**. **GL4000/GL5000** series is required.



Note: The following steps are explained for **CANape** 8.0 to 14.0. Other versions may have slightly different menu names, etc.



1. Connect the ECU to the FlexRay interface for **CANape**.
2. Start **CANape**:
 - > If a **CANape** project for the connected ECU exists, open this project.
 - > If no **CANape** project exists yet, create a new project based on the ECUs A2L file.

With **CANape** 8.0 and higher:

3. Select the signals to be logged via menu **Measurement|Measurement Configuration...** or press **<F4>**.
4. Make sure the ECU is online (menu **Calibration|Go Online**).
5. Start the measurement for a few seconds via **Measurement|Start** or press **<F9>**.
6. Stop the measurement (**Measurement|Stop** or **<Esc>**). **CANape** may warn you that the measurement file already exists. In this case skip the saving of the measurement file by clicking on the button **[Do not save measurement]**.
7. Go offline with the ECU via menu **Calibration|Go Offline**.
8. Use the **Tools|Logger configuration ...** menu command to select the desired ECU, and click on **[Create File]**. Select path and filename for the new created FIBEX file.
9. Leave the **Logger configuration** dialog with **[Close]**.

CANape records all information from the current connection establishment and saves it into a new created FIBEX file, which is stored to the **CANape** working directory. This FIBEX file contains exactly the same CCP/XCP connection setup as it was done by **CANape** at the start of the measurement, i.e. the logger will later setup exactly the same measurement. Additionally, the FIBEX file contains the full content of the original FIBEX file, which was assigned in **CANape** as network description file.

4.15.3 Creation of the Logger Configuration



Note: You can create the logger configuration with the **Vector Logger Configurator**.



Once the DBC, FIBEX and SKB files are created, the actual logger configuration can be created with the **Vector Logger Configurator** as follows.

Seed & Key is supported with **Vector Logger Configurator**

- > Version 1.1 or higher for **GL1000** series
- > Version 2.3 or higher for **GL2000** series
- > Version 2.0 or higher for **GL3000/GL4000** series
- > Version 2.8 for the **GL5000** series

1. Open the **Vector Logger Configurator**.
2. Create a new project via **File|New Project...** or load via **File|Open Project...** an existing one which shall be extended by the CCP/XCP measurement.
3. Include the DBC/FIBEX file to the project in **CCP/XCP|Descriptions** and assign the channel.

The column **Settings** displays whether the DBC/FIBEX file includes Seed & Key.

- > DBC/FIBEX files **without** Seed & Key are automatically enabled.
- > For DBC/FIBEX files **with** Seed & Key a second dialog is opened for including the SKB file.

If no SKB file is selected and the dialog is closed with **[Cancel]**, a warning symbol is automatically disabled.

The SKB file can be added later. Then you can activate the DBC/FIBEX file in **CCP/XCP|Descriptions**.

4. Load the configuration via the menu **Configuration|Write to Device...** in the logger (**GL1000/GL2000** series) or create a COD file via menu **Configuration|Export to COD File....** The **Vector Logger Configurator** automatically includes the DBC/FIBEX and SKB files in the download file.
5. Start the logger in logging mode.

The CCP/XCP connection is automatically established, if an SKB file is available additionally with Seed & Key. In this case the logger automatically calculates and transmits the correct key for the seed received from the ECU. The rest of the connection sequence is exactly the same as done by **CANape**.

After the connection is established, the ECU cyclically transmits CCP/XCP data to the logger. This data is logged as normal CAN data. The logger doesn't send any further CCP/XCP commands, as long as the connection stands. In case of a connection break (i.e. the logger does no longer receive CCP/XCP data from the ECU) the connection is automatically initiated again.

4.16 Tutorial 15: Usage as Interface (GL2000/GL3000/GL4000 Series)



Example: The following example describes how to use a logger of the GL2000/GL3000/GL4000 series in monitoring mode as a monitoring interface for CANoe or CANalyzer.



Reference: You can find further information about the monitoring mode in chapter 2.15 Monitoring Interface.

4.16.1 Configuration of the Logger



1. Open the **Vector Logger Configurator**.
2. Create a new project via **File|New Project...** or load via **File|Open Project...** an existing one which shall be extended by the interface functionality.
3. Enable the monitoring mode on page **Hardware|Monitoring|Monitoring Mode**.
4. Set the IP address of the logger and adjust the subnet mask and the port if necessary. Make sure that the settings match to your PC or network.
5. Optional you can change the channel and the CAN ID for the marker message that marks begin and end of the monitoring mode in the logging file.
6. If required you can set which messages, sent by the logger, should be displayed in **CANoe/CANalyzer**. In the same way you can specify whether Error frames are displayed.
7. Load the configuration as described in **Tutorial 4** into the Logger.

4.16.2 Configuration in CANoe/CANalyzer



1. Open **CANoe/CANalyzer**.
2. Create a new configuration with a template
 - > **CANoe/CANalyzer** up to version 8.0:
File|New Configuration...
 - > **CANoe/CANalyzer** version 9.0 and higher:
File|New...
3. Enable the GL-Logger mode via
 - > **CANoe/CANalyzer** version 7.6 SP3:
Configuration|Options|Configuration Settings|GL-Logger Settings
 - > **CANoe/CANalyzer** version 8.0:
Configuration|Options|Extensions|GL-Logger
 - > **CANoe/CANalyzer** version 9.0 and higher:
File|Options|Extensions|GL-Logger

4. Set the number of CAN, LIN, and FlexRay channels via
 - > **CANoe/CANalyzer** version 7.6 SP3:
Configuration|Options|Configuration Settings|Channel Usage
 - > **CANoe/CANalyzer** version 8.0:
Configuration|Options|Measurement|General
 - > **CANoe/CANalyzer** version 9.0 and higher:
File|Options|Measurement|General
5. If you want to use databases you have to add networks in the simulation setup and assign the corresponding databases.
6. Set the IP address and the port of the logger.
 - > **CANoe/CANalyzer** version 8.0:
Configuration|Network Hardware
 - > **CANoe/CANalyzer** version 9.0 and higher:
Hardware|Network Hardware

Adjust these settings with the settings of the **Vector Logger Configurator** and if necessary with your network.
7. Connect the PC with the logger via Ethernet. Therefor use the connection **ETH** at the **GL2000** and the connection **Eth2** at the **GL3000/GL4000**.
8. Click on **[Check Connection]**.

If the logger is identified, its configuration data is listed.
If the logger is not identified, the list remains empty. In this case check your network connection, the IP address, and the port.
9. Start the measurement.



Note: While the measurement the logger is in monitoring interface mode. In this mode no data is written to **Memory 1** and **Memory 2**. Classifications are continued in monitoring interface mode.

4.17 Tutorial 16: Logging of Diagnostic Data (GL Logger)



Example: The following example describes the creation of a configuration, to query and log data from the ECU cyclically, which can only be read out by diagnostic services. For this procedure signal request lists (parameter lists) are created.



1. Start the **Vector Logger Configurator**.
2. Create a new project via **File|New Project...** or load via **File|Open Project...** an existing one which shall be extended by the diagnostic functionality.
3. Open the node **Diagnostics|Diagnostic Descriptions** in the tree view.
4. Select via **[Add...]** a diagnostic description.
5. If several ECUs are available in the diagnostic description, you can select in the subsequent dialog those ECUs from which diagnostic data should be read out.
6. Open the **ECU Settings** dialog via **[ECU settings...]**.
7. Check for all ECUs the settings of the parameters for the diagnostic communication and adjust them if required.
8. Select in the **Session configuration** section the service request for the **Default session** and **Extended session**.
9. Close the dialog with **[OK]**.
10. Open the node **Requests** in the tree view.
11. Select from the selection list the **On cyclic timer** event and add it with **[Add...]**.
12. Set in the subsequent dialog the **Cycle time** and the **Delay** time after start.
13. Close the dialog with **[OK]**.
A new group with brief information about the event now appears in the list under **Requests**.
14. Select **Signal Request** using the **Request** selection menu.
15. In the **Diagnostic Signal Selection** dialog now displayed, the signals (parameter) are grouped by ECU. Note that only signals that are contained in responses of reading diagnostic services are listed.
16. Type in the name of the diagnostic signal. This triggers corresponding filtering of the list of diagnostic symbols underneath.
17. When you have found the desired signal, select it.
18. In the **DID**, **Service**, and **Session Type** fields, you can define the signal request more precisely.
19. Close the selection dialog for diagnostic signals with **[OK]**.
20. The new signal is added to the list of events.
21. Add additional signal requests for the event using the **Request** selection menu.
22. If required you can change the delay and cycle time by marking the **Event** row and pressing the **[Condition...]** button.
23. Create further service request lists by adding additional events with service requests.
24. Save the configuration on your PC.
25. Load the configuration as described in **Tutorial 2** or **Tutorial 4**.

4.18 Tutorial 17: Configuration of the 3G Data Transmission (GL2000 Series)



Example: The following example describes the creation of a configuration, to transmit logging data of the **GL2000** series via a 3G connection, as well as the configuration of the 3G router **LS300** from **Sierra Wireless**.

4.18.1 Configuration of the Logger



Note: For the transmission of logging data to a **ML Server**, a corresponding MLserver license (Online Data Transfer license) must be installed on the logger.



1. Start the **Vector Logger Configurator**.
2. Create a new project via **File|New Project...** or load via **File|Open Project...** an existing one which shall be extended by the 3G data transmission.
3. Open the node **3G** in the tree view.
4. Enable the **Start 3G connection** option.
5. Select an event that triggers the transmission of logging data and add this event with **[Add]** to the project.
6. Via **[...]** in the **Data Selection** column you can set which data should be transmitted at the occurrence of the event.
7. Set the IP address of the logger (**Logger IP**). The IP address must be located in the same subnet as the 3G router itself.
8. Set the IP address of the 3G router (**Gateway IP**). The presetting **192.168.13.31** is the factory setting of the 3G router **AirLink LS300** from **Sierra Wireless**. You can change this address via the configuration interface of the router.
9. Set the **Subnet Mask** for the subnet the logger is connected with the 3G router.
10. Set the IP address of the ML Server (**MLserver IP**). Via this IP address the logger will contact the **ML Server**.
11. Save the configuration on your PC.
12. Load the configuration into the logger as described in **Tutorial 2** Tutorial 4.

4.18.2 Connections and Displays of the Sierra Wireless AirLink LS300

Connections

The following connections of the **Wireless AirLink LS300** are required for the data transmission:

Front

- > 3G main antenna
- > Power supply
- > Ethernet interface
- > 3G antenna (Diversity)

Back

- > CAP for SIM card

LEDs

The four multi-colored LEDs on the front of the 3G router display the status of the different states. You can find a detailed description of these states in the device manual of the manufacturer.

Insert SIM card

Before switching on the device, insert the SIM card. Proceed as follows:


- > Remove the cap for the SIM card.
- > Push the card into the slot all the way to the stop.
- > Close the cap for the SIM card.



Note: When inserting the SIM card, please note the direction of the flattened edge of the SIM card.

Connection plan

In the following connection plan you can see how to connect the 3G router and the switch-on adapter **GLA600** to the logger.



4.18.3 Configuration of the 3G Router



Note:

- > The 3G router requires an activated SIM card and an external power supply (range of the power supply: 8 V ... 28 V). The 3G router is switched on and off from the **GL2000** via the switch-on adapter **GLA600**.
- > Due to security reasons it is strongly recommended to change the factory password.
- > After switching on, the 3G router is accessible after about 3 minutes. During this time any connection attempt to the ML Server fails. The status of the connection is displayed via LEDs (see also device manual of the manufacturer):
 - > LED **Network**: green
 - > LED **Signal**: green or yellow (depending on signal strength)
 - > LED **Activity**: off
 - > LED **Power**: green
 - > No LED flashes

Before using the **GL2000**, the 3G router must be configured to establish an internet connection by his own.

Proceed as follows to configure the 3G router:



1. Connect the 3G router with the PC via the Ethernet interface.
2. Switch the 3G router on by a connection with the logger via **GLA600** (see connection plan above). After that connect the **GLA600** with the power supply.



Note: The logger serves as on/off switch for the 3G router and therefore must be switched on during the whole configuration.

To keep the **GL2000** switched on the following possibilities are available:

- > Switch on the data logger without inserted SD card (not available for **GL2010**) or
- > Connect clamp 15 (pin 20 on the data logger) with the power supply or
- > Use a configuration with **Timeout to sleep mode** set to 0 s (**Vector Logger Configurator**: node **Hardware**, page **Settings**).


3. Open an Internet Browser on the PC.
4. Insert the IP address (with port): **http://192.168.13.31:9191**




Note: Ensure that the PC is located in the same subnet as the 3G (192.168.13.xx), or that the PC receives the IP address automatically.

After switching on, it may take up to 3 minutes until the device reacts.

5. The login dialog of the **ACEmanager** is opened.
Enter your user name and the password. At the delivery use the administrator user name **user** and the **12345**.




6. The **ACEmanager** main window is opened and you can configure the 3G router.



On **WAN/Cellular** page enter the net provider and the PIN number of the used SIM card. Confirm these settings with the **Apply** button.

7. Change the password of the 3G routers on the **Admin** page in the **Change Password** section. Confirm the change with the **[Apply]** button.
Remember the password for the next login.
8. To take over these settings, the 3G router must be rebooted. Therefore press the **Reboot** button.
9. After the reboot you can check on the **Status** page if the configuration was successful.
You can also check the status via the LEDs (see device manual of the manufacturer):
 - > LED **Network**: green
 - > LED **Signal**: green or yellow (depending on the signal strength)
 - > LED **Activity**: off
 - > LED **Power**: green
 - > No LED flashes

10. Optionally you can change the IP address of the router on the **LAN** page, section **Ethernet**.



11. After the configuration connect the 3G router again with the logger via Ethernet to enable a transmission of the logging data.

4.19 Tutorial 18: Record images with a HostCAM (GL3000/GL4000/GL5000 Series)



Example: The following example describes the initial setting of the network cameras HostCAM and F44 and how to create logger configurations that allow you to record the images of the camera with the loggers of the GL3000/GL4000/GL5000 series.



Note:

- > For the recording the camera is connected to the GL3000/GL4000 Ethernet connection **ETH 2**. For the GL5000 the camera is connected to one of the Ethernet ports **EP1** to **EP5**.
- > Camera F44 can only be connected to the GL5000.
- > For operation, a license must be installed either on the logger or on the camera. Please note that licenses cannot be transferred from the logger to the camera and vice versa.
- > If multiple cameras are triggered simultaneously, it may result that during the image transmission, the storage of recorded bus data to the memory medium is delayed. That may lead to a temporary impossibility to record any bus data.

4.19.1 Setting up the HostCAM/F44








Note:

The HostCAM/F44 is connected to the PC via Ethernet. It is recommended to use an USB-to-Ethernet adapter in order to access the camera outside of the company network.

The camera must be set up once as described hereafter before using it together with the GL3000/GL4000/GL5000.



1. Connect the **HostCAM** or **F44** to the PC using the Ethernet interface and supply it with voltage.
2. Start the **Vector Logger Configurator**.
3. Open in the menu **Tools|HostCAM Setup...** the dialog **HostCAM Setup**.
4. Select under **Network interface** the network adapter to which the camera is connected.
5. Click on the button  in order to search for connected cameras and to read their current settings.
6. Load the default settings of the camera via the button  **Set default settings**. If you have already set up the camera before, you may skip this step.
7. Adjust your settings in the table for **Main unit** and **Sensors**:
 - > Set up the ID of the camera (HostCAM1 ... HostCAM4), particularly if you connect multiple cameras to the logger.
In this example the default value **HostCAM1** is used.
 - > The IP address of the camera must be in the same subnet as the **GL3000/GL4000** (192.168.9.3) or **GL5000** (192.168.9.4). It must not be identical to the IP address of the logger. In most cases the default value 192.168.9.90 can be set especially if only one camera is connected.
In this example the default value **192.168.9.90** is used.
 - > **Wide Dynamic Range Mode** (only for F44 model). This mode improves the illumination in situations with strong contrast between bright and dark areas.
 - > Resolution
 - > Image frequency (frame rate)
 - > Select for your use case the mode **Triggered capturing** or **Long-term capturing**.
 - > If you chose the mode **Triggered capturing**, enter the pre and post-trigger times.
8. **For use in the USA:** Change under **Advanced** the power line frequency to 60 Hz.
9. Load the settings into the camera via the button .
10. Save the settings in a file via the button  | **Save settings** in order to be able to check them later without needing to connect the camera or to be able to use the same settings on other cameras.
11. Remove the camera from the PC and connect it to the **GL3000/GL4000** connection **ETH 2** or to the **GL5000** to one of the Ethernet ports **EP1** to **EP5**.



4.19.2 Configuration of a Triggered Capturing



Example: The following example describes the configuration of a triggered capturing of images by a HostCAM or a F44 with one sensor in the **Vector Logger Configurator**. The capturing shall always be started when Panel Key 1 is pressed. The status of the camera is displayed on LED2 and the triggering of the camera on LED3.



Note:

> Requirement

- During the setup of the HostCAM/F44, the **Triggered capturing** mode has been set.
- > The triggers should be chosen so that there is enough time between two triggers to allow the images of the last trigger to be transmitted.
- > During the image transmission, no other trigger signals can be received or evaluated by the logger.
- > For each measurement of a trigger, the images are stored in one ZIP file.



1. Start the **Vector Logger Configurator**.
2. Create a new project via **File|New Project...** or load via **File|Open Project...** an existent project to which the image recording shall be added.

Activation of the camera

3. Open the **Hardware** node in the tree view.
4. Click on **HostCAM**.
5. Activate the camera **HostCAM1**.
6. For the **GL5000**, additionally select the model P1214_E or **F44**(1).
Select also sensor 1 with a connected **F44**.
7. Set up the IP address of the camera. The presetting **192.168.9.90** corresponds to the default setting of the first camera. It can be changed as described above.
8. Choose the mode **Triggered capturing**.
9. Choose **Marker message...** (optional)

Configuration of a trigger event

10. Open the **Logging Memory 1|Trigger** node in the tree view.
11. Choose the mode **Triggered logging**.
12. Choose the trigger event **Key** and in the following dialog **Panel Key 1**.
13. Click in the column **Action/HostCAM** on [...] in order to activate the HostCAM1 on this trigger.
14. Activate in the dialog **Action Settings** the **HostCAM1** and **Trigger capturing**.
15. Close the dialog with **[OK]**.

Configuration of a LED

16. Open the **Output|LEDs** node in the tree view.
17. Select at **LED 2** the **HostCAM status** for the **HostCAM1**.
18. Select at **LED 3** the **HostCAM trigger** for the **HostCAM1**.
19. Save the configuration on your PC.
20. Load the configuration into the logger as described in **Tutorial 4**.

**Note:**

- > The triggers should be triggered by activating the key in the way that there is enough time between two triggers to allow the images of the last trigger to be transmitted.
- > When triggered, the image data are transmitted from the camera to the logger. It is impossible to trigger further camera recordings during the transmission.
- > For each camera recording, the images are stored in one ZIP file.

4.19.3 Configuration of a Long-term Capturing



Example: The following example describes the configuration of a long-term capturing of images by a HostCAM/F44 in the **Vector Logger Configurator**. The capturing shall be started by Panel Key 3 and stopped by Panel Key 4. The status of the camera is displayed on LED2. The running image capturing is displayed on LED 3.



Note:

> **Requirements:**

- > During the setup of the camera, the **Long-term capturing** mode has been set.
- > The picture resolution and image frame must be set low enough (e.g. 1 image per second).
- > For each measurement (without an interruption), the images are stored in one ZIP file. When the file reaches the size of 250 MB the capturing will be continued in a new ZIP file.



1. Start the **Vector Logger Configurator**.
2. Create a new project via **File|New Project...** or load via **File|Open Project...** an existent project to which the image recording shall be added.

Activation of the camera

3. Open the **Hardware** node in the tree view.
4. Click on **HostCAM**.
5. Activate the camera **HostCAM1**.
6. For the **GL5000**, additionally select the model P1214_E or **F44(1)**.
Select also sensor 1 with a connected **F44**.
7. Set up the IP address of the camera. The presetting **192.168.9.90** corresponds to the default setting of the first camera. It can be changed as described above.
8. Choose the mode **Long-term capturing**.

Configuration of start/stop events

9. Open the **Logging Memory 1|Trigger** node in the tree view.
10. Choose the mode **Conditioned long-term logging**.
11. Choose the trigger event **Key** and in the following dialog **Panel Key 3**.
12. Click in the column **Action/HostCAM** on [...] in order to activate the **HostCAM1** on this trigger.
13. Activate in the dialog **Action Settings** the **HostCAM1** and **Start capturing**.
14. Close the dialog with **[OK]**.
15. Choose again the trigger event **Key** and in the following dialog **Panel Key 4**.
16. Click in the column **Action/HostCAM** on [...].
17. Activate in the dialog **Action Settings** the **HostCAM1** and **Stop capturing**.
18. Close the dialog with **[OK]**.

Configuration of a LED

19. Open the **Output|LEDs** node in the tree view.
20. Select at **LED 2** the **HostCAM status** for the **HostCAM1**.
21. Select at **LED 3** the **HostCAM trigger** for the **HostCAM1**.
22. Save the configuration on your PC.
23. Load the configuration into the logger as described in [Tutorial 4](#).

5 Index

3

3G data transmission.....56

A

Automated sequences 19

C

CANape20

CCP/XCP 20, 33

Classification..... 12, 33

Configuration38

Conversion.....40, 41, 44

Conversion profiles36

D

Data compression 16

DBC file.....50

Dec/Hex36

Decimal values36

Diagnostic data55

Diagnostics 23, 33

Download 17, 40, 41, 44

F

F44.....60

FIBEX file51

File Manager34

Filter 16, 45

G

General32

General settings.....36

H

Hardware31

Hexadecimal values.....36

HostCAM60

I

Installation 30

Interface 53

K

Keys 8

L

LED 8

Logging formats 18

Logging memory 32

M

Marker 14

Memory media 16

Monitoring interface 25

N

Navigator 19

O

Operating mode 15

Output 33

Overwrite mode..... 15

P

Pack&Go 19

Permanent Logging..... 12

Property panel..... 35

R

Read out 41

Real-time clock 35

Refresh 36

Ring buffer 9

S

Seed & Key 21, 46, 50

SKB file 47

Stop Logging mode..... 15

Support6

T

Toolbar.....35, 36

Tree View.....31

Trigger.....10, 11, 45

Tutorial 37

U

Upload..... 17, 41, 44

X

XCP/CCP 46, 50

XCP/CCP license..... 49



More Information

- > News
- > Products
- > Demo Software
- > Support
- > Training Classes
- > Addresses

www.vector.com