



Component Location






1. Power door mirror

2. Power door mirror switch

Component




Mirror switch connector (12pin)



Inspection

1. Disconnect the negative (-) battery terminal.
2. Remove the front door trim panel.
(Refer to the Body group - "Front door")
3. Disconnect the 12P connector from the switch.




4. Check for continuity between the terminals in each switch position according to the table.

Item	Terminal Position	4	5	3	2	6	1	7	9
Left	UP	○	○	○	○	○	○	○	○
	DOWN	○	○	○	○	○	○	○	○
	OFF	○	○	○	○	○	○	○	○
	LEFT	○	○	○	○	○	○	○	○
	RIGHT	○	○	○	○	○	○	○	○
Right	UP			○	○	○	○	○	○
	DOWN			○	○	○	○	○	○
	OFF			○	○	○	○	○	○
	LEFT			○	○	○	○	○	○
	RIGHT			○	○	○	○	○	○

Inspection

1. Remove the front door quadrant delta cover.
(Refer to the Body group - "Front door")
2. Disconnect the power door mirror connector from the harness.



3. Apply battery voltage to each terminal as shown in the table and verify that the mirror operates properly.

Terminal Position	7	16	6	B+	GND
UP	○	○	○	○	○
DOWN	○	○	○	○	○
OFF	○	○	○	○	○
RIGHT	○	○	○	○	○
LEFT	○	○	○	○	○

Mirror Heater Inspection

Terminal Position	4	13
Heater	○	○

Side Repeater Lamp

Terminal Position	12	11
Lamp	B	E