


**Component (Open Type)**




1. Drive pinion nut
2. Companion flange
3. Front oil seal
4. Pinion front bearing
5. Differential carrier
6. Gasket
7. Filler plug
8. Side oil seal
9. Drain plug
10. Gasket
11. Pinion bearing adjusting spacer  
(Collapsible spacer)

12. Pinion rear bearing
13. Pinion height adjusting shim
14. Drive pinion gear
15. Side bearing adjusting washer
16. Side bearing
17. Side gear thrust washer
18. Side gear
19. Pinion mate shaft
20. Pinion mate gear
21. Pinion mate thrust washer
22. Drive gear(Ring gear)
23. Lock pin

24. Differential case
25. Ring gear bolt
26. Bearing cap
27. Bearing cap bolt
28. Dowel pin
29. Rear cover
30. Air breather
31. Cover bolt

**Component (LSD Type)**




1. Drive pinion nut
2. Companion flange
3. front oil seal
4. Pinion front bearing
5. Differential carrier
6. Gasket
7. Filler plug
8. Side oil seal
9. Drain plug

10. Gasket
11. Pinion bearing adjusting spacer  
(Collapsible spacer)
12. Pinion rear bearing
13. Pinion height adjusting shim
14. Drive pinion gear
15. Side bearing adjusting washer
16. Side bearing
17. Drive gear(Ring gear)
18. Limited slip differential assy(LSD)

19. Ring gear bolt
20. Bearing cap
21. Bearing cap bolt
22. Dowel pin
23. Rear cover
24. Air breather
25. Cover bolt

## Replacement

1. Drain the differential gear oil.





2. Remove the rear driveshaft(Refer to DS group-Rear driveshaft)
3. Remove the propellshaft assembly(Refer to DS group-Propellshaft)
4. Loosen the differential carrier assembly mount bolts and than remove the differential assembly(A)

---

### Tightening torque Nm (kgf.m, lb-ft) :

80~100 (8.0~10.0, 57.8~72.3)

---




5. Installation is the reverse order of removal.

## Disassembly

### Rear differential carrier


1. Before disassembling Rear differential carrier, drain off oil from Rear differential carrier.




**NOTE**

For the first time of oil change, there is a possibility that oil color looks black due to a phosphating wear.


2. Remove the cover bolts.




3. Before disassembling differential case assembly, paint match marks on one side of the bearing cap.




4. Loosen bearing cap bolts and remove bearing caps.



5. Lift differential case assembly out with tool.



6. Keep the side bearing outer races together with inner races.




#### NOTE

Do not mix them up.


Also, keep side bearing adjusting washers together with bearings.

#### Diff assembly Disassembly

1. Remove side bearing inner races. To prevent damage to bearing, engage puller jaws in groove.




2. Be careful not to confuse left- and right-hand parts.




3. Loosen ring gear bolts.

Tap drive gear off the differential case with a soft hammer.


Tap evenly all around to keep drive gear from binding.



4. Drive out pinion mate shaft lock pin with punch from drive gear side.



5. Remove the pinion mate shaft.




6. Remove side gears, pinion mate gears, side gear thrust washers, pinion mate thrust washers from differential case.




### **Pinion assembly disassembly**

1. Loosen the pinion locking nut.




2. Using the press, take out drive pinion (together with pinion rear bearing inner race, pinion bearing adjusting spacer)


Remove companion flange.



3. Using the press, remove pinion rear bearing inner race and pinion height adjusting shim .




4. Using the screwdriver, remove front oil seal.









5. Using the screwdriver, Remove side oil seals.






## Inspection

1. Check the tooth contact pattern.

Tooth contact	Contact state	Solution	
Standard contact			
1. Heal contact		<p>Increase the thickness of the pinion height adjusting shim, and position the drive pinion closer to the center of the drive gear.</p> <p>Also, for backlash adjustment, reposition the drive gear further from the drive pinion.</p>	
2. Face contact			
3. Toe contact		<p>Decrease the thickness of the pinion height adjusting shim, and position the drive pinion further from the center of the drive gear.</p> <p>Also, for backlash adjustment, reposition the drive gear closer to the drive pinion.</p>	
4. Flank contact			



#### NOTE


1. Tooth contact pattern is a method for judging the result of the adjustment of drive pinion height and final drive gear backlash. The adjustment of drive pinion height and final drive gear backlash should be repeated until the tooth contact patterns are similar to the standard tooth contact pattern.
2. When you cannot obtain a correct pattern, the drive gear and drive pinion have exceeded their limits. Both gears should be replaced as a set.

Content		Measures
Hypoid gear set(14+22) (Drive pinion & Drive gear)		If the gear teeth do not mesh or line-up correctly, determine the cause and adjust, repair, or replace as necessary. If the gear are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with a new gear set.
Bearing (4, 12, 16)		If found any chipped (by friction), pitted, worn, rusted, scratched mark, or unusual noise from the Bearing, replace with a new bearing ASSY (as a new set)
Oil seal (3, 8)		Oil seals must be replaced with a new one whenever disassembled.
Differential carrier (5)		Replace with a new one if found any wear or cracks on the contact sides of the Differential carrier.
Companion flange (2)		Replace with a new one if found any chipped marks or other damage on the contact sides of the Lips of the front oil seal.
Open type diff assy	side gear(18) & pinion mate gear(20)	Replace with a new one if found that it is chipped (by friction), damaged, or unusual worn.
	side gear thrust washer(17) & pinion mate thrust washer (21)	Replace with a new one if found that it is chipped (by friction), damaged, or unusual worn.
Lsd type diff assy	Limited slip differential assy (18)	Replace with a new one if found any wear or cracks on the contact sides of the Limited slip differential assy.


## Reassembly

### Pinion assembly


1. Press-fit pinion front and rear bearing outer races with tools.



2. Install selected pinion height adjusting shim in drive pinion gear.  
Using press and tool, press-fit pinion rear bearing inner race into it.




3. Install the pinion bearing adjusting spacer to the drive pinion.



**CAUTION**

Pinion bearing adjusting spacer is not reusable.  
Never reuse pinion bearing adjusting spacer.


4. Using press and tool, press-fit pinion front bearing inner race.




**NOTE**

The pressure do not exceed 5ton.

5. Using press and tool, press-fit front oil seal.



6. Using press and tool, press-fit companion flange.



**NOTE**


The pressure do not exceed 5ton.

7. Install the pinion locking nut to make that the bearing freeroad is standard.

---


**Tightening torque Nm (kgf.m, lb-ft) :**  
 112.7~161.8 (11.5~16.5, 83.1~119.3)

---




### Differential case

1. Fix the diff assembly with both hands and install it to the differential carrier.



2. Insert the left/right diff shim between the diff side bearing and carrier. And then install the bearing cap with marks.




3. Measure drive gear-to-drive pinion backlash with a dial indicator at several point.

---

**Standard** :0.10~0.15mm

---



#### NOTE


Thickness of the diff shim need to adjusted if backlash is small. Lessen the thickness of the left side diff shim. By contraries enlarge the thickness of the right side diff shim that much.

4. Check total preload with tool.

---

Standard : Pinion freerod : 1.9~4.9(0.2~0.5, 1.4~3.6)

---



5. Applies liquid sealant to differential carrier as shown in figure




6. Install the differential cover.


---

**Tightening torque Nm (kgf.m, lb-ft) :**  
 39.2~49.0 (4.0~5.0, 28.9~39.1)

---



7. Using press and tool, press-fit side oil seals.




8. Install the drain plug and pinar plug.

---

**Pillar plug** : 39.2~58.8(4.0~5.0, 28.9~43.3)

**Drain plug** : 49.0~68.6(5.0~7.0, 36.1~50.6)

---



9. Tighten air breather.

---

**Tightening torque Nm (kgf.m, lb-ft) :**

9.8~19.6 (1.0~2.0, 7.2~14.4)

---

