

Engine Coolant Refilling And Bleeding

WARNING

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.

CAUTION

When pouring engine coolant, be sure to shut the relay box lid and not to let coolant spill on the electrical parts or the paint. If any coolant spills, rinse it off immediately.

1. Make sure the engine and radiator are cool to the touch.
2. Remove radiator cap.
3. Loosen the drain plug, and drain the coolant
4. Tighten the radiator drain plug securely.
5. After draining engine coolant in the reservoir tank, clean the tank.
6. Fill the radiator with water through the radiator cap and tighten the cap.

NOTE

Pressure can blow water back out the radiator cap-pour water slowly while intermittently squeezing the radiator hoses.

7. After warming up the engine until the cooling fan operates several times, accelerate it at idle.
8. Wait until the engine is cool.
9. Repeat the step 1 to 8 until the drained water is clean.
10. Fill fluid mixture with coolant and water(5 : 5) (Tropical region – 4:6) slowly through the radiator cap. Push the upper/lower hoses of the radiator so as bleed air easily.

NOTE

- Use only genuine antifreeze/coolant.
- For best corrosion protection, the coolant concentration must be maintained year-round at 35% minimum.
Coolant concentrations less than 35% may not provide sufficient protection against corrosion or freezing.
- Coolant concentrations greater than 60% will impair cooling efficiency and are not recommended.

CAUTION

- Do not mix different brands of antifreeze/coolants.
- Do not use additional rust inhibitors or antirust products; they may not be compatible with the coolant.


11. Start the engine and run coolant circulates.
When the cooling fan operates and coolant circulates, refill coolant through the radiator cap.
 12. Repeat 11 until the cooling fan 3 ~ 5times and bleed air sufficiently out of the cooling system.
 13. Install the radiator cap and fill the reservoir tank to the "MAX" line with coolant.
 14. Run the vehicle under idle until the cooling fan operates 2 ~ 3 times.
 15. Stop the engine and wait coolant to cool.
 16. Repeat step.10 to step.15 until the coolant level doesn't fall any more, bleed air out of the cooling system
-

NOTE

As it is to bleed air out to the cooling system and refill coolant when coolant gets cool completely, recheck the coolant level in the reservoir tank for 2 ~ 3 days after replacing coolant.

Coolant capacity : 5.5 L

Components




- 1. Radiator assembly
- 2. Radiator mounting bracket
- 3. Mounting insulator
- 4. Intercooler

- 5. Radiator upper hose
- 6. Radiator lower hose
- 7. Cooling fan assembly

Inspection

Radiator Cap Test


1. Remove the radiator cap, wet its seal with engine coolant, then install it no pressure tester.



2. Apply a pressure of 93 ~ 123kPa (0.95 ~ 1.25kgf/cm², 14 ~ 19psi)
3. Check for a drop in pressure.
4. If the pressure drops, replace the cap.

Radiator Leakage Test

1. Wait until engine is cool, then carefully remove the radiator cap and fill the radiator with engine coolant, then install it on the pressure tester.




2. Apply a pressure tester to the radiator and apply a pressure of 93 ~ 123kPa (0.95 ~ 1.25kgf/cm² 14 ~18 psi).
3. Inspect for engine coolant leaks and a drop in pressure.
4. Remove the tester and reinstall the radiator cap.

NOTE

Check for engine oil in the coolant and/or coolant in the engine oil.

Removal

1. Remove the drain plug and drain the engine coolant.




2. Disconnect the breather hose (A), vacuum hose (B) and remove the air duct (C), air cleaner assembly (D).


Tightening torque :

Bolt : 7.8 ~ 9.8N.m (0.9 ~ 1.1kgf.m, 5.8 ~ 7.2lb-ft)

Clamp : 2.9~ 4.9N.m (0.3 ~ 0.5kgf.m, 2.1 ~ 3.6lb-ft)



3. Remove the radiator upper hose (A).




4. Disconnect the intercooler inlet hose (A), radiator lower hose (B).


Tightening torque :

Bolt : 14.7 ~ 19.6N.m (1.5 ~ 2.0kgf.m, 10.8 ~ 14.4lb-ft)

Clamp : 4.9~ 6.8N.m (0.5 ~ 0.7kgf.m, 3.6 ~ 5.0lb-ft)




5. Disconnect the BPS connector (A) and intercooler outlet hose (B).




6. Remove the radiator.

- (1) Remove the cooling fan connector(A).
- (2) Remove the reservoir tank(B).
- (3) Remove the fan assembly(C).
- (4) Remove the radiator after removing the radiator upper mounting bracket(D).



7. Installation is the reverse of removal.
8. Fill the engine coolant.
9. Start the engine and check for leaks.
10. Recheck the coolant level.

Components




Torque : N.m (kgf.m, lb-ft)

1. Water outlet pipe assembly
2. Water temp. control assembly
3. Heater bypass pipe & hose assembly
4. Turbo charger water pipe
5. Water pump


6. Thermostat
7. Water inlet fitting
8. Water pump pulley
9. Air vent hose & pipe
10. Gasket

Removal

1. Remove the drain plug (A) and drain the engine coolant.




2. Remove the drive belt (A).



3. Remove the water pump (A) and water pump gasket (B).

Tightening torque :

18.6 ~ 23.5Nm (1.9 ~ 2.4kgf.m, 13.7 ~ 17.4lb-ft)



4. Installation is the reverse of removal with a new water pump gasket.
5. Fill the engine coolant.
6. Start the engine and check for leaks.
7. Recheck the coolant level.

Inspection

1. Check each part for cracks, damage or wear, and replace the coolant pump assembly if necessary.
2. Check the bearing for damage, abnormal noise and sluggish rotation, and replace the coolant pump assembly if necessary.
3. Check for coolant leakage. If coolant leaks from hole, the seal is defective. Replace the coolant pump assembly.

NOTE

A small amount of 'weeping' from the bleed hole is normal.

GENESIS COUPE(BK) >2010 > G 2.0 DOHC > Engine Mechanical System > Cooling System > Water pump > Troubleshooting

Troubleshooting

Symptoms		Possible Causes		Remedy
Coolant leakage	• From the bleed hole of the water pump	Naked eye observation	• Check leaks after about ten-minute warming up.	• If coolant still leaks, replace a water pump.
	• From gaskets or bolts		• Check the tightening of the water pump mounting bolts.	• If leakage stops, reuse the water pump (Do not replace the pump with a new one).
	• From outer surface of water pump		• Check damage of gaskets or inflow of dust.	• Retighten the mounting bolts.
	• From outer surface of water pump		• Check the material or any cracks of the water pump.	• Replace the gasket and clean dust off.
Noise	• From bearings • From mechanical seals • Impeller interference	Inspection with a stethoscope	• After starting the engine, check noise with a stethoscope.	• If there is no noise, reuse the water pump(do not replace it).
				• If there is any noise from the water pump, remove the drive belt and recheck.
		Inspection after removing a drive belt	• After removing a water pump and a drive belt, check noise again.	• If there is noise, reuse the water pump. Check other drive line parts.
				• If there is no noise, replace the water pump with a new one.
		Inspection after removing a water pump	• After removing a water pump and a drive belt, check noise again.	• If there is any interference between them, replace the water pump with a new one.
Overheating	• Damaged impeller • Loosened impeller	Loosened impeller	• Corrosion of the impeller wing	• Check engine coolant. • Poor coolant quality / Maintenance check
			• Impeller separation from the shaft	• Replace the water pump.

Removal

NOTE

Removal of the thermostat would have an adverse effect, causing a lowering of cooling efficiency. Do not remove the thermostat, even if the engine tends to overheat.


1. Drain the engine coolant so its level is below the thermostat.
2. Remove the water inlet fitting (A) and thermostat (B).

Tightening torque :

18.6 ~ 23.5Nm (1.9 ~ 2.4kgf.m, 13.7 ~ 17.4lb-ft)

NOTE

Install the thermostat with jiggle valve upward.



3. Installation is the reverse of removal.
4. Fill the engine coolant.
5. Start the engine and check for leaks.
6. Recheck the coolant level.

GENESIS COUPE(BK) >2010 > G 2.0 DOHC > Engine Mechanical System > Cooling System > Thermostat > Troubleshooting

Troubleshooting

Symptoms		Possible Causes		Remedy
Coolant leakage	<ul style="list-style-type: none"> From the thermostat gasket 	Check the mounting bolts	<ul style="list-style-type: none"> Check the torque of the mounting bolts 	<ul style="list-style-type: none"> Retighten the bolts and check leakage again.
		Check the gasket for damage	<ul style="list-style-type: none"> Check gasket or seal for damage 	<ul style="list-style-type: none"> Replace gaskets and reuse the thermostat.
Cooled excessively	<ul style="list-style-type: none"> Low heater performance (cool air blown-out) Thermogauge indicates 'LOW' 	Visually check observation after removing the radiator cap.	<ul style="list-style-type: none"> Insufficient coolant or leakage. 	<ul style="list-style-type: none"> After refilling coolant, recheck.
		GDS check & Starting engine	<ul style="list-style-type: none"> Check DTCs Check connection of the fan clutch or the fan motor. ※ If the fan clutch is always connected, there will be a noise at idle.	<ul style="list-style-type: none"> Check the engine coolant sensor, wiring and connectors. Replace the components.
		Remove the thermostat and inspect	<ul style="list-style-type: none"> Check if there are dusts or chips in the thermostat valve. Check adherence of the thermostat. 	<ul style="list-style-type: none"> Clean the thermostat valve and reuse the thermostat. Replace the thermostat, if it doesn't work properly.
Heated excessively	<ul style="list-style-type: none"> Engine overheated Thermogauge indicates 'HI' 	Naked eyes observation after removing the radiator cap.	<ul style="list-style-type: none"> Insufficient coolant or leakage. ※ Be careful when removing a radiator cap of the overheated vehicle. <ul style="list-style-type: none"> Check air in cooling system. 	<ul style="list-style-type: none"> After refilling coolant, recheck. Check the cylinder head gaskets for damage and the tightening torque of the mounting bolts.
		GDS check & Starting engine	<ul style="list-style-type: none"> Check DTCs Check the fan motor performance as temperature varies. Check if the fan clutch slips. Check the water pump adherence or impeller damaged. 	<ul style="list-style-type: none"> Check the engine coolant sensor, wiring and connectors. Check the fan motor, the relay and the connector. Replace the fan clutch, if it doesn't work properly. Replace the water pump, if it doesn't work properly.
		Immerse the thermostat in boiling water and inspection.	<ul style="list-style-type: none"> After removing the thermostat, check it works properly. ※ Check the thermostat opens at the valve opening temperature.	<ul style="list-style-type: none"> Replace the thermostat, if it doesn't work properly.