

# Service Instructions

## VULCAN

A-130	3-130	3-550PD
A550	3-550	3-550A
A-1750	3-1750	3-1750A

DENTSPLY Ceramco  
Yucaipa, CA

## **SAFETY FIRST**

- \* Don't bypass the power cord's ground lead with two-wire extension cords or plug adaptors.
- \* Don't disconnect green/yellow safety-earth ground wire that connects the ground lug of the power receptacle to the chassis ground.
- \* Don't plug in the power cord until directed by the installation instructions.
- \* Don't repair the furnace unless you are a qualified technician and know how to work with hazardous voltages.
- \* Don't locate and operate the furnace in close proximity to combustible materials.
- \* Observe all WARNING statements. They point out situations that can cause injury or equipment damage.

# TABLE OF CONTENTS

## SECTION 1

### CIRCUIT DESCRIPTION A-CONTROL

1.1	INTRODUCTION .....	1-1
1.2	CIRCUIT DESCRIPTION .....	1-1
1.2.1	Analog Meter Readout .....	1-1
1.2.2	Front Panel Controls .....	1-1
1.2.3	Muffle Control .....	1-1
1.2.4	Power Supply .....	1-1

## SECTION 2

### TROUBLESHOOTING A-CONTROL

2.1	FACTORY REPAIR .....	2-1
2.2	BEFORE YOU START .....	2-1
2.3	TROUBLESHOOTING GUIDES .....	2-1
2.3.1	Power Supply .....	2-1
2.3.2	Analog Circuitry .....	2-1
2.3.3	Triac Drive .....	2-1
2.4	TROUBLESHOOTING COMPONENTS .....	2-1
2.5	BLOCK DIAGRAM .....	2-3
2.6	SCHEMATIC .....	2-4
2.7	CONTROL CIRCUIT BOARD .....	2-5
2.8	WIRING DIAGRAM .....	2-6

## SECTION 3

### CALIBRATION A-CONTROL

3.1	SCOPE .....	3-1
3.2	FACTORY REPAIR .....	3-1
3.3	ADJUSTMENTS .....	3-1
3.3.1	Door, Lift Drag Adjustment .....	3-1
3.4	CIRCUIT BOARD CALIBRATION .....	3-1
3.4.1	Required Test Equipment .....	3-1
3.4.2	Temperature .....	3-1

## SECTION 4

### CIRCUIT DESCRIPTION 3-STAGE

4.1	INTRODUCTION .....	
4.2	CIRCUIT DESCRIPTION .....	4-1
4.2.1	LCD Display Readout .....	4-1
4.2.2	Front Panel Control .....	4-1
4.2.3	Muffle Control .....	4-1
4.2.4	Power Supply .....	4-1
4.2.5	Motor Drive Control .....	4-1
4.2.6	Fan Drive Control .....	4-1

## SECTION 5

### TROUBLESHOOTING 3-STAGE

5.1	FACTORY REPAIR .....	5-1
5.2	BEFORE YOU START .....	5-1
5.2.1	Isolating a Problem .....	5-1
5.3	TROUBLESHOOTING GUIDES .....	5-1
5.3.1	Power Supply .....	5-1
5.3.2	Microprocessor .....	5-1
5.3.3	Peripheral Drive .....	5-1
5.3.4	Motor Drive .....	5-1
5.3.5	Analog Circuitry .....	5-1
5.3.6	Display Board .....	5-1
5.3.7	Fan Drive Control .....	5-2

5.4	TROUBLESHOOTING COMPONENTS .....	5-2
5.5	ERROR CODES .....	5-3
5.6	DIAGNOSTIC TABLES .....	5-4
5.7	BLOCK DIAGRAM .....	5-8
5.8	SCHEMATICS .....	5-9
5.9	WIRING DIAGRAM .....	5-12

## SECTION 6

### ADJUSTMENT/CALIBRATION 3-STAGE

6.1	SCOPE .....	6-1
6.2	FACTORY REPAIR .....	6-1
6.3	ADJUSTMENT/CALIBRATION .....	6-1
6.3.1	Temperature .....	6-1
6.3.2	Door, Lift Drag Adjustment .....	6-1
6.4	CIRCUIT BOARD CALIBRATION .....	6-1
6.4.1	Required Test Equipment .....	6-1
6.4.2	Temperature .....	6-1

## SECTION 7

### SERVICE PARTS

7.1	ORDERING INSTRUCTIONS .....	7-1
7.2	MUFFLE AND THERMOCOUPLE .....	7-1
7.3	MUFFLE (3-550 PD / AIR EXCH) .....	7-2
7.4	CABINET PARTS .....	7-3
7.5	DOOR PARTS .....	7-4
7.6	A-CONTROLLER PARTS .....	7-5
7.7	3-STAGE & 3-550 CONTROLLER PARTS .....	7-6
7.8	LIFT MECHANISM PARTS (3-550PD) .....	7-7

## SECTION 8

### DISASSEMBLY/REASSEMBLY

8.1	CONTROL DRAWER REMOVAL .....	8-1
8.2	TRIAC .....	8-1
8.3	MEMBRANE SWITCH .....	8-2
8.4	DISPLAY PCB .....	8-3
8.5	A-CONTROL PCB .....	8-4
8.6	3 STAGE CONTROL PCB .....	8-5
8.7	DOOR ASSEMBLY/ADJUSTMENT .....	8-6
8.8	HEATING PLATES .....	8-7
8.9	MUFFLE REPLACEMENT .....	8-8
8.10	THERMOCOUPLE (A-Control) .....	8-9
8.11	THERMOCOUPLE (3 STAGE) .....	8-9
8.12	MUFFLE REPLACEMENT (3-550 PD) .....	8-10
8.13	THERMOCOUPLE (3-550PD) .....	8-11
8.14	POWER SWITCH .....	8-12
8.15	POWER DOOR REPLACEMENT .....	8-13



### 2.1 FACTORY REPAIR

DENTSPLY Ceramco maintains a factory repair department for those customers not possessing the necessary personnel or test equipment to maintain the VULCAN. If a unit is returned to the factory for calibration or repair, a detailed description of the specific problem should be attached to minimize turnaround time. Call factory for RMA number before shipping at 909.795.2461.

### 2.2 BEFORE YOU START

Since no troubleshooting guide can possibly cover all the potential problems, the aim of this guide is to give a methodology which, if applied consistently, will lead to the problem area. Therefore, it is necessary to familiarize yourself with the VULCAN by reviewing the functional description in conjunction with the schematic. Successful troubleshooting depends upon understanding the circuit operation.

#### WARNING:

With covers removed, dangerous voltage points may be exposed. Contact with any of these points could cause serious injury.

### 2.3 TROUBLESHOOTING GUIDES

#### WARNING:

When measuring voltages use battery operated test equipment unless an isolation transformer is connected between circuit input and AC line.

#### 2.3.1 Power Supply

Rectifier diodes D2 and D3 convert the AC line voltage to a DC voltage, while resistors R11, R12 reduce the current flow thru the 8.6V internal zener diode of U2 and the 6.8V external zener diode D1. Capacitors C1 and C5 filter the rectified voltages. Most of the circuit's current consumption is taken up by the triac gate drive.

#### 2.3.2 Analog Circuitry

The thermocouple voltage which ranges from 0-45mV (25°C - 1100°C) is multiplied by amplifier U1 approximately 100 times (depending on the setting of potentiometer RP1) and added to the negative setpoint voltage from RP2. A sawtooth voltage signal is generated by U2 from a constant current source charging capacitor C4. The value of C4 determines the burst period of the triac output (typically 8 seconds). The triac gate output pulse current is about 60mA. The triac is triggered in quadrants II and III. Synchronization is provided by resistor R10. Its value determines the trigger pulse length.

#### 2.3.3 Triac Drive

A current pulse from U2 pin 6 of about 60mA will turn on the gate of the muffle triac which in turn will then carry the full load current. The voltage across the triac is now at 1-2 Vac. In order to comply with norms limiting the frequency at which a kW size load may be connected to the main line (fluorescent tubes "flickering") a proportional temperature control is provided by means of burst firing the triac.

#### NOTES:

---

---

---

---

---

---

---

---

### 2.4 TROUBLESHOOTING COMPONENTS

#### 2.4.1 Diode

A diode (except a zener) is defective if there is greater than 1 Vdc (typically 0.7 Vdc) forward voltage across it.

#### 2.4.2 Operational Amplifier

Generally, the "+" and "-" inputs of an operational amplifier will have less than 15 mV voltage difference when operating under normal conditions. If the output voltage stays at maximum positive (typically 1/3 of the supply voltage), the "+" input voltage should be more positive than the "-" input voltage. If the output voltage stays at minimum (typically 1-5 mV), the "-" input voltage should be more positive than the "+" input voltage.

#### 2.4.3 Triac

The gate to power line return voltage under load measures typically 1-2 Vac, while the MT2 to return voltage measures between 1.3-1.8 Vac. A triac without connections and no power applied can be checked for a go-no go condition with an ohmmeter. The gate to MT1 resistance for a power triac (20-40A) should be between 50 and 100 ohms; there should be infinite resistance between MT1 and MT2.

#### 2.4.4 Capacitor

Shorted capacitors have 0V across their terminals. Open capacitors can be located by using a good capacitor connected in parallel with the capacitor under test and observing the resulting effect.

Leaking capacitors will often have a decreased voltage across their terminals.

NOTES:

---

---

---

---

---


---


---

---

## 2.5 BLOCK DIAGRAM


A-CONTROL








**A-CONTROL**



## 2.8 WIRING DIAGRAM

**A-CONTROL**



### 3.1 SCOPE

This section gives the procedures to be used for the calibration and specification verification of the VULCAN. The furnace specifications are given in the Owner & Operator's Manual.

### 3.2 FACTORY REPAIR

DENTSPLY Ceramco maintains a factory repair department for those customers not possessing the necessary personnel or test equipment to maintain the VULCAN. If a unit is returned to the factory for calibration or repair, a detailed description of the specific problem should be included to minimize turnaround time. Call factory for RMA number before shipping at 909-.795.2461.

### 3.3 ADJUSTMENTS

#### 3.3.1 Door, Lift Drag Adjustment

The lift drag force is controlled by a set of friction washers on each of the upper pivot arms. If the drag becomes too stiff (too hard to open and close furnace) or too loose an adjustment can be made using the following procedure:

Tools required: 5/32" Allen Wrench

- Turn the allen head screws on the upper side of the furnace either clockwise to tighten or counterclockwise to loosen the drag force.

#### NOTE:

Equal adjustment should be made on each side  
Turn screws only 1/6 of a revolution at a time  
when making adjustment.

NOTES:

---

---

---

---

---

---

---

---

---

---

### 3.4 CIRCUIT BOARD CALIBRATION

Calibration of the VULCAN circuit board is performed in one single step.

#### 3.4.1 Required Test Equipment

- Multimeter
- Pot adjustment tool

#### WARNING

With control drawer opened, dangerous voltage points may be exposed. Contact with any of these points could cause serious injury.

#### 3.4.2 Temperature

Disconnect the power cord from the wall outlet and open the control drawer. Connect the black lead of the ohmmeter to the red thermocouple connection on temperature meter. Touch the red lead of the ohmmeter to the leg with a circle on R13. Adjust RP1 to read 1060 ohms on the ohmmeter.

On models A-550 rated at 120V the potentiometer RP3 should be adjusted the following way:

Touch the black lead of the ohmmeter to pin 3 of U3 and the red lead to the leg of R14 closest to the front panel. Adjust RP3 to read between 19 and 20 Kohm on the ohmmeter. This adjustment limits the amount of current going thru the muffle by about 15% in order to comply with safety agency rulings. For all other models RP3 should be fully clockwise.

As an alternate circuit board calibration, without the use of an ohmmeter, bring the furnace temperature to the desired level. At steady state temperature insert a thermocouple, connected to a temperature monitor, into the exhaust opening of the furnace and after stabilization read the muffle temperature. Compare this reading with the temperature meter reading of the furnace. In several steps adjust RP1 to obtain equal readings. Allow ample time between adjustment steps since only a few watts are added/subtracted which each adjustment of RP1.

#### 4.1 INTRODUCTION

The purpose of this section is to familiarize the user or service personnel with the circuit level operation of the VULCAN. This knowledge is necessary to aid in troubleshooting of a unit's failure and may also allow the user to gain greater insight into the VULCAN's versatility for particular applications. A detailed description is given for the following circuit functions:

- \* Display Readout
- \* Front Panel Control
- \* Muffle Control
- \* Power Supply
- \* Motor Drive Control (option for 3-Stage)
- \* Temperature Measurement

The muffle temperature is derived from a Thermocouple (type "K") which generates an output voltage of up to 50mV. This feedback signal is then manipulated by the electronics to control the muffle temperature.

#### 4.2 CIRCUIT DESCRIPTION 3-STAGE

##### 4.2.1 LCD Display Readout

The display board converts serial data from the microprocessor to 8-bit parallel data. Each byte transferred is either a command or a data byte depending on the state of the two control bits RS and E (DIS ENA). The 16 character LCD module is controlled by the microprocessor via its Serial Peripheral Interface (SPI) port. The display is updated every 0.5 sec or when a corresponding front panel key has been activated.

##### 4.2.2 Front Panel Control

The power on/off switch switches the AC line voltage. The membrane switches are arranged in a 8x4 matrix. The microprocessor scans the entire matrix every 50 msec by setting one column at a time to a logic 0 and then reading the rows. Once a contact closure has been detected this value is stored.

##### 4.2.3 Muffle Control

The microprocessor (U10) sends a serial digital signal to an octal peripheral driver (U16) which in turn converts and latches it to parallel data. This parallel data is then used to drive several peripheral devices (See S006). U16-13 is connected to an opto isolator (U8). The isolator's output is connected to the gate of the muffle triac. The muffle triac may be activated anytime during an AC cycle, but once activated it can only be opened when the AC sine wave passes through 0 volts. U10 accesses U16 0.5 msec before zero crossing to turn the triac off. At this time a value calculated by the control routine determines how much time should elapse before the triac is turned on again.

##### 4.2.4 Power Supply

Two DC power supply voltages are generated on the control circuit board; +12V and +5V. These voltages are generated from the AC line voltage.

##### 4.2.4.1 +12V Supply:

The transformer T1 provides an AC voltage with a ground referenced center tap. This voltage is rectified by diodes D41 and D42 and filtered by capacitor C40. This provides unregulated positive DC voltage for the switching regulator U9. The capacitor C42 protects against high voltage transients on the AC line that couple into the transformer secondary. The output U9-2 is a pulse train with a period T of typically 19.2usec. The catch diode D43 is a Schottky device which provides a return path for the load current when the output switch is off. Inductor L2 and capacitor C46 filter and stabilize the +12V dc voltage.

##### 4.2.4.2 +5V Supply:

Refer to schematic, page 5-9. DC voltage from the output of U9 is used by the +5V linear regulator U7 to generate the +5V. The capacitor C48 provides additional filtering. The constant current source U2 as well as the 1.23V reference diode D1 generate their outputs from this supply.

##### 4.2.5 Motor Drive Control (3-550 PD)

The +12VDC motor which moves the door vertically is controlled by a 16 pin motor controller/driver I.C. This I.C. provides all necessary functions for a complete closed loop system. A two wire cable connects the motor to the 1 Amp H-bridge switch on the I.C. The microprocessor (U10) activates the H-switch through two input pins. If both are low the motor will turn in one direction, if both are high the motor turns in the opposite direction. A third pin sends a signal from the motor controller/driver I.C. to the microprocessor when the motor has stalled (up or down position).

##### 4.2.6 Fan Drive Control 3-550A/1750A

The air exchange fan is controlled by means of the front panel membrane switch. Speed selections are from 0 - 9 (0 is off and 9 is highest speed). Speed 1 selection changes the air in the muffle twice a minute.

##### NOTES:

---



---



---



---



---

## 5.1 FACTORY REPAIR

DENTSPLY Ceramco maintains a factory repair department for those customers not possessing the necessary personnel or test equipment to maintain the VULCAN. If a unit is returned to the factory for calibration or repair, a detailed description of the specific problem should be attached to minimize turnaround time. Call factory for RMA number before shipping at 909.795.2461.

## 5.2 BEFORE YOU START

Since no troubleshooting guide can possibly cover all the potential problems, the aim of this guide is to give a methodology which, if applied consistently, will lead to the problem area. Therefore, it is necessary to familiarize yourself with the VULCAN by reviewing the functional description and the detailed circuit description (Section 4) in conjunction with the schematics (Section 5). Successful troubleshooting depends upon understanding the circuit operation within each functional block as well as the block relationships

### **WARNING**

With covers removed, dangerous voltage points may be exposed. Contact with any of these points could cause serious injury.

The intent of this section is to provide the information to return the VULCAN to proper operation. Information is divided into two parts. Part one contains the overall furnace troubleshooting block diagram which is useful in isolating defective blocks within the furnace. Part two consists of a series of circuit guides, one for each block shown in the block diagram, that provides settings and measurements for troubleshooting an individual block. Also, each circuit guide references related schematics and circuit descriptions. Inspect the components, wiring and circuit boards of the VULCAN for damage. Finally, ensure that the fuses are intact and the internal power supplies are good.

### 5.2.1 Isolating a problem

To successfully troubleshoot this furnace, the symptoms must first be identified, the faulty block isolated, then analyzed, and finally the defective component located and replaced.

After the block is isolated, refer to the appropriate functional circuit guide.

The circuit guide provides some but not necessarily all of the possible failure modes for a particular circuit. Where applicable, a furnace setup procedure is given to help isolate the problem for a particular failure mode.

## 5.3 TROUBLESHOOTING GUIDES

### 5.3.1 Power Supply

To determine a faulty power supply use the table on page 5-3. To troubleshoot a faulty power supply use the procedures listed on page 5-4. If the desired results are obtained in each of the steps in the tables, replace D43, U9 or U7 as appropriate.

### 5.3.2 Microprocessor

Generally, when the furnace is totally nonfunctional, i.e., display is unintelligible, no display, random relay clicking, no key response, or the front panel LED's stay on at power up, the problem is in the microprocessor section. However, before troubleshooting this section, check the appropriate dedicated circuits for correct operation. Detailed reading of the circuit description is also very important. See page 5-5 to troubleshoot the microprocessor.

### 5.3.3 Peripheral Drive

The peripheral driver U16 is accessed at every line voltage zero crossing (TP1=0) by the microprocessor (U10-32,33). The logic state of the eight output drivers, Y0-Y7, is latched into the shift register at time t0 on the high to low transition of SIOE. Input data present at the SI input is clocked into the shift register on the high to low transition of SCLK. See page 5-6 to troubleshoot the peripheral driver.

### 5.3.4 Motor Drive (optional accessory)

The motor driver U13 is accessed by the microprocessor to lift or lower the door. Two LED's are connected across the internal power H-switch to indicate its state. When both LED's are either on or off the motor is deactivated. If one of the LED's is on the motor is activated. U13-15 provides a feedback to the microprocessor to indicate an overcurrent condition which is set at approximately 450mA by resistor R26. See page 5-6 to troubleshoot the motor driver.

### 5.3.5 Analog Circuitry

The reference voltages used to control temperature and compare voltage signals are derived from the output of U7-2 (+5V), U9, and D1. See schematics for troubleshooting individual components. See page 5-6 to troubleshoot the analog circuitry.

### 5.3.6 Display Board

Serial data present on the input of U1-2 and U2-2 is transferred to the shift register on the logic "0" to logic "1" transition of the Clock input pulse. Information present at any register of U1 is transferred to its respective latch

when the Strobe is high (U1-4). A serial to parallel conversion takes place. As long as the Strobe is held high ("1") the latches will accept new data. The LCD display module will accept valid data on D0 - D7 when the Enable (J1-6) goes from a high to low transition. See page 5-7 to troubleshoot the display circuit board.

#### 5.3.7 Fan Drive (Optional Accessory)

The 12V DC fan is controlled by a FET device which is activated by the microprocessor. At its highest setting (9), the fan receives the full 12V DC. At lower settings the fan receives +12V pulses, to reduce the rpm's.

### 5.4 TROUBLESHOOTING COMPONENTS

#### 5.4.1 Diode

A diode (except a zener) is defective if there is greater than 1 Vdc (typically 0.7 Vdc) forward voltage across it.

#### 5.4.2 Operational Amplifier

Generally the "+" and "-" inputs of an operational amplifier will have less than 15 mV voltage difference when operating under normal conditions. (U3, U4:B, U15:B). When the output of the amplifier is connected to the "-" input (voltage follower connection), the output should be the same voltage as the "+" input voltage; otherwise, the amplifier is defective (U17:A).

If the output voltage stays at maximum positive (typically 1/3 of the supply voltage), the "+" input voltage should be more positive than the "-" input voltage (U17:B, U18:A, U4:A). If the output voltage stays at minimum (typically 1-5 mV), the "-" input voltage should be more positive than the "+" input voltage (U15:A).

#### 5.4.3 Triac

The gate to power line return voltage (K1) under load measures typically 1-2 Vac, while the MT2 to return voltage measures between 1.3-1.8 Vac.

A triac without connections can be checked for a go-no go condition with an ohmmeter. The gate to MT1 resistance for a power triac (20-40A) should be between 50 and 100 ohms; there should be infinite resistance between MT1 and MT2.

#### 5.4.4 Capacitor

Shorted capacitors have 0V across their terminals. Open capacitors can be located by using a good capacitor connected in parallel with the capacitor under test and observing the resulting effect. Leaking capacitors will often have a decreased voltage across their terminals.

#### 5.4.5 Logic levels

Microprocessor:	High	+3.5	-	+5.0V
	Low	0.0	-	+1.0V
74LSXXX:	High	+2.0	-	+5.0V
	Low	0.0	-	+0.5V
4XXX(CMOS)	High	+3.5	-	+5.0V
	Low	0.0	-	+1.5V

## 5.5 ERROR CODES

### Err 1 Muffle Over Temperature

The controller monitored a temperature above 1220°C. This could mean a faulty thermocouple (mV reading too high) or an erratic thermocouple performance (the temperature readout is not stable at elevated temperatures).

### Err 2 Open TC Detected

To check for open TC, turn power to furnace off and short TC input terminals. Turn power back on. If ERR 2 disappears, then replace TC. Possible solutions:

Change PCB if problem persists.

### Err 3 Tmax Over Temp

The controller monitored a temperature above  $T_{max} + 20^{\circ}\text{C}$ . This could mean:

- \* The  $T_{max}$  was set up too low for this program
- \* The destination temperature is relatively low compared to the programmed heat rate, eg. too much temperature overshoot.

### Err 7 Low Line Voltage

When the line voltage drops below the required operating level for the microprocessor and its peripherals, the processor receives a signal from U3:A-1 and terminates its normal operation. This error is most likely displayed after power outages or the power line is downloaded by other high power equipment.

\* Turn the furnace off, then on again

\* Check the AC plus or minus sign during <TEST>.

\* ( - ) Indicates low line voltage.

### Err 8 EEPROM read/write error

Program parameters entered during the idle mode are transferred and stored in a 16K-bit Electrically Erasable Programmable Read Only Memory (EEPROM) device. The serial data on U11-5 is monitored and any abnormal behavior from the devices' specs is answered with an error code. Press ENTER and check:

\* Data, Clock train on U11-5,6

\* Replace device

### Err 19 No line frequency detected

\* Check TP5, 100 or 120 Hz pulse train

\* Remove Power

D4,5 diode check (2)

**Furnace Setup Common Errors**

Symptom	Possible Setup Error
Display blank	No line voltage Power switch failure J3 disconnected
No Setup functions after ENTER	Furnace was in start cycle at power down
Muffle does not heat after power up	Not in start cycle Door switch not closed
No door movement after switch is pressed	Furnace is in TEST mode Motor connector J5 loose

**Power Supply Voltages**

Output Voltage	Voltage Tolerance	Output Ripple	Test At	Input Ripple	Test At
+12V	+/-350mV	0.02Vac	U2-1	3Vac	U1-1
+ 5V	+/-250mV	0.02Vac	U2-2	3Vac	U2-1



**Power Supply**

Fault	Setup	Check	Results desired
No DC output and no DC to U1-1 (15-30V)	Power off	F1 T1 winding D1	< 1 ohm Not shorted or open Not shorted or open
Low or no +12V DC output	Power off  Disconnect J3 turn Power on	D1  C46 U1-2 U2	Not shorted  Not shorted Pulse train of 50kHz No excessive heat

**Microprocessor**

Fault	Setup	Check	Results desired
Nonfunctional operation	N/A	U10-39 X1 U10-1,3,34,40 U10-2 U10-16thru28 U10-12thru15 U10-4thru11 U10-29,30 U10-31,32,33	4MHz, sinusoid approximately 0-4V >4.5V TP1 waveform digital low No stuck bits No stuck bits digital high No stuck bits
	Disconnect	Listen	Relay clicks, Sonar
Non-responsive to membrane switches	Disconnect	+5V to U10-16 U10-17 U10-18 U10-19 U10-21thru28	Sonar beeps low strobe

**Peripheral Drive Circuit**

Fault	Setup	Check	Results desired
All Y outputs high	N/A	U16-11 U16-5,7,6	No stuck bits
	Turn furnace Off then On	Display/ LED's	No Error codes Display OK
	Turn furnace Off	D46,47	Not shorted or open

**Motor Drive Circuit**

Fault	Setup	Check	Results desired
No door up or down when switch is activated	Furnace in idle Disconnect J5 Turn furnace on Activate switch Activate switch Turn furnace off Turn furnace on	U13-11 DS1,2  DS1 DS2 D16,17 U13-15  Motor switch	+12 VAC DS20,21 On  DS1 off, DS2 on DS2 off, DS1 on Not shorted or open digital high  Other keys respond
At up or down position one LED stays off	Add mA meter in series at J5  N/A	Stall current  U13-15	> 550 mA at up or down  High to low at up or down


**Analog Circuitry**


Fault	Setup	Check	Results desired
Muffle heats but display shows same temperature	N/A	JYELL1 U4 U8 TP2	TC yellow connected Gain approx. 20 No stuck bits 1.23V
Erratic temperature display	N/A	TP2 U4-1 U4-5	1.23V stable DC stable 5 kHz
Temperature drift	Hi T = 960°C  Turn furnace off	RED  U5-7  Reconnect TC wires	39-40mV stable  mV stable (.2mV/°C ambient increase typical)  No Err2 at elevated temperatures

**Display Board**


Fault	Setup	Check	Results desired
LCD dots are all on or off at power up	Furnace in idle	J3-8  J3 U2-8, 2	+5V  Tight fit No stuck bits
No LED's light up	Perform power up  N/A	Front Panel  J2-4	LED's turn off one by one +12V
One LED does not come on	Turn furnace off	LED	Not open or shorted
LCD display is darker	Turn furnace off  Turn furnace on	Temperature on panel  Temperature on panel	Less than 40°C  LCD lighter shade

## 5.7 BLOCK DIAGRAM







Power Supply



Temperature Circuit




LCD Display Circuit



## Microprocessor Circuit

## 5.9 WIRING DIAGRAM

3-STAGE, PD, A





## 6.1 SCOPE

This section gives the procedures to be used for the calibration and specification verification of the VULCAN. The furnace specifications are given in the Owner & Operator's Manual.

## 6.2 FACTORY REPAIR

DENTSPLY Ceramco maintains a factory repair department for those customers not possessing the necessary personnel or test equipment to maintain the VULCAN. If a unit is returned to the factory for calibration or repair, a detailed description of the specific problem should be included to minimize turnaround time. Call factory for RMA number before shipping at 909.795.2461.

## 6.3 ADJUSTMENT/CALIBRATION

### 6.3.1 Temperature

To verify the muffle temperature at a given setpoint insert the tip of a temperature probe into the exhaust opening far enough to reach the center of the muffle. Connect the other end of the probe to a temperature meter and let the meter reading stabilize. Once a steady reading is obtained on the temperature meter divide the setpoint (display) temperature by the meter temperature and multiply the result by the current Tcal value. The result will be the new Tcal temperature.

#### Example:

The temperature meter shows a reading of 520°C at a setpoint of 500°C. The Tcal temperature in the setup mode shows 1000°C.

The new setup temperature Tcal is now found by the following calculation:

$$\begin{aligned} Tcal &= \frac{500^{\circ}\text{C} \times 1000}{520^{\circ}\text{C}} \\ Tcal &= .961 \times 1000 = 961^{\circ}\text{C} \end{aligned}$$

Note: Abort the cycle before turning off the furnace.

This is the new Tcal temperature. Turn the furnace off and then on again, wait for **Setup?** on the display and press ENTER until Tcal = 1000°C appears. Key in 961 and press ENTER.

### 6.3.2 Door, Lift Drag Adjustment

The lift drag force is controlled by a set of friction washers on each of the upper pivot arms. A wave spring should maintain a relatively constant force even after several thousand cycles. If the drag becomes too stiff (too hard to open and close furnace) or too loose an adjustment can be made using the following procedure:

Tools required: 5/32" Allen Wrench

- Turn the allen head screws on the upper side of the furnace either clockwise to tighten or counterclockwise to loosen the drag force.

Note: Equal adjustment should be made on each side. Turn screws only 1/6 of a revolution at a time when making adjustment.

## 6.4 CIRCUIT BOARD CALIBRATION

Calibration of the VULCAN circuit board is performed in two steps: Software and hardware.

### 6.4.1 Required Test Equipment

- 4 1/2 digit millivoltmeter
- Temperature calibrator; Type K
- Pot adjustment tool

#### WARNING

With control drawer opened, dangerous voltage points may be exposed. Contact with any of these points could cause serious injury.

#### WARNING

Observe antistatic procedures when touching circuit board components which can be damaged by static electricity.

### 6.4.2 Temperature

Enter the setup mode (Owner's Manual page16) and enter 1000°C for Tcal. Disconnect the muffle thermocouple from the control circuit board and connect the temperature calibrator on its place. Set the output of the calibrator to 1000°C. Adjust R4 to read 39.7mV at TP3. Adjust R3 to read 1000°C on the furnace display. Instead of a calibrator, a low output impedance mV source set to 38.8 mV can be used as an input signal.

A ± 10°C calibration can be obtained without the temperature calibrator by performing the following sequence: Leave the control thermocouple connected and adjust R4 to read 39.7mV at TP3. Adjust R3 to read 52mV at TP4.

$$^{\circ}\text{F} = (1.8 \times ^{\circ}\text{C}) + 32$$

$$^{\circ}\text{C} = \frac{(^{\circ}\text{F} - 32)}{1.8}$$

### 7.1 ORDERING INSTRUCTIONS

A- CONTROL

3-STAGE

To order parts, select the part number required from the exploded view drawings on page 7.1. through page 7.6. The 130, 550, 1750 numbers refer to the particular size of furnace where the part number is different depending on the size.


When ordering parts please have the following information available:

1. Serial number of furnace.
2. Date purchased.
3. Purchased where.
4. Symptom of failure.
5. Part number of replacement part.
6. Preferred method of shipment.

Hardware Kit: 9493454

(Contains a selection of the fasteners used in the furnaces.)


### 7.2 Muffle and Thermocouple



### 7.3 Muffle (3-550 PD & AIR EXCH)

3-550A

3-550 PD



## 7.4 Cabinet Parts

A- CONTROL

3-STAGE

3-550 PD

**NOTE:** To convert to configurations shown, 9495115 - Retrofit Kit, is available for furnaces built prior to S/N 0626xxx.

POWER CORD (120 & 230V)  
(9390115) 130,550 120V  
(9309118) 230V US  
(9309117) 230V EURO  
(9493653) 1750 EURO  
(9409131) 1750 US

### 120V Socket Assy

(9302072) FUSE, 20 amp

(9494462)  
ADAPTER PLATE, 120V

(9494462) ADAPTER PLATE, 120V

(9493534) REAR PANEL  
3-550PD FURNACE

CABINET ASSY  
(9493320) 130 FURNACES  
(9493354) 550 FURNACES  
(9493384) 1750 FURNACES  
(9493807) 3-550 PD FURNACE

SOCKET ASSY.  
LOCATION

(9493338) DOOR  
SAFETY SWITCH

### 130, 230V Socket Assy

(9492995) SOCKET ASSY., 200/240V

(9320069) FUSE, 10 amp

(9492996) ADAPTER PLATE, 200/  
240V

### 550, 230V Socket Assy



(9302072) FUSE, 20 amp

(9495104) SOCKET ASSY., 200/240V


(9495099)  
ADAPTER PLATE, 200/240V

(9311017A) FUSE HOLDER


## 7.4 Cabinet Parts




## 7.5 Door Parts




## 7.6 A- Controller Parts



## 7.7 3-Stage Controller Parts



## 7.8 Lift Mechanism Parts





## DISASSEMBLY/REASSEMBLY



### 8.1 CONTROL DRAWER REMOVAL

Tools: Phillips #2 screwdriver

- To gain access to the electrical components and most other service jobs, removal of the control drawer is required.

#### WARNING:





Disconnect power cord from wall outlet before attempting to service the furnace.



### 8.2 TRIAC

Tools: Phillips #2 screwdriver  
1/4" nut driver  
needle nose pliers






8.2.1: Follow steps 8.1.1 through 8.1.2 of CONTROL DRAWER REMOVAL



### 8.3 MEMBRANE SWITCH

Tools: Phillips screwdriver  
Knife or other sharp edged device

8.3.1: Follow steps 8.1.1 through 8.1.2 of CONTROL DRAWER REMOVAL.




## 8.4 DISPLAY PCB

Tools: Phillips screwdriver


### CAUTION!

Use proper ESD grounding techniques when handling electronic components


8.4.1: Follow steps 8.1.1 through 8.1.2 of CONTROL DRAWER REMOVAL




8.4.2: Disconnect grey ribbon connector.



8.4.3: Remove from snap-on standoffs.



8.4.4: Replace with new Display PCB.



8.4.5: Connect grey ribbon connector. Bend away from Display PCB so it won't cut into ribbon.






## 8.5 A-CONTROL PCB

Tools: Phillips screwdriver  
Needle nose pliers  
3/8" nut driver or wrench  
1/4" nut driver  
13 mm nut driver or pliers


### CAUTION!

Use proper ESD grounding techniques when handling electronic components

8.5.1: Follow steps 8.1.1 through 8.1.2 of CONTROL DRAWER REMOVAL.



Reverse steps for reassembly.











## 8.6 3 STAGE CONTROL PCB

Tools: Phillips screwdriver  
Slotted screwdriver  
Needle nose pliers

### CAUTION!

Use proper ESD grounding techniques when handling electronic components


8.6.1: Follow steps 8.1.1 through 8.1.2 of CONTROL DRAWER REMOVAL.




## 8.7 DOOR ASSEMBLY/ ADJUSTMENT

Tools: 5/32 Allen wrench  
Phillips head screwdriver


If the door feels too stiff or too loose when lifting up and down, a tension adjustment can be made from the outside




8.7.1: If door tension is too loose tighten the screw on each side until the desired tension is reached. If too tight, loosen screw.




8.7.2: If door insulation is rubbing against cabinet, loosen the 2 screws on each side of door.



8.7.3: Rotate door out from cabinet and tighten 4 screws. Check to make sure that rope contacts muffle lip when closed and insulation clears cabinet when lifted.



8.7.4: If door or door insulation needs replacement, remove the 4 screws on bottom of door (step 5.7.2) and slide from slide out assy.



8.7.5: Remove 2 screws and slide out door insulation and spring. If door is to be replaced, remove 2 screws holding handle.

8.7.6: Replace with new insulation or door by reversing steps 8.7.4 - 8.7.5.

8.7.7: Set spacing as described in section 8.7.3. Important! Screws must be torqued to 25-30 in-lbs.

## 8.8 HEATING PLATES


Tools: Phillips head screwdriver  
small putty knife

Note: Like the headlights on a car, if one heating plate burns out, the other will likely burn out soon. Therefore, it would be advisable to replace both plates at once.


### WARNING:

Disconnect power from the wall outlet before attempting to service the furnace!


8.8.1: Follow steps 8.1.1 - 8.1.2 of CONTROL DRAWER REMOVAL.




8.8.1: Disconnect muffle wires from plate(s) to be replaced. (refer to wiring diagram 2.8 for A-Control and 5.9 for 3-stage control.)




8.8.2: Remove floor tray



8.8.3: Pull out bad plate(s) (Rotate bottom of plate toward center of muffle). Be careful when pulling leads thru holes in muffle.



8.8.4: Replace with new plate(s). There are brass bushings located in the heatshield below the muffle holes. Cut tie wraps located on terminals' insulation. Slide the piece of insulating sleeve (provided) over the existing ones and tie wrap at 1" below the heat shield. It may take a few attempts to locate this hole with the muffle terminal



8.8.5: Optional: a syringe of ceramic adhesive is provided to hold plates secure to sides. Stuff newspaper in muffle until adhesive sets (1 hr). There will be some movement of the plates without the adhesive.

8.8.6: Connect muffle wires from plate(s) to control PCB. Refer to wiring diagram 2.9 for A-Control or 5.10 for 3 stage control. (See step 8.8.2)

8.8.7: Install floor tray

8.8.8: Install control drawer by reversing steps 8.1.1 - 8.8.2



## 8.9 COMPLETE MUFFLE REPLACEMENT

Tools: Phillips head screwdriver; small flat head screwdriver; needle nose pliers





### WARNING:

Disconnect power from the wall outlet before attempting to service the furnace!


8.9.1: Follow steps 8.1.1 - 8.1.2 of CONTROL DRAWER REMOVAL.




8.9.4: Open door



8.9.9: Remove muffle assy







8.9.12: Check muffle resistance to verify wiring is correct before securing control drawer:

	100v	120v	200-240v
A-130, 3-130	8 ohms	8 ohm	32 ohms
A-550, 3-550	8 ohms	8 ohms	24 ohms
A-1750, 3-1750			12 ohms



### 8.10 THERMOCOUPLE (A-Control)

Tools: bladed screwdriver phillips head screwdriver, 3/8" nutdriver, wrench, 1/4" nutdriver

#### WARNING:

Disconnect power from the wall outlet before attempting to service the furnace!

- 8.10.1: Follow steps 8.1.1 - 8.1.2 of control drawer removal
- 8.10.2: Follow steps 8.9.3 - 8.9.7 from previous page for muffle replacement for furnaces without a rear access panel. Note: All 1750 furnaces and all furnaces with S/N date codes after 9701 will have rear access panel so that muffle will not need to be removed to service thermocouple (see step 8.11.6 for details).





### 8.11 THERMOCOUPLE (3 Stage Control)

Tools: bladed screwdriver  
phillips head screwdriver  
1/4" nutdriver

#### WARNING:

Disconnect power from the wall outlet before attempting to service the furnace!

- 8.11.1: Follow steps 8.1.1 - 8.1.2 of control drawer removal
- 8.11.2: Follow steps 8.9.3 - 8.9.7 from previous page for muffle replacement for furnaces without a rear access panel. Note: All 1750 furnaces and all furnaces with S/N date codes after 9701 will have rear access panel so that muffle will not need to be removed to service thermocouple (see step 8.11.6 for details).





- 8.11.5: Replace with new thermocouple by reversing previous steps 8.11.1 thru 8.11.4

## 8.12 COMPLETE MUFFLE REPLACEMENT (3-550 PD)







Tools: Phillips head screwdriver; bladed screw driver; needle nose pliers


8.12.1: Follow steps 8.1.1 - 8.1.2 of CONTROL DRAWER REMOVAL.



### WARNING:

Disconnect power from the wall outlet before attempting to service the furnace!





8.12.11: Check muffle resistance to verify wiring is correct before securing control drawer:

	100v	120v	200-240v
3-550 PD	8 ohms	8 ohms	24 ohms



### 8.13 THERMOCOUPLE (3-550 PD)



Tools: bladed screwdriver  
phillips head screwdriver 1/  
4" nutdriver

#### **WARNING:**

Disconnect power from the wall outlet before attempting to service the furnace!

8.13.1: Follow steps 8.1.1 - 8.1.2 of control drawer removal









8.13.5: Replace with new thermocouple by reversing previous steps 8.11.1 thru 8.11.4

## 8.14 POWER SWITCH

Tools: Slotted screwdriver

8.14.1: Follow steps 8.1.1 through 8.1.2 of CONTROL DRAWER REMOVAL




## 8.15 POWER DOOR MOTOR REPLACEMENT


8.15.1: Slide control drawer forward using steps 8.1.1 and 8.1.2

8.15.2: Slide muffler assembly forward using steps 8.1.3, 8.9.4, 8.9.5 and 8.9.6 (approximately 5 inches).


8.15.3: Remove the 2 screws which support rear panel.




8.15.4: Remove the 2 screws to free motor linkage bracket from base.




8.15.5: Disconnect wires (Female quick connect terminals) from motor.



8.15.6: Remove (4) screws to free motor bracket.



8.15.7: Remove (4) screws and shoulder bolt to free motor from motor bracket.



8.15.8: Replace with new motor by reversing previous steps 8.15.1 thru 8.15.7.

## This image shows a full page of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page, providing a template for writing. There are no margins, text, or other markings on the page.