

Document information

Info	Content
Keywords	ASC884xA/5xA
Definitions	ASC884xA/5xA: ASC8848A/49A/50A/51A/52A

Revision history

Rev	Date	Description
1.0	20120117	Initial version
1.01	20121023	1. Added SSM2603 related explain 2. Modified/Added Chapter 1, 2, 3 and 4 content.
1.02	20121221	Updated for ASC884xA/5xA

COMPANY CONFIDENTIAL

Contact information

For more information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: salesaddresses@nxp.com

1. Introduction

This user manual describes how to use ALSA test application for testing audio codec basic function (capture, mixer and playback).

1.1 Scope

- Illustrates SSM2603 and NVP1114A audio codec
- Test environment explanation
 - Basic root file system (basic_rootfs.sqfs)
 - Kilrogg (rootfs.sqfs)
- How to check AUDIO_SEL1 Jump need to “disable”
 - Non-disable: EVM ver. b
 - Need disable: EVM ver. c and ver. d
- Package contents

1.2 Package contents

```
-- ALSA_Lib
-- Alsa_Test_App
|  -- Capture
|  -- Mixer
|  -- playback
-- Install
|  -- ALSA
|  -- drivers
|    -- i2c
|  -- lib
```

2. Setup testing environment

2.1 Used basic root file system (basic_rootfs.sqfs)

Burn boot, Kernel and basic rootfs file system to EVM.

2.2 Used Kilrogg (rootfs.sqfs)

- Burn boot, Kernel and rootfs(Kilrogg) to EVM
- Stop all process

```
~# stopallproc
```
- Remove audio related driver

```
~ # rmmod i2c_gpio
~ # rmmod i2c_algo_bit
~ # rmmod Audio_Codec_Driver
```

3. SSM2603 audio codec

3.1 Put SSM2603.ko to drivers folder

3.2 Check install.sh file content

```
insmod drivers/i2c/i2c-gpio.ko bus_num=2 scl0=255 sda0=255 scl1=12 sda1=13
insmod drivers/SSM2603.ko
```

3.3 Run the script file in /Install/

```
sh install.sh
```

3.4 Capture audio files

- In /Alsa_Test_App/Capture/
- Run capture_app_infinite

Usage:

```
./capture_app_infinite -h
```

```
-c : codec chip type,
      this can be t(TW2866), s(SSM2603), a(WAU8822), m(WM8978), n(NVP1114A),
      c(CAT6011), i(AIC3104), l(ALC5623)
-n : channel number, this should be 2 or 4(only TW2866/NVP1114A supports 4).
-t : capture format, this can be p(PCM), u(u-Law), a(a-Law).
-d : capture device, this can be 0 or 1.
-r : capture sample rate, this can be 8000, 16000, 32000, 44100, 48000.
-0 : capture-channel#0 file name
-1 : capture-channel#1 file name
-2 : capture-channel#2 file name
-3 : capture-channel#3 file name
[EX]
      If we hope to use capture-dev#0 to capture 4 channels audio, u-Law, 44100, and write
      channel#0 data to /tmp/cap0.pcm, using TW2866/NVP1114A, the command will be
      " ./capture_app_infinite -c t -n 4 -d 0 -t u -r 44100 -0 /tmp/cap0.pcm"
```

3.4.1 Capture audio file

```
./capture_app_infinite -c s -n 2 -t p -d 0 -r 44100 -0 /tmp/cap0.pcm
```

3.5 Playback the audio files

In 'Alsa_Test_App/playback', run play_app_infinite

Usage: ./play_app_infinite -h

- -d: playback device number.
- -r: playback sample rate.
- -f: playback file name.

3.5.1 Play the audio file

```
./play_app_infinite -d 0 -r 44100 -f /tmp/cap0.pcm
```

3.6 Do audio mixer

3.6.1 Check "mixer_control.c"

```
#define CODECTYPE SSM2603
```

3.6.2 Setting audio function

```
./mixer_control
```

4. NVP1114A audio codec

4.1 Put NVP1114A_AUDIO.ko to drivers folder

4.2 Check install.sh file content

```
insmod drivers/i2c/i2c-gpio.ko bus_num=2 scl0=6 sda0=7 scl1=12 sda1=13
insmod drivers/NVP1114A_AUDIO.ko CodecNum=2
```

4.3 Run the script file in /Install/

```
sh install.sh
```

4.4 Capture audio files

- In /Alsa_Test_App/Capture/
- Run capture_app_infinite

Usage:

```
./capture_app_infinite -h
```

-c : codec chip type,

this can be t(TW2866), s(SSM2603), a(WAU8822), m(WM8978), n(NVP1114A),
c(CAT6011), i(AIC3104), l(ALC5623)

-n : channel number, this should be 2 or 4(only TW2866/NVP1114A supports 4).

-t : capture format, this can be p(PCM), u(u-Law), a(a-Law).

-d : capture device, this can be 0 or 1.

-r : capture sample rate, this can be 8000, 16000, 32000, 44100, 48000.

-0 : capture-channel#0 file name

-1 : capture-channel#1 file name

-2 : capture-channel#2 file name

-3 : capture-channel#3 file name

[EX]

If we hope to use capture-dev#0 to capture 4 channels audio, u-Law, 44100, and write channel#0 data to /tmp/cap0.pcm, using TW2866/NVP1114A, the command will be

```
"/capture_app_infinite -c t -n 4 -d 0 -t u -r 44100 -0 /tmp/cap0.pcm"
```

4.4.1 Initialization chip 0 and chip 1

Chip 0

```
./capture_app_infinite -c n -n 4 -t p -d 0 -r 16000 -0 /tmp/cap0.pcm -1 /tmp/cap1.pcm  
-2 /tmp/cap2.pcm -3 /tmp/cap3.pcm
```

Chip 1

```
./capture_app_infinite -c n -n 4 -t p -d 1 -r 16000 -0 /tmp/cap0.pcm -1 /tmp/cap1.pcm  
-2 /tmp/cap2.pcm -3 /tmp/cap3.pcm  
./capture_app_infinite -c n -n 4 -t p -d 0 -r 16000 -0 cap0.pcm -1 cap1.pcm
```

4.5 Playback the audio files

In 'Alsa_Test_App/playback', run play_app_infinite

Usage: ./play_app_infinite -h

- -d: playback device number.
- -r: playback sample rate.
- -f: playback file name.

4.5.1 Play the audio file

```
./play_app_infinite -d 1 -r 16000 -f /tmp/cap0.pcm  
./play_app_infinite -d 1 -r 16000 -f /tmp/cap1.pcm  
./play_app_infinite -d 1 -r 16000 -f /tmp/cap2.pcm  
./play_app_infinite -d 1 -r 16000 -f /tmp/cap3.pcm  
./play_app_infinite -d 1 -r 16000 -f /tmp/cap4.pcm  
./play_app_infinite -d 1 -r 16000 -f /tmp/cap5.pcm  
./play_app_infinite -d 1 -r 16000 -f /tmp/cap6.pcm  
./play_app_infinite -d 1 -r 16000 -f /tmp/cap7.pcm
```

4.6 Do audio mixer

In 'Alsa_Test_App/Mixer', run mixer_control.

Usage: ./mixer_control -h

```
NVP1114A AUDIO MIXER help  
== CAPTURE PART ==  
The following capture options should be used TOGETHER!!  
-d : choose a codec Device(0~1)
```

```
-c : choose a Channel(0~3) on this codec device.  
-v : choose a Volume value(0~15) on this channel.  
== PLAYBACK PART ==  
-p : adjust Playback volume(0~15)
```

4.6.1 Check "mixer_control.c"

```
#define CODECTYPE NVP1114A
```

4.6.2 Setting audio function

```
1  ./mixer_control -d 0 -c 0 -v 15  
2  ./mixer_control -d 0 -c 1 -v 15  
3  ./mixer_control -d 0 -c 2 -v 15  
4  ./mixer_control -d 0 -c 3 -v 15  
5  ./mixer_control -d 1 -c 0 -v 15  
6  ./mixer_control -d 1 -c 1 -v 15  
7  ./mixer_control -d 1 -c 2 -v 15  
8  ./mixer_control -d 1 -c 3 -v 15  
9  ./mixer_control -p 15
```

5. Legal information

5.1 Definitions

Draft — The document is a draft version only. The content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included herein and shall have no liability for the consequences of use of such information.

5.2 Disclaimers

Limited warranty and liability — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

Right to make changes — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors accepts no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Applications — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

Export control — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from national authorities.

6. Contents

1.	Introduction	3
1.1	[Package contents].....	3
1.2	Run the script file in /Install/	4
1.3	Capture audio files	4
1.3.1	Initialization chip 0 and chip 1	4
1.3.2	Play the audio file.....	6
1.4	Do audio mixer	6
1.4.1	Setting audio function.....	7
2.	Legal information	8
2.1	Definitions	8
2.2	Disclaimers.....	8
3.	Contents.....	9

Please be aware that important notices concerning this document and the product(s) described herein, have been included in the section 'Legal information'.
