


Arduino

 Non-Visible component

| Category | Requires | Version |
|--------------|------------------------------------|---------|
| Connectivity | API 19, Android 4.4 - 4.4.4 KitKat | 1 |

Overview

A non-visible component that connects the device via the USB Serial to Arduino hardware.

Events

After Read

Triggered after Read function

| Params | |
|---------|---------|
| success | Boolean |
| data | Text |

Methods

Baud Rate

Default baud rate is 9600 bps

| Params | |
|-----------|--------|
| baud Rate | Number |

Close

Returns: *Boolean*

Closes Arduino Connection

Initialize

Initializes Arduino Connection

Is Opened

Returns: *Boolean*

Returns true when the Arduino connection is open

Open

Returns: *Boolean*

Opens Arduino Connection

Read

Read from Serial

Write

Write Data to Serial

| Params | |
|--------|-----------------|
| data | <div>Text</div> |

Last update: January 26, 2020