

**maxon motor**

**maxon motor control**

**EPOS Positioning Controller**

**Windows 32-Bit DLL**

**Edition January 2007**

***EPOS***

**Positioning Controller**

**Documentation**

**Windows 32-Bit DLL**

maxon document number: 573057 - 12

# 1 Table of contents

<b>1</b>	<b>Table of contents.....</b>	<b>2</b>
<b>2</b>	<b>Table of figures.....</b>	<b>4</b>
<b>3</b>	<b>Table of tables .....</b>	<b>4</b>
<b>4</b>	<b>Introduction .....</b>	<b>5</b>
<b>5</b>	<b>Third party products .....</b>	<b>6</b>
5.1	IXXAT.....	6
5.2	Vector.....	6
5.3	National Instruments .....	6
<b>6</b>	<b>How to use this guide .....</b>	<b>7</b>
<b>7</b>	<b>Virtual Command Set Communication .....</b>	<b>8</b>
7.1	Communication Structure.....	8
7.2	Data Type Definitions .....	8
7.3	Initialisation .....	9
7.3.1	Open Device .....	9
7.3.2	Close All Devices.....	9
7.3.3	Close Device.....	10
7.3.4	Get Protocol Stack Settings.....	10
7.3.5	Set Protocol Stack Settings .....	10
7.4	Help Functions .....	11
7.4.1	Get Baudrate Selection.....	11
7.4.2	Get Device Name .....	12
7.4.3	Get Device Name Selection.....	12
7.4.4	Get Driver Info.....	13
7.4.5	Get Interface Name .....	13
7.4.6	Get Error Info .....	13
7.4.7	Get Interface Name Selection .....	14
7.4.8	Get Key Handle.....	14
7.4.9	Get Port Name .....	15
7.4.10	Get Port Name Selection .....	15
7.4.11	Get Protocol Stack Name .....	16
7.4.12	Get Protocol Stack Name Selection .....	16
7.4.13	Programming Example .....	16
<b>8</b>	<b>Virtual Command Set EPOS .....</b>	<b>17</b>
8.1	Configuration.....	17
8.1.1	Get Current Regulator Gain.....	17
8.1.2	Get Encoder Parameter.....	18
8.1.3	Get Motor Parameter .....	18
8.1.4	Get Position Regulator Gain .....	19
8.1.5	Get Velocity Regulator Gain .....	19
8.1.6	Set Current Regulator Gain .....	20
8.1.7	Set Encoder Parameter .....	20
8.1.8	Set Motor Parameter .....	21
8.1.9	Set Position Regulator Gain .....	21
8.1.10	Set Velocity Regulator Gain.....	22
8.2	Current Mode.....	23
8.2.1	Get Current Must .....	23
8.2.2	Set Current Must.....	23
8.3	Homing Mode.....	24
8.3.1	Find Home .....	24
8.3.2	Get Homing Parameter .....	25
8.3.3	Set Homing Parameter .....	26
8.3.4	Stop Homing .....	26
8.4	Inputs Outputs.....	27
8.4.1	Digital Input Configuration .....	29
8.4.2	Digital Output Configuration.....	30
8.4.3	Get All Digital Inputs .....	31
8.4.4	Get All Digital Outputs .....	31
8.4.5	Get Analog Input.....	32
8.4.6	Set All Digital Outputs .....	32
8.5	Motion Info .....	33
8.5.1	Get Current Is .....	33
8.5.2	Get Movement State.....	33
8.5.3	Get Position Is.....	34
8.5.4	Get Velocity Is.....	34
8.6	Position Mode .....	35
8.6.1	Get Position Must .....	35
8.6.2	Set Position Must.....	35
8.7	Profile Position Mode .....	36

maxon motor	
EPOS Positioning Controller	Windows 32-Bit DLL
8.7.1	Get Position Profile .....36
8.7.2	Get Target Position .....37
8.7.3	Halt Position Movement.....37
8.7.4	Move To Position .....38
8.7.5	Set Position Profile .....38
8.8	Profile Velocity Mode .....39
8.8.1	Get Target Velocity .....39
8.8.2	Get Velocity Profile .....40
8.8.3	Halt Velocity Movement.....40
8.8.4	Move With Velocity .....41
8.8.5	Set Velocity Profile.....41
8.9	State Machine .....42
8.9.1	Clear Fault .....42
8.9.2	Get Disable State.....43
8.9.3	Get Enable State .....43
8.9.4	Get Fault State.....44
8.9.5	Get Operation Mode .....44
8.9.6	Get Quick Stop State .....45
8.9.7	Set Disable State.....45
8.9.8	Set Enable State .....46
8.9.9	Set Operation Mode.....46
8.9.10	Set Quick Stop State .....47
8.9.11	Send NMT Service.....47
8.10	Utilities .....48
8.10.1	Get Object.....48
8.10.2	Get Version .....49
8.10.3	Restore .....49
8.10.4	Set Object .....50
8.10.5	Store .....50
8.11	Velocity Mode .....51
8.11.1	Get Velocity Must.....51
8.11.2	Set Velocity Must.....51
8.12	General CAN Commands .....52
8.12.1	Send CAN Frame .....52
8.12.2	Request CAN Frame .....52
<b>9</b>	<b>Virtual Dialog Set Communication.....53</b>
9.1	Initialisation .....53
9.1.1	Open Device Dialog.....53
<b>10</b>	<b>Error Overview .....54</b>
10.1	Overview Communication Errors .....54
10.2	Overview „Windows 32-Bit DLL„ specified Errors .....55
10.2.1	General Errors .....55
10.2.2	Interface Layer Errors .....55
10.2.3	Interface Layer 'RS232' Errors.....55
10.2.4	Interface Layer 'CAN' Errors.....55
10.2.5	Protocol Layer 'MaxonRS232' Errors .....55
10.2.6	Protocol Layer 'CANopen' Errors.....55
<b>11</b>	<b>Table of functions .....56</b>
<b>12</b>	<b>Version History .....58</b>

## 2 Table of figures

Figure 1: EPOS documentation hierarchy .....	7
Figure 2: Communication structure.....	8
Figure 3: Digital Input Functionality EPOS 24/1 and EPOS 24/5 Overview (default configuration) .....	27
Figure 4: Digital Output Functionality EPOS 24/5 and EPOS 70/10 Overview (default configuration) .....	28

## 3 Table of tables

Table 1: Data type definitions.....	8
Table 2: Homing methods .....	24
Table 3: Operation modes.....	44
Table 4: Operation modes.....	46
Table 5: Communication errors .....	54
Table 6: „Windows 32-Bit DLL“ specified general errors .....	55
Table 7: „Windows 32-Bit DLL“ specified interface layer.....	55
Table 8: „Windows 32-Bit DLL“ specified interface layer ‘RS232’ errors .....	55
Table 9: „Windows 32-Bit DLL“ specified interface layer ‘CAN’ errors.....	55
Table 10: „Windows 32-Bit DLL“ specified protocol ‘MaxonRS232’ errors .....	55
Table 11: „Windows 32-Bit DLL“ specified protocol ‘CANopen’ errors .....	55

## 4 Introduction

This documentation „Windows 32-Bit DLL” provides the instructions for the implemented functions. The library is arranged in groups of functions and helps to simplify the programming of the control software based on Windows.

This document describes the interface between a program and the Windows DLL (Dynamic Link Library). This DLL supports devices, which are attached to a **serial interface RS232** or to a **CAN board by IXXAT, Vector or National Instruments**. All other CANopen products of other manufacturers can also be used, however no motion control library is available.

The Windows DLL supports the SDO protocol from CANopen but the Windows DLL is not qualified to real-time communication.

Additional information are available in the following documents:

- „DLL Integration into MS VC++”  
The document „DLL Integration into MS VC++” describes detailed the implementation and structure for **Microsoft Visual C++**.
- „DLL Integration into MS Visual Basic”  
The document „DLL Integration into MS Visual Basic” describes detailed the implementation and structure for **Microsoft Visual Basic**.
- „DLL Integration into Borland C++”  
The document „DLL Integration into Borland C++” describes detailed the implementation and structure for **Borland C++ Builder**.
- „DLL Integration into Borland Delphi”  
The document „DLL Integration into Borland Delphi” describes detailed the implementation and structure for **Borland Delphi**.
- „DLL Integration into LabVIEW”  
The document „DLL Integration into LabVIEW” describes detailed the implementation and structure for **National Instruments LabVIEW**.
- „DLL Integration into National Instruments LabWindows/CVI”  
The document „DLL Integration into National Instruments LabWindows/CVI” describes detailed the implementation and structure for **National Instruments LabWindows/CVI**.

To several high-level languages, an appropriate example with a suitable documentation will be present.

This library is intended to cover most applications in automatisisation.

It is based on the experience of maxon motor control. Maxon motor control certifies that the content of this library is correct according to the best of their knowledge.

BECAUSE THIS LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THIS LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM „AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THIS LIBRARY IS WITH YOU. SHOULD THIS LIBRARY PROVE DEFECTIVE OR INSUFFICIENT, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION

The latest edition of these „Windows 32-Bit DLL”, additional documentation and software to the EPOS positioning controller may also be found in the internet under [www.maxonmotor.com](http://www.maxonmotor.com) category <Service & Downloads>.

## 5 Third party products

Use one of the listed PC CANopen interface cards. For all of these manufacturers motion control library, example and documentation are available.

All other CANopen products of other manufacturers can also be used, however no motion control library is available.

### 5.1 IXXAT

CANopen boards from IXXAT operated with an universal driver VCI V2. The Windows DLL works with this universal driver VCI V2 (Version 2.14 and greater) from IXXAT.

See addresses below for ordering CANopen boards.

#### Distributors

- [www.ixxat.de](http://www.ixxat.de) subdirectory <contact>

### 5.2 Vector

For use of Vector CANopen cards, the 'XL Driver Library' is needed. The latest edition of this 'XL Driver Library' may also be found in the internet under <http://www.vector-informatik.de/english/> category <Hardware Products> subdirectory <Interfaces>. The library has to be installed manually in the appropriate working or system directory. With this library, it is possible to write own CANopen applications based on Vector's XL hardware.

See address below for ordering CANopen boards.

#### Distributors

- [General distributors](#)

### 5.3 National Instruments

CAN Interfaces of National Instruments are supported. The NI-CAN Software and Hardware has to be installed.

See address below for ordering CAN boards.

#### Contact

- [www.ni.com/can](http://www.ni.com/can)

## 6 How to use this guide




Figure 1: EPOS documentation hierarchy

## 7 Virtual Command Set Communication

The Virtual Command Set Communication defines following groups:

[Initialisation](#)  
[Help Functions](#)

### 7.1 Communication Structure




Figure 2: Communication structure

### 7.2 Data Type Definitions

The „Windows 32-Bit DLL” is implemented with Microsoft Visual C++. Below is a table of all used data types.

Name	Data type	Size bits	Size bytes	Range
char	signed integer	8	1	– 128 ... 127
BYTE	unsigned integer	8	1	0 ... 256
short	signed integer	16	2	– 32'768 ... 32'767
WORD	unsigned integer	16	2	0 ... 65'535
long	signed integer	32	4	– 2'147'483'648 ... 2'147'483'647
DWORD	unsigned integer	32	4	0 ... 4'294'967'295
BOOL	boolean value	32	4	TRUE or FALSE
HANDLE	pointer to an object	32	4	0 ... 4'294'967'295

Table 1: Data type definitions



## 7.3 Initialisation

This group defines all required functions to initialize a correct communication:

[Open Device](#)  
[Close All Devices](#)  
[Close Device](#)  
[Get Protocol Stack Settings](#)  
[Set Protocol Stack Settings](#)

### 7.3.1 Open Device

#### Function

HANDLE **VCS\_OpenDevice** (char\* DeviceName, char\* ProtocolStackName, char\* InterfaceName, char\* PortName, DWORD \*pErrorCode)

#### Description

Function „VCS\_OpenDevice“ opens the port for sending and receiving commands. This function opens interfaces with the RS232 and with CANopen boards.

For exact names for DeviceName, ProtocolStackName, InterfaceName and PortName use the functions [Get Device Name Selection](#), [Get Protocol Stack Name Selection](#), [Get Interface Name Selection](#) and [Get Port Name Selection](#).

#### Parameters

DeviceName	char*	Name of connected device: EPOS
ProtocolStack-Name	char*	Name of used bus system: MAXON_RS232 or CANopen
InterfaceName	char*	Name of used interface: RS232: RS232 CANopen: Is composed of: Manufacturer_BoardName DeviceNumber  <i>Examples:</i> IXXAT_USB-to-CAN compact 0, IXXAT_iPCI320 PCI 0, ... Vector_CANcaseXL Channel 1, .. NI_PCI-CAN 0, ...
PortName	char*	Name of port: RS232: COM1, COM2 ... CANopen: 0, 1 ...

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	HANDLE	Handle for port access. Nonzero if successful; otherwise 0

#### Related Functions

[Open Device Dialog](#)

### 7.3.2 Close All Devices

#### Function

BOOL **VCS\_CloseAllDevices** (DWORD \*pErrorCode)

#### Description

Function „VCS\_CloseAllDevices“ closes all opened ports and releases it for other applications.

#### Return Parameter

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Open Device](#)

### 7.3.3 Close Device

#### Function

BOOL **VCS\_CloseDevice** (HANDLE KeyHandle, DWORD \*pErrorCode)

#### Description

Function „VCS\_CloseDevice“ closes the port and releases it for other applications.

#### Parameters

KeyHandle	HANDLE	Handle for port access
-----------	--------	------------------------

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Open Device](#)

### 7.3.4 Get Protocol Stack Settings

#### Function

BOOL **VCS\_GetProtocolStackSettings** (HANDLE KeyHandle, DWORD \*pBaudrate, DWORD \*pTimeout, DWORD \*pErrorCode)

#### Description

Function „VCS\_GetProtocolStackSettings“ returns the communication parameters baudrate and timeout.

#### Parameter

KeyHandle	HANDLE	Handle for port access
-----------	--------	------------------------

#### Return Parameters

pBaudrate	DWORD	Actual baudrate from opened port [Bit/s]
pTimeout	DWORD	Actual timeout from opened port [ms]
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### 7.3.5 Set Protocol Stack Settings

#### Function

BOOL **VCS\_SetProtocolStackSettings** (HANDLE KeyHandle, DWORD Baudrate, DWORD Timeout, DWORD \*pErrorCode)

#### Description

With function „VCS\_SetProtocolStackSettings“ it is possible to write the communication parameters. For exact values of baudrate use the function [Get Baudrate Selection](#).

#### Parameters

KeyHandle	HANDLE	Handle for port access
Baudrate	DWORD	Actual baudrate from opened port [Bit/s]
Timeout	DWORD	Actual timeout from opened port [ms]

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

## 7.4 Help Functions

This group defines all required functions to get additional information:

[Get Baudrate Selection](#)  
[Get Device Name](#)  
[Get Device Name Selection](#)  
[Get Driver Info](#)  
[Get Interface Name](#)  
[Get Interface Name Selection](#)  
[Get Key Handle](#)  
[Get Port Name](#)  
[Get Port Name Selection](#)  
[Get Protocol Stack Mode](#)  
[Get Protocol Stack Mode Selection](#)  
[Get Protocol Stack Name](#)  
[Get Protocol Stack Name Selection](#)

### 7.4.1 Get Baudrate Selection

#### Function

BOOL **VCS\_GetBaudrateSelection** (char\* DeviceName, char\* ProtocolStackName, char\* InterfaceName, char\* PortName, BOOL StartOfSelection, DWORD \*pBaudrateSel, BOOL \*pEndOfSelection, DWORD \*pErrorCode)

#### Description

Function „VCS\_GetBaudrateSelection“ returns all available baud rates for the connected port.

#### Parameters

DeviceName	char*	Name of device
ProtocolStack-Name	char*	Name of protocol stack
InterfaceName	char*	Interface name
PortName	char*	Port name
StartOfSelection	BOOL	True: Get first selection value False: Get next selection value

#### Return Parameters

pBaudrateSel	DWORD	Pointer to baudrate [Bit/s]
pEndOfSelection	BOOL	True: No more value available False: More value available
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

Go to [Programming Example](#)

## 7.4.2 Get Device Name

### Function

BOOL **VCS\_GetDeviceName** (HANDLE KeyHandle, char \*pDeviceName, WORD MaxStrSize, DWORD \*pErrorCode)

### Description

Function „VCS\_GetDeviceName“ returns the device name to corresponding handle.

### Parameters

KeyHandle	HANDLE	Handle for port access
MaxStrSize	WORD	Reserved memory size for the device name

### Return Parameters

pDeviceName	char*	Device name
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

## 7.4.3 Get Device Name Selection

### Function

BOOL **VCS\_GetDeviceNameSelection** (BOOL StartOfSelection, char \*pDeviceNameSel, WORD MaxStrSize, BOOL \*pEndOfSelection, DWORD \*pErrorCode)

### Description

Function „VCS\_GetDeviceNameSelection“ returns all available device names.

### Parameters

StartOfSelection	BOOL	True: Get first selection string False: Get next selection string
MaxStrSize	WORD	Reserved memory size for the device name

### Return Parameters

pDeviceNameSel	char*	Device name
pEndOfSelection	BOOL	True: No more string available False: More string available
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

Go to [Programming Example](#)

## 7.4.4 Get Driver Info

### Function

BOOL **VCS\_GetDriverInfo** (char \*pLibraryName, WORD MaxStrNameSize, char \*pLibraryVersion, WORD MaxStrVersionSize, DWORD \*pErrorCode)

### Description

Function „VCS\_GetDriverInfo“ returns the name and version from the Windows DLL.

### Parameters

MaxStrName-Size	WORD	Reserved memory size for the name
MaxStrVersion-Size	WORD	Reserved memory size for the version

### Return Parameters

pLibraryName	char*	Name from DLL
pLibraryVersion	char*	Version from DLL
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

## 7.4.5 Get Interface Name

### Function

BOOL **VCS\_GetInterfaceName** (HANDLE KeyHandle, char \*pInterfaceName, WORD MaxStrSize, DWORD \*pErrorCode)

### Description

Function „VCS\_GetInterfaceName“ returns the interface name to corresponding handle.

### Parameters

KeyHandle	HANDLE	Handle for port access
MaxStrSize	WORD	Reserved memory size for the interface name

### Return Parameters

pInterfaceName	char*	Pointer to interface name
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

## 7.4.6 Get Error Info

### Function

BOOL **VCS\_GetErrorInfo** (DWORD ErrorCodeValue, char\* pErrorInfo, WORD MaxStrSize)

### Description

Function „VCS\_GetErrorInfo“ returns the error information from a received error code.

### Parameters

ErrorCodeValue	DWORD	Received error code
MaxStrSize	WORD	Max. length of error string

### Return Parameters

pErrorInfo	char*	Error string
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### 7.4.7 Get Interface Name Selection

#### Function

BOOL **VCS\_GetInterfaceNameSelection** (char\* DeviceName, char\* ProtocolStackName, BOOL StartOfSelection, char \*pInterfaceNameSel, WORD MaxStrSize, BOOL \*pEndOfSelection, DWORD \*pErrorCode)

#### Description

Function „VCS\_GetInterfaceNameSelection” returns all available interface names.

#### Parameters

DeviceName	char*	Device name
ProtocolStack-Name	char*	Protocol stack name
StartOfSelection	BOOL	True: Get first selection string False: Get next selection string
MaxStrSize	WORD	Reserved memory size for the interface name

#### Return Parameters

pInterfaceName-Sel	char*	Pointer to interface name
pEndOfSelection	BOOL	True: No more string available False: More string available
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

Go to [Programming Example](#)

### 7.4.8 Get Key Handle

#### Function

BOOL **VCS\_GetKeyHandle** (char\* DeviceName, char\* ProtocolStackName, char\* InterfaceName, char\* PortName, HANDLE \*pKeyHandle, DWORD \*pErrorCode)

#### Description

Function „VCS\_GetKeyHandle” returns the Key-Handle.

#### Parameters

DeviceName	char*	Device name
ProtocolStack-Name	char*	Protocol stack name
InterfaceName	char*	Interface name
PortName	char*	Port name

#### Return Parameters

pKeyHandle	HANDLE	Handle for port access
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

## 7.4.9 Get Port Name

### Function

BOOL **VCS\_GetPortName** (HANDLE KeyHandle, char \*pPortName, WORD MaxStrSize, DWORD \*pErrorCode)

### Description

Function „VCS\_GetPortName“ returns the port name to corresponding handle.

### Parameters

KeyHandle	HANDLE	Handle for port access
MaxStrSize	WORD	Reserved memory size for the port name

### Return Parameters

pPortName	char*	Port name
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

## 7.4.10 Get Port Name Selection

### Function

BOOL **VCS\_GetPortNameSelection** (char\* DeviceName, char\* ProtocolStackName, char\* InterfaceName, BOOL StartOfSelection, char \*pPortSel, WORD MaxStrSize, BOOL \*pEndOfSelection, DWORD \*pErrorCode)

### Description

Function „VCS\_GetPortNameSelection“ returns all available port names.

### Parameters

DeviceName	char*	Device name
ProtocolStack-Name	char*	Protocol stack name
InterfaceName	char*	Interface name
StartOfSelection	BOOL	True: Get first selection string False: Get next selection string
MaxStrSize	WORD	Reserved memory size for the port name

### Return Parameters

pPortSel	char*	Pointer to port name
pEndOfSelection	BOOL	True: No more string available False: More string available
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

Go to [Programming Example](#)

### 7.4.11 Get Protocol Stack Name

#### Function

BOOL **VCS\_GetProtocolStackName** (HANDLE KeyHandle, char \*pProtocolStackName, WORD MaxStrSize, DWORD \*pErrorCode)

#### Description

Function „VCS\_GetProtocolStackName“ returns the protocol stack name to corresponding handle.

#### Parameters

KeyHandle	HANDLE	Handle for port access
MaxStrSize	WORD	Reserved memory size for the name

#### Return Parameters

pProtocolStack-Name	char*	Pointer to protocol stack name
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### 7.4.12 Get Protocol Stack Name Selection

#### Function

BOOL **VCS\_GetProtocolStackNameSelection** (char\* DeviceName, BOOL StartOfSelection, char \*pProtocolStackNameSel, WORD MaxStrSize, BOOL \*pEndOfSelection, DWORD \*pErrorCode)

#### Description

Function „VCS\_GetProtocolStackNameSelection“ returns all available protocol stack names.

#### Parameters

DeviceName	char*	Device name
StartOfSelection	BOOL	True: Get first selection string False: Get next selection string
MaxStrSize	WORD	Reserved memory size for the name

#### Return Parameters

pProtocolStack-NameSel	char*	Pointer to available protocol stack name
pEndOfSelection	BOOL	True: No more string available False: More string available
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### 7.4.13 Programming Example

The example shows how to read all protocol stack names of the available interfaces.

```
WORD wMaxStrSize = 100;
char* strDeviceName = "EPOS";
char* strProtocolStackName = (char*)malloc(wMaxStrSize);
BOOL oEndOfSel;
DWORD dErrorCode;

// get first protocol stack name
if(VCS_GetProtocolStackNameSelection(strDeviceName, true,
strProtocolStackName, wMaxStrSize, &oEndOfSel, &dErrorCode))
{
    // get next protocol stack name (as long as oEndOfSel == false)
    while(!oEndOfSel)
    {
        VCS_GetProtocolStackNameSelection (strDeviceName, false,
        strProtocolStackName, wMaxStrSize, &oEndOfSel, &dErrorCode)
    }
}
```



## 8 Virtual Command Set EPOS

The Virtual Command Set EPOS defines following groups:

[Configuration](#)  
[Current Mode](#)  
[Homing Mode](#)  
[Inputs Outputs](#)  
[Motion Info](#)  
[Position Mode](#)  
[Profile Position Mode](#)  
[Profile Velocity Mode](#)  
[State Machine](#)  
[Utilities](#)  
[Velocity Mode](#)

### 8.1 Configuration

This group defines all required functions for device configuration:

[Get Current Regulator Gain](#)  
[Get Encoder Parameter](#)  
[Get Motor Parameter](#)  
[Get Position Regulator Gain](#)  
[Get Velocity Regulator Gain](#)  
[Set Current Regulator Gain](#)  
[Set Encoder Parameter](#)  
[Set Motor Parameter](#)  
[Set Position Regulator Gain](#)  
[Set Velocity Regulator Gain](#)

#### 8.1.1 Get Current Regulator Gain

##### Function

BOOL **VCS\_GetCurrentRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD \*pP, WORD \*pI, DWORD \*pErrorCode)

##### Description

With function „VCS\_GetCurrentRegulatorGain“ it is possible to read all current regulator gains.

##### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

##### Return Parameters

pP	WORD	Current regulator P-Gain	Object: 0x60F6-01
pI	WORD	Current regulator I-Gain	Object: 0x60F6-02
pErrorCode	DWORD	Error information	
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0	

##### Related Functions

[Set Current Regulator Gain](#)

## 8.1.2 Get Encoder Parameter

### Function

BOOL **VCS\_GetEncoderParameter** (HANDLE KeyHandle, WORD NodeId, WORD \*pCounts, WORD \*pPositionSensorType, DWORD \*pErrorCode)

### Description

With function „VCS\_GetEncoderParameter“ it is possible to read all encoder parameters.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pCounts	WORD	Incremental encoder counts [pulse per turn]	Object: 0x2210-01
pPosition-SensorType	WORD	Position sensor type	Object: 0x2210-02
pErrorCode	DWORD	Error information	
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0	

### Related Functions

[Set Encoder Parameter](#)

## 8.1.3 Get Motor Parameter

### Function

BOOL **VCS\_GetMotorParameter** (HANDLE KeyHandle, WORD NodeId, WORD \*pMotorType, WORD \*pContinuousCurrent, WORD \*pPeakCurrent, BYTE \*pPolePair, WORD \*pThermalTimeConstant, DWORD \*pErrorCode)

### Description

With function „VCS\_GetMotorParameter“ it is possible to read all motor parameters.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pMotorType	WORD	Kind of motor	Object: 0x6402-00
pContinuous-Current	WORD	Maximal continuous current [mA]	Object: 0x6410-01
pPeakCurrent	WORD	Maximal peak current [mA]	Object: 0x6410-02
pPolePair	BYTE	Number of pole pairs	Object: 0x6410-03
pThermalTime-Constant	WORD	Thermal time constant Winding [s]	Object: 0x6410-05
pErrorCode	DWORD	Error information	
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0	

### Related Functions

[Set Motor Parameter](#)

### 8.1.4 Get Position Regulator Gain

#### Function

BOOL **VCS\_GetPositionRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD \*pP, WORD \*pI, WORD \*pD, DWORD \*pErrorCode)

#### Description

With function „VCS\_GetPositionRegulatorGain“ it is possible to read all position regulator gains.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pP	WORD	Position regulator P-Gain	Object: 0x60FB-01
pI	WORD	Position regulator I-Gain	Object: 0x60FB-02
pD	WORD	Position regulator D-Gain	Object: 0x60FB-03
pErrorCode	DWORD	Error information	
Return Value	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Set Position Regulator Gain](#)

### 8.1.5 Get Velocity Regulator Gain

#### Function

BOOL **VCS\_GetVelocityRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD \*pP, WORD \*pI, DWORD \*pErrorCode)

#### Description

With function „VCS\_GetVelocityRegulatorGain“ it is possible to read all velocity regulator gains.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pP	WORD	Velocity regulator P-Gain	Object: 0x60F9-01
pI	WORD	Velocity regulator I-Gain	Object: 0x60F9-02
pErrorCode	DWORD	Error information	
Return Value	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Set Velocity Regulator Gain](#)

## 8.1.6 Set Current Regulator Gain

### Function

BOOL **VCS\_SetCurrentRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD P, WORD I, DWORD \*pErrorCode)

### Description

With function „VCS\_SetCurrentRegulatorGain“ it is possible to write all current regulator gains. Determine the optimal parameters by using the 'Regulation Tuning' of EPOS\_UserInterface.

### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
P	WORD	Current regulator P-Gain	Object: 0x60F6-01
I	WORD	Current regulator I-Gain	Object: 0x60F6-02

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>		
	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Current Regulator Gain](#)

## 8.1.7 Set Encoder Parameter

### Function

BOOL **VCS\_SetEncoderParameter** (HANDLE KeyHandle, WORD NodeId, WORD Counts, WORD PositionSensorType, DWORD \*pErrorCode)

### Description

With function „VCS\_SetEncoderParameter“ it is possible to write all encoder parameters.

### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
Counts	WORD	Incremental Encoder counts [pulse per turn]	Object: 0x2210-01
PositionSensor-Type	WORD	Position Sensor Type	Object: 0x2210-02

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>		
	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Encoder Parameter](#)

### 8.1.8 Set Motor Parameter

#### Function

BOOL **VCS\_SetMotorParameter** (HANDLE KeyHandle, WORD NodeId, WORD MotorType, WORD ContinuousCurrent, WORD PeakCurrent, BYTE PolePair, WORD ThermalTimeConstant, DWORD \*pErrorCode)

#### Description

With function „VCS\_SetMotorParameter“ it is possible to write all motor parameters.

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
MotorType	WORD	Kind of motor	Object: 0x6402-00
Continuous-Current	WORD	Maximal continuous current [mA]	Object: 0x6410-01
PeakCurrent	WORD	Maximal peak current [mA]	Object: 0x6410-02
PolePair	BYTE	Number of pole pairs	Object: 0x6410-03
ThermalTime-Constant	WORD	Thermal time constant Winding [s]	Object: 0x6410-05

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Get Motor Parameter](#)

### 8.1.9 Set Position Regulator Gain

#### Function

BOOL **VCS\_SetPositionRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD P, WORD I, WORD D, DWORD \*pErrorCode)

#### Description

With function „VCS\_SetPositionRegulatorGain“ it is possible to write all position regulator gains. Determine the optimal parameters by using the 'Regulation Tuning' of EPOS\_UserInterface.

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
P	WORD	Position regulator P-Gain	Object: 0x60FB-01
I	WORD	Position regulator I-Gain	Object: 0x60FB-02
D	WORD	Position regulator D-Gain	Object: 0x60FB-03

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Get Position Regulator Gain](#)

### 8.1.10 Set Velocity Regulator Gain

#### Function

BOOL **VCS\_SetVelocityRegulatorGain** (HANDLE KeyHandle, WORD NodeId, WORD P, WORD I, DWORD \*pErrorCode)

#### Description

With function „VCS\_SetVelocityRegulatorGain“ it is possible to write all velocity regulator gains. Determine the optimal parameters by using the 'Regulation Tuning' of EPOS\_UserInterface.

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
P	WORD	Velocity regulator P-Gain	Object: 0x60F9-01
I	WORD	Velocity regulator I-Gain	Object: 0x60F9-02

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Get Velocity Regulator Gain](#)

## 8.2 Current Mode

This group defines all required functions for current mode:

[Get Current Must](#)

[Set Current Must](#)

### 8.2.1 Get Current Must

#### Function

BOOL **VCS\_GetCurrentMust** (HANDLE KeyHandle, WORD NodeId, short \*pCurrentMust, DWORD \*pErrorCode)

#### Description

With function „VCS\_GetCurrentMust“ it is possible to read the current mode demand value.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pCurrentMust	short	Current mode demand value [mA]	Object: 0x2030-00
pErrorCode	DWORD	Error information	
<b>Return Value</b>			
	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Set Current Must](#)

### 8.2.2 Set Current Must

#### Function

BOOL **VCS\_SetCurrentMust** (HANDLE KeyHandle, WORD NodeId, short CurrentMust, DWORD \*pErrorCode)

#### Description

With function „VCS\_SetCurrentMust“ it is possible to write current mode demand value.

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
CurrentMust	short	Current mode demand value [mA]	Object: 0x2030-00

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>		
	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Get Current Must](#)

## 8.3 Homing Mode

This group defines all required functions for homing mode:

[Find Home](#)  
[Get Homing Parameter](#)  
[Set Homing Parameter](#)  
[Stop Homing](#)

### 8.3.1 Find Home

#### Function

BOOL **VCS\_FindHome** (HANDLE KeyHandle, WORD NodeId, \_\_int8 HomingMethod, DWORD \*pErrorCode)

#### Description

With function „VCS\_FindHome“ and the Parameter „HomingMethod“ it is possible to find the system home. For example a home switch.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)
HomingMethod	__int8	Homing method <span style="color: red;">Object: 0x6098-00</span>

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

Method Number	Description
35	Actual Position
34	Index Positive Speed
33	Index Negative Speed
27	Home Switch Negative Speed
23	Home Switch Positive Speed
18	Positive Limit Switch
17	Negative Limit Switch
11	Home Switch Negative Speed & Index
7	Home Switch Positive Speed & Index
2	Positive Limit Switch & Index
1	Negative Limit Switch & Index
0	No homing operation required
-1	Current Threshold Positive Speed & Index
-2	Current Threshold Negative Speed & Index
-3	Current Threshold Positive Speed
-4	Current Threshold Negative Speed

Table 2: Homing methods

#### Related Functions

[Set Homing Parameter](#)  
[Stop Homing](#)



### 8.3.2 Get Homing Parameter

#### Function

BOOL **VCS\_GetHomingParameter** (HANDLE KeyHandle, WORD NodeId, DWORD \*pHomingAcceleration, DWORD \*pSpeedSwitch, DWORD \*pSpeedIndex, long \*pHomeOffset, WORD \*pCurrentThreshold, long \*pHomePosition, DWORD \*pErrorCode)

#### Description

With function „VCS\_GetHomingParameter“ it is possible to read all homing parameters.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pHoming-Acceleration	DWORD	Acceleration for homing profile [rpm/s]	Object: 0x609A-00
pSpeedSwitch	DWORD	Speed during search for switch [rpm]	Object: 0x6099-01
pSpeedIndex	DWORD	Speed during search for index signal [rpm]	Object: 0x6099-02
pHomeOffset	long	Home offset after homing [qc]	Object: 0x607C-00
pCurrent-Threshold	WORD	Current threshold for homing method -1, -2, -3 and -4 [mA]	Object: 0x2080-00
pHomePosition	long	Home position value [qc]	Object: 0x2081-00
pErrorCode	DWORD	Error information	
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Find Home](#)

[Stop Homing](#)

[Set Homing Parameter](#)

### 8.3.3 Set Homing Parameter

#### Function

BOOL **VCS\_SetHomingParameter** (HANDLE KeyHandle, WORD NodeId, DWORD HomingAcceleration, DWORD SpeedSwitch, DWORD SpeedIndex, long HomeOffset, WORD CurrentThreshold, long HomePosition, DWORD \*pErrorCode)

#### Description

With function „VCS\_SetHomingParameter“ it is possible to write all homing parameters.

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
Homing-Acceleration	DWORD	Acceleration for homing profile [rpm/s]	Object: 0x609A-00
SpeedSwitch	DWORD	Speed during search for switch [rpm]	Object: 0x6099-01
SpeedIndex	DWORD	Speed during search for index signal [rpm]	Object: 0x6099-02
HomeOffset	long	Home offset after homing [qc]	Object: 0x607C-00
Current-Threshold	WORD	Current threshold for homing method -1, -2, -3 and -4 [mA]	Object: 0x2080-00
HomePosition	Long	Assign the current Homing position with this value [qc]	Object: 0x2081-00

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Find Home](#)  
[Stop Homing](#)  
[Get Homing Parameter](#)

### 8.3.4 Stop Homing

#### Function

BOOL **VCS\_StopHoming** (HANDLE KeyHandle, WORD NodeId, DWORD \*pErrorCode)

#### Description

The function „VCS\_StopHoming“ interrupts homing.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Find Home](#)  
[Set Homing Parameter](#)

## 8.4 Inputs Outputs

This group defines all required functions for inputs and outputs information:

[Digital Input Configuration](#)  
[Digital Output Configuration](#)  
[Get All Digital Inputs](#)  
[Get All Digital Outputs](#)  
[Get Analog Input](#)  
[Set All Digital Outputs](#)

### Digital Input Overview

The number of supported digital inputs depend on hardware (EPOS 24/1 and EPOS 24/5 and MCD EPOS 60 W have six digital inputs; EPOS 70/10 supports eight digital inputs). There are some predefined functions for digital inputs like home switch, limit switches, position marker and also some general purpose inputs for general purpose process inputs.




Figure 3: Digital Input Functionality EPOS 24/1 and EPOS 24/5 Overview (default configuration)

### Remark

More information about the inputs from the other devices (i. e. EPOS 70/10 and MCD EPOS) are available in the document EPOS Firmware Specification!

### Digital Outputs Overview

There is a predefined function for digital output: Ready/Fault. If an output is configured with this function then a hardware signal is available if a fault occurs or not. There are also some general purpose outputs for general process controlling for example lighting a lamp. The configuration is similar to the digital inputs configuration.




Figure 4: Digital Output Functionality EPOS 24/5 and EPOS 70/10 Overview (default configuration)

### Remark

More information about the inputs from the other devices (i. e. EPOS 24/1 and MCD EPOS) are available in the document EPOS Firmware Specification!

### 8.4.1 Digital Input Configuration

#### Function

BOOL **VCS\_DigitalInputConfiguration** (HANDLE KeyHandle, WORD NodeId, WORD DigInputNb, WORD Configuration, BOOL Mask, BOOL Polarity, BOOL ExecutionMask, DWORD \*pErrorCode)

#### Description

„VCS\_DigitalInputConfiguration” sets the parameter for a digital input.

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
DigInputNb	WORD	Number of digital input (Sub index of object)	Object: 0x2070-0x
Configuration	WORD	Configures which functionality will be assigned to digital input (bit number)	
Mask	BOOL	1: Functionality state will be displayed 0: not displayed	Object: 0x2071-02
Polarity	BOOL	1: Low level 0: High level	Object: 0x2071-03
ExecutionMask	BOOL	1: Set the error routine. Only for positive and negative switch.	Object: 0x2071-04

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Get All Digital Inputs](#)

## 8.4.2 Digital Output Configuration

### Function

BOOL **VCS\_DigitalOutputConfiguration** (HANDLE KeyHandle, WORD NodeId, WORD DigOutputNb WORD Configuration, BOOL State, BOOL Mask, BOOL Polarity, DWORD \*pErrorCode)

### Description

„VCS\_DigitalOutputConfiguration” sets parameter for a digital output.

### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
DigOutputNb	WORD	Number of digital output (Sub-Index of object)	Object: 0x2079-0x
Configuration	WORD	Configures which functionality will be assigned to digital output (bit number)	
State	BOOL	State of digital output	Object: 0x2078-01
Mask	BOOL	1: Register will be modified	Object: 0x2078-02
Polarity	BOOL	1: Output will be inverted	Object: 0x2078-03

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get All Digital Outputs](#)

[Set All Digital Outputs](#)

### 8.4.3 Get All Digital Inputs

#### Function

BOOL **VCS\_GetAllDigitalInputs** (HANDLE KeyHandle, WORD NodeId, WORD \*pInput, DWORD \*pErrorCode)

#### Description

„VCS\_GetAllDigitalInputs“ returns state of all digital inputs.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pInput	WORD	State of all digital inputs	Object: 0x2071-01
pErrorCode	DWORD	Error information	
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Digital Input Configuration](#)

### 8.4.4 Get All Digital Outputs

#### Function

BOOL **VCS\_GetAllDigitalOutputs** (HANDLE KeyHandle, WORD NodeId, WORD \*pOutputs, DWORD \*pErrorCode)

#### Description

„VCS\_GetAllDigitalOutputs“ returns state of all digital outputs.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pOutputs	WORD	State of all digital outputs	Object: 0x2078-01
pErrorCode	DWORD	Error information	
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Digital Output Configuration](#)

[Set All Digital Outputs](#)

### 8.4.5 Get Analog Input

#### Function

BOOL **VCS\_GetAnalogInput** (HANDLE KeyHandle, WORD NodeId, WORD Number, WORD \*pAnalog, DWORD \*pErrorCode)

#### Description

„VCS\_GetAnalogInput“ returns the analog value from input 1 or 2.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)
Number	WORD	Analog input number 1 or 2

#### Return Parameters

pAnalog	WORD	Analog value from input [mV]	Object: 0x207C-01 or Object: 0x207C-02
pErrorCode	DWORD	Error information	
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0	

### 8.4.6 Set All Digital Outputs

#### Function

BOOL **VCS\_SetAllDigitalOutputs** (HANDLE KeyHandle, WORD NodeId, WORD Outputs, DWORD \*pErrorCode)

#### Description

„VCS\_SetAllDigitalOutputs“ set state of all digital outputs

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
Outputs	WORD	State of all digital outputs	Object: 0x2078-01

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Digital Output Configuration](#)

[Get All Digital Outputs](#)



## 8.5 Motion Info

This group defines all required functions for motion information:

[Get Current Is](#)  
[Get Movement State](#)  
[Get Position Is](#)  
[Get Velocity Is](#)

### 8.5.1 Get Current Is

#### Function

BOOL **VCS\_GetCurrentIs** (HANDLE KeyHandle, WORD NodeId, short \*pCurrentIs, DWORD \*pErrorCode)

#### Description

„VCS\_GetCurrentIs“ returns the current actual value.

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	

#### Return Parameters

pCurrentIs	short	Current actual value [mA]	Object: 0x6078-00
pErrorCode	DWORD	Error information	
Return Value	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Get Movement State](#)  
[Get Position Is](#)  
[Get Velocity Is](#)

### 8.5.2 Get Movement State

#### Function

BOOL **VCS\_GetMovementState** (HANDLE KeyHandle, WORD NodeId, BOOL \*pTargetReached, DWORD \*pErrorCode)

#### Description

With „VCS\_GetMovementState“ it is possible to check, if drive has reached the target.

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	

#### Return Parameters

pTargetReached	BOOL	The drive has reached the target. The function reads actual state of bit 10 from the status word.	Object: 0x6041-00 Bit 10
pErrorCode	DWORD	Error information	
Return Value	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Get Current Is](#)  
[Get Position Is](#)  
[Get Velocity Is](#)

### 8.5.3 Get Position Is

#### Function

BOOL **VCS\_GetPositionIs** (HANDLE KeyHandle, WORD NodeId, long \*pPositionIs, DWORD \*pErrorCode)

#### Description

„VCS\_GetPositionIs” returns the position actual value.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pPositionIs	long	Position actual value [qc]	Object: 0x6064-00
pErrorCode	DWORD	Error information	
<b>Return Value</b>			
	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Get Current Is](#)

[Get Movement State](#)

[Get Velocity Is](#)

[Get Position Must](#)

[Set Position Must](#)

### 8.5.4 Get Velocity Is

#### Function

BOOL **VCS\_GetVelocityIs** (HANDLE KeyHandle, WORD NodeId, long \*pVelocityIs, DWORD \*pErrorCode)

#### Description

„VCS\_GetVelocityIs” read the velocity actual value.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pVelocityIs	long	Velocity actual value [rpm]	Object: 0x606C-00
pErrorCode	DWORD	Error information	
<b>Return Value</b>			
	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Get Current Is](#)

[Get Movement State](#)

[Get Position Is](#)

## 8.6 Position Mode

This group defines all required functions for position mode:

[Get Position Must](#)  
[Set Position Must](#)

### 8.6.1 Get Position Must

#### Function

BOOL **VCS\_GetPositionMust** (HANDLE KeyHandle, WORD NodeId, long \*pPositionMust, DWORD \*pErrorCode)

#### Description

„VCS\_GetPositionMust“ returns the position demand value.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pPositionMust	long	Position demand value [qc]	Object: 0x2062-00
pErrorCode	DWORD	Error information	
<b>Return Value</b>			
	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Get Position Is](#)

### 8.6.2 Set Position Must

#### Function

BOOL **VCS\_SetPositionMust** (HANDLE KeyHandle, WORD NodeId, long PositionMust, DWORD \*pErrorCode)

#### Description

„VCS\_SetPositionMust“ sets the position demand value.

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
PositionMust	long	Position demand value [qc]	Object: 0x2062-00

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>		
	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Get Position Is](#)

## 8.7 Profile Position Mode

This group defines all required functions for profile position mode:

[Get Position Profile](#)  
[Get Target Position](#)  
[Halt Position Movement](#)  
[Move To Position](#)  
[Set Position Profile](#)

### 8.7.1 Get Position Profile

#### Function

BOOL **VCS\_GetPositionProfile** (HANDLE KeyHandle, WORD NodeId, DWORD \*pProfileVelocity, DWORD \*pProfileAcceleration, DWORD \*pProfileDeceleration, DWORD \*pErrorCode)

#### Description

„VCS\_GetPositionProfile“ returns the position profile parameters.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pProfileVelocity	DWORD	Position profile velocity [rpm]	Object: 0x6081-00
pProfile-Acceleration	DWORD	Position profile acceleration [rpm/s]	Object: 0x6083-00
pProfile-Deceleration	DWORD	Position profile deceleration [rpm/s]	Object: 0x6084-00
pErrorCode	DWORD	Error information	
<b>Return Value</b>			
	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Get Target Position](#)  
[Halt Position Movement](#)  
[Move To Position](#)  
[Set Position Profile](#)

## 8.7.2 Get Target Position

### Function

BOOL **VCS\_GetTargetPosition** (HANDLE KeyHandle, WORD NodeId, long \*pTargetPosition, DWORD \*pErrorCode)

### Description

The function „VCS\_GetTargetPosition“ returns the profile position mode target value.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pTargetPosition	long	Target position [qc]	Object: 0x607A-00
pErrorCode	DWORD	Error information	
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0	

### Related Functions

[Get Position Profile](#)  
[Halt Position Movement](#)  
[Move To Position](#)  
[Set Position Profile](#)

## 8.7.3 Halt Position Movement

### Function

BOOL **VCS\_HaltPositionMovement** (HANDLE KeyHandle, WORD NodeId, DWORD \*pErrorCode)

### Description

With function „VCS\_HaltPositionMovement“ movement stops with profile deceleration.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Position Profile](#)  
[Get Target Position](#)  
[Move To Position](#)  
[Set Position Profile](#)

## 8.7.4 Move To Position

### Function

BOOL **VCS\_MoveToPosition** (HANDLE KeyHandle, WORD NodeId, long TargetPosition, BOOL Absolute, BOOL Immediately, DWORD \*pErrorCode)

### Description

With function „VCS\_MoveToPosition“ device movement starts with position profile to target position.

### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
TargetPosition	long	Target position [qc]	Object: 0x607A-00
Absolute	BOOL	TRUE starts an absolute, FALSE a relative movement	Object: 0x6040-00 Bit 6
Immediately	BOOL	TRUE starts immediately, FALSE waits to end of last positioning	Object: 0x6040-00 Bit 5

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Position Profile](#)  
[Get Target Position](#)  
[Halt Position Movement](#)  
[Set Position Profile](#)

## 8.7.5 Set Position Profile

### Function

BOOL **VCS\_SetPositionProfile** (HANDLE KeyHandle, WORD NodeId, DWORD ProfileVelocity, DWORD ProfileAcceleration, DWORD ProfileDeceleration, DWORD \*pErrorCode)

### Description

„VCS\_SetPositionProfile“ sets the position profile parameters.

### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
ProfileVelocity	DWORD	Position profile velocity [rpm]	Object: 0x6081-00
Profile-Acceleration	DWORD	Position profile acceleration [rpm/s]	Object: 0x6083-00
Profile-Deceleration	DWORD	Position profile deceleration [rpm/s]	Object: 0x6084-00

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Position Profile](#)  
[Get Target Position](#)  
[Halt Position Movement](#)  
[Move To Position](#)

## 8.8 Profile Velocity Mode

This group defines all required functions for profile velocity mode:

[Get Target Velocity](#)  
[Get Velocity Profile](#)  
[Halt Velocity Movement](#)  
[Move With Velocity](#)  
[Set Velocity Profile](#)

### 8.8.1 Get Target Velocity

#### Function

BOOL **VCS\_GetTargetVelocity** (HANDLE KeyHandle, WORD NodeId, long \*pTargetVelocity, DWORD \*pErrorCode)

#### Description

The function „VCS\_GetTargetVelocity” returns the profile velocity mode target value.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pTargetVelocity	long	Target velocity [rpm]	Object: 0x60FF-00
pErrorCode	DWORD	Error information	
Return Value	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Get Velocity Profile](#)  
[Halt Velocity Movement](#)  
[Move With Velocity](#)  
[Set Velocity Profile](#)

## 8.8.2 Get Velocity Profile

### Function

BOOL **VCS\_GetVelocityProfile** (HANDLE KeyHandle, WORD NodeId, DWORD \*pProfileAcceleration, DWORD \*pProfileDeceleration, DWORD \*pErrorCode)

### Description

„VCS\_GetVelocityProfile“ returns the velocity profile parameters.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pProfile-Acceleration	DWORD	Velocity profile acceleration [rpm/s]	Object: 0x6083-00
pProfile-Deceleration	DWORD	Velocity profile deceleration [rpm/s]	Object: 0x6084-00
pErrorCode	DWORD	Error information	
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0	

### Related Functions

[Get Target Velocity](#)  
[Halt Velocity Movement](#)  
[Move With Velocity](#)  
[Set Velocity Profile](#)

## 8.8.3 Halt Velocity Movement

### Function

BOOL **VCS\_HaltVelocityMovement** (HANDLE KeyHandle, WORD NodeId, DWORD \*pErrorCode)

### Description

With function „VCS\_HaltVelocityMovement“ movement stops with profile deceleration.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Target Velocity](#)  
[Get Velocity Profile](#)  
[Move With Velocity](#)  
[Set Velocity Profile](#)



## 8.8.4 Move With Velocity

### Function

BOOL **VCS\_MoveWithVelocity** (HANDLE KeyHandle, WORD NodeId, long TargetVelocity, DWORD \*pErrorCode)

### Description

With function „VCS\_MoveWithVelocity“ device movement starts with velocity profile to target velocity.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)
TargetVelocity	long	Target velocity [rpm] <span style="color: red;">Object: 0x60FF-00</span>

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Target Velocity](#)  
[Get Velocity Profile](#)  
[Halt Velocity Movement](#)  
[Set Velocity Profile](#)

## 8.8.5 Set Velocity Profile

### Function

BOOL **VCS\_SetVelocityProfile** (HANDLE KeyHandle, WORD NodeId, DWORD ProfileAcceleration, DWORD ProfileDeceleration, DWORD \*pErrorCode)

### Description

„VCS\_SetVelocityProfile“ sets the velocity profile parameters.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)
Profile-Acceleration	DWORD	Velocity profile acceleration [rpm/s] <span style="color: red;">Object: 0x6083-00</span>
Profile-Deceleration	DWORD	Velocity profile deceleration [rpm/s] <span style="color: red;">Object: 0x6084-00</span>

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Target Velocity](#)  
[Get Velocity Profile](#)  
[Halt Velocity Movement](#)  
[Move With Velocity](#)

## 8.9 State Machine

For detailed information how the state machine functions refer to document „EPOS Firmware Specification“.

This group defines all required function blocks for device state machine:

[Clear Fault](#)  
[Get Disable State](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Operation Mode](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Operation Mode](#)  
[Set Quick Stop State](#)  
[Send NMT Service](#)

### 8.9.1 Clear Fault

#### Function

BOOL **VCS\_ClearFault** (HANDLE KeyHandle, WORD NodeId, DWORD \*pErrorCode)

#### Description

With function „VCS\_ClearFault“ the device changes from fault state to disable state.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Get Disable State](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)

## 8.9.2 Get Disable State

### Function

BOOL **VCS\_GetDisableState** (HANDLE KeyHandle, WORD NodeId, BOOL \*plsDisabled, DWORD \*pErrorCode)

### Description

The function „VCS\_GetDisableState“ returns the device state disable (plsDisabled = TRUE).

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

plsDisabled	BOOL	Device disable state
pErrorCode	DWORD	Error information
<b>Return Value</b>		
	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Clear Fault](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)

## 8.9.3 Get Enable State

### Function

BOOL **VCS\_GetEnableState** (HANDLE KeyHandle, WORD NodeId, BOOL \*plsEnabled, DWORD \*pErrorCode)

### Description

The function „VCS\_GetEnableState“ returns the device state enable (plsEnabled = TRUE).

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

plsEnabled	BOOL	Device enable state
pErrorCode	DWORD	Error information
<b>Return Value</b>		
	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Clear Fault](#)  
[Get Disable State](#)  
[Get Fault State](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)

### 8.9.4 Get Fault State

#### Function

BOOL **VCS\_GetFaultState** (HANDLE KeyHandle, WORD NodeId, BOOL \*plsInFault, DWORD \*pErrorCode)

#### Description

The function „VCS\_GetFaultState” returns the device state fault (plsInFault = TRUE).

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

plsInFault	BOOL	Device fault state
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Remarks

Get error information by read out the error history (use [Get Object](#) with index 0x1005, SubIndex 0x01 et sqq.)

#### Related Functions

[Clear Fault](#)  
[Get Disable State](#)  
[Get Enable State](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)

### 8.9.5 Get Operation Mode

#### Function

BOOL **VCS\_GetOperationMode** (HANDLE KeyHandle, WORD NodeId, \_\_int8 \*pMode, DWORD \*pErrorCode)

#### Description

„VCS\_GetOperationMode” returns the operation mode:

<i>Value</i>	<i>Mode</i>
6 (06h)	Homing Mode
3 (03h)	Profile Velocity Mode
1 (01h)	Profile Position Mode
-1 (FFh)	Position Mode
-2 (FEh)	Velocity Mode
-3 (FDh)	Current Mode
-5 (FBh)	Master Encoder Mode
-6 (FAh)	Step/Direction Mode

Table 3: Operation modes

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pMode	__int8	Operation Mode	Object: 0x6061-00
pErrorCode	DWORD	Error information	
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Set Operation Mode](#)

## 8.9.6 Get Quick Stop State

### Function

BOOL **VCS\_GetQuickStopState** (HANDLE KeyHandle, WORD NodeId, BOOL \*plsQuickStopped, DWORD \*pErrorCode)

### Description

The function „VCS\_GetQuickStopState” returns the device state quick stop (plsQuickStopped = TRUE).

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

plsQuick- Stopped	BOOL	Device quick stop state
pErrorCode	DWORD	Error information
<b>Return Value</b>		
	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Clear Fault](#)  
[Get Disable State](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)

## 8.9.7 Set Disable State

### Function

BOOL **VCS\_SetDisableState** (HANDLE KeyHandle, WORD NodeId, DWORD \*pErrorCode)

### Description

With function „VCS\_SetDisableState” changes the device to disable state.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>		
	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Clear Fault](#)  
[Get Disable State](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Quick Stop State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)

## 8.9.8 Set Enable State

### Function

BOOL **VCS\_SetEnableState** (HANDLE KeyHandle, WORD NodeId, DWORD \*pErrorCode)

### Description

With the function „VCS\_SetEnableState“ the device changes to enable state.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Clear Fault](#)  
[Get Disable State](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Quick Stop State](#)

## 8.9.9 Set Operation Mode

### Function

BOOL **VCS\_SetOperationMode** (HANDLE KeyHandle, WORD NodeId, \_\_int8 Mode, DWORD \*pErrorCode)

### Description

„VCS\_SetOperationMode“ sets the operation mode. Mode can have the following values:

<b>Mode</b>	<b>Value</b>
Homing Mode	6 (06h)
Profile Velocity Mode	3 (03h)
Profile Position Mode	1 (01h)
Position Mode	-1 (FFh)
Velocity Mode	-2 (FEh)
Current Mode	-3 (FDh)
Master Encoder Mode	-5 (FBh)
Step/Direction Mode	-6 (FAh)

Table 4: Operation modes

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)
Mode	__int8	Operation Mode <span style="color: red;">Object: 0x6060-00</span>

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Operation Mode](#)

### 8.9.10 Set Quick Stop State

#### Function

BOOL **VCS\_SetQuickStopState** (HANDLE KeyHandle, WORD NodeId, DWORD \*pErrorCode)

#### Description

With function „VCS\_SetQuickStopState“ the device changes to quick stop state.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Clear Fault](#)  
[Get Disable State](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)

### 8.9.11 Send NMT Service

#### Function

BOOL **VCS\_SendNMTService** (HANDLE KeyHandle, WORD NodeId, WORD CommandSpecifier, DWORD \*pErrorCode)

#### Description

The function „VCS\_SendNMTService“ is used to send a NMT protocol from a master to a slave. It is a command without acknowledge.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)
Command-Specifier	WORD	Following NMT services are available: 1   Start Remote Node 2   Stop Remote Node 128   Enter Pre-Operational 129   Reset Node 130   Reset Communication

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

## 8.10 Utilities

This group defines all functions, which do not fall in the other groups:

[Get Object](#)  
[Get Version](#)  
[Restore](#)  
[Set Object](#)  
[Store](#)

### 8.10.1 Get Object

#### Function

BOOL **VCS\_GetObject** (HANDLE KeyHandle, WORD NodeId, WORD ObjectIndex, BYTE ObjectSubIndex, void \*pData, DWORD NbOfBytesToRead, DWORD pNbOfBytesRead, DWORD \*pErrorCode)

#### Description

The function „VCS\_GetObject” read an object value at the given index and sub index from object dictionary.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)
ObjectIndex	WORD	Object index
ObjectSubIndex	BYTE	Object sub index
NbOfBytesTo-Read	DWORD	Object length to read (number of bytes)

#### Return Parameters

pData	void	Object data
pNbOfBytes-Read	DWORD	Object length read (number of bytes)
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

#### Remarks

All information about object index, object sub index and object length can be checked in the document EPOS Firmware Specification.

#### Related Functions

[Get Version](#)  
[Restore](#)  
[Set Object](#)  
[Store](#)



## 8.10.2 Get Version

### Function

BOOL **VCS\_GetVersion** (HANDLE KeyHandle, WORD NodeId, WORD \*pHardwareVersion, WORD \*pSoftwareVersion, WORD \*pApplicationNumber, WORD \*pApplicationVersion, DWORD \*pErrorCode)

### Description

„VCS\_GetVersion” returns the firmware version.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pHardware-Version	WORD	Hardware version	Object: 0x2003-01
pSoftware-Version	WORD	Software version	Object: 0x2003-02
pApplication-Number	WORD	Application number	Object: 0x2003-03
pApplication-Version	WORD	Application version	Object: 0x2003-04
pErrorCode	DWORD	Error information	
<b>Return Value</b>			
	BOOL	Nonzero if successful; otherwise 0	

### Related Functions

[Get Object](#)  
[Restore](#)  
[Set Object](#)  
[Store](#)

## 8.10.3 Restore

### Function

BOOL **VCS\_Restore** (HANDLE KeyHandle, WORD NodeId, DWORD \*pErrorCode)

### Description

The function „VCS\_Restore” restores all default parameters.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>		
	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Object](#)  
[Get Version](#)  
[Set Object](#)  
[Store](#)

## 8.10.4 Set Object

### Function

BOOL **VCS\_SetObject** (HANDLE KeyHandle, WORD NodeId, WORD ObjectIndex, BYTE ObjectSubIndex, void Data, DWORD NbOfBytesToWrite, DWORD NbOfBytesWritten, DWORD \*pErrorCode)

### Description

The function „VCS\_SetObject” writes an object value at the given index and sub index from object dictionary.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)
ObjectIndex	WORD	Object index
ObjectSubIndex	BYTE	Object sub index
Data	void	Object data
NbOfBytesTo-Write	DWORD	Object length to write (number of bytes)

### Return Parameters

pNbOfBytes-Written	DWORD	Object length written (number of bytes)
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Remarks

All information about object index, object sub index and object length can be checked in the document EPOS Firmware Specification.

### Related Functions

[Get Object](#)  
[Get Version](#)  
[Restore](#)  
[Store](#)

## 8.10.5 Store

### Function

BOOL **VCS\_Store** (HANDLE KeyHandle, WORD NodeId, DWORD \*pErrorCode)

### Description

The function „VCS\_Store” stores all parameters.

### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### Related Functions

[Get Object](#)  
[Get Version](#)  
[Restore](#)  
[Set Object](#)

## 8.11 Velocity Mode

This group defines all required functions for velocity mode:

[Get Velocity Must](#)

[Set Velocity Must](#)

### 8.11.1 Get Velocity Must

#### Function

BOOL **VCS\_GetVelocityMust** (HANDLE KeyHandle, WORD NodeId, long \*pVelocityMust, DWORD \*pErrorCode)

#### Description

The function „VCS\_GetVelocityMust” returns the position demand value.

#### Parameters

KeyHandle	HANDLE	Handle for port access
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)

#### Return Parameters

pVelocityMust	long	Velocity demand value [rpm]	Object: 0x206B-00
pErrorCode	DWORD	Error information	
<b>Return Value</b>			
	BOOL	Nonzero if successful; otherwise 0	

#### Related Functions

[Get Velocity Is](#)

[Set Velocity Must](#)

### 8.11.2 Set Velocity Must

#### Function

BOOL **VCS\_SetVelocityMust** (HANDLE KeyHandle, WORD NodeId, long VelocityMust, DWORD \*pErrorCode)

#### Description

The function „VCS\_SetVelocityMust” sets the velocity demand value.

#### Parameters

KeyHandle	HANDLE	Handle for port access	
NodeId	WORD	Identification ID of the addressed device (is given by hardware switches)	
VelocityMust	long	Velocity demand value [rpm]	Object: 0x206B-00

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>		
	BOOL	Nonzero if successful; otherwise 0

#### Related Functions

[Get Velocity Is](#)

[Get Velocity Must](#)

## 8.12 General CAN Commands

### 8.12.1 Send CAN Frame

#### Function

BOOL **VCS\_SendCANFrame** (HANDLE KeyHandle, WORD CobID, WORD Length, void \*pData, DWORD \*pErrorCode)

#### Description

Function „VCS\_SendCANFrame“ sends a general CAN Frame to the CAN bus.

#### Parameters

KeyHandle	HANDLE	Handle for port access
CobID	WORD	CAN Frame 11-bit Identifier
Length	WORD	CAN Frame Data Length Code (DLC)
pData	void	CAN Frame Data

#### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

### 8.12.2 Request CAN Frame

#### Function

BOOL **VCS\_RequestCANFrame** (HANDLE KeyHandle, WORD CobID, WORD Length, void \*pData, DWORD \*pErrorCode)

#### Description

Function „VCS\_RequestCANFrame“ requests a general CAN Frame from the CAN bus using Remote Transmit Request (RTR).

#### Parameters

KeyHandle	HANDLE	Handle for port access
CobID	WORD	CAN Frame 11-bit Identifier
Length	WORD	CAN Frame Data Length Code (DLC)

#### Return Parameters

pData	void	CAN Frame Data
pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

## 9 Virtual Dialog Set Communication

The Virtual Dialog Set Communication defines following groups:

### [Initialisation](#)

### 9.1 Initialisation

#### 9.1.1 Open Device Dialog

##### Function

HANDLE **VCS\_OpenDeviceDlg** (DWORD \*pErrorCode)

##### Description

The function „VCS\_OpenDeviceDlg” registers available interfaces (CAN and RS232) with which the EPOS can be operated and opened the selected interface for communication.

##### Return Parameters

pErrorCode	DWORD	Error information
<b>Return Value</b>	BOOL	Nonzero if successful; otherwise 0

##### Related Functions

[Open Device](#)

## 10 Error Overview

### 10.1 Overview Communication Errors

Abort Code	Name	Error cause
0x0000 0000	No Communication Error	The communication was successful
0x0503 0000	Toggle Error	Toggle bit not alternated
0x0504 0000	SDO Time Out	SDO protocol timed out
0x0504 0001	Client/server specifier Error	Client/server command specifier not valid or unknown
0x0504 0002	Invalid block size	Invalid block size (block mode only)
0x0504 0003	Invalid sequence	Invalid sequence number (block mode only)
0x0504 0004	CrcError	CRC error (block mode only)
0x0504 0005	Out of Memory Error	Out of Memory
0x0601 0000	Access Error	Unsupported access to an object (e.g. write command to a read-only object)
0x0601 0001	Write Only	Read command to a write only object
0x0601 0002	Read Only	Write command to a read only object
0x0602 0000	Object does not exist Error	The last read or write command had a wrong object index or -sub index
0x0604 0041	PDO mapping Error	The object cannot be mapped to the PDO
0x0604 0042	PDO length Error	The number and length of the objects to be mapped would exceed PDO length
0x0604 0043	General parameter Error	General parameter incompatibility
0x0604 0047	General Intern Incompatibility Error	General internal incompatibility in device
0x0606 0000	Hardware Error	Access failed due to an hardware error
0x0607 0010	Service Parameter Error	Data type does not match, length or service parameter does not match
0x0607 0012	Service Parameter Error too High Error	Data type does not match, length or service parameter too high
0x0607 0013	Service Parameter Error too Low Error	Data type does not match, length or service parameter too low
0x0609 0011	Object Sub-index Error	The last read or write command had a wrong Object sub index
0x0609 0030	Value Range Error	Value range of parameter exceeded
0x0609 0031	Value too High Error	Value of parameter written too high
0x0609 0032	Value too Low Error	Value of parameter written too low
0x0609 0036	Maximum less Minimum Error	Maximum value is less than minimum value
0x0800 0000	General Error	General error
0x0800 0020	Transfer or store Error	Data cannot be transferred or stored
0x0800 0021	Local control Error	Data cannot be transferred or stored to application because of local control
0x0800 0022	Wrong Device State	Data cannot be transferred or stored to application because of the present device state
0x0F00 FFB9	Error CAN id	Wrong CAN id
0x0F00 FFBC	Error Service Mode	The device is not in service mode
0x0F00 FFBE	Password Error	The password is wrong
0x0F00 FFBF	Illegal Command Error	The RS232 command is illegal (does not exist)
0x0F00 FFC0	Wrong NMT State Error	The device is in wrong NMT state

Table 5: Communication errors

## 10.2 Overview „Windows 32-Bit DLL,, specified Errors

### 10.2.1 General Errors

Code	Name	Error cause
0x0000 0000	No Error	The function was successful
0x1000 0001	Internal Error	Internal Error
0x1000 0002	Null Pointer	Null Pointer passed to function
0x1000 0003	Handle not Valid	Handle passed to function is not valid
0x1000 0004	Bad Virtual Device Name	Virtual Device name is not valid
0x1000 0005	Bad Device Name	Device name is not valid
0x1000 0006	Bad ProtocolStack Name	ProtocolStack name is not valid
0x1000 0007	Bad Interface Name	Interface name is not valid
0x1000 0008	Bad Port Name	Port is not valid
0x1000 0009	Library not Loaded	Could not load external library
0x1000 000A	ExecutingCommand	Command failed
0x1000 000B	Timeout	Timeout occurred during execution
0x1000 000C	BadParameter	Bad Parameter passed to function
0x1000 000D	CommandAbortedByUser	Command aborted by user

Table 6: „Windows 32-Bit DLL” specified general errors

### 10.2.2 Interface Layer Errors

Code	Name	Error cause
0x2000 0001	Opening Interface	Error opening interface
0x2000 0002	Closing Interface	Error closing interface
0x2000 0003	Interface not Open	Interface is not open
0x2000 0004	Opening Port	Error opening port
0x2000 0005	Closing Port	Error closing port
0x2000 0006	Port not Open	Port is not open
0x2000 0007	ResetPort	Error resetting port
0x2000 0008	SetPortSettings	Error configuring port settings
0x2000 0009	SetPortMode	Error configuring port mode

Table 7: „Windows 32-Bit DLL” specified interface layer errors

### 10.2.3 Interface Layer 'RS232' Errors

Code	Name	Error cause
0x2100 0001	WriteData	Error writing data
0x2100 0002	ReadData	Error reading data

Table 8: „Windows 32-Bit DLL” specified interface layer 'RS232' errors

### 10.2.4 Interface Layer 'CAN' Errors

Code	Name	Error cause
0x2200 0001	ReceiveCanFrame	Error receiving CAN Frame
0x2200 0002	TransmitCanFrame	Error transmitting CAN Frame

Table 9: „Windows 32-Bit DLL” specified interface layer 'CAN' errors

### 10.2.5 Protocol Layer 'MaxonRS232' Errors

Code	Name	Error cause
0x3100 0001	NegAckReceived	Negative acknowledge received
0x3100 0002	BadCrcReceived	Bad checksum received
0x3100 0003	BadDataSizeReceived	Bad data size received

Table 10: „Windows 32-Bit DLL” specified protocol 'MaxonRS232' errors

### 10.2.6 Protocol Layer 'CANopen' Errors

Code	Name	Error cause
0x3200 0001	SdoReceiveFrameNotReceived	CAN Frame of SDO protocol not received
0x3200 0002	RequestedCanFrameNotReceived	Requested CAN Frame not received

Table 11: „Windows 32-Bit DLL” specified protocol 'CANopen' errors

## 11 Table of functions

7.3	Initialisation .....	9
	HANDLE <b>VCS_OpenDevice</b> (char* DeviceName, char* ProtocolStackName, char* InterfaceName, char* PortName, DWORD *pErrorCode) .....	9
	BOOL <b>VCS_CloseAllDevices</b> (DWORD *pErrorCode) .....	9
	BOOL <b>VCS_CloseDevice</b> (HANDLE KeyHandle, DWORD *pErrorCode) .....	10
	BOOL <b>VCS_GetProtocolStackSettings</b> (HANDLE KeyHandle, DWORD *pBaudrate, DWORD *pTimeout, DWORD *pErrorCode) .....	10
	BOOL <b>VCS_SetProtocolStackSettings</b> (HANDLE KeyHandle, DWORD Baudrate, DWORD Timeout, DWORD *pErrorCode) .....	10
7.4	Help Functions .....	11
	BOOL <b>VCS_GetBaudrateSelection</b> (char* DeviceName, char* ProtocolStackName, char* InterfaceName, char* PortName, BOOL StartOfSelection, DWORD *pBaudrateSel, BOOL *pEndOfSelection, DWORD *pErrorCode) .....	11
	BOOL <b>VCS_GetDeviceName</b> (HANDLE KeyHandle, char *pDeviceName, WORD MaxStrSize, DWORD *pErrorCode) .....	12
	BOOL <b>VCS_GetDeviceNameSelection</b> (BOOL StartOfSelection, char *pDeviceNameSel, WORD MaxStrSize, BOOL *pEndOfSelection, DWORD *pErrorCode) .....	12
	BOOL <b>VCS_GetDriverInfo</b> (char *pLibraryName, WORD MaxStrNameSize, char *pLibraryVersion, WORD MaxStrVersionSize, DWORD *pErrorCode) .....	13
	BOOL <b>VCS_GetInterfaceName</b> (HANDLE KeyHandle, char *pInterfaceName, WORD MaxStrSize, DWORD *pErrorCode) .....	13
	BOOL <b>VCS_GetErrorInfo</b> (DWORD ErrorCodeValue, char* pErrorInfo, WORD MaxStrSize) .....	13
	BOOL <b>VCS_GetInterfaceNameSelection</b> (char* DeviceName, char* ProtocolStackName, BOOL StartOfSelection, char *pInterfaceNameSel, WORD MaxStrSize, BOOL *pEndOfSelection, DWORD *pErrorCode) .....	14
	BOOL <b>VCS_GetKeyHandle</b> (char* DeviceName, char* ProtocolStackName, char* InterfaceName, char* PortName, HANDLE *pKeyHandle, DWORD *pErrorCode) .....	14
	BOOL <b>VCS_GetPortName</b> (HANDLE KeyHandle, char *pPortName, WORD MaxStrSize, DWORD *pErrorCode) .....	15
	BOOL <b>VCS_GetPortNameSelection</b> (char* DeviceName, char* ProtocolStackName, char* InterfaceName, BOOL StartOfSelection, char *pPortSel, WORD MaxStrSize, BOOL *pEndOfSelection, DWORD *pErrorCode) .....	15
	BOOL <b>VCS_GetProtocolStackName</b> (HANDLE KeyHandle, char *pProtocolStackName, WORD MaxStrSize, DWORD *pErrorCode) .....	16
	BOOL <b>VCS_GetProtocolStackNameSelection</b> (char* DeviceName, BOOL StartOfSelection, char *pProtocolStackNameSel, WORD MaxStrSize, BOOL *pEndOfSelection, DWORD *pErrorCode) .....	16
8.1	Configuration .....	17
	BOOL <b>VCS_GetCurrentRegulatorGain</b> (HANDLE KeyHandle, WORD NodeId, WORD *pP, WORD *pI, DWORD *pErrorCode) .....	17
	BOOL <b>VCS_GetEncoderParameter</b> (HANDLE KeyHandle, WORD NodeId, WORD *pCounts, WORD *pPositionSensorType, DWORD *pErrorCode) .....	18
	BOOL <b>VCS_GetMotorParameter</b> (HANDLE KeyHandle, WORD NodeId, WORD *pMotorType, WORD *pContinuousCurrent, WORD *pPeakCurrent, BYTE *pPolePair, WORD *pThermalTimeConstant, DWORD *pErrorCode) .....	18
	BOOL <b>VCS_GetPositionRegulatorGain</b> (HANDLE KeyHandle, WORD NodeId, WORD *pP, WORD *pI, WORD *pD, DWORD *pErrorCode) .....	19
	BOOL <b>VCS_GetVelocityRegulatorGain</b> (HANDLE KeyHandle, WORD NodeId, WORD *pP, WORD *pI, DWORD *pErrorCode) .....	19
	BOOL <b>VCS_SetCurrentRegulatorGain</b> (HANDLE KeyHandle, WORD NodeId, WORD P, WORD I, DWORD *pErrorCode) .....	20
	BOOL <b>VCS_SetEncoderParameter</b> (HANDLE KeyHandle, WORD NodeId, WORD Counts, WORD PositionSensorType, DWORD *pErrorCode) .....	20
	BOOL <b>VCS_SetMotorParameter</b> (HANDLE KeyHandle, WORD NodeId, WORD MotorType, WORD ContinuousCurrent, WORD PeakCurrent, BYTE PolePair, WORD ThermalTimeConstant, DWORD *pErrorCode) .....	21
	BOOL <b>VCS_SetPositionRegulatorGain</b> (HANDLE KeyHandle, WORD NodeId, WORD P, WORD I, WORD D, DWORD *pErrorCode) .....	21
	BOOL <b>VCS_SetVelocityRegulatorGain</b> (HANDLE KeyHandle, WORD NodeId, WORD P, WORD I, DWORD *pErrorCode) .....	22
8.2	Current Mode .....	23
	BOOL <b>VCS_GetCurrentMust</b> (HANDLE KeyHandle, WORD NodeId, short *pCurrentMust, DWORD *pErrorCode) .....	23
	BOOL <b>VCS_SetCurrentMust</b> (HANDLE KeyHandle, WORD NodeId, short CurrentMust, DWORD *pErrorCode) .....	23
8.3	Homing Mode .....	24
	BOOL <b>VCS_FindHome</b> (HANDLE KeyHandle, WORD NodeId, __int8 HomingMethod, DWORD *pErrorCode) .....	24
	BOOL <b>VCS_GetHomingParameter</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pHomingAcceleration, DWORD *pSpeedSwitch, DWORD *pSpeedIndex, long *pHomeOffset, WORD *pCurrentThreshold, long *pHomePosition, DWORD *pErrorCode) .....	25
	BOOL <b>VCS_SetHomingParameter</b> (HANDLE KeyHandle, WORD NodeId, DWORD HomingAcceleration, DWORD SpeedSwitch, DWORD SpeedIndex, long HomeOffset, WORD CurrentThreshold, long HomePosition, DWORD *pErrorCode) .....	26
	BOOL <b>VCS_StopHoming</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode) .....	26
8.4	Inputs Outputs .....	27



maxon motor	
EPOS Positioning Controller	Windows 32-Bit DLL
BOOL <b>VCS_DigitalInputConfiguration</b> (HANDLE KeyHandle, WORD NodeId, WORD DigInputNb, WORD Configuration, BOOL Mask, BOOL Polarity, BOOL ExecutionMask, DWORD *pErrorCode).....	29
BOOL <b>VCS_DigitalOutputConfiguration</b> (HANDLE KeyHandle, WORD NodeId, WORD DigOutputNb, WORD Configuration, BOOL State, BOOL Mask, BOOL Polarity, DWORD *pErrorCode) .....	30
BOOL <b>VCS_GetAllDigitalInputs</b> (HANDLE KeyHandle, WORD NodeId, WORD *pInput, DWORD *pErrorCode) .....	31
BOOL <b>VCS_GetAllDigitalOutputs</b> (HANDLE KeyHandle, WORD NodeId, WORD *pOutputs, DWORD *pErrorCode) .....	31
BOOL <b>VCS_GetAnalogInput</b> (HANDLE KeyHandle, WORD NodeId, WORD Number, WORD *pAnalog, DWORD *pErrorCode).....	32
BOOL <b>VCS_SetAllDigitalOutputs</b> (HANDLE KeyHandle, WORD NodeId, WORD Outputs, DWORD *pErrorCode) .....	32
8.5 Motion Info .....	<b>33</b>
BOOL <b>VCS_GetCurrentIs</b> (HANDLE KeyHandle, WORD NodeId, short *pCurrentIs, DWORD *pErrorCode) .....	33
BOOL <b>VCS_GetMovementState</b> (HANDLE KeyHandle, WORD NodeId, BOOL *pTargetReached, DWORD *pErrorCode) .....	33
BOOL <b>VCS_GetPositionIs</b> (HANDLE KeyHandle, WORD NodeId, long *pPositionIs, DWORD *pErrorCode) .....	34
BOOL <b>VCS_GetVelocityIs</b> (HANDLE KeyHandle, WORD NodeId, long *pVelocityIs, DWORD *pErrorCode) .....	34
8.6 Position Mode .....	<b>35</b>
BOOL <b>VCS_GetPositionMust</b> (HANDLE KeyHandle, WORD NodeId, long *pPositionMust, DWORD *pErrorCode) .....	35
BOOL <b>VCS_SetPositionMust</b> (HANDLE KeyHandle, WORD NodeId, long PositionMust, DWORD *pErrorCode).....	35
8.7 Profile Position Mode .....	<b>36</b>
BOOL <b>VCS_GetPositionProfile</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pProfileVelocity, DWORD *pProfileAcceleration, DWORD *pProfileDeceleration, DWORD *pErrorCode) .....	36
BOOL <b>VCS_GetTargetPosition</b> (HANDLE KeyHandle, WORD NodeId, long *pTargetPosition, DWORD *pErrorCode).....	37
BOOL <b>VCS_HaltPositionMovement</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode).....	37
BOOL <b>VCS_MoveToPosition</b> (HANDLE KeyHandle, WORD NodeId, long TargetPosition, BOOL Absolute, BOOL Immediately, DWORD *pErrorCode) .....	38
BOOL <b>VCS_SetPositionProfile</b> (HANDLE KeyHandle, WORD NodeId, DWORD ProfileVelocity, DWORD ProfileAcceleration, DWORD ProfileDeceleration, DWORD *pErrorCode) .....	38
8.8 Profile Velocity Mode .....	<b>39</b>
BOOL <b>VCS_GetTargetVelocity</b> (HANDLE KeyHandle, WORD NodeId, long *pTargetVelocity, DWORD *pErrorCode) .....	39
BOOL <b>VCS_GetVelocityProfile</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pProfileAcceleration, DWORD *pProfileDeceleration, DWORD *pErrorCode) .....	40
BOOL <b>VCS_HaltVelocityMovement</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode) .....	40
BOOL <b>VCS_MoveWithVelocity</b> (HANDLE KeyHandle, WORD NodeId, long TargetVelocity, DWORD *pErrorCode).....	41
BOOL <b>VCS_SetVelocityProfile</b> (HANDLE KeyHandle, WORD NodeId, DWORD ProfileAcceleration, DWORD ProfileDeceleration, DWORD *pErrorCode) .....	41
8.9 State Machine .....	<b>42</b>
BOOL <b>VCS_ClearFault</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode).....	42
BOOL <b>VCS_GetDisableState</b> (HANDLE KeyHandle, WORD NodeId, BOOL *pIsDisabled, DWORD *pErrorCode) .....	43
BOOL <b>VCS_GetEnableState</b> (HANDLE KeyHandle, WORD NodeId, BOOL *pIsEnabled, DWORD *pErrorCode) .....	43
BOOL <b>VCS_GetFaultState</b> (HANDLE KeyHandle, WORD NodeId, BOOL *pIsInFault, DWORD *pErrorCode).....	44
BOOL <b>VCS_GetOperationMode</b> (HANDLE KeyHandle, WORD NodeId, __int8 *pMode, DWORD *pErrorCode).....	44
BOOL <b>VCS_GetQuickStopState</b> (HANDLE KeyHandle, WORD NodeId, BOOL *pIsQuickStopped, DWORD *pErrorCode).....	45
BOOL <b>VCS_SetDisableState</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode) .....	45
BOOL <b>VCS_SetEnableState</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode) .....	46
BOOL <b>VCS_SetOperationMode</b> (HANDLE KeyHandle, WORD NodeId, __int8 Mode, DWORD *pErrorCode) .....	46
BOOL <b>VCS_SetQuickStopState</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode) .....	47
BOOL <b>VCS_SendNMTService</b> (HANDLE KeyHandle, WORD NodeId, WORD CommandSpecifier, DWORD *pErrorCode).....	47
8.10 Utilities .....	<b>48</b>
BOOL <b>VCS_GetObject</b> (HANDLE KeyHandle, WORD NodeId, WORD ObjectIndex, BYTE ObjectSubIndex, void *pData, DWORD NbOfBytesToRead, DWORD pNbOfBytesRead, DWORD *pErrorCode).....	48
BOOL <b>VCS_GetVersion</b> (HANDLE KeyHandle, WORD NodeId, WORD *pHardwareVersion, WORD *pSoftwareVersion, WORD *pApplicationNumber, WORD *pApplicationVersion, DWORD *pErrorCode) .....	49
BOOL <b>VCS_Restore</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode).....	49
BOOL <b>VCS_SetObject</b> (HANDLE KeyHandle, WORD NodeId, WORD ObjectIndex, BYTE ObjectSubIndex, void Data, DWORD NbOfBytesToWrite, DWORD NbOfBytesWritten, DWORD *pErrorCode).....	50
BOOL <b>VCS_Store</b> (HANDLE KeyHandle, WORD NodeId, DWORD *pErrorCode) .....	50
8.11 Velocity Mode.....	<b>51</b>
BOOL <b>VCS_GetVelocityMust</b> (HANDLE KeyHandle, WORD NodeId, long *pVelocityMust, DWORD *pErrorCode) .....	51
BOOL <b>VCS_SetVelocityMust</b> (HANDLE KeyHandle, WORD NodeId, long VelocityMust, DWORD *pErrorCode) .....	51
8.12 General CAN Commands .....	<b>52</b>
BOOL <b>VCS_SendCANFrame</b> (HANDLE KeyHandle, WORD CobiD, WORD Length, void *pData, DWORD *pErrorCode) .....	52
BOOL <b>VCS_RequestCANFrame</b> (HANDLE KeyHandle, WORD CobiD, WORD Length, void *pData, DWORD *pErrorCode) .....	52
9.1 Initialisation .....	<b>53</b>
HANDLE <b>VCS_OpenDeviceDlg</b> (DWORD *pErrorCode) .....	53

## 12 Version History

Date	DLL Version	Documentation	Description
11.11.2003	1.00	Edition November 2003	<ul style="list-style-type: none"> <li>First library version</li> </ul>
01.12.2003	1.01	Edition December 2003	<ul style="list-style-type: none"> <li>All selection functions have been changed:               <ul style="list-style-type: none"> <li>BOOL <a href="#">VCS_GetBaudrateSelection(..)</a></li> <li>BOOL <a href="#">VCS_GetDeviceName(..)</a></li> <li>BOOL <a href="#">VCS_GetDeviceNameSelection(..)</a></li> <li>BOOL <a href="#">VCS_GetDriverInfo(..)</a></li> <li>BOOL <a href="#">VCS_GetInterfaceName(..)</a></li> <li>BOOL <a href="#">VCS_GetInterfaceNameSelection(..)</a></li> <li>BOOL <a href="#">VCS_GetPortName(..)</a></li> <li>BOOL <a href="#">VCS_GetPortNameSelection(..)</a></li> <li>BOOL <a href="#">VCS_GetProtocolStackModeSelection(..)</a></li> <li>BOOL <a href="#">VCS_GetProtocolStackName(..)</a></li> <li>BOOL <a href="#">VCS_GetProtocolStackNameSelection(..)</a></li> </ul> </li> </ul>
05.01.2004	1.02	Edition January 2004	<ul style="list-style-type: none"> <li>Insert IXXAT details</li> </ul>
06.04.2004	2.0.0.0	Edition April 2004	<ul style="list-style-type: none"> <li>New functions documented:               <ul style="list-style-type: none"> <li>BOOL <a href="#">VCS_CloseAllDevices(..)</a></li> <li>BOOL <a href="#">VCS_DigitalInputConfiguration(..)</a></li> <li>BOOL <a href="#">VCS_DigitalOutputConfiguration(..)</a></li> <li>BOOL <a href="#">VCS_GetAllDigitalInputs(..)</a></li> <li>BOOL <a href="#">VCS_GetAllDigitalOutputs(..)</a></li> <li>BOOL <a href="#">VCS_GetAnalogInput(..)</a></li> <li>BOOL <a href="#">VCS_SetAllDigitalOutputs(..)</a></li> <li>BOOL <a href="#">VCS_SendNMTService(..)</a></li> <li>HANDLE <a href="#">VCS_OpenDeviceDlg(..)</a></li> </ul> </li> <li>All this functions have been changed:               <ul style="list-style-type: none"> <li>BOOL <a href="#">VCS_GetBaudrateSelection(..)</a></li> <li>BOOL <a href="#">VCS_FindHome(..)</a></li> <li>BOOL <a href="#">VCS_GetHomingParameter(..)</a></li> <li>BOOL <a href="#">VCS_SetHomingParameter(..)</a></li> <li>BOOL <a href="#">VCS_MoveToPosition(..)</a></li> <li>BOOL <a href="#">VCS_GetOperationMode(..)</a></li> <li>BOOL <a href="#">VCS_SetOperationMode(..)</a></li> <li>BOOL <a href="#">VCS_GetObject(..)</a></li> <li>BOOL <a href="#">VCS_SetObject(..)</a></li> </ul> </li> <li>All this functions have been deleted:               <ul style="list-style-type: none"> <li>BOOL <a href="#">VCS_GetProtocolStackMode(..)</a></li> <li>BOOL <a href="#">VCS_GetProtocolStackModeSelection(..)</a></li> </ul> </li> </ul>
16.07.2004	2.0.3.0	Edition July 2004	<ul style="list-style-type: none"> <li>Error correction documentation</li> <li>Additional information about error codes</li> </ul>
01.03.2005	3.0.0.0	Edition March 2005	<ul style="list-style-type: none"> <li>Insert Vector details</li> </ul>
01.10.2005	4.0.0.0	Edition October 2005	<ul style="list-style-type: none"> <li>Error correction documentation</li> </ul>
03.02.2006	4.0.0.0	Edition February 2006	<ul style="list-style-type: none"> <li>Additional information about error codes</li> </ul>
12.04.2006	4.1.0.0	Edition April 2006	<ul style="list-style-type: none"> <li>New error codes</li> </ul>
12.04.2006	4.1.1.0	Edition April 2006	<ul style="list-style-type: none"> <li><a href="#">VCS_SendCANFrame</a> bug fixed</li> </ul>
11.10.2006	4.2.0.0	Edition October 2006	<ul style="list-style-type: none"> <li>New function: <a href="#">VCS_GetErrorInfo(..)</a></li> </ul>
16.10.2006	4.2.1.0	Edition October 2006	<ul style="list-style-type: none"> <li><a href="#">VCS_GetDriverInfo</a>, <a href="#">VCS_SetHomingParameter</a> bug fixed</li> </ul>
10.01.2007	4.3.0.0	Edition January 2007	<ul style="list-style-type: none"> <li>Support for National Instruments Interfaces</li> </ul>