

The diagram shows the back panel of the X11DPH-Tq with the following ports labeled:

- 1. D-Sub 15-pin female (VGA)
- 2. D-Sub 9-pin female (COM1)
- 3. D-Sub 15-pin female (USB 0)
- 4. D-Sub 9-pin female (USB 1)
- 5. D-Sub 15-pin female (USB 2)
- 6. D-Sub 9-pin female (IPMI LAN)
- 7. RJ45 (GLAN1)
- 8. RJ45 (GLAN2)
- 9. D-Sub 15-pin female (Unit Identifier Switch)
- 10. D-Sub 9-pin female (Unit Identifier Switch)

Back Panel I/O Ports			
1.	COM1	6.	USB 3 (USB 3.0)
2.	USB 0 (USB 3.0)	7.	GLAN1 (X11DPH-I), 10G_LAN1 (X11DPH-T/X11DPH-Tq)
3.	USB 1 (USB 3.0)	8.	GLAN2 (X11DPH-I), 10G_LAN2 (X11DPH-T/X11DPH-Tq)
4.	IPMI LAN	9.	UIDA
5.	USB 2 (USB 3.0)	10.	Unit Identifier Switch (UID)

**Notes:** 1. Please refer to Chapter 2 of the user's manual for detailed instructions of CPU/Heatsink and memory installation. 2. Please refer to our website at [www.supermicro.com](http://www.supermicro.com) for CPU/Memory support updates. 3. All graphics shown in this quick reference guide are for illustration only. Your components may or may not look the same as the graphics shown in this quick reference guide.

	1	2	
PWR } Power Button	○	○	Ground
Reset } Reset Button	○	○	Ground
3.3V	○	○	Power Fail LED
UID LED	○	○	OH/Fan Fail LED
3.3V Stby	○	○	NIC2 Active LED
3.3V Stby	○	○	NIC1 Active LED
3.3V Stby	○	○	HDD LED
3.3V Stby	○	○	PWR LED
X	○	○	X
NMI	○	○	Ground
	19	20	