

## Dell EqualLogic SNMPv2 Configuration

### Prerequisites

Relies on: **Dell EqualLogic SNMP Agent (EQLGROUP-MIB)**

Port 161 must be open bidirectionally between the ParkView Agent and the monitored array.

To configure SNMP read-only access, click:

Group Configuration > SNMP tab

The Group SNMP window appears.

#### Group SNMP



To allow access from an SNMP management console to the group, you must specify at least one read-only SNMP community name, which acts as a password.

To specify an SNMP community name, in the SNMP Access panel click **Add**. In the Add list item dialog box, specify a unique SNMP read-only community name, up to 64 alphanumeric characters, and click **OK**. You can specify up to five read-only community names for the SNMP agent to use to authenticate SNMP requests.

#### GLOBAL HEADQUARTERS

**office:** 5910 Landerbrook Drive  
Cleveland, Ohio 44124

**call:** 1 877.778.8707

#### EMEA HEADQUARTERS

**office:** 6 Mitre Passage, 7th Floor,  
London, SE10 0ER

**call:** +44 (0) 208.885.9900

#### APAC HEADQUARTERS

**office:** 380 Jalan Besar, #09-09-12  
ARC 380, Singapore, 209000

**call:** +65 69585850

#### LATAM HEADQUARTERS

**office:** Avda. Luis Alberto de Herrera 1248, Flr. 12  
11300, Buceo, Montevideo, Uruguay

\* Screenshots may vary depending on management software version

Because multiple PS Systems can be managed by the same controller, this solution can discover multiple enclosures.

Typical platform: **Dell EqualLogic**

Operating system: **Storage System**

## Monitors

| Object Type                            | Discovered Properties  |
|--|--|
| Enclosure (MS_HW_ENCLOSURE)            | <ul style="list-style-type: none"><li>Additional Information 1</li><li>Model</li><li>Serial Number</li><li>Type</li><li>Vendor</li></ul> |
| Disk Controller (MS_HW_DISKCONTROLLER) | <ul style="list-style-type: none"><li>Firmware Version</li><li>Model</li><li>Serial Number</li></ul>                                     |
| Battery (MS_HW_BATTERY)                | <ul style="list-style-type: none"><li>Type</li></ul>   |
| Fan (MS_HW_FAN)                        | <ul style="list-style-type: none"><li>Alarm Threshold</li><li>Fan Type/Location</li><li>Warning Threshold</li></ul>                      |
| Logical Disk, RAID (MS_HW_LOGICALDISK) | <ul style="list-style-type: none"><li>Logical Disk Type</li><li>Size</li></ul>   |

