



83

PRINCIPLE OF OPERATION AND FAULT FINDING - HOW FUEL GAUGE WORKS

Other sub-section involved :

17

• Engine :

XXX

• Gearbox :

XXX

Basic manual :

M.R. 305

This Technical Note covers the operation and fault finding for the fuel gauge system on TWINGO vehicles.

"The repair methods given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The methods may be modified as a result of changes by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed".


All copyrights reserved by the Renault S.A.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of the Renault S.A.




PETROL GAUGE  
MANAGEMENT

Normal operation



The microprocessor only extinguishes one segment if the gauge indicates approx. **3.5 litres** less after driving a minimum of 12 miles (20 km) and a maximum of 45 miles (70 km).




Once a segment has extinguished, it will not illuminate again until the tank is filled up, **with the ignition switched off**.


**Special points:** How the last segment is extinguished before switching to reserve

The microprocessor no longer notes the gauge information: it calculates approximate average consumption on the basis of **speed information only**. The last segment will extinguish when it has calculated that the petrol used is **3.5 litres**.

In summary:





Special point about tank :




The tank shape incorporates a separate section with capacity for **11 litres** which the gauge does not register directly.

OPERATION (continued)

Special note on the position of the segments if the tank is partly filled.





Approx. 4 segments illuminated



Approx. 4 segments also illuminated.

OPERATION (continued)



Approx. 6 segments illuminated.

In conclusion, the petrol contained in **part B** of the tank is not registered below **26 litres**.


BACK-UP MANAGEMENT

Speed information fault

If the speed information is zero for more than **10 minutes**, the instrument panel will reduce the gauge reading on the basis of information from the sender unit only (one segment extinguished approx. every 3.5 l).

If no speed information is available, there is also no distance information. (The min. and max. thresholds of 12 miles/45 miles (**20 km/70 km**) have disappeared.)

**ATTENTION :** As soon as the second segment is extinguished, the fuel reserve will illuminate directly for safety reasons.



**Summary:**

- No linear gauge from 12 to 45 miles (20 to 70 km) per graduated segment.
- In all cases, the minimum warning light illuminates without the risk of a breakdown.
- When filling up, it is essential to switch off the ignition.

### DIAGNOSIS - INTRODUCTION

**Information is required from the customer in order to deal with certain customer complaints. Obtain all necessary information before the customer leaves the workshop.**

### PRECAUTION

It is essential to use bornier **Elé. 1302** to perform any checks carried out on the 15-track instrument panel connector.

The following points can be checked using bornier **Elé. 1302**:

- Continuities.  
To do this, just connect the bornier to the 15-track instrument panel connector on the wiring harness side of the connector.
- Resistances and voltages.  
To do this, connect the bornier in series to the 15-track instrument panel connector.

If bornier **Elé. 1302** is not used for these checks, the connector could be damaged irreparably.


FAULT FINDING - CUSTOMER COMPLAINTS

NOTES	Do not refer to these customer complaints until a full check has been carried out using the XR25.
-------	---

THE FUEL GAUGE INDICATOR DOES NOT INDICATE FULL	CHART 1
A SEGMENT EXTINGUISHES AFTER DRIVING DIFFERENT MILEAGES (for example, one segment extinguishes after travelling 10 kilometres and another after travelling 30 kilometres)	CHART 2
THE FUEL GAUGE REMAINS BLOCKED AT ONE READING	CHART 3
ONE OR SEVERAL SEGMENTS ILLUMINATE AGAIN AFTER SWITCHING THE IGNITION ON AND OFF	CHART 4
THE LAST TWO SEGMENTS ON THE FUEL GAUGE EXTINGUISH AT THE SAME TIME AND THE "LOW FUEL" WARNING LIGHT ILLUMINATES	CHART 5
THE WARNING LIGHT ILLUMINATES TOO EARLY	CHART 6
THE WARNING LIGHT ILLUMINATES WHEN THE FUEL TANK HAS BEEN FILLED UP	CHART 7
THE WARNING LIGHT FLASHES	CHART 8
DIFFICULT TO FILL UP WITH FUEL USING A FILLER NOZZLE AT THE PETROL PUMP	CHART 9

FAULT FINDING CHARTS

CHART 1	THE FUEL GAUGE DOES NOT INDICATE FULL
NOTES	<b>Important :</b> Check the operation of the fuel gauge system before starting fault finding (see M.R. 305 section 83). <b>Note:</b> It is assumed that the tank is full after the petrol pump nozzle is activated three times at 5 seconds intervals.




AFTER REPAIR	Check that the fuel gauge indicates full (ten segments illuminated).
--------------	--



FAULT FINDING CHARTS

CHART 1  
continued




**AFTER  
REPAIR**

Check that the fuel gauge shows full (illumination of 10 segments).

FAULT FINDING CHARTS

CHART 2	<b>A SEGMENT EXTINGUISHES AFTER DRIVING DIFFERENT MILEAGES</b> (for example, one segment extinguishes after travelling 10 kilometres and another after travelling 30 kilometres)
---------	---


NOTES	<b>Important :</b> Check the operation of the fuel gauge system before starting the fault finding procedure (see M.R. 305 section 83). <b>Comment:</b> This problem can occur when the ignition is switched on and the vehicle has been stationary for a continuous period of 10 minutes (speed display stays at 0 km/h).
-------	--



AFTER REPAIR	Check that the vehicle speed display is operating correctly. Check that the fuel gauge display is operating correctly.
--------------	---

FAULT FINDING CHARTS

CHART 2  
continued



Connect bornier **Elé. 1302** in series on the 15-track instrument panel connector. Connect the XR 25. Use the frequency generator function key **G**, terminal **G** output. Connect the frequency generator wire to track 7 of bornier **Elé. 1302**.  
With the ignition on, enter the following codes on the XR 25 :

- **G** **1** , display should show ~ 36 km/h
- **G** **3** , display should show ~ 112 km/h
- **G** **5** , display should show ~ 190 km/h

Are these the speeds displayed?

no → Change the instrument panel.

yes  
↓

Check the wiring for continuity and to ensure that there are no short circuits between the vehicle speed sensor connector, tracks :

- A1 and +after ignition,
- B1 and track 7 of the 15-track instrument panel connector,
- C1 and vehicle earth.

Is the wiring in good condition ?

no → Repair the faulty wiring.


yes  
↓

Change the vehicle speed sensor.

<b>AFTER REPAIR</b>	Check that the vehicle speed display is operating correctly. Check that the fuel gauge display is operating correctly.
---------------------	---

FAULT FINDING CHARTS

CHART 3	THE FUEL GAUGE REMAINS BLOCKED AT ONE READING
NOTES	<b>Important :</b> Check the operation of the fuel gauge system before starting the fault finding procedure (see M.R. 305 section 83).



AFTER REPAIR	Check that the vehicle speed display is operating correctly. Check that the fuel gauge display is operating correctly.
--------------	---

FAULT FINDING CHARTS

CHART 3  
continued

A

Connect bornier **Elé. 1302** in series on the 15-track instrument panel connector. Connect the XR 25. Use the frequency generator function key **G**, output terminal **G**. Connect the frequency generator wire to track 7 of bornier **Elé. 1302**.

With the ignition on, enter the following codes on the XR 25 :

- **G** **1** , display should show ~ 36 km/h
- **G** **3** , display should show ~ 112 km/h
- **G** **5** , display should show ~ 190 km/h

Are these the speeds displayed ?

no

Change the instrument panel.

yes

Check the wiring for continuity and to ensure that there are no short circuits between the vehicle speed sensor connector, tracks :

- A1 and +after ignition,
- B1 and track 7 of the 15-track instrument panel connector,
- C1 and vehicle earth.

Is the wiring harness in good condition?

no

Repair the faulty wiring.


yes

Change the speed sensor.

**AFTER  
REPAIR**

Check that the vehicle speed display is operating correctly.  
Check that the fuel gauge display is operating correctly.

FAULT FINDING CHARTS



FAULT FINDING CHARTS

CHART 4  
continued

A

Check the condition of the vehicle speed  
sensor feed fuse.

Is the fuse in good condition?

no

Change the fuse.

yes

Connect bornier **Elé. 1302** in series to the 15-  
track instrument panel connector. Connect  
the XR 25. Use the frequency generator  
function key **G**, output terminal **G**.  
Connect the frequency generator wire to  
track 7 of bornier **Elé. 1302**.  
With the ignition on, enter the following  
codes on the XR 25 :

no

Change the instrument panel.

- **G** **1** , display should show ~ 36 km/h
- **G** **3** , display should show ~ 112 km/h
- **G** **5** , display should show ~ 190 km/h

Are these the speeds displayed ?

yes

Check wiring for continuity and to ensure that  
there are no short circuits in the electric wiring  
between speed sensor connector, tracks:

- A1 and +after ignition,
- B1 and track 7 of the 15-track instrument  
panel connector,
- C1 and the vehicle earth.

Is the electric wiring in good condition?

no

Repair the faulty electrical wiring.

yes


Change the speed sensor.

**AFTER  
REPAIR**

Check that the vehicle speed display is operating correctly.  
Check that the fuel gauge display is operating correctly.

FAULT FINDING CHARTS

CHART 5	THE LAST TWO SEGMENTS ON THE FUEL GAUGE EXTINGUISH AT THE SAME TIME AND THE "LOW FUEL" WARNING LIGHT ILLUMINATES
NOTES	<b>Important :</b> Check the operation of the fuel gauge system before starting the fault finding procedure (see M.R. 305 section 83). <b>Remark:</b> This phenomenon may occur when the ignition is switched on and the vehicle is stationary for 10 consecutive minutes (speed display fixed at 0 km/h).




AFTER REPAIR	Check that the fuel gauge display is operating correctly.
--------------	---



FAULT FINDING CHARTS

CHART 5  
continued


A



<b>AFTER REPAIR</b>	Check that the vehicle speed display is operating correctly. Check that the fuel gauge display is operating correctly.
---------------------	---

FAULT FINDING CHARTS


CHART 6	THE WARNING LIGHT ILLUMINATES TOO EARLY
NOTES	<b>Important :</b> Check the operation of the fuel gauge system before starting the fault finding procedure (see M.R. 305 section 83).



AFTER REPAIR	Check that the fuel gauge display is operating correctly.
--------------	---

FAULT FINDING CHARTS

CHART 6  
continued 1




**AFTER  
REPAIR**

Check that the fuel gauge display is operating correctly.

FAULT FINDING CHARTS

CHART 6  
continued 2



Connect bornier **Elé. 1302** in series on the 15-track instrument panel connector. Connect the XR 25. Use the frequency generator function key **G**, output terminal **G**. Connect the frequency generator wire to track 7 of bornier **Elé. 1302**.

With the ignition on, enter the following codes on the XR 25 :

- **G** **1** , display should show ~ 36 km/h
- **G** **3** , display should show ~ 112 km/h
- **G** **5** , display should show ~ 190 km/h

Are these the speeds displayed?

no

Change the instrument panel.

yes

Check the wiring for continuity and to ensure that there are no short circuits between the vehicle speed sensor connector, tracks :

- A1 and +after ignition,
- B1 and track 7 of the 15-track instrument panel connector,
- C1 and vehicle earth.

Is the wiring harness in good condition?

no

Repair the faulty electric wiring.

yes


Change the speed sensor.

**AFTER  
REPAIR**

Check that the vehicle speed display is operating correctly.  
Check that the fuel gauge display is operating correctly.

FAULT FINDING CHARTS


CHART 7	THE WARNING LIGHT ILLUMINATES WHEN THE FUEL TANK HAS BEEN FILLED UP
NOTES	<b>Important :</b> Check the operation of the fuel gauge system before starting the fault finding procedure (see M.R. 305 section 83).



AFTER REPAIR	Check that the fuel gauge shows the correct display when the tank is full (10 segments illuminated).
--------------	--

FAULT FINDING CHARTS


CHART 8	THE WARNING LIGHT FLASHES
NOTES	<b>Important:</b> Check the operation of the fuel gauge system before starting the fault finding procedure (see M.R. 305 section 83). Check that the 6-track connector for the fuel gauge is properly connected.



AFTER REPAIR	Check that the fuel gauge display is operating correctly.
--------------	---

FAULT FINDING CHARTS

CHART 8  
continued



**AFTER  
REPAIR**

Check that the fuel gauge display is operating correctly.

FAULT FINDING CHARTS

