

List of connections

CONNECTION CODES	CONNECTION TITLE
100A	MINIMUM WINDSCREEN WASHER INDICATOR LIGHT - CONTROL
101A	LEVEL CORRECTOR FAULT WARNING LIGHT - CONTROL
101B	LEFT-HAND FRONT LEVEL CORRECTOR SOLENOID VALVE CONTROL
101C	LEFT-HAND REAR LEVEL CORRECTOR SOLENOID VALVE CONTROL
101D	RIGHT-HAND FRONT LEVEL CORRECTOR SOLENOID VALVE CONTROL
101E	RIGHT-HAND REAR LEVEL CORRECTOR SOLENOID VALVE CONTROL
101F	LEVEL CORRECTOR SAFETY COMMON SUPPLY
101G	LEVEL CORRECTOR COMPRESSOR RELAY +
101H	LEVEL CORRECTOR BUTTON INPUT
101J	LOAD PRESSURE SENSOR + SIGNAL
101K	LEVEL CORRECTOR NORMAL HEIGHT WARNING LIGHT CONTROL
101L	LEVEL CORRECTOR COMMON HEIGHT SENSOR
101M	LEVEL CORRECTOR SERVICE FAULT > STOP INDICATOR LIGHT
101N	BETWEEN LEFT-HAND REAR LEVEL CORRECTOR HEIGHT
101Q	BETWEEN RIGHT-HAND REAR LEVEL CORRECTOR HEIGHT
101R	SOLENOID > LEVEL CORRECTOR OUTPUT SIGNAL - CONTROL
101S	LEVEL CORRECTOR COMPRESSOR UNIT FUSE CONTROL + SIGNAL
101T	LEVEL CORRECTOR THERMAL CIRCUIT BREAKER
101U	LEVEL CORRECTOR POWER RELAY - CONTROL
101V	LEVEL CORRECTOR SAFETY RELAY CONTROL
101W	ELECTRONIC COMPUTER SENSOR > ALARM MANAGEMENT CONTROL
101X	BLEED SOLENOID VALVE > ALARM MANAGEMENT - CONTROL
101Y	BETWEEN VEHICLE LOAD
101Z	BETWEEN FRONT LEVEL CORRECTOR HEIGHT
102A	FUEL CAP PRESENCE DETECTION + SIGNAL
103A	HEADLIGHT POSITION CONTROL
103B	ACTUATOR +
103C	RIGHT-HAND REAR POTENTIOMETER SENSOR +
103D	BETWEEN RIGHT-HAND REAR POTENTIOMETER SENSOR
103E	RIGHT-HAND REAR POTENTIOMETER SENSOR +
103F	RIGHT-HAND FRONT POTENTIOMETER SENSOR +
103G	BETWEEN RIGHT-HAND FRONT POTENTIOMETER SENSOR
103H	RIGHT-HAND FRONT POTENTIOMETER SENSOR -
103J	ACTUATOR CONTROL
103K	HEATED REAR SCREEN FAULT WARNING LIGHT
103L	FRONT HEIGHT SENSOR SHUNT
103M	REAR HEIGHT SENSOR SHUNT
104A	ELECTRIC COOLANT PUMP > COMPUTER - CONTROL
104B	ELECTRIC COOLANT PUMP + CONTROL
104C	ANTI-PERCOLATION TIMER - CONTROL
104D	COOLANT PUMP > RELAY + CONTROL
104E	INJECTION RELAY COOLANT PUMP TIMER FUSE + CONTROL
104F	FAN UNIT TEMPERATURE SWITCH THRESHOLD > DIODE CONTROL 1
104G	FAN UNIT HIGH SPEED RELAY TEMPERATURE SWITCH THRESHOLD CONTROL 2
104H	FAN UNIT HIGH SPEED RELAY > LOW SPEED RELAY + CONTROL
104J	INJECTION PROTECTION RELAY ANTI-PERCOLATION RELAY + CONTROL
104K	AFTER IGNITION TIMED RELAY + CONTROL
104L	INJECTION COMPUTER ANTI-PERCOLATION RELAY - CONTROL
104M	AIR CONDITIONING FAN UNIT LOW SPEED RELAY COOLANT PUMP + CONTROL
104N	ANTI-PERCOLATION RELAY FAN UNIT LOW SPEED RELAY + CONTROL
104P	COOLANT PUMP FUSE COOLANT PUMP TIMER + CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
104S	ANTI-PERCOLATION TIMED TEMPERATURE SWITCH + CONTROL
104T	ANTIPERCOLATION TIMED FAN UNIT LOW SPEED RELAY + CONTROL
104U	INJECTION RELAY ANTI-PERCOLATION TEMPERATURE SWITCH + CONTROL
104V	ANTI-PERCOLATION TEMPERATURE SWITCH COOLANT TIMER - CONTROL
104W	ANTI-PERCOLATION RELAY LOW SPEED FAN UNIT RESISTANCE + CONTROL
104X	HIGH SPEED FAN UNIT > HIGH SPEED UNIT RELAY - CONTROL
104Y	HIGH SPEED FAN UNIT > HIGH SPEED UNIT RELAY + CONTROL
104Z	LOW SPEED FAN UNIT RELAY > HIGH SPEED RELAY + CONTROL
107A	CAR PHONE SPEAKER + SIGNAL
107B	CAR PHONE SPEAKER - SIGNAL
107C	VOICE SYNTHESIS CUT-OUT CAR PHONE SIGNAL
107D	RADIO CUT-OUT CAR PHONE SIGNAL
107G	HANDS FREE TELEPHONE MICROPHONE +
107H	HANDS FREE TELEPHONE MICROPHONE -
107J	TELEPHONE MICROPHONE SHIELDING
109A	VARIABLE POWER ASSISTED STEERING MOTOR PHASE A CONTROL
109B	VARIABLE POWER ASSISTED STEERING MOTOR PHASE B CONTROL
109C	VARIABLE POWER ASSISTED STEERING MOTOR COMMON PHASE
109D	VARIABLE POWER ASSISTED STEERING MOTOR PHASE C CONTROL
109E	VARIABLE POWER ASSISTED STEERING MOTOR PHASE D CONTROL
109F	STEERING WHEEL ANGLE SENSOR +
109G	VARIABLE POWER ASSISTED STEERING FAULT WARNING LIGHT CONTROL
109H	ELECTRIC POWER ASSISTED STEERING FAULT WARNING LIGHT CONTROL
109I	STEERING WHEEL ANGLE SENSOR -
109J	ELECTRIC POWER ASSISTED STEERING CONTROL FAULT FINDING SIGNAL
109K	ELECTRIC POWER ASSISTED STEERING TORQUE SENSOR SUPPLY 1
109L	ELECTRIC POWER ASSISTED STEERING TORQUE SENSOR SUPPLY 2
109M	ELECTRIC POWER ASSISTED STEERING TORQUE SENSOR SIGNAL 1
109N	ELECTRIC POWER ASSISTED STEERING TORQUE SENSOR SIGNAL 2
109P	ELECTRIC POWER ASSISTED STEERING TORQUE SENSOR EARTH 1
109Q	ELECTRIC POWER ASSISTED STEERING TORQUE SENSOR EARTH 2
109R	ELECTRIC POWER ASSISTED STEERING MOTOR + CONTROL
109S	ELECTRIC POWER ASSISTED STEERING MOTOR - CONTROL
109T	ELECTRIC POWER ASSISTED STEERING MOTOR SLEEVE A
109U	ELECTRIC POWER ASSISTED STEERING MOTOR SLEEVE B
109V	VARIABLE POWER ASSISTED STEERING SOLENOID VALVE + CONTROL
109W	VARIABLE POWER ASSISTED STEERING SOLENOID VALVE - CONTROL
109X	STEERING WHEEL ANGLE SENSOR SIGNAL 2
109Y	STEERING WHEEL TORQUE SENSOR SHIELDING
109Z	STEERING WHEEL ANGLE SENSOR SIGNAL 1
10A	DIPPED LIGHTS + CONTROL
10B	REDUCED DIPPED LIGHTS + CONTROL
10C	DIPPED LIGHTS > MAIN BEAM LIGHTS SIGNAL
10D	DIP REDUCTION UNIT > DIP REDUCTION RESISTANCE + CONTROL
10E	DIPPED LIGHTS FUSE + CONTROL
10F	DIPPED LIGHTS RELAY > SIDE LIGHTS - CONTROL
10G	DIPPED LIGHTS INDICATOR LIGHT + CONTROL
10H	SEVERE COLD PROTECTED + SIDE LIGHT FEED
10P1	LEFT HAND DIPPED LIGHTS PROTECTED FUSE + CONTROL
10P2	RIGHT HAND DIPPED LIGHTS PROTECTED FUSE + CONTROL
113A	ENRICHER SOLENOID VALVE > TEMPERATURE SWITCH - CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
115A	OIL TEMPERATURE SENSOR - OIL - SIGNAL
116A	EXTERIOR TEMPERATURE SENSOR SIGNAL
116B	EXTERIOR TEMPERATURE SENSOR 0V SIGNAL
116C	LIGHTING RHEOSTAT RELAY LIGHTING + CONTROL
117A	ANTI-PERCOLATION FAN UNIT > ANTI-PERCOLATION RELAY + CONTROL
117B	ANTI-PERCOLATION FAN UNIT > ANTI-PERCOLATION TEMPERATURE SWITCH - CONTROL
117C	ANTI-PERCOLATION RELAY > ANTI-RETURN DIODE - CONTROL
117D	ANTI-RETURN DIODE > INJECTION COMPUTER CONTROL
119A	TIMED FUEL PUMP MINIMUM FUEL - CONTROL
119B	PUMP TIMER ADDITIONAL FUEL PUMP + CONTROL
11A	MAIN BEAM HEADLIGHTS + CONTROL
11B	MAIN BEAM HEADLIGHTS > RELAY + CONTROL
11C	MAIN BEAM HEADLIGHTS FUSE + CONTROL
11D	+ SEVERE COLD PROTECTED MAIN BEAM HEADLIGHT
11P1	LEFT HAND MAIN BEAM HEADLIGHTS PROTECTED FUSE + CONTROL
11P2	RIGHT-HAND MAIN BEAM HEADLIGHTS PROTECTED FUSE + CONTROL
120H	HEATED WINDSCREEN RELAY - CONTROL
120J	LEFT HAND HEATED WINDSCREEN > RELAY + CONTROL
120K	HEATED WINDSCREEN RELAY > AIR CONDITIONING INSTRUMENT PANEL - CONTROL
120M	RIGHT HAND HEATED WINDSCREEN > RELAY + CONTROL
120N	POWER ASSISTED STEERING PRESSURE SWITCH HEATED WINDSCREEN OPERATION SIGNAL
122A	DEPOLLUTION SOLENOID VALVE CONTROL
122B	DIESEL PUMP GAS RECIRCULATION EGR SOLENOID VALVE + CONTROL
122C	SOLENOID VALVE > GAS RECIRCULATION TEMPERATURE SWITCH - CONTROL
122D	ALTIMETRIC CORRECTION RELAY + CONTROL
122E	DIESEL PUMP > ALTIMETRIC RELAY + CONTROL
122F	DIESEL PUMP RELAY > AIR SOLENOID VALVE - CONTROL
122G	RIGHT-HAND REVERSING SIGNAL
122H	ALTIMETRIC CORRECTOR SIGNAL
122J	AIR PUMP + > SOLENOID VALVE
122K	AIR PUMP SOLENOID VALVE > COMPUTER CONTROL
122L	COMPUTER > ANTI-RETURN DIODE CATHODE
122M	COMPUTER > ANTI-RETURN DIODE CATHODE
122N	GAS RECIRCULATION EGR SOLENOID VALVE TIMER +
122P	GAS RECIRCULATION EGR SOLENOID VALVE COMPUTER TIMER - CONTROL
122Q	GAS RECIRCULATION EGR SOLENOID VALVE ENGINE TEMPERATURE SWITCH - CONTROL
122R	EGR TEMPERATURE SWITCH TIMER RELAY
122S	GAS RECIRCULATION TIMER > CLUTCH SWITCH EARTH
122T	ACCELERATED IDLE SPEED IDLE SOLENOID VALVE>PRE P CENTRAL COMPUTER UNIT TIMER -
122Z	EGR PRE POST TIMER COMPUTER EGR SOLENOID VALVE + CONTROL
123A	HEATED SCREEN START UP CONTROL UNIT CONTROL
123B	LEFT-HAND HEATED SCREEN TIMER - CONTROL
123C	RIGHT -HAND HEATED SCREEN TIMER - CONTROL
123D	RIGHT-HAND HEATED SCREEN START UP > RELAY + CONTROL
123E	HEATED WINDSCREEN TIMER CONTROL
123F	AFTER IGNITION + FEED > HEATED WINDSCREEN SWITCH
123G	LEFT-HAND HEATED SCREEN START UP > RELAY + CONTROL
123H	HEATED WINDSCREEN RELAY + POWER
123J	LEFT HAND HEATED WINDSCREEN > RELAY + CONTROL
123K	HEATED WINDSCREEN RELAY > AIR CONDITIONING INSTRUMENT PANEL - CONTROL
123M	RIGHT HAND HEATED WINDSCREEN > RELAY + CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
123N	COMPUTER > HEATED SCREEN START UP SIGNAL
123Y	POWER ASSISTED STEERING PRESSURE SWITCH HEATED WINDSCREEN OPERATION SIGNAL
123Z	HEATED WINDSCREEN RELAY - CONTROL
124A	CATALYTIC CONVERTER TEMPERATURE SENSOR +
124B	CATALYTIC CONVERTER TEMPERATURE SENSOR -
124C	CATALYTIC CONVERTER FAULT WARNING LIGHT - CONTROL
124D	CATALYTIC CONVERTER TEMPERATURE SENSOR SHIELDING
124E	CATALYTIC CONVERTER TEMPERATURE SENSOR SIGNAL
125D	BUZZER + > DRIVING SCHOOL ALARM INDICATOR LIGHT
125F	BUZZER > INDICATOR LIGHT > SWITCH EARTH
127A	LCD PANEL SELECTION - CONTROL
128A	BUS CA1 SATELLITE GUIDANCE - > CARMINAT DISPLAY
128B	CARMINAT DISPLAY TRANSMISSION SIGNAL
128C	CARMINAT DISPLAY RECEPTION SIGNAL
129A	AIRBAG FAULT WARNING LIGHT - CONTROL
129B	PASSENGER'S PRETENSIONER + SIGNAL
129C	PASSENGER'S PRETENSIONER - SIGNAL
129D	DRIVER'S PRETENSIONER + SIGNAL
129E	DRIVER'S PRETENSIONER - SIGNAL
129F	DRIVER'S AIR BAG + SIGNAL
129G	DRIVER'S AIR BAG - SIGNAL
129H	PASSENGER AIRBAG 1 + SIGNAL
129K	PASSENGER AIRBAG 1 - SIGNAL
129L	PASSENGER AIRBAG 2 + SIGNAL
129M	PASSENGER AIRBAG 2 - SIGNAL
129N	PASSENGER'S SIDE SENSOR -
129P	PASSENGER'S SIDE SENSOR + SIGNAL
129Q	DRIVER'S SIDE SENSOR -
129R	LEFT-HAND PASSENGER AIRBAG SUPPLY + SIGNAL
129S	LEFT-HAND PASSENGER AIRBAG SUPPLY - SIGNAL
129T	RIGHT-HAND PASSENGER AIRBAG SUPPLY + SIGNAL
129U	RIGHT-HAND PASSENGER AIRBAG SUPPLY - SIGNAL
129V	PASSENGER AIRBAG + SIGNAL
129W	PASSENGER AIRBAG - SIGNAL
129X	PASSENGER'S PRETENSIONER + SIGNAL
129Y	PASSENGER'S PRETENSIONER - SIGNAL
129Z	DRIVER'S SIDE SENSOR + SIGNAL
130A	RADIO INTERFERENCE CONDENSER + > IGNITION POWER MODULE
133A	MINIMUM SPEED RECORDER SIGNAL
133B	INSTRUMENT PANEL > CENTRAL COMPUTER UNIT CANH SIGNAL
133C	INSTRUMENT PANEL > CENTRAL COMPUTER UNIT CANL SIGNAL
133D	FUEL LEVEL > CENTRAL COMPUTER UNIT SIGNAL
133E	HEATER FUNCTION WARNING LIGHT > COMPUTER UNIT SIGNAL
133G	INSTRUMENT PANEL + > COMPUTER UNIT
133H	INSTRUMENT PANEL > VOICE SYNTHESIS CANH SIGNAL
133K	INSTRUMENT PANEL > VOICE SYNTHESIS CANL SIGNAL
133L	INSTRUMENT PANEL ALARM / PASSENGER COMPARTMENT CENTRAL UNIT CONTROL
135A	DOOR INDICATOR LIGHT - SIGNAL
135B	- CODE INDICATOR LIGHT > MONO SWITCH
135C	CODE FUSE > RELAY + SUPPLY
137A	RIGHT-HAND BONNET + SWITCH

List of connections

CONNECTION CODES	CONNECTION TITLE
137B	RIGHT-HAND BONNET SWITCH -
137C	DEPOLLUTION FAULT INDICATOR LIGHT CONTROL
137D	DATA + SIGNAL
137E	DATA - SIGNAL
139A	DIESEL FUEL FILTER HEATER + CONTROL
139B	DIESEL FUEL FILTER HEATER RELAY + CONTROL
139C	INTERCONNECTION UNIT > DIESEL HEATER CONTROL - SIGNAL
13A	INTERIOR LIGHTING > BODY PANEL - CONTROL
13AB	FRONT LIGHT SUPPLY > INFRARED TRANSMITTER
13AC	LIGHTING TIMER UNIT + CONTROL
13AD	COURTESY LIGHT TIMER + CONTROL
13AE	INTERIOR LIGHTS > TIMER RELAY BODY PANEL - CONTROL
13AG	LUGGAGE COMPARTMENT LIGHTING TIMER + CONTROL
13AH	REAR GROUND LIGHTING TIMER + CONTROL
13AK	BOOT LATCH MODULE SIGNAL 1
13AL	COURTESY LIGHT RHEOSTAT CONTROL
13AM	RIGHT-HAND COURTESY MIRROR LIGHT CONTROL
13AN	LEFT-HAND COURTESY MIRROR LIGHT CONTROL
13AP	LIGHTING/ TIMER / DIODE CONTROL
13B	INTERIOR LIGHTING > DRIVER'S BODY PANEL - CONTROL
13C	COURTESY LIGHTS - CONTROL >
13D	COURTESY LIGHTS > COURTESY LIGHTS SWITCH - CONTROL
13E	COURTESY LIGHT > TIMER SWITCH - CONTROL
13F	COURTESY LIGHTS > FRONT PASSENGER BODY PANEL - CONTROL
13G	COURTESY LIGHT > LEFT-HAND REAR BODY PANEL - CONTROL
13H	COURTESY LIGHT > RIGHT-HAND REAR BODY PANEL - CONTROL
13K	COURTESY LIGHT > LEFT-HAND REAR RIGHT-HAND REAR BODY PANEL - CONTROL
13L	FRONT ROOF LIGHT > TIMER RELAY - CONTROL
13M	REAR COURTESY LIGHTS > TIMER RELAYED BODY PANEL - CONTROL
13N	INTERIOR LIGHTING > REAR BODY PANEL - CONTROL
13P	SIDE DOOR LIGHTS + > REAR DOOR > LED
13R	INTERIOR LIGHTING - > DIODE
13S	FRONT DOOR SWITCH -
13XA	DECODER COMPUTER INFRARED TRANSMITTER RELAY - CONTROL
13XB	PASSENGER COMPARTMENT LIGHTING - > INFRARED TRANSMITTER RELAY
13XC	LIGHTING - > TAILGATE DOOR SWITCH
13XD	LIGHTING - > WINDOW DOOR SWITCH
13XE	INTERIOR LIGHTING - > WINDOW UNIT
13XF	COURTESY LIGHTS LINE 1 - > DECODER COMPUTER
13XG	LIGHTING - > TAILGATE RIGHT-HAND DOOR SWITCH
13XH	TAILGATE WINDOW DOOR SWITCH -
13XJ	DOOR SWITCH -
13XK	LUGGAGE COMPARTMENT LIGHTING - CONTROL > CEILING COURTESY LIGHT SWITCH
13XL	PASSENGER COMPARTMENT LIGHTING - > RIGHT-HAND FRONT BODY PANEL SWITCH
13XM	PASSENGER COMPARTMENT LIGHTING - > LEFT-HAND FRONT BODY PANEL SWITCH
13XP	TAILGATE DOOR SWITCH - SIGNAL >
13XS	OPENING REAR WINDOW PANEL SWITCH -
13XT	OPENING REAR WINDOW PANEL SWITCH - SIGNAL
141A	- CONTROL RELAY AFTER IGNITION > MULTI-TIMER UNIT
141B	INFORMATION DISPLAY CONTROL SIGNAL LINE 1 UNDER STEERING WHEEL
141C	INFORMATION DISPLAY CONTROL SIGNAL LINE 2 UNDER STEERING WHEEL

List of connections

CONNECTION CODES	CONNECTION TITLE
141D	INFORMATION DISPLAY CONTROL SIGNAL LINE 3 UNDER STEERING WHEEL
141G	INFORMATION DISPLAY CONTROL SIGNAL LINE 4 UNDER STEERING WHEEL
141H	INFORMATION DISPLAY CONTROL SIGNAL LINE 5 UNDER STEERING WHEEL
141K	INFORMATION DISPLAY CONTROL SIGNAL COLUMN 1 UNDER STEERING WHEEL
141L	INFORMATION DISPLAY CONTROL SIGNAL COLUMN 2 UNDER STEERING WHEEL
141M	INFORMATION DISPLAY CONTROL SIGNAL COLUMN 3 UNDER STEERING WHEEL
141N	INFORMATION DISPLAY CONTROL SIGNAL COLUMN 4 UNDER STEERING WHEEL
141P	INFORMATION DISPLAY CONTROL SIGNAL COLUMN 5 UNDER STEERING WHEEL
142A	ELECTRIC HOOD OPENING > HOOD SWITCH - CONTROL
142B	HOOD TOP DEAD CENTRE SENSOR > HOOD - SIGNAL
142C	HOOD COVER 1 LOCK SWITCH > HOOD - SIGNAL
142D	HOOD COVER 2 LOCK SWITCH > HOOD - SIGNAL
142E	HOOD COVER CYLINDER OPENING > HOOD - SIGNAL
142F	MASTER CYLINDER OPENING - SIGNAL
142G	CENTRAL DOOR LOCKING OPENING HOOD COVER LOCK > C + CONTROL
142H	CENTRAL DOOR LOCKING CLOSURE HOOD COVER LOCK > C + CONTROL
142J	MASTER CYLINDER CLOSING - SIGNAL
142K	MODULE DOOR CENTRAL LOCKING OPENING > LUGGAGE COMPARTMENT + CONTROL
142L	MODULE DOOR CENTRAL LOCKING CLOSING > LUGGAGE COMPARTMENT + CONTROL
142M	ELECTRIC HOOD CLOSURE - CONTROL
142N	5TH HOOP CYLINDER CLOSURE - SIGNAL
142Q	5TH HOOP CYLINDER OPENING - SIGNAL
142R	HOOD COVER 3 LOCK SWITCH > HOOD - SIGNAL
142S	BONNET CENTRAL UNIT FAULT FINDING SIGNAL
142T	HOOD WARNING BUZZER +
145A	INTERLOCK CONTROL
145B	CARD PRESENCE + SIGNAL
145C	CARD READER DATA TRANSFER
145D	PASSENGER COMPARTMENT COMPUTER DATA TRANSFER
145E	HANDS FREE ACCESS AERIAL 1 SIGNAL
145F	VEHICLE WITHOUT KEY REAR RADIO FREQUENCY AERIAL 1 EARTH
145G	CARD AT STOP + SIGNAL
145H	RADIO FREQUENCY SIGNAL
145I	COLUMN LOCK +
145J	HALL SAFETY SENSOR - CONTROL
145K	RADIO FREQUENCY REFERENCE SIGNAL
145L	START INVITATION INDICATOR LIGHT CONTROL
145M	ENGINE RUNNING INDICATOR LIGHT CONTROL
145N	ENGINE START/STOP BUTTON + SIGNAL
145O	VEHICLE WITHOUT KEY REAR RADIO FREQUENCY AERIAL 1 SIGNAL
145P	DOOR HANDLE INFRARED SENSOR +
145Q	PASSENGER HANDLE INFRARED SENSOR SIGNAL
145R	RIGHT-HAND REAR HANDLE INFRARED SENSOR SIGNAL
145S	LEFT-HAND REAR HANDLE INFRARED SENSOR SIGNAL
145T	DRIVER'S HANDLE INFRARED SENSOR SIGNAL
145U	HANDS FREE ACCESS AERIAL 2 SIGNAL
145V	HANDS FREE STARTER AERIAL 1 SIGNAL
145W	HORN RELAY - CONTROL
145X	CLUTCH - SIGNAL
145Y	HANDS FREE STARTER AERIAL 2 SIGNAL
145Z	MANUAL GEARBOX NEUTRAL + SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
146A	SUPPORT SYSTEM ELECTRONIC READER SENSOR -
146B	SUPPORT SYSTEM ELECTRONIC READER SENSOR SUPPLY
146C	SUPPORT SYSTEM ELECTRONIC READING WARNING LIGHT CONTROL
147A	TRACKING DISTANCE SIGNAL
147H	CAN HIGH SIGNAL > AUTOMATIC CRUISE CONTROL
147L	CAN LOW SIGNAL > AUTOMATIC CRUISE CONTROL
148A	SEATBELT FITTED IN THE DRIVER'S SEAT - CONTROL
148B	SEATBELT FITTED IN THE DRIVER'S SEAT + CONTROL
148C	SEATBELT FITTED IN THE PASSENGER'S SEAT + CONTROL
148D	SEATBELT FITTED IN THE PASSENGER'S SEAT - CONTROL
14A	WINDSCREEN WIPER LOW SPEED + CONTROL
14B	WINDSCREEN WIPER HIGH SPEED + CONTROL
14C	PARK POSITION WINDSCREEN WIPER + CONTROL
14D	LOW SPEED WINDSCREEN WIPER TIME SWITCH CONTROL
14E	WINDSCREEN WIPER TIME SWITCH + CONTROL
14F	HIGH SPEED WIPER > DRIVING SCHOOL HIGH SPEED RELAY + CONTROL
14G	FRONT LOW SPEED WIPER > COMPUTER CONTROL
14H	FRONT HIGH SPEED WIPER > COMPUTER CONTROL
14J	INTERCONNECTION COMPUTER - > PROTECTED + AFTER IGNITION FEED > WIPER FUSE
14K	FRONT LOW SPEED WIPER TIMER + CONTROL
14L	FRONT HIGH SPEED WIPER TIMER + CONTROL
14M	FRONT WIPER PARK POSITION > COMPUTER CONTROL
14P	TRANSPONDER AERIAL - > FRONT WIPER CONTROL > COMPUTER
14Q	WINDSCREEN WIPER START/STOP RAIN SENSOR + SIGNAL
14R	WINDSCREEN WIPER HIGH SPEED RAIN SENSOR PIVOT + SIGNAL
14S	RAIN SENSOR SERIES LINE SIGNAL
150A	ACCOMPANIED DRIVING DYNAMIC BRAKE ACTUATOR +
150B	ACCOMPANIED DRIVING DYNAMIC BRAKE ACTUATOR SIGNAL
150C	ACCOMPANIED DRIVING DYNAMIC BRAKE ACTUATOR -
150D	STATIC LOCKING CONTROL
150G	STATIC UNLOCKING CONTROL
150H	LOCKING WARNING LIGHT CONTROL
150K	CLUTCH SENSOR SIGNAL
150L	CLUTCH SENSOR -
150M	DYNAMIC BRAKE ACTUATOR +
150N	DYNAMIC BRAKE ACTUATOR SIGNAL
150P	DYNAMIC BRAKE ACTUATOR -
151A	EXTERIOR LEFT-HAND REAR SENSOR +
151B	EXTERIOR LEFT-HAND REAR SENSOR -
151C	EXTERIOR LEFT-HAND REAR SENSOR SIGNAL
151D	EXTERIOR RIGHT-HAND REAR SENSOR +
151G	EXTERIOR RIGHT-HAND REAR SENSOR -
151H	EXTERIOR RIGHT-HAND REAR SENSOR SIGNAL
151K	INTERIOR LEFT-HAND REAR SENSOR +
151L	INTERIOR LEFT-HAND REAR SENSOR -
151M	INTERIOR LEFT-HAND REAR SENSOR SIGNAL
151N	INTERIOR RIGHT-HAND REAR SENSOR +
151P	INTERIOR RIGHT-HAND REAR SENSOR -
151Q	INTERIOR RIGHT-HAND REAR SENSOR SIGNAL
151R	BUZZER +
151S	BUZZER CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
151T	CARAVAN DETECTION SIGNAL
151U	EXTERIOR SENSOR +
151V	EXTERIOR SENSOR -
153A	ELECTRIC POWER ASSISTED STEERING CANH SIGNAL
153B	ELECTRIC POWER ASSISTED STEERING CANL SIGNAL
153C	ELECTRIC POWER ASSISTED STEERING FAULT FINDING LINE K SIGNAL
153D	ELECTRIC POWER ASSISTED STEERING BATTERY +
153G	ELECTRIC POWER ASSISTED STEERING COMPUTER 0V
154A	INTER SYSTEM CONNECTION CAN WARNING LIGHT CONTROL
154A	TMN CANLIS
155A	ASCENDING EDGE VEHICLE SPEED SIGNAL
155B	DESCENDING EDGE VEHICLE SPEED SIGNAL
155C	VEHICLE SPEED SENSOR +
15A	REAR SCREEN DE-ICING WARNING LIGHT CONTROL
15B	REAR SCREEN DE-ICING + CONTROL
15C	HEATED REAR WINDOW RELAY +
15D	RIGHT REAR VIEW MIRROR DE-ICING + CONTROL
15E	LEFT-HAND REAR VIEW MIRROR DE-ICING + CONTROL
15H	REAR DE-ICING - CONTROL > REAR SCREEN CONTROL UNIT
15J	REAR SCREEN HEATER OPERATION
15K	REAR SCREEN HEATER LEFT-HAND PROTECTED +
15L	REAR SCREEN HEATER RIGHT-HAND PROTECTED +
15LP	HEATED REAR SCREEN PROTECTED + CONTROL
15M	HEATED REAR SCREEN CONTROL RELAY
15RP	REAR VIEW MIRROR DE-ICING PROTECTED + CONTROL
16A	FRONT WASHER PUMP + CONTROL
17A	GLOVEBOX LIGHTING - CONTROL
18A	LUGGAGE COMPARTMENT LIGHTING - CONTROL
19A	DRIVING LIGHT > RHEOSTAT + CONTROL
19B	DRIVER'S POSITION LIGHTING + CONTROL
19C	DRIVING LIGHT RHEOSTAT + CONTROL
19D	ACCESSORIES FEED LIGHTING > RELAY > SHUNT + CONTROL
19E	DRIVING LIGHT > RHEOSTAT > STRAP - CONTROL
19F	RHEOSTAT +
19G	PULSE WIDTH MODULATION LIGHTING SIGNAL
19H	RHEOSTAT -
1a	STARTER SOLENOID > RELAY + CONTROL
1B	STARTER RELAY COIL - CONTROL
1C	DIODE CATHODE STARTER SOLENOID + CONTROL
200A	BRAKE DIFFERENTIAL LOCKING + CONTROL
200B	BRAKE DIFFERENTIAL LOCKING WARNING LIGHT + CONTROL
200C	AUXILIARY DRIVE + CONTROL
200D	AUXILIARY DRIVE WARNING LIGHT + CONTROL
200G	REAR START ACCOUSTIC DEVICE + SIGNAL
20A	CENTRAL DOOR LOCKING CLOSURE PANEL TIMER + CONTROL
20AA	TAILGATE STRIKER RELAY - CONTROL
20AB	TAILGATE STRIKER POSITION SIGNAL
20AC	COVER LOCK OPENING CONTROL
20AD	OPENING ELEMENTS CONDITION INDICATOR LIGHT CONTROL
20AG	WINDOW OPENING MOTOR AUTHORISED SUPPLY
20AH	OPENING WINDOW CONDITION SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
20AJ	FUEL FILLER FLAP TAILGATE PASSENGER EXIT EXTERNAL CONTROL
20AK	REAR DOOR EXTERNAL INTERNAL LOCKING CONTROL
20AL	REAR INTERNAL LOCKING CONTROL
20AM	DRIVER'S REAR EXTERNAL LOCKING CONTROL
20AN	FRONT INTERNAL DRIVER'S EXTERNAL UNLOCKING CONTROL
20AP	FRONT INTERNAL LOCKING CONTROL
20AR	DEAD LOCK MOTOR CONTROL
20AS	DRIVER'S DOOR OPENING MOTOR CONTROL
20AT	DRIVER'S DOOR CLOSING MOTOR CONTROL
20AU	DRIVER'S DOOR CENTRAL LOCKING OPENING CONTROL
20AV	DRIVER'S DOOR CENTRAL LOCKING CLOSING CONTROL
20AW	PULSE DOORS UNLOCKING LOCKING CONTROL
20AX	OPENING FRONT DEAD-LOCK CONTROL
20AY	CLOSING FRONT DEAD-LOCK CONTROL
20AZ	OPENING REAR DEAD-LOCK CONTROL
20B	CENTRAL DOOR LOCKING OPENING TIMER + CONTROL
20BA	CLOSING REAR DEAD-LOCK CONTROL
20BC	FUEL FLAP/ DRIVER'S DOOR OPENING MOTORS CONTROL
20BD	FRONT/ REAR PASSENGER DOOR OPENING MOTORS CONTROL
20BG	REAR DOORS DEADLOCKING CONDITION SIGNAL
20BH	FUEL FLAP/ DRIVER'S DOOR LOCKING MOTOR CONTROL
20BK	REAR DOORS/ PASSENGER DOORS LOCKING MOTOR CONTROL
20BL	FUEL FLAP CLOSING CONTROL
20C	CENTRAL DOOR LOCKING OPENING + CONTROL
20D	CENTRAL DOOR LOCKING CLOSURE + CONTROL
20E	INFRA-RED + RECEPTION
20F	INFRA-RED RECEPTION SIGNAL
20G	TAILGATE MOTOR OPENING CONTROL
20H	TAILGATE MOTOR CLOSING
20J	WINDOW MOTOR OPENING
20K	WINDOW MOTOR CLOSING
20L	CENTRAL DOOR LOCKING OPENING > AUTHORISATION RELAY + CONTROL
20M	DOOR LOCKING LED
20N	PASSENGER DOOR CENTRAL DOOR LOCKING OPENING > FUSE + CONTROL
20P	CAB DOORS CENTRAL DOOR LOCKING OPENING > FUSE + CONTROL
20R	PASSENGER DOOR LOCK + CONTROL
20S	TAILGATE MOTOR OPENING AUTHORISED SUPPLY
20T	CHILD SAFETY LED - CONTROL
20U	LEFT-HAND REAR DOOR DEADLOCKING SIGNAL
20V	RIGHT-HAND REAR DOOR DEADLOCKING SIGNAL
20W	REAR DEADLOCKING MOTOR CONTROL
20X	FRONT DEADLOCKING MOTOR CONTROL
20Y	REAR DEADLOCKING RELAY - CONTROL
20Z	FRONT DEADLOCKING RELAY CONTROL
21A	DRIVER'S WINDOW WINDER RISE CONTROL
21B	DRIVER'S WINDOW WINDER LOWER CONTROL
21C	PULSE WINDOW WINDER STANDARD UPWARD CONTROL
21D	PULSE WINDOW WINDER PULSE UPWARD - CONTROL
21E	PULSE WINDOW WINDER STANDARD DOWNWARD CONTROL
21F	PULSE WINDOW WINDER PULSE DOWNWARD CONTROL
21G	PULSE SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
21H	WINDOW WINDER CENTRALISED UPWARD - CONTROL
21J	WINDOW WINDER CENTRALISED DOWNWARD - CONTROL
21K	ANTI-TRAPPING SUNROOF ELECTRIC WINDOW SERIAL SIGNAL
22A	PASSENGER WINDOW WINDER RISE CONTROL
22B	PASSENGER WINDOW WINDER DESCENT CONTROL
22C	FRONT WINDOW WINDER FESTOON LAMP 1 CONTROL
22D	FRONT WINDOW WINDER FESTOON LAMP 2 CONTROL
22G	PASSENGER WINDOW WINDER RISE RELAY COIL - CONTROL
22H	PASSENGER WINDOW WINDER DESCENT RELAY COIL - CONTROL
22K	MULTIPLEXING CANH > ELECTRIC WINDOW FESTOON LAMP 1 CONTROL
22L	MULTIPLEXING CANL ELECTRIC WINDOW FESTOON LAMP 1 CONTROL
22Q	DESCENT RELAY LEFT-HAND REAR WINDOW WINDER DESCENT - CONTROL
22R	
22S	PASSENGER PULSE ELECTRIC WINDOW DESCENT CONTROL
23A	RIGHT-HAND REAR QUARTER LIGHT CLOSURE > WINDOW WINDER RISE CONTROL
23B	RIGHT-HAND REAR QUARTER LIGHT OPENING > WINDOW WINDER DESCENT CONTROL
23C	LEFT-HAND REAR QUARTER LIGHT CLOSURE > WINDOW WINDER RISE CONTROL
23D	LEFT-HAND REAR QUARTER LIGHT OPENING > WINDOW WINDER DESCENT CONTROL
23E	REAR OPERATION LOCKING RELAY COIL CONTROL
23EA	REAR ELECTRIC WINDOW RELAY CONTROL
23F	REAR OPERATIONS RELAY > REAR WINDOW WINDER CONTROL
23G	RIGHT-HAND REAR WINDOW WINDER FESTOON LAMP 1 CONTROL
23H	RIGHT-HAND REAR WINDOW WINDER FESTOON LAMP 2 CONTROL
23J	LEFT-HAND REAR WINDOW WINDER FESTOON LAMP 1 CONTROL
23K	LEFT-HAND REAR WINDOW WINDER FESTOON LAMP 2 CONTROL
23L	REAR WINDOW WINDER ANTI-TRAPPING INHIBITOR + CONTROL
23M	FRONT REAR WINDOW WINDER RESUPPLY
23N	FRONT REAR WINDOW WINDER RAISING
23P	LEFT-HAND REAR WINDOW WINDER RAISE RELAY COIL - CONTROL
23Q	LEFT-HAND REAR WINDOW WINDER DESCENT RELAY COIL - CONTROL
23R	RIGHT-HAND REAR WINDOW WINDER RAISE RELAY COIL - CONTROL
23S	RIGHT-HAND REAR WINDOW WINDER DESCENT RELAY COIL - CONTROL
24A	REAR WINDOW WINDER PUMP + CONTROL
25A	BRAKE PAD WEAR WARNING LIGHT - CONTROL
26A	INTERLOCK CONTROL
26AA	DRIVER'S FRONT DOOR VEHICLE WITHOUT EXTERNAL KEY AERIAL A SIGNAL
26AB	DRIVER'S FRONT DOOR VEHICLE WITHOUT KEY EXTERNAL AERIAL B SIGNAL
26AC	PASSENGER FRONT DOOR VEHICLE WITHOUT KEY EXTERNAL AERIAL A SIGNAL
26AD	RIGHT-HAND FRONT DOOR VEHICLE WITHOUT EXTERNAL KEY AERIAL 2 SIGNAL
26AG	DRIVER'S REAR DOOR VEHICLE WITHOUT EXTERNAL KEY AERIAL A SIGNAL
26AH	DRIVER'S REAR DOOR VEHICLE WITHOUT EXTERNAL KEY AERIAL B SIGNAL
26AK	PASSENGER REAR DOOR VEHICLE WITHOUT EXTERNAL KEY AERIAL A SIGNAL
26AL	PASSENGER REAR DOOR VEHICLE WITHOUT KEY AERIAL B SIGNAL
26AM	LUGGAGE COMPARTMENT LID VEHICLE WITHOUT EXTERNAL KEY AERIAL A SIGNAL
26AN	LUGGAGE COMPARTMENT LID VEHICLE WITHOUT EXTERNAL KEY AERIAL 2 SIGNAL
26AP	VEHICLE WITHOUT KEY DRIVER'S SIDE DOORS SWITCH / LOCKING SIGNAL
26AQ	VEHICLE WITHOUT KEY PASSENGER SIDE DOORS SWITCH / LOCKING SIGNAL
26AR	LEVEL 2 VEHICLE WITHOUT KEY LUGGAGE COMPARTMENT LID DOOR SWITCH/LOCKING SIGNAL
26AS	LEVEL 2 VEHICLE WITHOUT KEY RIGHT-HAND REAR DOOR SWITCH / LOCKING SIGNAL
26AT	INTERNAL 1 VEHICLE WITHOUT KEY AERIAL 1 SIGNAL
26AU	VEHICLE WITHOUT KEY INTERNAL 1 AERIAL 2 SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
26AV	VEHICLE WITHOUT KEY INTERNAL 2 AERIAL 1 SIGNAL
26AW	VEHICLE WITHOUT KEY INTERNAL 2 AERIAL 2 SIGNAL
26AX	VEHICLE WITHOUT KEY INTERNAL 3 AERIAL 1 SIGNAL
26AY	VEHICLE WITHOUT KEY INTERNAL 3 AERIAL 2 SIGNAL
26AZ	VEHICLE WITHOUT KEY STEERING COLUMN LOCK CAN H SIGNAL
26B	CARD PRESENCE + SIGNAL
26BA	VEHICLE WITHOUT KEY STEERING COLUMN LOCK CAN L SIGNAL
26BC	BADGE POSITION LED CONTROL
26BD	BADGE PLAYER / PASSENGER COMPARTMENT CENTRAL UNIT SYNCHRONISATION SIGNAL
26BG	BADGE PLAYER / PASSENGER COMPARTMENT CENTRAL UNIT DATA SIGNAL
26BH	BADGE PLAYER +
26BK	BADGE PLAYER -
26C	CARD READER DATA TRANSFER
26D	PASSENGER COMPARTMENT CENTRAL UNIT DATA TRANSMISSION
26E	HANDS FREE ACCESS AERIAL 1 SIGNAL
26F	VEHICLE WITHOUT KEY 2 AERIAL RADIO FREQUENCY EARTH
26G	CARD AT STOP + SIGNAL
26H	RADIO FREQUENCY SIGNAL
26I	COLUMN LOCK +
26J	HALL SAFETY SENSOR - CONTROL
26K	RADIO FREQUENCY REFERENCE SIGNAL
26L	START INVITATION WARNING LIGHT CONTROL
26M	ENGINE RUNNING WARNING LIGHT CONTROL
26N	ENGINE START/STOP + SIGNAL
26O	CARDLESS VEHICLE 2 AERIAL 1 RADIO FREQUENCY SIGNAL
26P	DOOR HANDLE INFRARED SENSOR +
26Q	PASSENGER SIDE DOORS HANDLE INFRARED SENSOR SIGNAL
26R	RIGHT-HAND REAR HANDLE INFRARED SENSOR SIGNAL
26S	DRIVER'S REAR HANDLE INFRARED SENSOR SIGNAL
26T	DRIVER'S HANDLE INFRARED SENSOR SIGNAL
26U	HANDS FREE ACCESS AERIAL 2 SIGNAL
26V	HANDS FREE STARTING AERIAL 1 SIGNAL
26W	HORN RELAY - CONTROL
26X	CLUTCH - SIGNAL
26Y	HANDS FREE STARTER AERIAL 2 SIGNAL
26Z	AUTOMATIC GEARBOX NEUTRAL + SIGNAL
27A	HAND BRAKE WARNING LIGHT CONTROL
27B	HAND BRAKE SWITCH > LAMPS FAILURE SIGNAL
28A	OIL PRESSURE WARNING LIGHT - CONTROL
28AA	ELECTRONIC COMPUTER OIL PRESSURE
29A	FUEL MINIMUM LEVEL INDICATOR - CONTROL
2A	ALTERNATOR LOAD WARNING LIGHT - CONTROL
2B	ALTERNATOR REGULATION > DISCHARGING RELAY + CONTROL
2C	LOAD > DIODE CATHODE WARNING - LIGHT
2D	AFTER IGNITION + FEED > CONTROL EXCITATION BREAK RELAY
2E	CONTROL FAULT
2F	LOAD INDICATOR BREAK > TIMER RELAY +
2G	CONTROL EXCITATION BREAK RELAY TIMER SUPPLY
2H	ALTERNATOR SECURITY RELAY > C BAT - COIL
2HA	BATTERY CHARGER OPERATION WARNING LIGHT
2HB	BATTERY CHARGER ALARM SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
2HC	BATTERY CHARGER EARTH
2HD	BATTERY CHARGER FUSE BATTERY +
2HE	10A>16A LOAD SIGNAL
2J	BATTERY CHARGER + HIGH VOLTAGE
2JA	BATTERY CHARGER - HIGH VOLTAGE
2JB	DRIVING RANGE EXTENDER STARTING CONTROL
2JC	+ INJECTION ECU > ELECTRIC VEHICLES ECU
2JD	ALTERNATOR + EXCITATION
2JE	SECTOR PHASE
2JG	SECTOR NEUTRAL
2JH	SECTOR EARTH
2K	EDF TERMINAL ALTERNATOR BATTERY CHARGER SIGNAL
3%	.
30A	BRAKE FLUID WARNING LIGHT - CONTROL
31A	COOLANT TEMPERATURE WARNING LIGHT - CONTROL
32A	OIL OIL LEVEL SENSOR SIGNAL 2 -
32B	OIL OIL LEVEL SENSOR SIGNAL 1 -
34A	LEFT-HAND REAR SPEAKER + SIGNAL
34AA	DRIVING LIGHT > RADIO SIGNAL
34AB	RHEOSTAT > RADIO SIGNAL
34AC	EARTH > RADIO SIGNAL
34AD	BSCK RADIO>CLUSTER CONTROL
34AE	GND RADIO>CLUSTER CONTROL
34AF	BDATA RADIO>CLUSTER CONTROL
34AG	BSET RADIO>CLUSTER CONTROL
34AH	BINH RADIO>CLUSTER CONTROL
34AJ	RADIO6>CLUSTER CONTROL
34AK	SPEED INFORMATION BY RADIO
34AL	RADIO > DIODE ACCESSORIES + FEED
34AM	WAVE SEPARATOR AERIAL + AMPLIFIER
34AN	AERIAL SIGNAL
34AP	RADIO SATELLITE L0 SIGNAL
34AQ	RADIO SATELLITE L1 SIGNAL
34AR	RADIO SATELLITE L2 SIGNAL
34AS	RADIO SATELLITE IN0 SIGNAL
34AT	RADIO SATELLITE IN1 SIGNAL
34AU	RADIO SATELLITE IN2 SIGNAL
34AV	+ RADIO EMISSION RECEPTION > POWER LOCK
34AW	- RADIO EMISSION RECEPTION > POWER LOCK
34AX	COMPUTER + > POWER LOCK
34AY	COMPUTER - > POWER LOCK
34AZ	COMPACT DISC BUS SIGNAL 1
34B	LEFT-HAND REAR SPEAKER - SIGNAL
34BA	COMPACT DISC BUS SIGNAL 2
34BB	COMPACT DISC - BUS
34BC	COMPACT DISC BATTERY +
34BD	COMPACT DISC + ACCESSORY
34BG	COMPACT DISC AUDIO SIGNAL
34BH	COMPACT DISC - AUDIO 1
34BK	COMPACT DISC - AUDIO 2
34BL	COMPACT DISC SCREENING

List of connections

CONNECTION CODES	CONNECTION TITLE
34BM	COMPACT DISC + REMOTE CONTROL
34BN	COMPACT DISC - REMOTE CONTROL
34BP	COMPACT DISC INFRARED + ACCESSORY
34BQ	COMPACT DISC STOP START CONTROL
34BR	RADIO CANH SHUNT SIGNAL
34BS	RADIO CANL SHUNT SIGNAL
34BT	VIDEO CANH SHUNT SIGNAL
34BU	VIDEO CANL SHUNT SIGNAL
34BV	REAR VIDEO SCREEN OPENING SIGNAL
34BW	REAR VIDEO SCREEN CLOSING SIGNAL
34BX	VIDEO CONTROL RADIO LEFT-HAND AUDIO + SIGNAL
34BY	RADIO LEFT-HAND AUDIO > VIDEO CONTROL - SIGNAL
34BZ	VIDEO CONTROL RADIO RIGHT-HAND AUDIO + SIGNAL
34C	RIGHT-HAND REAR SPEAKER - SIGNAL
34CA	RADIO RIGHT-HAND AUDIO > VIDEO CONTROL - SIGNAL
34CB	VIDEO SCREEN RETRACTION OPENING CONTROL
34CC	VIDEO SCREEN RETRACTION CLOSING CONTROL
34CD	DVD CANL SIGNAL
34CG	DVD CANH SIGNAL
34CH	- DVD
34CK	DVD RIGHT-HAND - AUDIO
34CL	DVD RIGHT-HAND AUDIO SIGNAL
34CM	DVD LEFT-HAND - AUDIO
34CN	DVD LEFT-HAND AUDIO SIGNAL
34CP	Y VIDEO - SIGNAL
34CQ	Y VIDEO + SIGNAL
34CR	+ DVD
34CS	C VIDEO - SIGNAL
34CT	C VIDEO + SIGNAL
34CU	VIDEO SECONDARY START SIGNAL
34CV	VIDEO SCREEN TILT + CONTROL
34CW	VIDEO SCREEN TILT - CONTROL
34CX	VIDEO IMAGE DIRECTION SIGNAL
34CY	VIDEO IMAGE FORMAT SIGNAL 1
34CZ	VIDEO IMAGE FORMAT SIGNAL 2
34D	RIGHT-HAND REAR SPEAKER + SIGNAL
34DA	VIDEO SIGNAL 0 VOLT
34DB	RED RVB SIGNAL SIGN
34DC	GREEN RVB VIDEO SIGNAL
34DD	BLUE RVB VIDEO SIGNAL
34DG	VIDEO SCREEN - 1
34DH	VIDEO SCREEN - 2
34DK	VIDEO SCREEN - 3
34DL	VIDEO SYNCHRONISATION SIGNAL
34DM	VIDEO SCREEN BRIGHTNESS SIGNAL
34DN	VIDEO SCREEN STOP START CONTROL
34DP	VIDEO SCREEN + 1
34DQ	VIDEO SCREEN + 2
34DR	RADIO CANH SIGNAL
34DS	RADIO CANL SIGNAL
34DT	TELEPHONE / COMMUNICATIONS AUDIO INCOMING SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
34DU	TELEPHONE / COMMUNICATIONS AUDIO 0 VOLT
34DV	RADIO SATELLITE - SIGNAL
34DW	50 > 60 HERTZ CONTROL
34DX	AFTER IGNITION + / RADIO DIODE
34DY	INSTRUMENT PANEL ALARM / RADIO CONTROL
34DZ	MULTIMEDIA 1 CAN H SIGNAL
34E	RIGHT-HAND FRONT SPEAKER + SIGNAL
34F	RIGHT-HAND FRONT SPEAKER - SIGNAL
34G	LEFT-HAND FRONT SPEAKER + SIGNAL
34GA	MULTIMEDIA 1 CAN L SIGNAL
34GB	MULTIMEDIA 2 CAN H SIGNAL
34GC	MULTIMEDIA 2 CAN L SIGNAL
34GD	COMMUNICATION 1 STOP START SIGNAL
34GG	COMMUNICATION 2 STOP START SIGNAL
34GH	RADIO DISPLAY + REMOTE CONTROL
34GK	RADIO DISPLAY - REMOTE CONTROL
34GL	DVD PLAYER STOP START SIGNAL
34GM	VIDEO LED CONTROL
34GN	VIDEO SIGNAL
34GO	VIDEO REMOTE CONTROL SIGNAL
34GP	VIDEO 1 CONTROL +5 VOLTS
34GQ	VIDEO 2 CONTROL +5 VOLTS
34H	LEFT-HAND FRONT SPEAKER - SIGNAL
34K	RIGHT-HAND REAR SPEAKER > HEADSET SOCKET ELECTRONICS UNIT + SIGNAL
34L	LEFT-HAND REAR SPEAKER > HEADSET SOCKET ELECTRONICS UNIT + SIGNAL
34M	AERIAL + CONTROL
34N	AVERAGE>NE VOLUME AUTOMATION REWIND SIGNAL
34P	TELEPHONE OPERATION SIGNAL
34R	REAR SPEAKER > HEADSET SOCKET ELECTRONICS UNIT - SIGNAL
34S	12C RADIO DATA BUS SIGNAL
34T	12C RADIO CLOCK SIGNAL
34U	12C RADIO MARK - MARKING SIGNAL
34V	12C SHIELDING EARTH SIGNAL
34W	VAN RADIO DATA BUS SIGNAL
34X	B VAN RADIO DATA BUS SIGNAL
34Y	VAN RADIO EARTH SIGNAL
34Z	RADIO OPERATE SIGNAL
35A	REAR CIGAR LIGHTER > PROTECTED RELAY LIGHTING
36A	REAR SCREEN WIPER + CONTROL
36B	REAR SCREEN WIPER PARK POSITION + CONTROL
36C	REAR SCREEN WIPER PARK POSITION SWITCH - SIGNAL
36E	REAR SCREEN WIPER TIMER + CONTROL
37A	- EGR SOLENOID VALVE > COOLANT TEMPERATURE SWITCH > SENSOR LOAD
37AA	HEATER 2 SPARK PLUG CONTROL
37AB	HEATER 3 SPARK PLUG CONTROL
37AC	HEATER 4 SPARK PLUG CONTROL
37B	HEATER WARNING LIGHT - CONTROL
37C	LOAD SWITCH - CONTROL
37D	COLD START SOLENOID VALVE > ANTI-STALL DEVICE + CONTROL
37E	COOLANT TEMPERATURE SWITCH + CONTROL
37F	SPARK PLUG 1> 3 + CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
37G	SPARK PLUG 2> 4 + CONTROL
37H	DIESEL ELECTRONIC FAULT
37J	ADVANCE WITHDRAWAL SENSOR RELAY CONTROL
37K	COOLANT TEMPERATURE SENSOR + SIGNAL
37L	AIR FLAP > EGR PRE POST TIMER COMPUTER SOLENOID VALVE -
37M	DIESEL PUMP SOLENOID VALVE > ADVANCE WITHDRAWAL SIGNAL + CONTROL
37N	BURNER TUBE SOLENOID VALVE - CONTROL
37Q	BURNER TUBE SOLENOID VALVE > BURNER TUBE SOLENOID VALVE RELAY + CONTROL
37R	BURNER TUBE - CONTROL
37S	BURNER TUBE > BURNER TUBE RELAY + CONTROL
37T	BURNER TUBE > SOLENOID VALVE > FLAMESTART CASING + CONTROL
37U	ADVANCE WITHDRAWAL SOLENOID VALVE > BREAK RELAY CONTROL
37X	RELAY SHIELDED SUPPLY
37Y	+ EGR SOLENOID VALVE > COOLANT TEMPERATURE SWITCH
37Z	HEATER 1 SPARK PLUG CONTROL
38A	FAN ASSEMBLY RELAY + CONTROL
38AA	COMMANDE+ FAST IDLING > PREHEATING UNIT
38AB	AIR CONDITIONING CLUTCH RELAY > COOLANT SENSOR + CONTROL
38AC	AIR CONDITIONING CLUTCH RELAY COIL > AIR CONDITIONING TIMER + CONTROL
38AD	ACCELERATOR PEDAL TIMING RELAY COIL > PEDAL DISENGAGING - CONTROL
38AG	TIMER RELAY TIMING UNIT + CONTROL
38AH	SPEED 1 FAN MOTOR + CONTROL
38AJ	SPEED 2 FAN MOTOR + CONTROL
38AK	SPEED 3 FAN MOTOR + CONTROL
38AL	SPEED 4 FAN MOTOR + CONTROL
38AM	INJECTOR AIR CONDITIONING BREAK > RELAY SIGNAL
38AN	AIR CONDITIONING RECIRCULATION - CONTROL
38AP	AIR CONDITIONING EVAPORATOR SENSOR + SIGNAL
38AQ	COMPRESSOR VARIABLE CYLINDER - CONTROL
38AR	AIR CONDITIONING STOP START SIGNAL
38AS	AIR CONDITIONING COMPRESSOR CYCLING SIGNAL
38AT	AIR CONDITIONING BREAK > RELAY SIGNAL
38AU	AIR CONDITIONING HIGH SPEED CONTROL
38AV	AIR CONDITIONING FAN SUPPLY RELAY CONTROL
38AW	DIESEL AIR CONDITIONING BREAK > OIL TEMPERATURE SWITCH SIGNAL
38AX	AIR CONDITIONING OFF > INJECTOR COMPUTER RELAY CONTROL
38AY	FAN SPEED SIGNAL
38AZ	CONTROL SETTING - GUIDE TIMER PROTECTED > DIODE RELAY CONTROL
38B	AIR CONDITIONING BREAK > OIL TEMPERATURE SWITCH
38BA	FREON PRESSURE
38BB	EVAPORATOR REFERENCE > FREON PRESSURE SENSOR SIGNAL
38BC	AIR CONDITIONING + HIGH TENSION
38BD	AIR CONDITIONING - HIGH TENSION
38BE	HEATING - HIGH TENSION
38BG	HEATING + HIGH TENSION
38CA	PASSENGER AIR INLET + MOTOR
38CB	PASSENGER AIR INLET - MOTOR
38CC	DRIVER AIR INLET + MOTOR
38CD	DRIVER AIR INLET - MOTOR
38CE	PASSENGER MIXER + MOTOR
38CF	PASSENGER MIXER - MOTOR

List of connections

CONNECTION CODES	CONNECTION TITLE
38CG	PASSENGER MIXER POTENTIOMETER -
38CH	PASSENGER MIXER POTENTIOMETER +
38CJ	PASSENGER MIXER POTENTIOMETER OUTLET
38CK	DRIVER MIXER + MOTOR
38CL	DRIVER MIXER - MOTOR
38CM	DRIVER MIXER POTENTIOMETER -
38CN	DRIVER MIXER POTENTIOMETER +
38CP	DRIVER OUT POTENTIOMETER
38CQ	PASSENGER DISTRIBUTION + MOTOR
38CR	PASSENGER DISTRIBUTION - MOTOR
38CS	PASSENGER DISTRIBUTION POTENTIOMETER -
38CT	PASSENGER DISTRIBUTION POTENTIOMETER +
38CU	PASSENGER OUT POTENTIOMETER
38CV	DRIVER DISTRIBUTION + MOTOR
38CW	DRIVER DISTRIBUTION - MOTOR
38CX	DRIVER DISTRIBUTION POTENTIOMETER -
38CY	DRIVER DISTRIBUTION POTENTIOMETER +
38CZ	DRIVER DISTRIBUTION OUT POTENTIOMETER
38DA	HEATER FAN > AIR CONDITIONING INSTRUMENT PANEL - CONTROL
38DB	HEATING VENTILATION FAN > HEATING/VENTILATION INSTRUMENT PANEL + CONTROL
38DC	PASSENGER MIXER + CONTROL
38DD	PASSENGER MIXER - CONTROL
38DE	PASSENGER MIXER COMMON CONTROL
38DF	HEATING/VENTILATION BREAK > COOLANT TEMPERATURE SENSOR SIGNAL
38DG	AIR CONDITIONING > AIR CONDITIONING CONTROL PANEL - RELAY
38DH	FAST IDLING > HEATED WINDSCREEN > AIR CONDITIONING > CASING + CONTROL
38DJ	PASSENGER COLD MIXER WARNING LIGHT - CONTROL
38DK	PASSENGER HOT MIXER WARNING LIGHT - CONTROL
38DL	DRIVER POSITION PROTECTED > CONTROL PANEL + LIGHTS
38DM	RIGHT-HAND MOTOR EXTERNAL AIR
38DN	RIGHT-HAND MOTOR PASSENGER COMPARTMENT RECIRCULATION
38DP	LEFT-HAND MOTOR EXTERNAL AIR
38DQ	LEFT-HAND MOTOR PASSENGER COMPARTMENT RECIRCULATION
38DR	RIGHT-HAND MIXER MOTOR HOT DIRECTION
38DS	RIGHT-HAND MIXER MOTOR COLD DIRECTION
38DT	RIGHT-HAND MIXER MOTOR POTENTIOMETER +
38DU	RIGHT-HAND MIXER MOTOR -POTENTIOMETER
38DV	RIGHT-HAND MIXER MOTOR OUT POTENTIOMETER
38DW	LEFT-HAND MIXER MOTOR HOT DIRECTION
38DX	LEFT-HAND MIXER MOTOR COLD DIRECTION
38DY	LEFT-HAND MIXER MOTOR POTENTIOMETER -
38DZ	LEFT-HAND MIXER MOTOR POTENTIOMETER +
38E	AIR CONDITIONING + RECIRCULATION
38EA	LEFT-HAND MIXER MOTOR OUT POTENTIOMETER
38EB	RIGHT-HAND DISTRIBUTION MOTOR VENTILATION DIRECTION
38EC	RIGHT-HAND DISTRIBUTION MOTOR DE-ICING DIRECTION
38ED	RIGHT-HAND DISTRIBUTION MOTOR POTENTIOMETER -
38EE	RIGHT-HAND DISTRIBUTION MOTOR POTENTIOMETER +
38EF	RIGHT-HAND DISTRIBUTION MOTOR OUT POTENTIOMETER
38EG	LEFT-HAND DISTRIBUTION MOTOR VENTILATION DIRECTION
38EH	LEFT-HAND DISTRIBUTION MOTOR DE-ICING DIRECTION

List of connections

CONNECTION CODES	CONNECTION TITLE
38EJ	LEFT-HAND DISTRIBUTION MOTOR POTENTIOMETER -
38EK	LEFT-HAND DISTRIBUTION MOTOR POTENTIOMETER +
38EL	LEFT-HAND DISTRIBUTION MOTOR OUT POTENTIOMETER
38EM	DE-ICING > AIR CONDITIONING INSTRUMENT PANEL RELAY CONTROL
38EN	MIXER MOTOR > PASSENGER + CONTROL
38EP	MIXER MOTOR > PASSENGER - CONTROL
38EQ	PASSENGER MIXER MOTOR COMMON CONTROL
38ER	PASSENGER MIXER COMMON WARNING LIGHT
38ES	AIR CONDITIONING WARNING LIGHT - CONTROL
38ET	RECIRCULATION WARNING LIGHT - CONTROL
38EU	REAR SCREEN HEATING CONTROL
38EV	RECIRCULATION + CONTROL
38EW	EVAPORATOR TEMPERATURE SENSOR 0 VOLT
38FA	BATTERY + >PASSENGER COMPARTMENT FAN RELAY FUSE
38FB	ACCESSORIES + FEED > PASSENGER COMPARTMENT FAN RELAY FUSE
38FC	PASSENGER COMPARTMENT FAN > RELAY CONTROL
38FD	PASSENGER COMPARTMENT FAN > PROGRAMMING RELAY CONTROL
38FE	PASSENGER COMPARTMENT FAN DIVERSION RELAY BATTERY +
38FF	PASSENGER COMPARTMENT FAN DIVERSION RELAY CONTROL
38FG	PASSENGER COMPARTMENT FAN RELAY CONTROL
38FH	SPEED 3 PASSENGER COMPARTMENT FAN > RELAY+ CONTROL
38FJ	SPEED 3 IMMOBILISATION
38FK	HEATING + COOLANT PUMP
38FL	FLAME SENSOR +
38FM	FLAME SENSOR -
38FN	INDEPENDENT HEATING FAN
38FP	INDEPENDENT HEATING REGULATION - THERMOSTAT
38FQ	INDEPENDENT HEATING REGULATION + THERMOSTAT
38FR	INDEPENDENT HEATING SAFETY THERMOSTAT SIGNAL
38FS	INDEPENDENT HEATING PREHEATING SPARK PLUG
38FT	FUEL PUMP +
38FU	FUEL PUMP -
38FV	INDEPENDENT HEATING EARTH
38FW	HEATING REQUIREMENT
38GA	DIESEL ACCELERATOR POTENTIOMETER +
38GB	DIESEL ACCELERATOR POTENTIOMETER SIGNAL
38GC	DIESEL ACCELERATION POTENTIOMETER -
38GD	INTERNAL TEMPERATURE SENSOR HOT + POINT
38GG	INTERNAL TEMPERATURE SENSOR -
38GH	INTERNAL TEMPERATURE SENSOR TURBINE DIAGNOSTIC SIGNAL
38GK	INTERNAL TEMPERATURE SENSOR VENTILATION + TURBINE
38GL	INTERNAL TEMPERATURE SENSOR VENTILATION - TURBINE
38GM	HEATING MINIMUM PRESSURE > AIR CONDITIONING > PASSENGER CONTROL
38GN	HEATING MINIMUM PRESSURE INDICATOR > AIR CONDITIONING > PASSENGER CONTROL
38GP	POSITION 1 MIXER > PASSENGER CONTROL
38GQ	POSITION 2 MIXER > PASSENGER CONTROL
38GR	POSITION 3 MIXER > PASSENGER CONTROL
38GS	POSITION 4 MIXER > PASSENGER CONTROL
38GT	AIR CONDITIONING POWER CONSUMPTION SIGNAL
38GU	AIR CONDITIONING AIR CONDITIONING CANH SIGNAL
38GV	AIR CONDITIONING AIR CONDITIONING CANL SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
38GW	SUN SENSOR 0V
38GX	SUN SENSOR SIGNAL
38GY	INTERNAL TEMPERATURE HUMIDITY SENSOR -
38GZ	INTERNAL TEMPERATURE SENSOR SIGNAL
38H	COLD AIR BLOWING DEVICE > INJECTION > CONDIT OPERATION SENSOR 3 + CONTROL
38HA	HUMIDITY SENSOR SIGNAL
38HB	ADDITIONAL PASSENGER COMPARTMENT HEATING CONTROL
38HC	AIR CONDITIONING FAN SPEED RETURN SIGNAL
38HD	ULTRA FAST HEATING BY-PASS SOLENOID VALVE CONTROL
38HG	ULTRA FAST HEATING REVERSAL SOLENOID VALVE CONTROL
38HH	ULTRA FAST HEATING REVERSAL SIGNAL
38HI	ULTRA FAST HEATING FREON PRESSURE SENSOR SIGNAL
38HJ	ULTRA FAST HEATING FREON TEMPERATURE SENSOR +
38HK	ULTRA FAST HEATING FREON TEMPERATURE SENSOR SIGNAL
38HL	ULTRA FAST HEATING SENSOR 0V
38HM	ULTRA FAST HEATING COOLANT EVAPORATION SENSOR SIGNAL
38HN	ULTRA FAST HEATING COOLANT EVAPORATION SENSOR +
38HP	AIR CONDITIONING HEATING/VENTILATION FAN SPEED 0V
38HQ	AIR CONDITIONING PASSENGER COMPARTMENT FAN 2 SPEED CONTROL
38HR	AIR CONDITIONING PASSENGER COMPARTMENT GVM 2 SPEED SIGNAL
38HS	PASSENGER COMPARTMENT DE-ICING DISTRIBUTION MOTOR 1 CONTROL
38HT	PASSENGER COMPARTMENT DE-ICING DISTRIBUTION MOTOR 2 CONTROL
38HU	PASSENGER COMPARTMENT LEFT-HAND MIXER MOTOR 1 CONTROL
38HV	PASSENGER COMPARTMENT LEFT-HAND MIXER MOTOR 2 CONTROL
38HW	PASSENGER COMPARTMENT RIGHT-HAND MIXER MOTOR 1 CONTROL
38HX	PASSENGER COMPARTMENT RIGHT-HAND MIXER MOTOR 2 CONTROL
38HY	BASE DISTRIBUTION MOTOR 1 CONTROL
38HZ	BASE DISTRIBUTION MOTOR 2 CONTROL
38J	AIR CONDITIONING BREAK > AUTO SPEED UNIT COMPUTER SIGNAL
38JA	RECIRCULATION MOTOR 1 CONTROL
38JB	RECIRCULATION MOTOR 2 CONTROL
38JC	PROTECTED CANL SIGNAL
38JD	PROTECTED CANH SIGNAL
38JG	TOXICITY SENSOR +
38JH	NITROGEN OXIDE TOXICITY SENSOR SIGNAL
38JK	CARBON DIOXIDE TOXICITY SENSOR SIGNAL
38JL	AIR TOXICITY 0V SENSOR
38JM	WINDSCREEN TEMPERATURE SENSOR SIGNAL
38JN	HUMIDITY TEMPERATURE SUN 0V SENSOR
38JP	RECIRCULATION MOTOR PASSENGER COMPARTMENT FAN SPEED 1 CONTROL
38JQ	PASSENGER COMPARTMENT DE-ICING DISTRIBUTION MOTOR 2 CONTROL 1
38JR	PASSENGER COMPARTMENT DE-ICING DISTRIBUTION MOTOR 2 CONTROL 2
38JS	REAR DISTRIBUTION MOTOR CONTROL 1
38JT	REAR DISTRIBUTION MOTOR CONTROL 2
38JU	PASSENGER COMPARTMENT HEATING RESISTOR RELAY CONTROL 1
38JV	PASSENGER COMPARTMENT HEATING RESISTOR RELAY CONTROL 2
38JW	PASSENGER COMPARTMENT HEATING RESISTOR RELAY CONTROL 3
38JX	LEFT-HAND AIR TEMPERATURE SIGNAL
38JY	RIGHT-HAND AIR TEMPERATURE SIGNAL
38JZ	BUS ON UNITARY WIRE + SIGNAL
38K	AIR CONDITIONING BREAK > PETROL COMPUTER > DIESEL CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
38KA	BUS ON UNITARY WIRE - SIGNAL
38KB	HEATER UNIT BY-PASS SOLENOID VALVE CONTROL
38KC	HEATER UNIT BY-PASS SOLENOID VALVE SUPPLY
38KD	EVAPORATION 2 AIR TEMPERATURE SIGNAL
38KG	ULTRA FAST HEATING SOLENOID VALVE 1 CONTROL
38KH	ULTRA FAST HEATING SOLENOID VALVE 2 CONTROL
38KK	ULTRA FAST HEATING SOLENOID VALVE 3 CONTROL
38KL	ULTRA FAST HEATING SOLENOID VALVE 1 SIGNAL
38KM	ULTRA FAST HEATING SOLENOID VALVE 2 SIGNAL
38KN	ULTRA FAST HEATING SOLENOID VALVE 3 SIGNAL
38KP	AIR FLAP POSITION SENSOR -
38KQ	AIR FLAP POSITION SENSOR +
38KR	LEFT-HAND AIR FLAP POSITION SIGNAL
38KS	RIGHT-HAND AIR FLAP POSITION SIGNAL
38KT	BOILER TIMER SIGNAL
38KU	COOLANT PUMP + CONTROL
38KV	COOLANT - PUMP
38KW	BLOWN AIR TEMPERATURE SIGNAL
38KX	BLOWN AIR TEMPERATURE 0 VOLT
38KY	AIR DISTRIBUTION MOTOR B2 COIL CONTROL
38KZ	DISTRIBUTION MOTOR A2 COIL CONTROL
38L	INJECTION AIR CONDITIONING > FAST IDLING CONTROL
38LA	AIR DISTRIBUTION MOTOR B1 COIL CONTROL
38LB	AIR DISTRIBUTION MOTOR A1 COIL CONTROL
38LC	AIR MIXER MOTOR B2 COIL CONTROL
38LD	AIR MIXER MOTOR A2 COIL CONTROL
38LG	AIR MIXER MOTOR B1 COIL CONTROL
38LH	AIR MIXER MOTOR A1 COIL CONTROL
38LK	PASSENGER COMPARTMENT HEAT RESISTOR RELAY CONTROL 4
38LL	PASSENGER COMPARTMENT HEATING RESISTOR / RELAY 1 CONTROL
38LM	PASSENGER COMPARTMENT HEATING RESISTOR / RELAY 2 CONTROL
38LN	PASSENGER COMPARTMENT HEATING RESISTOR / RELAY 3 CONTROL
38LO	PASSENGER COMPARTMENT HEAT RESISTOR / EARTH RELAY 4 CONTROL
38LP	AIR CONDITIONING STOP START CONTROL
38LQ	FAN SPEED 0 SIGNAL
38LR	SPEED 2/ PASSENGER COMPARTMENT FAN INSTRUCTION CONTROL
38LS	SPEED 3/ PASSENGER COMPARTMENT FAN SPEED SIGNAL CONTROL
38N	AIR CONDITIONING CLUTCH RELAY > OPERATION SENSOR 3 + CONTROL
38P	WINDSCREEN WIPER AIR CONDITIONING > COOLANT SENSOR + CLUTCH
38R	AIR CONDITIONING CLUTCH + CONTROL
38S	VARIABLE RESISTANCE COIL +
38U	RHEOSTAT CURSOR
38V	FAN LOW SPEED RESISTOR + CONTROL
38W	(AC) FREON - PRESSURE SENSOR
38X	FREON PRESSURE SENSOR SIGNAL
38Y	FREON + PRESSURE SENSOR
38Z	AIR CONDITIONING CYCLE > PETROL COMPUTER > DIESEL CONTROL
39A	HEADLIGHT WASHER PUMP + CONTROL
39B	HEADLIGHT WASHER RELAY COIL > TIMER - CONTROL
39C	HEADLIGHT WASHER PUMP MOTOR CONTROL
39D	HEADLIGHT WASHER PUMP RELAY - CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
39G	HEADLIGHT WASHER RELAY 1 + CONTROL
39H	HEADLIGHT WASHER RELAY 2 + CONTROL
3a	OXYGEN SENSOR SIGNAL
3AA	LATCH POWER RELAY COIL - CONTROL
3AB	+ ECU > INJECTION LOCKING RELAY
3ABP	PROTECTED + ECU > INJECTION LOCKING RELAY
3AC	FUEL PUMP RELAY COIL - CONTROL
3AD	LOCKING RELAY + CONTROL
3AE	HEATER- REHEATING RELAY COIL - CONTROL
3AF	IGNITION POWER MODULE > INJECTION COMPUTER SIGNAL 1
3AG	THROTTLE BODY HEATER > RELAY + CONTROL
3AH	PULSE WIDTH MODULATION THROTTLE VALVE ANGLE SIGNAL
3AJ	THROTTLE POSITION POTENTIOMETER + SIGNAL
3AJA	THROTTLE POSITION POTENTIOMETER + SIGNAL
3AJB	THROTTLE MOTOR + CONTROL
3AJC	THROTTLE MOTOR - CONTROL
3AK	IDLE RICHNESS POTENTIOMETER > OXYGEN SENSOR SIGNAL
3AM	INJECTOR > INJECTION COMPUTER - CONTROL
3AN	FULL LOAD SWITCH - SIGNAL
3AP	AMPLIFIED TOP DEAD CENTRE SIGNAL
3AQ	THROTTLE POSITION POTENTIOMETER + SIGNAL
3AS	FUEL PUMP > DIODE RELAY CONTROL
3AT	WASTEGATE SOLENOID VALVE CONTROL
3AU	FUEL PUMP > FUEL PUMP RELAY - CIRCUIT + BREAK
3AUP	+ PROTECTED FUEL PUMP > FUEL PUMP FUSE
3AW	POWER-ASSISTED STEERING PRESSURE SWITCH > INJECTION COMPUTER + SIGNAL
3AX	GROUP 1 SENSOR -
3AY	NO LOAD SWITCH - SIGNAL
3AYA	INJECTOR COMPUTER NO LOAD > CATHODE SIGNAL
3AYB	SEMI-AUTOMATIC CLUTCH COMPUTER NO LOAD > ANODE SIGNAL
3AYC	RELAY REGULATOR MOTOR NO LOAD > ANODE SIGNAL
3AZ	GROUP 1 SENSOR SIGNAL
3B	AIR TEMPERATURE SENSOR + SIGNAL
3BA	POWER-ASSISTED STEERING PRESSURE SWITCH > INJECTION COMPUTER - SIGNAL
3BB	CANISTER BLEED SOLENOID VALVE CONTROL
3BC	IDLING REGULATION SOLENOID VALVE > INJECTION COMPUTER - CONTROL
3BC1	SEVERE COLD FAST IDLING REGULATOR VALVE CONTROL
3BD	INJECTION FAULT WARNING LIGHT - CONTROL
3BE	AUTOMAT GEARBOX INJECTION COMPUTER TOP DEAD CENTRE SIGNAL
3BF	COLD START + INJECTOR
3BG	MOTOR SPEED > TDC SENSOR SIGNAL
3BH	DIAGNOSTIC L > INJECTION SIGNAL
3BJ	DIAGNOSTIC K > INJECTION SIGNAL
3BK	HEATER > INJECTION FAULT - INDICATOR
3BL	MOTOR SPEED > TDC SENSOR - SIGNAL
3BQ	INJECTION + COMPUTER > INJECTION PROTECTION RELAY
3BR	IGNITION INJECTOR + PUMP
3BS	IGNITION COIL CONTROL
3BT	OXYGEN SENSOR - SIGNAL
3BU	IDLING REGULATION CONTROL 1
3BV	IDLING REGULATION CONTROL 2

List of connections

CONNECTION CODES	CONNECTION TITLE
3BW	IDLING REGULATION CONTROL 3
3BX	IDLING REGULATION CONTROL 4
3BY	LATCH POWER > DIODE - RELAY
3BZ	AFTER SALES PINKING CORRECTION SERVICE
3C	COOLANT TEMPERATURE SENSOR + SIGNAL
3CA	INJECTOR 1-5 IGNITION POWER MODULE IGNITION SIGNAL 1
3CB	INJECTOR 3-6 IGNITION POWER MODULE IGNITION SIGNAL 2
3CC	INJECTOR 3-4 IGNITION POWER MODULE IGNITION SIGNAL 3
3CD	INJECTOR COIL 1> INJECTOR COIL 4 - CONTROL
3CE	IGNITION COIL 1CONTROL
3CF	IGNITION COIL 2 CONTROL
3CG	IGNITION COIL 3 CONTROL
3CH	INJECTOR COIL 2 > INJECTOR COIL 3 - CONTROL
3CJ	GROUP 1 SENSOR -
3CK	GROUP 2 SENSOR -
3CL	FUEL PUMP RELAY > AUTOMATIC GEARBOX TOP DEAD CENTRE BOITE VITESSES - CONTROL
3CM	GROUP 3 SENSOR -
3CN	IDLING AIR RICHNESS THROTTLE SENSOR EARTH
3CP	INJECTION COMPUTER > IGNITION ILLUMINATION POWER MODULE CONTROL
3CQ	CYLINDER 1 SENSOR SIGNAL
3CR	INJECTOR 1 - CONTROL
3CS	INJECTOR 2 - CONTROL
3CT	INJECTOR 3 - CONTROL
3CU	INJECTOR 4 - CONTROL
3CV	INJECTOR IGNITION COIL 1-4 - CONTROL
3CW	INJECTOR IGNITION COIL 2 -3 - CONTROL
3CX	EGR SOLENOID VALVE - CONTROL
3CY	VERLOG WARNING LIGHT > INJECTION - CONTROL
3CZ	INJECTION COMPUTER > IGNITION ILLUMINATION POWER MODULE CONTROL
3D	GROUP 4 SENSOR -
3DA	INJECTOR 1-4 - CONTROL
3DB	INJECTOR 2-3 - CONTROL
3DC	AIR PUMP RELAY > INJECTION COMPUTER - CONTROL
3DE	OXYGEN SENSOR RELAY > INJECTION COMPUTER - CONTROL
3DG	OXYGEN SENSOR > OXYGEN SENSOR HEATER RELAY +
3DH	BREAK + > AIR > AIR PUMP RELAY
3DK	VEHICLE SPEED + SIGNAL
3DL	VEHICLE SPEED - SIGNAL
3DM	INJECTOR 5 - CONTROL
3DN	TOP DEAD CENTRE CYL1 COOLANT TEMPERATURE SENSOR EARTH
3DQ	PINKING SENSOR -
3DR	CYLINDER 1 SENSOR +
3DS	IDLING REGULATION SOLENOID VALVE CLOSURE - CONTROL
3DT	OXYGEN SENSOR EARTH SIGNAL
3DU	AIR - FLOWMETER
3DV	AIR FLOWMETER + SIGNAL
3DW	AIR FLOWMETER - SIGNAL
3DX	VARIABLE INLET 1 SOLENOID VALVE CONTROL
3DY	FUEL PUMP SUPPLY > FUEL PUMP RELAY
3DZ	SENSOR EARTH
3E	THROTTLE OXYGEN RICHNESS PRESSURE SENSOR POTENTIOMETER EARTH

List of connections

CONNECTION CODES	CONNECTION TITLE
3EA	POWER RELAY > MAIN RELAY CONTROL
3EB	AFTER MAIN RELAY BATTERY +
3EC	MAIN RELAY > COMPUTER CONTROL
3ED	IGNITION COIL + > FLOWMETER > POWER RELAY
3EE	COMPUTER HEATER OXYGEN SENSOR RELAY CONTROL
3EF	POWER RELAY + HEATER OXYGEN SENSOR
3EG	VARIABLE DISTRIBUTION SOLENOID VALVE > RELAY CONTROL
3EH	FRONT VARIABLE DISTRIBUTION SOLENOID VALVE CONTROL
3EJ	FUEL RESERVOIR AIR SOLENOID VALVE > COMPUTER CONTROL
3EK	INJECTOR 6 - CONTROL
3EL	EGR POTENTIOMETER + SIGNAL
3EM	OXYGEN SENSOR SIGNAL
3EN	IGNITION COIL 4 CONTROL
3EQ	IGNITION COIL 5 CONTROL
3ER	IGNITION COIL 6 CONTROL
3ES	VARIABLE 2 OR LINE INLET SOLENOID VALVE CONTROL
3ET	POTENTIOMETER COOLANT AIR NEEDLE REGULATION SENSOR EARTH
3EU	LOAD 1 POTENTIOMETER +
3EV	EGR SOLENOID VALVE > COMPUTER - CONTROL
3EW	SOLENOID VALVE CAM > COMPUTER - CONTROL
3EX	RIGHT-HAND LIFT SIGNAL
3EY	SPARK PLUG (1-3) RELAY COIL 1 - CONTROL
3EZ	SPARK PLUG (2 -4) RELAY COIL 2 - CONTROL
3F	ATMOSPHERIC PRESSURE SENSOR SIGNAL
3FA	LOAD 1 POTENTIOMETER + SIGNAL
3FAA	MULTIPLEXED INJECTION SIGNAL
3FAB	FUEL TEMPERATURE + SIGNAL
3FAC	INJECTION COMPUTER SUPPLY RELAY - CONTROL
3FAD	FLOW INSTRUCTION > AUTOMATIC GEARBOX TORQUE REDUCTION SIGNAL
3FAE	ACCELERATOR PEDAL POSITION > COMPUTER SENSOR -
3FAX	PULSE 1 SPEED REGULATION SIGNAL
3FAY	PULSE 2 SPEED REGULATION SIGNAL
3FB	INJECTION + > PROTECTIVE RELAY
3FC	INJECTOR 1 5 - CONTROL
3FD	INJECTOR 2 6 - CONTROL
3FE	INJECTOR 3 4 - CONTROL
3FF	HEATER RELAY - CONTROL
3FG	REAR VARIABLE DISTRIBUTION SOLENOID VALVE CONTROL
3FH	ANTIPOLLUTION FAULT WARNING LIGHT - CONTROL
3FJ	INJECTION COMPUTER SENSOR -
3FK	ENGINE RUNNING SIGNAL
3FL	ANALOGUE- > SENSOR
3FM	FLOWMETER SUPPLY
3FN	ENGINE SPEED SENSOR SIGNAL
3FP	SLIDE VALVE FLOW - CONTROL
3FQ	SLIDE VALVE FLOW POSITION SENSOR REFERENCE
3FR	SLIDE VALVE FLOW SENSOR CENTRE POINT
3FS	SLIDE VALVE FLOW POSITION SENSOR SUPPLY
3FT	PROTECTIVE RELAY BATTERY +
3FU	NEEDLE LIFT SENSOR SIGNAL
3FV	NEEDLE LIFT SENSOR -

List of connections

CONNECTION CODES	CONNECTION TITLE
3FW	ELECTRIC STOP SOLENOID VALVE - CONTROL
3FX	SPEED REGULATOR STOP START - CONTROL
3FY	HEATING RELAY DIAGNOSTIC SIGNAL
3FZ	ADVANCE SOLENOID VALVE - CONTROL
3G	OXYGEN SENSOR -
3GA	OXYGEN SENSOR SIGNAL
3GB	EGR SOLENOID VALVE - CONTROL
3GC	EGR +SENSOR
3GD	EGR SENSOR -
3GE	EGR SENSOR SIGNAL
3GF	UPSTREAM OXYGEN SENSOR HEATER - CONTROL
3GG	DOWNSTREAM OXYGEN SENSOR HEATER - CONTROL
3GH	UPSTREAM OXYGEN SENSOR EARTH
3GJ	DOWNSTREAM OXYGEN SENSOR EARTH
3GK	UPSTREAM OXYGEN SENSOR SIGNAL
3GL	DOWNSTREAM OXYGEN SENSOR SIGNAL
3GM	AIR INLET SOLENOID VALVE - CONTROL
3GN	MANIFOLD PRESSURE SENSOR EARTH
3GP	"CATALYTIC CONVERTER TEMPERATURE COOLANT EARTH SENSOR"
3GQ	THROTTLE POSITION POTENTIOMETER - > PRESSURE SENSOR RESERVOIR
3GR	THROTTLE POSITION POTENTIOMETER + > PRESSURE SENSOR RESERVOIR
3GS	COOLANT TEMPERATURE ALARM
3GT	LATCH POWER ACTUATOR RELAY CONTROL
3GU	FUEL PUMP LEAK DETECTION - CONTROL
3GV	PUMP SWITCH LEAK DETECTION + SIGNAL
3GW	ANTI-LOCK BRAKING SYSTEM WHEEL SPEED
3GX	LIQUID PETROLEUM GAS FUEL SELECTION WARNING LIGHT + CONTROL
3GY	LIQUID PETROLEUM GAS FUEL SELECTION WARNING LIGHT - CONTROL
3GZ	LIQUID PETROLEUM GAS SELECTION + CONTROL
3H	LIQUID PETROLEUM GAS SELECTION - CONTROL
3HA	INJECTOR SWITCHING >LIQUID PETROLEUM GAS INJECTOR SIMULATOR + CONTROL
3HB	INJECTOR SIMULATOR >LIQUID PETROLEUM GAS COMPUTER - SIGNAL
3HC	LIQUID PETROLEUM GAS INJECTOR SIMULATOR > INJECTION COMPUTER 1 - CONTROL
3HD	FUEL TEMPERATURE SENSOR -
3HE	COOLANT TEMPERATURE PULSE WIDTH MODULATION SIGNAL
3HF	LIQUID PETROLEUM GAS ELECTRONIC CONTROL UNIT SOLENOID VALVE RELAY - CONTROL
3HG	ATMOSPHERIC PRESSURE SENSOR +
3HH	LIQUID PETROLEUM GAS INJECTOR SIMULATOR>INJECTN ELECTR CENTRAL UNIT - CONTROL
3HI	FUEL PRESSURE REGULATION SOLENOID VALVE - CONTROL
3HJ	HIGH PRESSURE PUMP PISTON 3 DECLUTCHING SOLENOID VALVE - CONTROL
3HK	TURBOCHARGER LEAK CONTROL SOLENOID VALVE - CONTROL
3HL	SPARK PLUG 2 DIAGNOSTIC SIGNAL
3HM	SPARK PLUG 1 DIAGNOSTIC SIGNAL
3HN	OXYGEN SENSOR RELAY > INJECTOR COMPUTER + SIGNAL
3HP	LIQUID PETROLEUM GAS IGNITION COMPUTER > IGNITION ADAPTATION - SIGNAL
3HQ	LIQUID PETROLEUM GAS EXPANSION VALVE SOLENOID VALVE > COMPUTER + CONTROL
3HR	SOLENOID VALVE BREAK RELAY COIL + CONTROL
3HS	SOLENOID VALVE BREAK RELAY / - CONTROL
3HT	LIQUID PETROLEUM GAS INJECTOR SIMULATOR > COMPUTER I - CONTROL
3HU	LIQUID PETROLEUM GAS INJECTOR SIMULATOR > COMPUTER I - CONTROL
3HV	LIQUID PETROLEUM GAS GAUGE REFERENCE 0V SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
3HW	CONTROL
3HX	PETROL LEVEL SIGNAL INHIBITOR > PETROLEUM GAS COMPUTER - CONTROL
3HY	LIQUID PETROLEUM GAS > INJECTION COMPUTER SIGNAL
3HZ	SIGNAL > INJECTION COMPUTER
3J	INJECTION DIAGNOSTIC SIGNAL
3JA	ADDITIONAL HEATER 1 RELAY COIL CONTROL
3JAA	ADDITIONAL HEATER 2 RELAY COIL CONTROL
3JAB	SUPPLEMENT HEATER 3 RELAY CONTROL
3JAC	ADDITIONAL HEATER 4 + CONTROL
3JAD	ADDITIONAL HEATERS 2/3 SPARK PLUG + CONTROL
3JB	ADDITIONAL HEATER 1 SPARK PLUG + CONTROL
3JC	ADDITIONAL HEATER 2 SPARK PLUG + CONTROL
3JD	ADDITIONAL HEATER 3 SPARK PLUG + CONTROL
3JE	RIGHT-HAND FRONT WHEEL SENSOR SIGNAL 1
3JF	RIGHT-HAND FRONT WHEEL SENSOR SIGNAL 2
3JG	5 VOLTS
3JH	WHEEL SPEED CASING EARTH > INJECTION COMPUTER
3JJ	FUEL PUMP > SWITCH INERTIA RELAY +
3JK	COOLANT TEMPERATURE -
3JL	THROTTLE POTENTIOMETER -
3JM	EGR SOLENOID VALVE -
3JN	FAN 1 RELAY - CONTROL
3JP	FAN 2 RELAY - CONTROL
3JQ	AIR TEMPERATURE -
3JR	ATMOSPHERIC THROTTLE MOTOR REGULATION FLOWMETER SENSOR EARTH
3JS	ADDITIONAL SPARK PLUG SUPPLY > ADDITIONAL HEATER RELAY
3JT	AIR CONDITIONING COOLANT TEMPERATURE SIGNAL
3JU	ADVANCE SOLENOID VALVE > DIESEL INJECTION COMPUTER CONTROL
3JV	HEATING 2 RELAY DIAGNOSTIC SIGNAL
3JW	LIQUID PETROLEUM GAS TEMPERATURE SIGNAL
3JX	LIQUID PETROLEUM GAS FLOW SIGNAL
3JY	LIQUID PETROLEUM GAS + INSTRUMENTATION
3JZ	LIQUID PETROLEUM GAS INJECTOR + CONTROL
3K	THROTTLE POTENTIOMETER PRESSURE SENSOR EARTH
3KA	AIR FLOW SIGNAL
3KB	ROTOR COMPENSATION SIGNAL
3KC	CAM SENSOR SIGNAL
3KD	SPARK PLUG 1 DIAGNOSTIC SIGNAL
3KG	INLET FLAP SOLENOID VALVE - CONTROL
3KH	EGR + RECOPY
3KJ	AIR + FLOWMETER
3KK	SPARK PLUG 2 DIAGNOSTIC SIGNAL
3KL	DIESEL PUMP MEMORY SIGNAL
3KM	LOAD 1 POTENTIOMETER -
3KN	AIR - FLOWMETER
3KP	DIESEL FUEL TEMPERATURE - > DIESEL PUMP MEMORY
3KQ	AIR TEMPERATURE SIGNAL
3KR	INDUCTANCE SWITCH SIGNAL
3KS	POWER-ASSISTED STEERING PUMP ASSEMBLY RELAY > COMPUTER CONTROL
3KT	DIESEL PUMP ROTOR SENSOR SIGNAL
3KU	DIESEL PUMP ROTOR B CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
3KV	DIESEL PUMP ROTOR A CONTROL
3KW	INJECTORS - CONTROL 1
3KX	INJECTORS CONTROL 2
3KY	INJECTORS CONTROL 3
3KZ	INJECTORS CONTROL 4
3L	INJECTOR 1 +
3LA	INJECTOR 2 +
3LB	INJECTOR 3 +
3LC	INJECTOR 4 +
3LD	FUEL TEMPERATURE SENSOR -
3LG	ATMOSPHERIC PRESSURE SENSOR +
3LH	FLAP - CONTROL
3LI	FUEL PRESSURE REGULATION SOLENOID VALVE - CONTROL
3LJ	HIGH PRESSURE PUMP PISTON 3 DECLUTCHING SOLENOID VALVE - CONTROL
3LK	TURBOCHARGER LEAK CONTROL SOLENOID VALVE - CONTROL
3LL	+ > INERTIA SWITCH
3LM	SPARK PLUG 1 DIAGNOSTIC SIGNAL
3LN	TURBOCHARGING PRESSURE SENSOR -
3LP	TURBOCHARGING PRESSURE SENSOR + SIGNAL
3LQ	TURBOCHARGING PRESSURE SENSOR +
3LR	LOAD 1 POTENTIOMETER +
3LS	LOAD 1 POTENTIOMETER + SIGNAL
3LT	LOAD 1 POTENTIOMETER -
3LU	LOAD 2 POTENTIOMETER +
3LV	LOAD 2 POTENTIOMETER -
3LW	LOAD 2 POTENTIOMETER + SIGNAL
3LX	RAIL FUEL PRESSURE SENSOR +
3LY	RAIL FUEL PRESSURE SENSOR +SIGNAL
3LZ	RAIL FUEL PRESSURE SENSOR -
3M	CANISTER BLEED SOLENOID VALVE - CONTROL
3MA	EXHAUST TEMPERATURE SENSOR + SIGNAL
3MB	EXHAUST TEMPERATURE SENSOR - SIGNAL
3MC	AIR SWIRL POSITION SWITCH - CONTROL
3MD	AIR SWIRL SOLENOID VALVE - CONTROL
3MG	TURBOCHARGER PRESSURE SOLENOID VALVE - CONTROL
3MH	ACCELERATION + SIMULATOR > ELECTRONIC CONTROL UNIT
3MI	ACCELERATION - SIMULATOR > ELECTRONIC CONTROL UNIT
3MJ	ACCELERATION SIMULATOR > ELECTRONIC CONTROL UNIT SIGNAL
3MK	VEHICLE SPEED > ELECTRONIC CONTROL UNIT SIGNAL
3ML	LIQUID PETROLEUM GAS INJECTOR - CONTROL
3MM	PETROL GAUGE LEVEL > LIQUID PETROLEUM GAS ECU SIGNAL
3MN	MOTORIZE +5V THROTTLE POTENTIOMETER
3MO	MOTORIZE THROTTLE POTENTIOMETER SENSOR -
3MP	MOTORIZE THROTTLE POTENTIOMETER 1 SIGNAL
3MQ	MOTORIZE THROTTLE POTENTIOMETER 2 SIGNAL
3MR	RESERVE SIGNAL
3MS	ENGINE CANH SIGNAL
3MT	ENGINE CANL SIGNAL
3MU	LIQUID PETROLEUM GAS FAULT INDICATOR CONTROL
3MV	EMERGENCY STOP CONTROL
3MW	ENGINE SAFETY INDICATOR CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
3MX	TURBOCHARGER PRESSURE SENSOR +5V
3MY	TURBOCHARGER PRESSURE SENSOR SIGNAL
3MZ	TURBOCHARGER PRESSURE SENSOR -
3N	FUEL PUMP + >
3NA	INERTIA SWITCH IGNITER + COIL > FUEL PUMP RELAY
3NA1	FUEL PUMP + > INERTIA SWITCH
3NB	EXHAUST EGR SOLENOID VALVE CONTROL 1
3NC	EXHAUST EGR SOLENOID VALVE CONTROL 2
3ND	EXHAUST EGR SOLENOID VALVE CONTROL 3
3NG	EXHAUST EGR SOLENOID VALVE CONTROL 4
3NH	FUEL + PRESSURE SENSOR
3NK	FUEL - PRESSURE SENSOR
3NL	FUEL PRESSURE SENSOR SIGNAL
3NP	PROTECTED + PUMP
3NQ	RENAULT USE PULSE 5 SIGNAL
3NR	INJECTOR + >
3NS	DIESEL PUMP INFO > ALTIMETRIC RELAY
3NT	ALTIMETRIC CORRECTION RELAY CONTROL
3NU	LIQUID PETROLEUM GAS PRESSURE SENSOR +
3NV	LIQUID PETROLEUM GAS PRESSURE SENSOR SIGNAL
3NW	LIQUID PETROLEUM GAS PRESSURE SENSOR -
3NX	GRAVITY 1 INDICATOR - CONTROL
3NY	GRAVITY 2 INDICATOR - CONTROL
3NZ	PUMP + CONTROL > LEFT-HAND BREAK RELAY
3P	DISCHARGE STARTUP SENSOR +
3PA	DISCHARGE STARTUP SENSOR SIGNAL
3PB	COOLANT TEMPERATURE SENSOR ->AIR
3PC	CAMSHAFT SHIFT CONTROL
3PD	SPEED LIMITER STOP START CONTROL
3PG	INJECTION ACCELEROMETER SENSOR SUPPLY
3PH	INJECTION ACCELEROMETER SENSOR EARTH
3PJ	INJECTION ACCELEROMETER SENSOR SIGNAL
3PK	CAMSHAFT ROW A>B SENSOR SUPPLY
3PL	CAMSHAFT ROW A>B SENSOR EARTH
3PM	CAMSHAFT ROW A SENSOR SIGNAL
3PN	CAMSHAFT ROW B SENSOR SIGNAL
3PP	UPSTREAM ROW B OXYGEN SENSOR HEATING CONTROL
3PQ	DOWNSTREAM ROW B OXYGEN SENSOR HEATING CONTROL
3PR	DOWNSTREAM ROW B OXYGEN SENSOR -
3PS	UPSTREAM ROW B OXYGEN SENSOR -
3PT	DOWNSTREAM ROW B OXYGEN SENSOR SIGNAL
3PU	UPSTREAM ROW B OXYGEN SENSOR SIGNAL
3PV	CAMSHAFT ROW B SHIFT CONTROL
3PW	PINKING 1 SENSOR EARTH
3PX	PINKING 2 SENSOR EARTH
3PY	CASING END OF TRAVEL PRESENCE SIGNAL
3PZ	INJECTOR CONTROL UNIT DIAGNOSTIC SIGNAL
3Q	"PINKING, COOLANT, AIR SENSOR -S"
3QA	INJECTOR 1 RESISTORS - CONTROL
3QB	INJECTOR 2 RESISTORS - CONTROL
3QC	INJECTOR 3 RESISTORS - CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
3QD	INJECTOR 4 RESISTORS - CONTROL
3QG	INJECTOR 5 RESISTORS - CONTROL
3QH	INJECTOR 6 RESISTORS - CONTROL
3QK	CAMSHAFT SENSOR + SIGNAL
3QL	CAMSHAFT SENSOR - SIGNAL
3QM	SOLENOID VALVE 1 PRESSURE HIGH PRESSURE FUEL - CONTROL
3QN	SOLENOID VALVE 2 PRESSURE HIGH PRESSURE FUEL - CONTROL
3QP	INJECTOR 1 INJECTION ELECTRONIC CONTROL UNIT EDU CONTROL
3QQ	INJECTOR 2 INJECTION ELECTRONIC CONTROL UNIT EDU CONTROL
3QR	INJECTOR 3 INJECTION ELECTRONIC CONTROL UNIT EDU CONTROL
3QS	INJECTOR 4 INJECTION ELECTRONIC CONTROL UNIT EDU CONTROL
3QT	INJECTOR 5 INJECTION ELECTRONIC CONTROL UNIT EDU CONTROL
3QU	INJECTOR 6 INJECTION ELECTRONIC CONTROL UNIT EDU CONTROL
3QV	SUPPLEMENT HEATER RELAY CONTROL CAMSHAFT VARIATOR CONTROL
3QW	BRAKE SERVO PRESSURE SENSOR SIGNAL
3QX	LIQUID PETROLEUM GAS INJ 1 - CONTROL
3QY	LIQUID PETROLEUM GAS INJ 2 - CONTROL
3QZ	LIQUID PETROLEUM GAS INJ 3 - CONTROL
3RA	LIQUID PETROLEUM GAS INJ 4 - CONTROL
3RB	LIQUID PETROLEUM GAS ACTUATOR RELAY CONTROL
3RC	LIQUID PETROLEUM GAS STOP START SIGNAL
3RD	LIQUID PETROLEUM GAS GAUGE SIGNAL
3RG	RAIL PRESSURE REGULATION - CONTROL
3RH	INLET FLAP SOLENOID VALVE - CONTROL
3RJ	ACOUSTIC RELAY - CONTROL
3RK	CATALYTIC CONVERTER HEATER RELAY A - CONTROL
3RL	CATALYTIC CONVERTER HEATER RELAY B - CONTROL
3RM	CATALYTIC CONVERTER TEMPERATURE SENSOR SIGNAL
3RN	CATALYTIC CONVERTER TEMPERATURE SENSOR -
3RO	ADDITIONAL BATTERY +
3RP	ADDITIONAL - BATTERY
3RQ	CATALYTIC CONVERTER + HEATER
3RR	CATALYTIC CONVERTER TEMPERATURE INDICATOR - CONTROL
3RS	GRAVITY 1 INDICATOR CONTROL
3RT	GRAVITY 2 INDICATOR CONTROL
3RU	IDLING REGULATION SOLENOID VALVE OPENING - CONTROL
3RV	TURBOCHARGER POSITION POTENTIOMETER SIGNAL
3RW	ION 1 SENSOR SIGNAL
3RX	ION 2 SENSOR SIGNAL
3RY	ION 3 SENSOR SIGNAL
3RZ	ION 4 SENSOR SIGNAL
3S	PINKING 1 SENSOR > FRONT + SIGNAL
3SA	IONISATION 1 SENSOR SIGNAL
3SB	IONISATION 2 SENSOR SIGNAL
3SC	IONISATION 3 SENSOR SIGNAL
3SD	IONISATION 4 SENSOR SIGNAL
3SG	THROTTLE AIR TEMPERATURE SIGNAL
3SH	THROTTLE - AIR TEMPERATURE
3SM	ENGINE 2 CANH SIGNAL
3SN	ENGINE 2 CANL SIGNAL
3SO	LEFT-HAND RESERVOIR SOLENOID VALVE CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
3SP	HEATER 1 PLUGS CONTROL
3SQ	HEATER 2 PLUGS CONTROL
3SR	HEATER 3 PLUGS CONTROL
3SS	HEATER 4 PLUGS CONTROL
3ST	HEATER 5 PLUGS CONTROL
3SU	HEATER 6 PLUGS CONTROL
3SV	INLET CAMSHAFT SENSOR SIGNAL
3SW	EXHAUST CAMSHAFT SENSOR SIGNAL
3SX	INLET CAMSHAFT SENSOR -
3SY	EXHAUST CAMSHAFT SENSOR -
3SZ	VARIABLE INLET CAMSHAFT CONTROL
3T	PINKING 2 SENSOR > REAR + SIGNAL
3TA	VARIABLE EXHAUST CAMSHAFT CONTROL
3TB	PARTICLE FILTER RELAY CONTROL
3TC	PARTICLE FILTER HEATER RELAY DIAGNOSTIC SIGNAL
3TD	PARTICLE FILTER UPSTREAM TEMPERATURE SENSOR SIGNAL
3TG	PARTICLE FILTER DOWNSTREAM TEMPERATURE SENSOR SIGNAL
3TH	PARTICLE FILTER UPSTREAM PRESSURE SENSOR SIGNAL
3TK	PARTICLE FILTER UPSTREAM PRESSURE SENSOR -
3TL	PARTICLE FILTER DIFFERENTIAL PRESSURE SIGNAL
3TM	PARTICLE FILTER DIFFERENTIAL PRESSURE SENSOR -
3TN	OIL AGEING SENSOR SIGNAL
3TP	EGR BY-PASS SOLENOID VALVE CONTROL
3TQ	EGR SOLENOID VALVE BY-PASS POSITION SWITCH
3TR	CERIUM GAUGE SIGNAL
3TS	CERIUM - GAUGE
3TT	CERIUM PUMP CONTROL
3TU	OIL TRANSFER PUMP RELAY CONTROL
3TV	HYDROCARBONS SENSOR SIGNAL
3TW	HYDROCARBONS SENSOR -
3TX	HYDROCARBON SENSOR HEATER CONTROL
3TY	ENGINE OVER-REVVING SIGNAL
3TZ	FUEL CIRCUIT DIAGNOSTIC SIGNAL
3U	IDLING REGULATION SIGNAL 1
3UA	FUEL CIRCUIT DIAGNOSTIC CONTROL
3UB	OIL AGEING TEMPERATURE SENSOR -
3UC	OIL AGEING TEMPERATURE SENSOR +
3UD	ALCOHOL HEATER RELAY CONTROL
3UG	ALCOHOL COLD START INJECTOR CONTROL
3UH	CAN H3 SIGNAL WITHOUT CAM
3UI	CAN L3 SIGNAL WITHOUT CAM
3UJ	SENSOR SIGNAL WITHOUT CAM
3UK	TOOTH SIGNAL SYNCHRONISATION SIGNAL + WITHOUT CAM
3UL	TOOTH SIGNAL SYNCHRONISATION SIGNAL - WITHOUT CAM
3UM	RIGHT-HAND INLET CAMSHAFT SENSOR SIGNAL
3UN	RIGHT-HAND EXHAUST CAMSHAFT SENSOR SIGNAL
3UP	LEFT-HAND INLET CAMSHAFT SENSOR SIGNAL
3UQ	LEFT-HAND EXHAUST CAMSHAFT SENSOR SIGNAL
3UR	RIGHT-HAND VARIABLE INLET CAMSHAFT VARIATOR CONTROL
3US	LEFT-HAND VARIABLE INLET CAMSHAFT VARIATOR CONTROL
3UT	RIGHT-HAND VARIABLE EXHAUST CAMSHAFT VARIATOR CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
3UU	LEFT-HAND VARIABLE EXHAUST CAMSHAFT VARIATOR CONTROL
3UV	THROTTLE ENGINE SAFETY RELAY CONTROL
3UW	THROTTLE ENGINE + CONTROL MECHANISM
3UX	POWER-ASSISTED STEERING ANALOGUE PRESSURE SIGNAL
3UY	RIGHT-HAND INLET CAMSHAFT SENSOR -
3UZ	RIGHT-HAND EXHAUST CAMSHAFT SENSOR -
3V	IDLING REGULATION SIGNAL 2
3VA	LEFT-HAND INLET CAMSHAFT SENSOR -
3VB	LEFT-HAND EXHAUST CAMSHAFT SENSOR -
3VC	OIL PUMP RELAY DIAGNOSTIC SIGNAL
3VD	DUAL-MODE SOLENOID VALVE CONTROL
3W	IDLING REGULATION SIGNAL 3
3X	IDLING REGULATION SIGNAL 1
3Y	IDLING REGULATION SIGNAL 2
3Z	ANTI-PERCOLATION RELAY > INJECTION COMPUTER - CONTROL
40A	DRIVER'S RIGHT-HAND>LEFT-HAND REAR VIEW MIRROR CONTROL
40B	PASSENGER HIGH>LOW REAR VIEW MIRROR CONTROL
40C	DRIVER'S HIGH>LOW REAR VIEW MIRROR CONTROL
40D	PASSENGER RIGHT-HAND>LEFT-HAND REAR VIEW MIRROR CONTROL
40E	REAR VIEW MIRROR COMMON MOTOR
40F	DRIVER'S FOLDING REAR VIEW MIRROR MOTOR CONTROL 1
40G	DRIVER'S FOLDING REAR VIEW MIRROR MOTOR CONTROL 2
40H	PASSENGER FOLDING REAR VIEW MIRROR MOTOR CONTROL 1
40J	PASSENGER FOLDING REAR VIEW MIRROR MOTOR CONTROL 2
40K	FOLDING REAR VIEW MIRROR STOP START CONTROL
40L	REAR VIEW MIRROR COMMON - SIGNAL
40M	REAR VIEW MIRROR CONTROL SUPPLY
40N	CONTROLLED EARTH 2
40P	REAR VIEW MIRROR DE-ICING FUSE PROTECTED + CONTROL
40Q	DRIVER'S LEFT-HAND>RIGHT-HAND REAR VIEW MIRROR CONTROL
40R	DRIVER'S HIGH>LOW REAR VIEW MIRROR CONTROL
40S	PASSENGER LEFT-HAND>RIGHT-HAND REAR VIEW MIRROR CONTROL
40T	PASSENGER HIGH>LOW REAR VIEW MIRROR CONTROL
40U	ELECTROCHROME REAR VIEW MIRROR + CONTROL
40V	ELECTROCHROME REAR VIEW MIRROR - CONTROL
40W	REAR VIEW MIRRORS FOLDING CONTROL
40X	REAR VIEW MIRRORS DEPLOYMENT CONTROL
41A	FUEL LEVEL GAUGE + SIGNAL
41B	FUEL LEVEL - LEVEL)
42A	COOLANT TEMPERATURE + SIGNAL
42B	COOLANT TEMPERATURE CASING MANAGEMENT SUPPLY 1
42C	COOLANT TEMPERATURE CASING MANAGEMENT SUPPLY 2
43A	FRONT LIGHT SUPPLY
44A	LEVEL CORRECTOR REGULATION BUTTON - CONTROL
44AA	VERTICAL ACCELEROMETER +
44AB	VERTICAL - ACCELEROMETER
44AC	VERTICAL ACCELEROMETER SIGNAL
44AD	LONGITUDINAL ACCELEROMETER +
44AE	LONGITUDINAL - ACCELEROMETER
44AF	LONGITUDINAL ACCELEROMETER SIGNAL
44AG	LEFT-HAND FRONT VARIABLE SHOCK ABSORBER SOLENOID VALVE +

List of connections

CONNECTION CODES	CONNECTION TITLE
44AH	LEFT-HAND FRONT STANDARD VARIABLE SHOCK ABSORBER SOLENOID VALVE CONTROL
44AJ	LEFT-HAND FRONT VARIABLE COMFORT SHOCK ABSORBER SOLENOID VALVE CONTROL
44AK	RIGHT-HAND FRONT VARIABLE SHOCK ABSORBER SOLENOID VALVE +
44AL	RIGHT-HAND FRONT STANDARD VARIABLE SHOCK ABSORBER SOLENOID VALVE CONTROL
44AM	RIGHT-HAND FRONT VARIABLE COMFORT SHOCK ABSORBER SOLENOID VALVE CONTROL
44AN	LEFT-HAND REAR VARIABLE SHOCK ABSORBER +
44AQ	LEFT-HAND REAR STANDARD VARIABLE SHOCK ABSORBER SOLENOID VALVE CONTROL
44AR	LEFT-HAND REAR COMFORT VARIABLE SHOCK ABSORBER SOLENOID VALVE CONTROL
44AS	RIGHT-HAND REAR VARIABLE SHOCK ABSORBER +
44AT	RIGHT-HAND REAR STANDARD VARIABLE SHOCK ABSORBER SOLENOID VALVE CONTROL
44AU	RIGHT-HAND REAR COMFORT VARIABLE SHOCK ABSORBER SOLENOID VALVE CONTROL
44AV	EXHAUST LEVEL CORRECTOR SOLENOID VALVE CONTROL
44AW	FAN COMPRESSOR > FAN COM DISCONNECTING THERMO-SWITCH RELAY + CONTROL
44AX	FAN COMPRESSOR > FAN RELAY COMPRESSOR > FUSE CHECK + CONTROL
44AY	RESERVOIR LEVEL CORRECTION SOLENOID VALVE CONTROL
44B	STANDARD WARNING LIGHT + > LEVEL CORRECTOR REGULATION HEIGHT
44C	VARIABLE SHOCK ABSORBER REGUALTION BUTTON - CONTROL
44D	LAMP WARNING LIGHT + >VARIABLE SHOCK ABSORBER SELF- REGULATION
44E	CONTROLLED-SUSPENSION SAFETY CONTROL
44F	CONTROLLED-SUSPENSION FAULT WARNING LIGHT CONTROL
44G	STEERING WHEEL ANGLE + REFERENCE
44H	STEERING WHEEL - ANGLE
44J	STEERING WHEEL ANGLE SIGNAL
44K	CONTROLLED-SUSPENSION SAFETY RELAY - CONTROL
44L	COMPUTER + SAFETY > CONTROLLED-SUSPENSION SAFETY RELAY
44M	LEFT-HAND REAR LEVEL CORRECTOR SOLENOID VALVE - CONTROL
44N	LEFT-HAND FRONT LEVEL CORRECTOR SOLENOID VALVE - CONTROL
44Q	RIGHT-HAND FRONT LEVEL CORRECTOR SOLENOID VALVE - CONTROL
44R	RIGHT-HAND REAR LEVEL CORRECTOR SOLENOID VALVE - CONTROL
44S	PNEUMATIC PRESSURE SENSOR ENTER
44T	COMPRESSOR FAN POWER RELAY - CONTROL
44U	FRONT HEIGHT SENSOR + SIGNAL
44V	FRONT HEIGHT SENSOR -
44W	LEFT-HAND REAR SENSOR + SIGNAL
44X	REAR HEIGHT SENSOR -
44Y	RIGHT-HAND REAR SENSOR + SIGNAL
45A	ALTERNATOR BUILT INTO THE INERTIA FLYWHEEL SPEED SENSOR -
45AA	BATTERY CURRENT SIGNAL
45AB	DIRECT CURRENT DIRECT CURRENT SIGNAL
45AC	DIRECT CURRENT DIRECT CURRENT DIAGNOSTIC SIGNAL
45AD	INVERTER DIAGNOSTIC SIGNAL
45AG	START AND GO INHIBITION SIGNAL
45AH	BATTERY TEMPERATURE SIGNAL
45AK	LAPTOP CAN K SIGNAL
45B	START AND GO - INHIBITION
45C	BATTERY TEMPERATURE -
45D	STARTER ALTERNATOR BUILT INTO THE INERTIA FLYWHEEL SPEED SENSOR +
45G	STARTER ALTERNATOR BUILT INTO THE INERTIA FLYWHEEL POWER - BATTERY
45H	STARTER ALTERNATOR BUILT INTO THE INERTIA FLYWHEEL - ECU
45J	BATTERY DIRECT CONVERTER + 12V
45K	SPEED SENSOR SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
45L	SPEED ENGAGED SENSOR -
45M	SPEED ENGAGED SENSOR +
45N	GEAR LEVER POSITION SIGNAL
45P	U PHASE SUPPLY
45Q	V PHASE SUPPLY
45R	W PHASE SUPPLY
45S	STEERING WHEEL FAULT CONTROL
45T	DIRECT CURRENT START STOP CONTROL
45U	INVERTER START STOP CONTROL
45V	START AND GO INDICATOR LIGHT CONTROL
45W	DIRECT CURRENT ANGULAR SIGNAL
45X	LAPTOP CAN L SIGNAL
45Y	CURRENT AMPLITUDE SETTING SIGNAL
45Z	INVERTER FREQUENCY SETTING SIGNAL
46A	SATELLITE GUIDANCE > CARMINAT DISPLAY - COUPLING
46AA	SPEAKER NAVIGATION + SIGNAL
46AB	SPEAKER NAVIGATION - SIGNAL
46AC	NAVIGATION STOP START 0V
46AD	NAVIGATION STOP START CONTROL
46AE	ATTENUATION RADIO COMMUNICATION INTERFACE CASING > RADIO ATTENUATION
46AF	LUMINOUS 0V
46AG	OPERATION 1 CONTROL
46AH	OPERATION 2 CONTROL
46AJ	OPERATION 3 CONTROL
46AK	OPERATION 4 CONTROL
46AL	KEYBOARD LIGHTING 0V
46AM	KEYBOARD LIGHTING +
46AN	TELECOM KEYPAD -
46AP	KEYBOARD EMERGENCY CALL SIGNAL
46AQ	KEYBOARD EMERGENCY CALL SIGNAL
46AR	CAR PHONE HANDSET SPEAKER SIGNAL
46AS	CAR PHONE HANDSET MIKE SIGNAL
46AT	CAR PHONE HANDSET - ANALOGUE
46AU	CAR PHONE HANDSET - NUMERIC
46AV	CAR PHONE HANDSET SWITCH SIGNAL
46AW	CARPHONE + HANDSET
46AX	HANDSET 7 SIGNAL
46AY	HANDSET 8 SIGNAL
46AZ	AUDIO NAVIGATION + SIGNAL
46B	CARMINAT DISPLAY TRANSMISSION SIGNAL
46BA	AUDIO NAVIGATION - SIGNAL
46BB	NAVIGATION 1 CANH SIGNAL
46BC	NAVIGATION CANL SIGNAL
46BD	NAVIGATION DISPLAY LUMINOUS SIGNAL
46BG	DISPLAY - 1
46BH	DISPLAY - 2
46BK	DISPLAY - 3
46BL	NAVIGATION H SHUNT SIGNAL
46BM	NAVIGATION L SHUNT SIGNAL
46BN	ROTARY KNOB -
46BP	ROTARY KNOB +

List of connections

CONNECTION CODES	CONNECTION TITLE
46BQ	ROTARY KNOB LEFT-HAND DISPLACEMENT SIGNAL
46BR	ROTARY KNOB RIGHT-HAND DISPLACEMENT SIGNAL
46BS	VALIDATION SWITCH SIGNAL
46BT	KEYBOARD 1 -
46BU	KEYBOARD 2 -
46BV	MULTIFUNCTION DISPLAY CLOCK SHUNT SIGNAL
46BW	GENERAL MOTORS HEIGHT 1 DATA BUS SIGNAL
46BX	GENERAL MOTORS HEIGHT 2 DATA BUS SIGNAL
46BY	NAVIGATION 2 CANH SIGNAL
46BZ	NAVIGATION 2 CANL SIGNAL
46C	CARMINAT DISPLAY RECEPTION SIGNAL
46D	COMMUNICATION INTERFACE CASING LIGHTING RHEOSTAT > DISPLAY + SIGNAL
46E	COMMUNICATION INTERFACE CASING LIGHTING RHEOSTAT > DISPLAY SIGNAL 0V
46F	DISPLAY BLUE GREEN RED MODE > COMPUTER CONTROL
46G	DISPLAY GREEN VIDEO > COMPUTER
46H	DISPLAY BLUE VIDEO > COMPUTER SIGNAL
46J	DISPLAY VIDEO SYNCHRONISATION > COMPUTER SIGNAL
46K	DISPLAY RED VIDEO > COMPUTER SIGNAL
46L	DISPLAY VIDEO > COMPUTER 0V SIGNAL
46M	1 DISPLAY + > COMPUTER
46N	2 DISPLAY + > COMPUTER
46P	NAVIGATION MENU 1 CONTROL
46Q	NAVIGATION MENU 2 CONTROL
46R	NAVIGATION MENU 3 CONTROL
46S	BIN > NAVIGATION
46T	COMMUNICATION INTERFACE CASING > NAVIGATION
46U	COMMUNICATION INTERFACE CASING > NAVIGATION
46V	COMMUNICATION INTERFACE CASING > NAVIGATION
46W	NAVIGATION REAR START 0V
46X	NAVIGATION MENU 4 CONTROL
46Y	LUMINOUS + CONTROL
46Z	LUMINOUS - CONTROL
47A	FUEL LEVEL - GAUGE >
47C	EXTERNAL TEMPERATURE SENSOR + SIGNAL
47D	EXTERNAL TEMPERATURE SENSOR SIGNAL 0V
47E	DRIVING ASSISTANCE - SPEED
47F	VEHICLE SPEED SIGNAL
47H	FUEL OUTFLOW SIGNAL
47J	DRIVING ASSISTANCE ZERO ALLOWANCE - CONTROL
47K	DRIVING ASSISTANCE ADVANCE - CONTROL
47M	FUEL - OUTFLOW
47N	ODOMETER SIGNAL
47Q	OIL TEMPERATURE SENSOR + SIGNAL
47R	OIL TEMPERATURE SENSOR SIGNAL 0V
47T	X TRACER (CARMINAT)
47U	Y TRACER (CARMINAT)
47V	MAGNETO + > MAGNETOMETER COMPUTER
47W	SECONDARY SPEED SIGNAL
47X	DISPLAY OUTLET EXTERNAL TEMPERATURE SIGNAL
48A	POWER ASSISTED STEERING SOLENOID VALVE + CONTROL
48B	HEATER ELECTRIC PUMP UNIT SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
48C	ELECTRIC PUMP UNIT + CONTROL
48H	ELECTRIC PUMP UNIT RELAY>ELECTR PUMP UNIT STARTING AUTHORISATION RELAY - CONTR
48J	ELECTRIC PUMP AUTHORISATION RELAY + SUPPLY
48K	ELECTRIC PUMP UNIT STARTING AUTHORISATION RELAY 1 SWITCH > RELAY 2 - CONTROL
49A	FAN - CONTROL
49B	FAN + CONTROL
49C	FAN RELAY + CONTROL
49D	FAN 1 + CONTROL
49E	FAN FUSE TEST SIGNAL
49F	AIR CONDITIONING + CONTROL
49G	HIGH SPEED FAN RELAY + CONTROL
49H	LOW SPEED FAN RELAY + CONTROL
49J	FAN LOW SPEED - CONTROL
49K	FAN HIGH SPEED - CONTROL
49L	FAN LOW SPEED RESISTOR + CONTROL
49M	FAN LOCKING WARNING LIGHT - CONTROL
49N	FAN > PERCOLATION RELAY > COOLANT THERMOSTAT + CONTROL
49P	FAN THERMOSTAT > INJECTOR COMPUTER - CONTROL
49Q	HIGH SPEED FAN RELAY - CONTROL
49R	HIGH SPEED FAN SUPPLY
49S	PROTECTED > DUAL THRESHOLD THERMOSTAT FUSE BATTERY +
49T	FAN LOW SPEED RELAY 2 HIGH SPEED RELAY SHUTTLE CONTROL
49TA	BATTERY + > RADIATOR FAN RELAY FUSE
49TB	RADIATOR FAN RELAY CONTROL
49TC	RADIATOR FAN RELAY +
49TD	BATTERY COOLANT PUMP EARTH
49TE	BATTERY COOLANT PUMP CONTROL
49U	FAN LOW SPEED RELAY SHUTTLE CONTROL
4AA	BRAKE MINIMUM LEVEL SENSOR SIGNAL
4AB	WHEEL ANTI-LOCKING > RELAY + COMPUTER
4AC	BRAKE FLUID WARNING LIGHT SENSOR SUPPLY
4AD	WHEEL ANTI-LOCKING BRAKE MINIMUM LEVEL SIGNAL
4AG	HYDRAULIC LOCK PUMP + CONTROL
4AH	DIRECTIONAL STABILITY CONTROL SENSOR WITHOUT CANH SIGNAL
4AK	ISO STANDARD K DIAGNOSTIC ABS 2 SIGNAL
4AL	HYDRAULIC CONTROL 2 > COMPUTER SIGNAL
4AM	HYDRAULIC CONTROL 3 > COMPUTER SIGNAL
4AN	HYDRAULIC CONTROL 4 > COMPUTER SIGNAL
4AP	DIRECTIONAL STABILITY CONTROL SENSOR WITHOUT CANL SIGNAL
4AQ	DEACTIVATED ACTIVATED DIRECTIONAL STABILITY CONTROL - CONTROL
4AR	BRAKE PRESSURE 1 SENSOR + 5V
4AS	BRAKE PRESSURE 1 SENSOR -
4AT	BRAKE PRESSURE 1 SENSOR SIGNAL
4AU	BRAKE PRESSURE 2 SENSOR + 5V
4AV	BRAKE PRESSURE 2 SENSOR -
4AW	BRAKE PRESSURE 2 SENSOR SIGNAL
4AX	WHEEL ANTI-LOCKING COMPUTER + CONTROL
4AY	BRAKE PEDAL POTENTIOMETER + 5V
4AZ	BRAKE PEDAL POTENTIOMETER - 5V
4B	ELECTRIC PUMP UNIT REGULATION 2 SIGNAL
4BA	HYDRAULIC CONTROL > COMPUTER SIGNAL 1

List of connections

CONNECTION CODES	CONNECTION TITLE
4BB	BRAKE PEDAL POTENTIOMETER SIGNAL
4BC	BOOSTER + SOLENOID
4BD	BOOSTER SOLENOID - CONTROL
4BE	WHEEL ANTI-LOCKING LEFT-HAND REAR SENSOR EARTH
4BG	MASTER CYLINDER + MICROSWITCH
4BH	REST MASTER CYLINDER MICROSWITCH + SIGNAL
4BJ	CLUTCH SWITCH SIGNAL
4BK	MID POINT SWITCH SIGNAL
4BL	(4X4) WHEEL ANTI-LOCKING TURBOCHARGER COMPENSATOR SIGNAL
4BM	LONGITUDINAL ACCELERATOR SENSOR -
4BN	LONGITUDINAL ACCELERATOR SENSOR +
4BP	ACTIVE MASTER CYLINDER MICROSWITCH + SIGNAL
4BQ	LONGITUDINAL ACCELERATOR SENSOR + SIGNAL
4BR	ENGAGE VENTILATION SIGNAL
4BS	WHEEL ANTI-LOCKING RELAY + CONTROL
4BT	ENGINE RELAY - SUPPLY
4BU	ENGAGE ENGINE SIGNAL
4BV	VENTILATION RELAY - SUPPLY
4BW	WHEEL ANTI-LOCKING RIGHT-HAND REAR SENSOR EARTH
4BX	PRELOAD + PUMP
4BY	PRELOAD - PUMP
4BZ	YAW SENSOR TEST SIGNAL
4C	LEFT-HAND FRONT WHEEL SENSOR SIGNAL
4CA	PEDAL 1 TRAVEL HOOD
4CB	PEDAL 2 TRAVEL HOOD
4CC	SUPPLY RELAY CONTROL
4CD	WHEEL ANTI-LOCKING + ELECTRONIC CENTRAL UNIT
4CE	PUMP RELAY CONTROL
4CF	ENGINE 1 SENSOR
4CG	ENGINE 2 SENSOR
4CJ	RIGHT-HAND FRONT WHEEL > WHEEL ANTI-LOCKING COMPUTER SIGNAL
4CK	LEFT-HAND FRONT WHEEL > WHEEL ANTI-LOCKING COMPUTER SIGNAL
4CL	RIGHT-HAND REAR WHEEL > WHEEL ANTI-LOCKING COMPUTER SIGNAL
4CM	LEFT-HAND REAR WHEEL > WHEEL ANTI-LOCKING COMPUTER SIGNAL
4CN	RIGHT-HAND FRONT SOLENOID VALVE OPENING CONTROL
4CQ	RIGHT-HAND FRONT SOLENOID VALVE CLOSURE CONTROL
4CR	LEFT-HAND FRONT SOLENOID VALVE OPENING CONTROL
4CS	LEFT-HAND FRONT SOLENOID VALVE CLOSURE CONTROL
4CT	ELECTRIC PUMP UNIT MOTOR SENSOR +
4CU	ELECTRIC PUMP UNIT MOTOR SENSOR -
4CV	YAW SENSOR REFERENCE SIGNAL
4CW	YAW SENSOR SIGNAL
4CX	TRANSVERSAL ACCELERATION SENSOR SIGNAL
4CY	YAW > TRANSVERSAL ACCELERATION SENSOR -
4CZ	YAW > TRANSVERSAL ACCELERATION SENSOR +
4D	ISO STANDARD L DIAGNOSTIC WHEEL ANTI-LOCKING 1 SIGNAL
4DA	DIRECTIONAL STABILITY CONTROL MULTIFUNCTION INDICATOR CONTROL
4DB	REFERENCE FAULT INDICATOR > WHEEL ANTI-LOCKING ELECTRONIC CONTROL UNIT CONTROL
4DC	SENSOR + 1
4DD	SENSOR - 1
4DG	BRAKE FAULT INDICATOR > ELECTRONIC CONTROL UNIT CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
4DH	BRAKE LIGHTS CONTROL RELAY CONTROL
4DK	CLUSTER SENSOR +12 VOLTS
4DL	CLUSTER -
4DM	ABS CANH SIGNAL
4DN	WHEEL ANTI-LOCKING CANL SIGNAL
4E	LEFT-HAND FRONT WHEEL SENSOR +
4F	ABS COMPUTER 1 SIGNAL
4G	LEFT-HAND REAR SENSOR SIGNAL
4H	LEFT-HAND REAR WHEEL SENSOR +
4J	WHEEL ANTI-LOCKING COMPUTER 3 SIGNAL
4K	WHEEL ANTI-LOCKING COMPUTER 4 SIGNAL
4L	WHEEL ANTI-LOCKING COMPUTER 5 SIGNAL
4M	RIGHT-HAND FRONT WHEEL SENSOR SIGNAL
4N	RIGHT-HAND FRONT WHEEL SENSOR +
4P	VEHICLE SPEED TACHOMETER SIGNAL
4Q	WHEEL ANTI-LOCKING COMPUTER 8 SIGNAL
4R	WHEEL ANTI-LOCKING COMPUTER 9 SIGNAL
4S	RIGHT-HAND REAR SENSOR SIGNAL
4T	RIGHT-HAND REAR WHEEL SENSOR +
4V	WHEEL ANTI-LOCKING COMPUTER 6 SIGNAL
4W	WHEEL ANTI-LOCKING COMPUTER 2 SIGNAL
4X	WHEEL ANTI-LOCKING COMPUTER 7 SIGNAL
4Y	BRAKE FAULT WARNING - LIGHT
4Z	WHEEL ANTI-LOCK WARNING - LIGHT
50A	OIL PRESSURE SIGNAL
51A	TOP DEAD CENTRE SENSOR 2 INFO
51B	TOP DEAD CENTRE SENSOR 1 INFO
51C	IGNITION ASSISTANCE CASING - CONTROL
51D	RELAYED INTEGRAL OR IGNITION POWER MODULE + SUPPLY
51F	5 DEGREE FORWARD MOVEMENT - SIGNAL
51G	10 DEGREE FORWARD MOVEMENT - SIGNAL
51K	INTEGRAL MODULE > DIODE - SIGNAL
52A	REAR SUNROOF OPENING CONTROL
52B	FRONT SUNROOF CLOSING CONTROL
52C	SUNROOF RELAY +
52D	DIGITAL CONTROL EARTH
52E	0 BIT DIGITAL CONTROL
52G	1 BIT DIGITAL CONTROL
52H	2 BIT DIGITAL CONTROL
52J	3 BIT DIGITAL CONTROL
54A	PROTECTED + > FUSE > HIGH TENSION SWITCH CONTROL
54B	CIRCUIT-BREAK + > HIGH TENSION SWITCH CONTROL
54C	SWITCH > IMPACT SIGNAL
54D	HEIGHT SWITCH RELAY > IMPACT SWITCH CONTROL
54E	HEIGHT SWITCH > COMPUTER CONTROL
55A	ACCELERATOR POTENTIOMETER +
55B	ACCELERATOR POTENTIOMETER -
55C	ACCELERATOR POTENTIOMETER SIGNAL
55D	NO LOAD SWITCH SIGNAL
55E	ACCELERATOR+ SWITCH
55F	FOOT FULLY DOWN SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
55G	ENGINE SPEED SENSOR +
55H	ENGINE SPEED SENSOR -
55J	ENGINE TEMPERATURE - SIGNAL
55K	CHOPPER EARTH
55L	FRONT START SIGNAL
55M	NEUTRAL POINT SIGNAL
55N	REAR START SIGNAL
55P	APPLICATION OF POWER AUTHORISATION
55Q	REGENERATIVE BRAKING IMMOBILISATION
55R	ENGINE TEMPERATURE + SIGNAL
55S	ENGINE SPEED SIGNAL
55T	AFTER IGNITION + > CHOPPER PROTECTED
55U	ACCELERATOR 2 POTENTIOMETER +
55V	ACCELERATOR 2 POTENTIOMETER -
55W	ACCELERATOR 2 POTENTIOMETER SIGNAL
56A	VACUUM PUMP > PRESSURE SWITCH SUPPLY
56B	AFTER IGNITION + > VACUUM PUMP PRESSURE SWITCH PROTECTED
56C	VACUUM PUMP EARTH
57A	BATTERY ENERGY INDICATION
57AA	TENSION BATTERY GAUGE MINIMUM INDICATOR
57AB	ELECTRONIC FAULT INDICATOR
57AC	REAR DE-ICING RELAY + CONTROL
57AD	GEARBOX CONTROL SENSOR -
57AE	GEARBOX CONTROL SENSOR SIGNAL
57AF	GEARBOX CONTROL SENSOR +
57AG	COMPUTER + AFTER IGNITION
57AH	COMPUTER PROTECTED BATTERY + FEED
57AJ	COMPUTER ACCESSORIES + ANODE DIODE
57AK	HEATED REAR SCREEN DE-ICING + > RELAY
57AL	DE-ICING REQUIREMENT
57AM	HYDROGEN DILUTION FAN CONTROL
57AP	AIR CONDITIONING STARTER > CENTRAL ELECTRIC UNIT CONTROL
57AQ	STARTER > ELECTRONIC CONTROL UNIT CONTROL
57AR	FRONT WHEEL DRIVE BATTERIES FAN CONTROL
57AS	REAR WHEEL DRIVE BATTERIES FAN CONTROL
57B	OVERSPEEDING WARNING LIGHT
57C	COMPUTER BATTERY +
57D	DRIVE BATTERY 108 VOLT
57E	DRIVE BATTERY -108 VOLT
57F	HORN +
57G	HORN -
57H	CURRENT PROBE +
57J	CURRENT PROBE SIGNAL
57K	CURRENT PROBE -
57L	FRONT BATTERY CONTAINER TEMPERATURE SENSOR +
57M	FRONT BATTERY CONTAINER TEMPERATURE SENSOR -
57N	REAR BATTERY CONTAINER TEMPERATURE SENSOR + 1
57P	REAR BATTERY CONTAINER TEMPERATURE SENSOR - 1
57Q	REAR BATTERY CONTAINER TEMPERATURE SENSOR + 2
57R	REAR BATTERY CONTAINER TEMPERATURE SENSOR - 2
57S	CONVERTOR INHIBITION

List of connections

CONNECTION CODES	CONNECTION TITLE
57T	DRIVE BATTERY CURRENT + SIGNAL
57U	DRIVE BATTERY CURRENT - SIGNAL
57V	CONVERTER FAULT
57W	CHARGING PLUG PRESENCE
57X	DRIVE TRAIN ALARM INDICATOR
57Y	INSULATION FAULT INDICATOR
57Z	ELECTROLYTE MINIMUM ALARM INDICATOR
58A	DISPLAY INCREMENTATION
58B	DISPLAY DECREMENTATION
58C	PROGRAMMING MODE
58D	DISPLAY START STOP SIGNAL
58E	RHEOSTAT DISPLAY + SIDE LIGHT
5A	BRAKE PEDAL SWITCH + SIGNAL
5AA	AUTOMATIC GEARBOX +POTENTIOMETER
5AB	AUTOMATIC GEARBOX -POTENTIOMETER
5AC	AUTOMATIC GEARBOX POTENTIOMETER SIGNAL
5AD	ELECTRONIC CLUTCH PRESSURE SENSOR - SIGNAL
5AE	CLUTCH ELECTRIC PUMP UNIT MOTOR + CONTROL
5AF	AUTOMATIC CLUTCH ELECTRIC PUMP UNIT RELAY COIL - CONTROL
5AG	AUTOMATIC CLUTCH MODULATION SOLENOID VALVE +
5AH	AUTOMATIC CLUTCH MODULATION SOLENOID VALVE -
5AI	ENGAGED SPEED > AUTOMATIC CLUTCH POSITION +SENSOR
5AJ	AUTOMATIC CLUTCH ENGAGED SPEED SENSOR +SIGNAL
5AK	ENGAGED SPEED > AUTOMATIC CLUTCH POSITION -SENSOR
5AL	BUZZER > AUTOMATIC CLUTCH COMPUTER CONTROL
5AN	AUTOMATIC CLUTCH POSITION SENSOR + SIGNAL
5AP	AUTOMATIC CLUTCH LEVER THRUST -SIGNAL
5AQ	AUTOMATIC CLUTCH SPEED LEVER PULL -SIGNAL
5AR	AUTOMATIC CLUTCH ACCELERATOR POSITION +SENSOR
5AS	AUTOMATIC CLUTCH ACCELERATOR POSITION SENSOR SIGNAL
5AT	AUTOMATIC CLUTCH ACCELERATOR POSITION -SENSOR
5AU	SEQUENCE +SOLENOID VALVE
5AV	SEQUENCE 1 SOLENOID VALVE - CONTROL
5AW	SEQUENCE 2 SOLENOID VALVE - CONTROL
5AX	SEQUENCE 3 SOLENOID VALVE - CONTROL
5AY	SEQUENCE 4 SOLENOID VALVE - CONTROL
5AZ	SEQUENCE 5 SOLENOID VALVE - CONTROL
5B	TRANSMISSION MODE SELECTION - CONTROL
5BA	MODULATION +SOLENOID VALVE
5BB	SEQUENCE 6 SOLENOID VALVE - CONTROL
5BC	""""PRESSURE 1 SOLENOID VALVE -"
5BD	""""PRESSURE 2 SOLENOID VALVE -"
5BE	PRESSURE 3 SOLENOID VALVE -
5BF	PRESSURE 3 SOLENOID VALVE CONTROL
5BG	1 REVERSE LIGHTS > MULTIFUNCTION SWITCH CONTROL
5BH	2 REVERSE LIGHTS > MULTIFUNCTION SWITCH CONTROL
5BJ	EVAPORATOR 3 CONTROL
5BK	VEHICLE SPEED SENSOR + SIGNAL
5BL	VEHICLE SPEED SENSOR - SIGNAL
5BM	(VOLVO) AUTOMATIC GEARBOX SPEED INFO
5BN	ECONOMY TRANSMISSION MODE SELECTION

List of connections

CONNECTION CODES	CONNECTION TITLE
5BR	ENGINE LOAD SIGNAL
5BS	IGNITION > AUTOMATIC GEARBOX + SOLENOID
5BT	PRESSURE 2 +SOLENOID VALVE
5BU	PRESSURE 2 SOLENOID VALVE CTRL
5BV	SPEED 1 CHANGE SOLENOID VALVE
5BW	SPEED CHANGE SOLENOID VALVE 2
5BX	BRIDGING MODULATION SOLENOID VALVE CONTROL
5BY	GEARBOX OIL TEMPERATURE -
5BZ	GEARBOX OIL TEMPERATURE +
5C	NO LOAD SWITCH - CONTROL
5CA	SPEED SENSOR +INPUT
5CB	SPEED SENSOR -INPUT
5CC	GEARBOX LOGIC LEVEL
5CD	GEARBOX B LOGIC LEVEL
5CE	GEARBOX C LOGIC LEVEL
5CF	MULTIFUNCTION SWITCH PARITY SWITCH
5CG	VOLVO BRAKE PEDAL SWITCH INFO
5CH	SAFETY > RELAY BATTERY +
5CI	AUTOMATIC CLUTCH FAULT WARNING LIGHT -CONTROL
5CJ	TORQUE 1 REDUCTION SIGNAL
5CK	TORQUE 2 REDUCTION SIGNAL
5CL	RETURN TORQUE REDUCTION SIGNAL
5CM	RELAYED AUTOMATIC GEARBOX BATTERIES +
5CN	AUTOMATIC GEARBOX FAULT > VOICE SYNTHESIS SIGNAL
5CQ	AUTOMATIC GEARBOX DISPLAY SIGNAL
5CR	AUTOMATIC GEARBOX PULSE 25 SIGNAL
5CS	ENGINE SPEED> TDC + SIGNAL
5CT	MOTOR SPEED > TDC SENSOR - SIGNAL
5CU	UNDERDRIVE INDICATOR
5CW	GEARBOX ACCELERATED IDLING CONTROL
5D	AUTOMATIC GEARBOX FAULT INDICATOR - CONTROL
5DA	GEARBOX ENTER SPEED SENSOR + SIGNAL
5DB	GEARBOX ENTER SPEED SENSOR - SIGNAL
5DC	NO LOAD SIGNAL
5DD	EXCHANGER FLOWMETER CONTROL SOLENOID VALVE +
5DE	NEUTRAL PARK SWITCH MULTIFUNCTION SWITCH - CONTROL
5DF	MULTIFUNCTION SWITCH 1 SIGNAL
5DG	MULTIFUNCTION SWITCH 2 SIGNAL
5DH	MULTIFUNCTION SWITCH 3 SIGNAL
5DJ	MULTIFUNCTION SWITCH 4 SIGNAL
5DK	MULTIFUNCTION > AUTOMATIC GEARBOX COMPUTER SWITCH -
5DL	MODULATION 3 SOLENOID VALVE CONTROL
5DM	MODULATION 4 SOLENOID VALVE CONTROL
5DN	EXCHANGER FLOWMETER CONTROL SOLENOID VALVE - CONTROL
5DP	1ST CONTROL > N-1 PULSE CONTROL
5DQ	ANTI-SKID SIGNAL
5DR	BRAKE PEDAL OPENING SWITCH SIGNAL
5DS	TORQUE > PULSE WIDTH MODULATION SIGNAL
5DT	SWITCH KEY LOCKING CONTROL
5DU	GEAR LEVER LOCKING - CONTROL
5DV	POLLUTION FAULT INDICATOR - CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
5DW	ENGAGED SPEED SENSOR + SIGNAL
5DX	AUTOMATIC CLUTCH CYLINDER POSITION SENSOR + SIGNAL
5DY	PARKING POSITION - CONTROL
5DZ	BRAKE PEDAL CLOSING SWITCH SIGNAL
5E	AUTOMATIC GEARBOX INDICATOR > AU GEARBOX FAULT CLEARANCE CONTROL
5EA	AUTOMATIC GEARBOX LIGHTING PARKING POSITION > MULTISELECTION SWITCH
5EB	AUTOMATIC GEARBOX LIGHTING WIPER BLADE POSITION > MULTISELECTION SWITCH
5EC	AUTOMATIC GEARBOX LIGHTING NEUTRAL POSITION > MULTISELECTION SWITCH
5ED	AUTOMATIC GEARBOX LIGHTING BRANCH POSITION > MULTISELECTION SWITCH
5EE	AUTOMATIC GEARBOX LIGHTING 3RD POSITION > MULTISELECTION SWITCH
5EF	AUTOMATIC GEARBOX LIGHTING 2ND POSITION > MULTISELECTION SWITCH
5EG	AUTOMATIC GEARBOX LIGHTING 1ST POSITION > MULTISELECTION SWITCH
5EH	AUTOMATIC GEARBOX LIGHTING COMMON > MULTISELECTION SWITCH
5EJ	AUTOMATIC CLUTCH LEVER PUSH > AUTOMATIC GEARBOX SHIFT PATTERN SIGNAL
5EK	AUTOMATIC CLUTCH LEVER PULL > GEARBOX ADHESION LOW STARTING SIGNAL
5F	AUTOMATIC GEARBOX DIAGNOSTIC SIGNAL
5FA	ENGAGED POSITION SENSOR SIGNAL
5FB	SELECTION POSITION SENSOR SIGNAL
5FC	SELECTION 1 SOLENOID VALVE CONTROL
5FD	SELECTION 2 SOLENOID VALVE CONTROL
5FE	ENGAGED 1 SOLENOID VALVE CONTROL
5FF	ENGAGED 2 SOLENOID VALVE CONTROL
5FG	CLUTCH SOLENOID VALVE CONTROL
5FH	AUTOMATIC MODE SWITCH SIGNAL
5FI	GEAR LEVER SWITCH -
5FJ	UPPER SWITCH PULSE MULTIFUNCTION SWITCH CONTROL
5FK	STAND-BY SWITCH PULSE MULTIFUNCTION SWITCH CONTROL
5FL	NEUTRAL SWITCH PULSE MULTIFUNCTION SWITCH CONTROL
5FM	LOWER SWITCH PULSE MULTIFUNCTION SWITCH CONTROL
5G	ECO-PERFORMANCE WARNING - LIGHT
5GA	ROBOTIC GEARBOX DISPLAY -
5GB	REVERSING LED SIGNAL
5GC	NEUTRAL LED SIGNAL
5GD	AUTOMATIC MODE LED SIGNAL
5GG	MANUAL MODE LED SIGNAL
5GH	SHIFT LOCK + SIGNAL
5GK	SELECTION 1 SWITCH SIGNAL
5GL	SELECTION 2 SWITCH SIGNAL
5GM	SELECTION 3 SWITCH SIGNAL
5GN	SELECTION 4 SWITCH SIGNAL
5GO	GEAR SELECTION ENGINE + CONTROL
5GP	GEAR SELECTION ENGINE - CONTROL
5GQ	ENGINE POSITION SENSOR 1 SIGNAL
5GR	ENGINE POSITION SENSOR -
5GS	ENGINE POSITION SENSOR +
5GT	CLUTCH + CONTROL
5GU	AUTOMATIC GEARBOX DISPLAY CANH SIGNAL
5GV	AUTOMATIC GEARBOX DISPLAY CANL SIGNAL
5GW	REVERSE LIGHTS RELAY CONTROL
5GX	ENGINE POSITION SENSOR 2 SIGNAL
5GY	ELECTRIC GEARBOX CONTROL SWITCH SENSOR +

List of connections

CONNECTION CODES	CONNECTION TITLE
5GZ	ELECTRIC GEARBOX CONTROL SWITCH SENSOR -
5H	N+1 PULSE SWITCH CONTROL
5HA	ELECTRIC GEARBOX ECU SUPPLY RELAY CONTROL
5J	INJECTION AUTOMATIC GEARBOX NEUTRAL PARK SIGNAL
5K	RETROSWITCH - CONTROL
5L	INJECTOR POTENTIOMETER + > AUTOMATIC GEARBOX COMPUTER
5LI	.
5M	INJECTOR POTENTIOMETER - > AUTOMATIC GEARBOX COMPUTER
5N	INJECTOR POTENTIOMETER > AUTOMAT GEARBOX COMPUTER SIGNAL
5P	LOW ADHERENCE > GEAR SELECTION PASSAGE - CONTROL
5Q	MODULATION SOLENOID VALVE CONTROL 1
5R	MODULATION SOLENOID VALVE CONTROL 2
5S	AIR CONDITIONING CONTROL RELAY - CONTROL
5SN	VEHICLE SPEED INPUT EARTH
5SP	VEHICLE SPEED + INPUT
5T	GEARBOX OUTPUT SPEED SENSOR +
5TA	GEARBOX OUTPUT SPEED SENSOR -
5U	LINE PRESSURE SENSOR +
5V	LINE PRESSURE SENSOR -
5W	LINE PRESSURE SENSOR + SIGNAL
5X	LOW TRACTION STARTING - CONTROL
5Y	LOW SPEED FAN RELAY TERMINAL 2
5Z	AUTOMATIC TRANSMISSION TORQUE REDUCTION CONTROL
5ZA	UNDERDRIVE CONTROL
5ZB	UNDERDRIVE SIGNAL
60A	EUROBAG FAULT INDICATOR LIGHT -
60AA	PASSENGER'S SIDE AIRBAG + SIGNAL
60AB	DRIVER'S SIDE AIRBAG + SIGNAL
60AC	DRIVER'S SIDE AIRBAG - SIGNAL
60AD	PASSENGER'S SIDE AIRBAG - SIGNAL
60AF	PASSENGER'S SIDE SATELLITE + SIGNAL
60AG	DRIVER'S SIDE FRONT SATELLITE + SIGNAL
60AH	DRIVER'S SIDE SATELLITE - SIGNAL
60AJ	PASSENGER'S SIDE FRONT SATELLITE - SIGNAL
60AK	DRIVER'S CHEST PRETENSIONER + CONTROL
60AL	DRIVER'S CHEST PRETENSIONER - CONTROL
60AM	DRIVER'S LEVEL 1 FRONTAL AIRBAG + CONTROL
60AN	DRIVER'S LEVEL 1 FRONTAL AIRBAG - CONTROL
60AP	DRIVER'S LEVEL 2 FRONTAL AIRBAG + CONTROL
60AQ	DRIVER'S LEVEL 2 FRONTAL AIRBAG - CONTROL
60AR	DRIVER'S CHEST SIDE AIRBAG + CONTROL
60AS	DRIVER'S CHEST SIDE AIRBAG - CONTROL
60AT	DRIVER'S HEAD SIDE AIRBAG + CONTROL
60AU	DRIVER'S HEAD SIDE AIRBAG - CONTROL
60AV	DRIVER'S SIDE REAR INERTIA REEL PRETENSIONER + CONTROL
60AW	DRIVER'S SIDE REAR INERTIA REEL PRETENSIONER - CONTROL
60AX	LEFT-HAND REAR SIDE AIRBAG + CONTROL
60AY	DRIVER'S SIDE REAR CHEST SIDE AIRBAG - CONTROL
60AZ	PASSENGER'S CHEST PRETENSIONER + CONTROL
60B	PASSENGER'S PRETENSIONER + SIGNAL
60BA	PASSENGER'S CHEST PRETENSIONER - CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
60BB	PASSENGER'S CHEST SIDE AIRBAG + CONTROL
60BC	PASSENGER'S CHEST SIDE AIRBAG - CONTROL
60BD	PASSENGER'S HEAD SIDE AIRBAG + CONTROL
60BE	PASSENGER'S HEAD SIDE AIRBAG - CONTROL
60BG	PASSENGER'S SIDE REAR INERTIA REEL PRETENSIONER + CONTROL
60BH	PASSENGER'S SIDE REAR INERTIA REEL PRETENSIONER - CONTROL
60BK	PASSENGER'S SIDE REAR CHEST SIDE AIRBAG + CONTROL
60BL	PASSENGER'S SIDE REAR SIDE AIRBAG - CONTROL
60BM	CHILD SEAT B PRESENCE SIGNAL
60BN	CHILD SEAT B ISOFIX PRESENCE - SIGNAL
60BP	DRIVER'S SEAT POSITION SIGNAL
60BQ	PASSENGER'S SEAT POSITION SIGNAL
60BR	AIRBAG COMPUTER IMPACT SIGNAL
60BS	RIGHT-HAND REAR PRETENSIONER 2 + CONTROL
60BT	RIGHT-HAND REAR PRETENSIONER 2 - CONTROL
60BU	LEFT-HAND REAR PRETENSIONER 2 + CONTROL
60BV	LEFT-HAND REAR PRETENSIONER 2 - CONTROL
60BW	CHILD SEAT A ISOFIX PRESENCE - SIGNAL
60BX	CHILD SEAT B PRESENCE SIGNAL
60BY	DRIVER'S HEAD CURTAIN AIRBAG + CONTROL
60BZ	DRIVER'S HEAD CURTAIN AIRBAG - CONTROL
60C	PASSENGER'S PRETENSIONER - SIGNAL
60CA	PASSENGER HEAD CURTAIN AIRBAG + CONTROL
60CB	PASSENGER HEAD CURTAIN AIRBAG - CONTROL
60CC	CHILD SEAT PRESENCE INDICATOR LIGHT CONTROL
60CD	AIRBAG INHIBITION INDICATOR LIGHT CONTROL
60CG	VEHICLE HIGH DECELERATION SIGNAL
60CH	PASSENGER SIDE FRONTAL SATELLITE + SIGNAL
60CK	PASSENGER SIDE FRONTAL SATELLITE - SIGNAL
60CL	DRIVER'S SEAT POSITION EARTH
60CM	DRIVER'S FRONT INERTIA REEL PRETENSIONER + CONTROL
60CN	DRIVER'S FRONT PRETENSIONER - CONTROL
60CP	PASSENGER'S INERTIA REEL PRETENSIONER + CONTROL
60CQ	PASSENGER'S FRONT INERTIA REEL PRETENSIONER - CONTROL
60D	DRIVER'S PRETENSIONER + SIGNAL
60E	DRIVER'S PRETENSIONER - SIGNAL
60F	DRIVER'S EUROBAG + SIGNAL
60G	DRIVER'S EUROBAG - SIGNAL
60H	PASSENGER 1 EUROBAG + SIGNAL
60K	LEVEL 1 PASSENGER FRONTAL AIRBAG - CONTROL
60L	LEVEL 2 PASSENGER FRONTAL EUROBAG + CONTROL
60M	LEVEL 2 PASSENGER FRONTAL EUROBAG - CONTROL
60N	PASSENGER SIDE SENSOR -
60P	PASSENGER SIDE SENSOR + SIGNAL
60Q	DRIVER'S SIDE SENSOR -
60R	LEFT-HAND PASSENGER AIRBAG IGNITER + SIGNAL
60S	LEFT-HAND PASSENGER AIRBAG IGNITER - SIGNAL
60T	RIGHT-HAND PASSENGER AIRBAG IGNITER + SIGNAL
60U	RIGHT-HAND PASSENGER AIRBAG IGNITER - SIGNAL
60V	PASSENGER EUROBAG + SIGNAL
60W	PASSENGER EUROBAG - SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
60X	PASSENGER'S PRETENSIONER + SIGNAL
60Y	PASSENGER'S PRETENSIONER - SIGNAL
60Z	DRIVER'S SIDE SENSOR + SIGNAL
63A	RIGHT HAND REGISTRATION PLATE + >
63B	LEFT HAND REGISTRATION PLATE + >
63C	LEFT-HAND REGISTRATION PLATE - CONTROL >
63D	RIGHT-HAND REGISTRATION PLATE - CONTROL >
63G	SIDE LIGHT FEED + > DRIVING SCHOOL SWITCH CONTROL
63H	REGISTRATION PLATE LIGHT > REAR SIDE LIGHT + CONTROL
63J	REGISTRATION PLATE LIGHT > REAR SIDE LIGHT - CONTROL
63K	LEFT-HAND REAR + SIDE LIGHT FEED > FEED UNIT
63L	RIGHT-HAND REAR + SIDE LIGHT FEED > FEED UNIT
63M	RIGHT-HAND FRONT + SIDE LIGHT FEED > FEED UNIT
63N	LEFT-HAND FRONT + SIDE LIGHT FEED > FEED UNIT
63Q	REGISTRATION PLATE LIGHT > FEED UNIT + CONTROL
64A	INDICATOR LIGHTS + CIRCUIT BREAKER
64AP	PROTECTED INDICATOR LIGHTS +
64B	TIMING > FLASHER UNIT TIMER + CONTROL
64C	LEFT-HAND INDICATOR LIGHTS CONTROL
64D	RIGHT-HAND INDICATOR LIGHTS CONTROL
64E	INDICATOR LIGHTS WARNING LIGHT + CONTROL
64F	HAZARD WARNING LIGHT + CONTROL
64G	INDICATOR LIGHTS > DRIVING SCHOOL SWITCH + CONTROL
64H	FLASHER - > MONITOR CONTROL
64J	HAZARD WARNING LIGHT - CONTROL
64K	FLASHER UNIT TIMING +
64N	CENTRAL FLASHER UNIT TIMER + CONTROL
64P	PROTECTED FLASHER +
64Q	CENTRAL FLASHER UNIT TIMER - CONTROL
64S	RIGHT-HAND FLASHER TIMER OPERATION CONTROL > COMPUTER
64T	LEFT-HAND FLASHER TIMER OPERATION CONTROL > COMPUTER
64U	RIGHT-HAND INDICATOR CONTROL
64V	LEFT-HAND INDICATOR CONTROL
65A	BRAKE LIGHTS + CONTROL
65B	RIGHT-HAND BRAKE > FEED UNIT + CONTROL
65C	LEFT-HAND BRAKE > FEED UNIT + CONTROL
65D	ADDITIONAL BRAKE LIGHT 1 > FEED UNIT + CONTROL
65E	ADDITIONAL BRAKE LIGHT 2 > FEED UNIT + CONTROL
65G	BRAKE LIGHTS CONTROL > RELAY
65H	BRAKE LIGHTS INDICATOR LIGHT CONTROL
66C	REVERSE LIGHTS FUSE + CONTROL
66D	REVERSE LIGHTS RELAY + CONTROL
67A	HORN + CONTROL
67B	ELECTRO-PNEUMATIC HORN + CONTROL > RELAY
67C	HORN FUSE + CONTROL
67CP	HORN > FUSE + CONTROL
67D	HORN RELAY CONTROL
67P	PROTECTED FUSE HORN +
67Q	PROTECTED BATTERY FEED + > COUNTERCHECK MARK POWER FUSE UNIT
67R	COUNTERCHECK MARK POWER UNIT -
67S	BLUE LIGHTS > POWER UNIT + CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
67T	ORANGE LIGHTS > POWER UNIT + CONTROL
67U	HORN MODULE > POWER UNIT + CONTROL
67V	BLUE LIGHTS - > POWER CONTROL
67W	RAMP LIGHTS > POWER UNIT + CONTROL
67X	HORN MODULE - > POWER UNIT
69A	REV COUNTER SIGNAL > ALTERNATOR
69B	REV COUNTER SIGNAL > INJECTION
70A	WHEEL INFLATION FAULT WARNING LIGHT CONTROL
70B	RADIO FREQUENCY TRANSMISSION SIGNAL UNDER TYRE PRESSURE
70C	FRONT LEFT-HAND TYRE PRESSURE MONITORING AERIAL SIGNAL 1
70D	FRONT LEFT-HAND TYRE PRESSURE MONITORING AERIAL SIGNAL 2
70G	FRONT RIGHT-HAND TYRE PRESSURE MONITORING AERIAL SIGNAL 1
70H	FRONT RIGHT-HAND TYRE PRESSURE MONITORING AERIAL SIGNAL 2
70K	TYRE PRESSURE MONITORING SERVICE INDICATOR LIGHT CONTROL
70L	TYRE PRESSURE MONITORING STOP INDICATOR LIGHT CONTROL
73A	CARBURETTOR PILLAR HEATER + > RELAY
73B	HEATER RELAY > TEMPERATURE SWITCH - CONTROL
73C	HEATER RELAY + CONTROL > RELAY
74A	ENGINE DEPOLLUTION MOTOR REDUCER > COMPUTER CONTROL
74B	ENGINE DEPOLLUTION MOTOR REDUCER - > COMPUTER
75A	EARTH > DECODER UNIT > DOOR OPENING
76A	DEGASSING WINDSCREEN WIPER > TIMER + CONTROL
77A	INTAKE HEATER RELAY COIL + CONTROL
77B	INTAKE HEATER + CONTROL
78A	DIPPED LIGHTS > RELAY + CONTROL
78B	SIDE LIGHTS FUSE + CONTROL
78C	DIPPED LIGHTS > RELAY + CONTROL
78D	DIPPED LIGHTS WARNING LIGHT + CONTROL
78G	MAIN RELAY CONTROL > EARTH > STARTING
78H	DAY/NIGHT RELAY CONTROL
78J	DAY RELAY SWITCH
78K	NIGHT RELAY SWITCH
78L	RUNNING LIGHTS CODE RELAY BATTERY +
78M	CODE RELAY COIL CONTROL
78N	LIGHTS RELAY COIL CONTROL
78P	LIGHTS RELAY LIGHTS CONTROL
78Q	CODE RELAY CODE CONTROL
79A	HEATED SEAT + CONTROL
79B	DRIVER'S HEATED SEAT + CONTROL
79C	PASSENGER'S HEATED SEAT + CONTROL
79F	HEATED SEAT WARNING LIGHT CONTROL
79G	PASSENGER'S HEATED SEAT WARNING LIGHT > IDENTIFICATION + CONTROL
79H	DRIVER IDENTIFICATION > DRIVER'S HEATED SEAT BUTTON + CONTROL
79I	PASSENGER IDENTIFICATION > PASSENGER'S HEATED SEAT BUTTON + CONTROL
79J	DRIVER'S HEATED SEAT WARNING LIGHT > IDENTIFICATION + CONTROL
79K	LEFT-HAND HEATED SEAT RELAY + CONTROL
79L	RIGHT-HAND HEATED SEAT RELAY + CONTROL
80A	BONNET SWITCH - SIGNAL
80AA	TRANSPONDER CODE - SIGNAL 1
80AB	TRANSPONDER CODE - SIGNAL 2
80AC	ULTRA-SOUND > ECU (M PLT) CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
80BA	SOFTWARE LOCK LED CONTROL
80BB	KEY PRESENCE
80BC	ELECTRIC STOP SOLENOID VALVE + > INERTIA SWITCH
80BD	VISUAL INFORMATION RELAY CONTROL > DOOR ELECTRIC LOCKING UNIT
80C	ULTRASOUND +
80CA	HIGH FREQUENCY OR ULTRA SOUND STOP
80D	ULTRA SOUND SENSOR SIGNAL
80DA	DRIVER'S SIDE FRONT ULTRA SOUND SENSOR INFO
80E	ALARM WARNING LIGHT CONTROL
80EA	ALARM VOLUMETRIC EXCLUSION
80F	ALARM SIREN CONTROL
80FA	COUNTERCHECK MARK SIREN +
80FB	COUNTERCHECK MARK SIREN -
80FC	SIREN CONTROL SUPPLY
80FD	SIREN RELAY CONTROL
80FE	GYRO-HEADLIGHT RELAY CONTROL
80FF	ORANGE LIGHT RELAY CONTROL
80G	ALARM STOP/START BUTTON SUPPLY
80H	ALARM SUPPLY > STOP/START CONTROL
80K	OPENING SIGNAL > ULTRASOUND
80L	CLOSING SIGNAL > ULTRASOUND
80M	LOGICAL OPENING SIGNAL
80N	LOGICAL CLOSURE SIGNAL
80P	DRIVER'S DOOR SWITCH SIGNAL
80Q	DOOR SWITCH - SIGNAL
80R	SIREN CUT-OUT SIGNAL 1
80S	SIREN CUT-OUT SIGNAL 2
80T	SOFTWARE LOCK WARNING LIGHT CONTROL
80U	ELECTRIC STOP SOLENOID VALVE + CONTROL > VRMT INTR RELAY
80V	SWITCH KEY SENSOR - SIGNAL
80W	TRANSPONDER AERIAL -
80X	TRANSPONDER AERIAL BUS SIGNAL
80Y	TRANSPONDER CLOCK SIGNAL
80Z	TRANSPONDER AERIAL +
85A	SUPPLY BY 4X4 SWITCH
85B	4X4 ELECTRIC + SIGNAL
85C	4X4 ELECTRIC - SIGNAL
86A	CRUISE CONTROL +
86B	ACCELERATION SIGNAL
86C	DECELERATION SIGNAL
86D	CLUTCH + SIGNAL
86E	OVERSPEED RELAY BRAKE SWITCH SUPPLY
86F	WARNING LIGHT + > SAFETY SOLENOID VALVE
86G	CRUISE CONTROL PROGRAMMING CONTROL
86H	BRAKE SWITCH SIGNAL
86J	ELECTRIC PUMP UNIT +
86K	DECELERATION - SIGNAL
86L	ACCELERATION - SIGNAL
86M	CRUISE CONTROL PROGRAMMING RETURN SIGNAL
86N	SPEED REGULATOR COMPUTER IGNITION > CRUISE CONTROL STOP SWITCH
86Q	CRUISE CONTROL PROGRAMMING CONTROL RETURN

List of connections

CONNECTION CODES	CONNECTION TITLE
86R	RIVET DIESEL STOP
86S	CRUISE CONTROL INTERFACE STOP SWITCH SIGNAL
86T	CRUISE CONTROL INTERFACE PROGRAMMING RETURN SIGNAL
86U	CRUISE CONTROL INTERFACE SPEED PROGRAMMING SIGNAL
87A	LEFT-HAND REAR NOTCH 1 SWITCH - SIGNAL
87B	RIGHT-HAND REAR NOTCH 1 SWITCH - SIGNAL
87C	VOICE SYNTHESIZER SPEAKER + SIGNAL
87D	VOICE SYNTHESIZER SPEAKER - SIGNAL
87E	VOICE SYNTHESIZER TEST > VOICE SYNTHESIZER CONTROL - SIGNAL
87F	RADIO CUT-OUT VOICE SYNTHESIZER SIGNAL
87G	PASSENGER NOTCH 1 SWITCH - SIGNAL
87H	DRIVER NOTCH 1 SWITCH - SIGNAL
87J	BULB FAULT SIGNAL
87K	LEFT-HAND BRAKE LIGHTS FAULT SIGNAL
87L	RIGHT-HAND BRAKE LIGHTS FAULT SIGNAL
87M	VOICE SYNTHESIZER MESSAGE REPETITION - CONTROL
87N	VOICE SYNTHESIZER CUT-OUT - CONTROL
87Q	LINE B HEATER REGULATION
87R	BONNET NOTCH 1 SWITCH - SIGNAL
87S	TEMPERATURE REGULATION SIGNAL
87T	REAR LUGGAGE COMPARTMENT DOOR NOTCH 1 SWITCH SIGNAL
87U	CENTRAL BRAKE LIGHTS FAULT SIGNAL
87V	ENGINE OIL LEVEL MINIMUM SIGNAL
87W	COVER MODULE NOTCH 1 SWITCH SIGNAL
88A	+ START/STOP UNIT MEMORY
88AA	FRONT BOOSTER POTENTIOMETER SIGNAL
88AB	REAR BOOSTER POTENTIOMETER SIGNAL
88AC	HEADREST POTENTIOMETER SIGNAL
88AD	SEAT BACK MEMORY MOTOR CONTROL
88AE	SEAT SIDES MEMORY MOTOR CONTROL
88AF	FRONT BOOSTER MOTOR CONTROL
88AG	REAR BOOSTER MOTOR CONTROL
88AH	HEAD REST MOTOR CONTROL
88AJ	COLUMN MOTOR CONTROL
88AK	COLUMN POTENTIOMETER SIGNAL
88AL	COLUMN POTENTIOMETER -
88AM	REAR VIEW MIRROR MOTOR COMMON CONTROL
88AN	REAR VIEW MIRROR POTENTIOMETER + COMMON
88AQ	PASSENGER REAR VIEW MIRROR TOP/BOTTOM POSITION CONTROL
88AR	PASSENGER REAR VIEW MIRROR LEFT/RIGHT POSITION CONTROL
88AS	PASSENGER REAR VIEW MIRROR LEFT/RIGHT POTENTIOMETER SIGNAL
88AT	PASSENGER REAR VIEW MIRROR TOP/BOTTOM POTENTIOMETER SIGNAL
88AU	DRIVER'S REAR VIEW MIRROR LEFT/RIGHT POTENTIOMETER SIGNAL
88AV	DRIVER'S REAR VIEW MIRROR TOP/BOTTOM POTENTIOMETER SIGNAL
88AW	DRIVER'S REAR VIEW MIRROR LEFT/RIGHT POSITION MOTOR CONTROL
88AX	DRIVER'S REAR VIEW MIRROR TOP/BOTTOM POSITION MOTOR CONTROL
88AY	DRIVER'S REAR VIEW MIRROR POTENTIOMETER - COMMON
88AZ	DRIVER'S MEMORY REAR VIEW MIRROR TOP/BOTTOM CONTROL
88B	SEAT SIDES CONTROL > MEMORY
88BA	REAR VIEW MIRROR MEMORY COMMON CONTROL
88BB	REAR VIEW MIRROR POTENTIOMETER - COMMON

List of connections

CONNECTION CODES	CONNECTION TITLE
88BC	REAR VIEW MIRROR NON-MEMORY COMMON CONTROL
88BF	MEMORY CONTROL 1
88BG	MEMORY CONTROL 3
88BH	MEMORY CONTROL
88BJ	SEAT BOOSTER TOP MEMORY CONTROL
88BK	SEAT BOOSTER BOTTOM MEMORY CONTROL
88BL	BOOSTER POTENTIOMETER SIGNAL
88BM	BOOSTER MOTOR CONTROL
88BN	REAR-VIEW MIRROR > COLUMN POTENTIOMETER COMMON +
88BQ	REAR-VIEW MIRROR > COLUMN POTENTIOMETER COMMON -
88BR	SWITCH - 1
88BS	SWITCH - 2
88BT	SWITCH - 3
88BU	REAR VIEW MIRROR MOVEMENT INHIBITION > COLUMN CONTROL
88BV	COLUMN COMMON MOTOR
88BW	DOOR MULTI-PLEXING CANH SIGNAL
88BX	DOOR MULTI-PLEXING CANL SIGNAL
88BY	DRIVER'S FOLDING REAR VIEW MIRROR MOTOR CONTROL
88BZ	PASSENGER FOLDING REAR VIEW MIRROR MOTOR CONTROL
88C	SEAT SIDES MEMORY REAR CONTROL
88CA	DRIVER'S REAR VIEW MIRROR COMMON MOTOR
88CB	PASSENGER'S REAR VIEW MIRROR COMMON MOTOR
88CC	DRIVER > PASSENGER FOLDING REAR VIEW MIRROR SIGNAL
88CD	COMMON FOLDING REAR VIEW MIRROR
88CG	MEMORISED SEAT SERIAL LINE SIGNAL
88D	SEAT BACK MEMORY FRONT CONTROL
88E	SEAT BACK MEMORY REAR CONTROL
88F	SEAT BOOSTER TOP FRONT MEMORY CONTROL
88G	SEAT BOOSTER BOTTOM FRONT MEMORY CONTROL
88H	SEAT BOOSTER TOP REAR MEMORY CONTROL
88J	SEAT BOOSTER BOTTOM REAR MEMORY CONTROL
88K	SEAT HEAD-REST TOP MEMORY CONTROL
88L	SEAT HEAD-REST BOTTOM MEMORY CONTROL
88M	STEERING WHEEL MEMORY FRONT CONTROL
88N	STEERING WHEEL MEMORY REAR CONTROL
88Q	COMMON MEMORY CONTROL
88R	PASSENGER REAR VIEW MIRROR > MEMORY 1 LEFT>RIGHT CONTROL
88S	MEMORY CONTROL 2
88T	DRIVER'S REAR VIEW MIRROR > MEMORY 3 LEFT>RIGHT CONTROL
88U	PASSENGER'S REAR VIEW MIRROR > MEMORY TOP>BOTTOM CONTROL
88V	SEAT MOTOR COMMON CONTROL
88W	SEAT MEMORY POTENTIOMETER +
88X	SEAT MEMORY POTENTIOMETER -
88Y	SEAT SIDES MEMORY POTENTIOMETER SIGNAL
88Z	SEAT BACK MEMORY POTENTIOMETER SIGNAL
89A	RIGHT-HAND FRONT SHOCK ABSORBER MOTOR + CONTROL
89B	LEFT-HAND REAR SHOCK ABSORBER MOTOR + CONTROL
89BA	VARIABLE SHOCK ABSORBER LEFT-HAND FRONT N SOLENOID VALVE CONTROL
89BC	BETWEEN VARIABLE SHOCK ABSORBER STEERING WHEEL ANGLE
89C	LEFT-HAND FRONT SHOCK ABSORBER MOTOR + CONTROL
89D	RIGHT-HAND REAR SHOCK ABSORBER MOTOR + CONTROL

List of connections

CONNECTION CODES	CONNECTION TITLE
89DA	STEERING WHEEL ANGLE 1 POTENTIOMETER SIGNAL
89DB	STEERING WHEEL ANGLE 2 POTENTIOMETER SIGNAL
89E	RIGHT-HAND REAR SHOCK ABSORBER A SIGNAL
89F	RIGHT-HAND REAR SHOCK ABSORBER B SIGNAL
89G	LEFT-HAND FRONT SHOCK ABSORBER A SIGNAL
89H	LEFT-HAND FRONT SHOCK ABSORBER B SIGNAL
89J	LEFT-HAND REAR SHOCK ABSORBER A SIGNAL
89K	VARIABLE SHOCK ABSORBER SERVICE WARNING LIGHT - CONTROL
89M	RIGHT-HAND FRONT AMTR SIGNAL
89N	RIGHT-HAND FRONT SHOCK ABSORBER B SIGNAL
89Q	SPORT DISTRIBUTION CONTROL > AUTOMATIC
89R	LEFT-HAND REAR > RIGHT-HAND FRONT MOTOR COMMON -
89S	RIGHT-HAND REAR > LEFT-HAND FRONT MOTOR COMMON -
89T	TRANSVERSE ACCELEROMETER SIGNAL
89U	LEFT-HAND REAR SHOCK ABSORBER B SIGNAL
89V	VERTICAL ACCELERATOR SIGNAL
89W	ACCELEROMETER + > STEERING WHEEL ANGLE
89X	- ACCELEROMETER > STEERING WHEEL ANGLE
89Y	VARIABLE SHOCK ABSORBER RIGHT-HAND FRONT SOLENOID VALVE SUPPLY
89Z	VARIABLE SHOCK ABSORBER RIGHT-HAND REAR SOLENOID VALVE SUPPLY
8A	FOG LIGHTS RELAY +
8B	FRONT FOG LIGHTS + > RELAY
8C	FRONT FOG LIGHTS - RELAY
8D	FRONT FOG LIGHTS CIRCUIT CUT-OUT + > WARNING LIGHT
8DP	FRONT FOG LIGHTS FUSE PROTECTED +
8E	LEFT-HAND FRONT FOG LIGHT + > RESISTANCE
8F	RIGHT-HAND FRONT FOG LIGHT + > RESISTANCE
8GP	FRONT FOG LIGHTS FUSE PROTECTED + RESISTANCE
8H	FRONT FOG LIGHTS > COMPUTER + CONTROL
92A	RIGHT-HAND REAR SEATBACK +
92B	RIGHT-HAND REAR SEATBACK -
92C	LEFT-HAND REAR SEATBACK +
92D	LEFT-HAND REAR SEATBACK -
96A	SEATBELT WARNING LIGHT - CONTROL
96B	DOOR OPEN WARNING LIGHT - CONTROL
96C	SEATBELT WARNING LIGHT +
96D	OPENING WARNING LIGHT CONTROL > INSTRUMENT PANEL
96G	PASSENGER SEATBELT SIGNAL
97A	OVERSPEED WARNING LIGHT > RELAY - CONTROL
97C	OVERSPEED HORN + SUPPLY
99A	CONTROL CABINET UNLOCKING CONTROL
99B	REAR PARTITION VENTILATOR +
99C	RESERVED WARNING LIGHT + CONTROL
99D	RESERVED WARNING LIGHT - CONTROL
99E	BATTER CUT-OUT RESETTING RELAY - CONTROL
99G	PASSENGER LIGHT + CONTROL
99H	+ > BATTERY CUT-OUT RELAY
99J	SIGNALLING BRIDGE LIGHT +
99K	LEFT-HAND EXPLODED LIGHT +
99L	GYRO LIGHT +
99M	LEFT-HAND ORANGE LIGHT +

List of connections

CONNECTION CODES	CONNECTION TITLE
99N	RIGHT-HAND ORANGE LIGHT +
99P	LEFT-HAND SIDE LIGHT +
99Q	RIGHT-HAND SIDE LIGHT +
99R	FRONT LIGHT +
99S	RIGHT-HAND EXPLODED LIGHT +
9A	REAR FOG LIGHT RELAY + CONTROL
9B	REAR FOG LIGHTS + CONTROL
9C	REAR FOG LIGHTS INDICATOR LIGHT + CONTROL
9D	REAR FOG LIGHTS FUSE > RELAY + CONTROL
9DP	REAR FOG LIGHTS FUSE PROTECTED +
9F	FOG LIGHTS CONTROL > FOG LIGHTS RNIT RELAY COIL IGNITION
9G	LIGHTS ON REMINDER BUZZER > CATHODE DIODE
9J	REAR FOG LIGHTS FUSE + CONTROL
9M	SHUNT
9M1	SOFTWARE LOCKING SHUNT
9M2	INTER LIGHTING SHUNT
9P	PROTECTED REAR FOG LIGHTS + CONTROL
9Q	REAR FOG LIGHTS RETURN
9S	LEFT-HAND REAR FOG LIGHTS + CONTROL
9T	RIGHT-HAND REAR FOG LIGHTS + CONTROL
9U	RIGHT-HAND REAR FOG LIGHTS - CONTROL
9V	LEFT-HAND REAR FOG LIGHTS - CONTROL
A	+ AFTER IGNITION FEED
A1	ELECTRIC WINDOW > RELAY + AFTER IGNITION FEED
A2	GAS RECIRCULATION SOLENOID VALVE BEFORE AFTER TIMER FUSE + AFTER IGNITION FEED
A3	+ AFTER IGNITION FEED
ABP*	UNALLOCATED FINAL DRIVE UNIT OR + AFTER IGNITION FEED
ABP1	LH REAR>LH REAR ELECTR WINDOW SHUNT>PROTECTED BATTERY OR + AFTER IGNITION FEED
ABP2	RH RR > RHD RR ELECTR WINDOW SHUNT>PROTECTED BATTERY OR + AFTER IGNITION FEED
ABP3	SUNROOF SHUNT > PROTECTED BATTERY OR + AFTER IGNITION FEED
ABP4	LEFT-HAND FRONT RIGHT-HAND FRONT ELECTRIC WINDOW > BATTERY OR AFTER IGNITION
ABP5	LEFT-HAND REAR RIGHT-HAND REAR ELECTRIC WINDOW > BATTERY OR AFTER IGNITION
AP*	UNALLOCATED PROTECTED + AFTER IGNITION FEED
AP1	LH REAR > LEFT-HAND FRONT ELECTRIC WINDOW FUSE PROTECTED + AFTER IGNITION FEED
AP10	BRAKE LIGHT FUSE PROTECTED + AFTER IGNITION FEED
AP11	REVERSE LIGHTS FUSE PROTECTED + AFTER IGNITION FEED
AP12	HEATED REAR SCREEN FUSE PROTECTED + AFTER IGNITION FEED
AP13	FAN CONVERTER > FUSE > PROTECTED + AFTER IGNITION FEED
AP14	HEATER + AFTER IGNITION FEED
AP15	ENGINE FUNCTION FUSE PROTECTED + AFTER IGNITION FEED
AP16	SUNROOF FUSE PROTECTED + AFTER IGNITION FEED
AP17	INJECTION SIMULATOR FUSE PROTECTED + AFTER IGNITION FEED
AP18	PASSENGER SEAT FUSE PROTECTED + AFTER IGNITION FEED
AP19	LEFT-HAND REAR SEAT FUSE PROTECTED + AFTER IGNITION FEED
AP1B	AFTER IGNITION RELAY NORMALLY CLOSED SWITCH > + AFTER IGNITION FEED
AP2	RH REAR > RH FRONT ELECTRIC WINDOW FUSE PROTECTED + AFTER IGNITION FEED
AP20	RIGHT-HAND REAR SEAT FUSE PROTECTED + AFTER IGNITION FEED
AP21	LEVEL CORRECTOR FUSE PROTECTED + AFTER IGNITION FEED
AP22	HEATED SEAT FUSE PROTECTED + AFTER IGNITION FEED
AP23	VARIABLE POWER ASSISTED STEERING FUSE PROTECTED + AFTER IGNITION FEED
AP24	FRONT PASSENGER SEAT FUSE PROTECTED + AFTER IGNITION FEED

List of connections

CONNECTION CODES	CONNECTION TITLE
AP25	AIR BAG FUSE PROTECTED + AFTER IGNITION FEED
AP26	BRAKE LIGHT FUSE PROTECTED + AFTER IGNITION FEED
AP27	WINDSCREEN WIPER PARK POSITION FUSE PROTECTED + AFTER IGNITION FEED
AP28	FAN UNIT FUSE PROTECTED + AFTER IGNITION FEED
AP29	SAFETY ENGINE FUNCTION FUSE PROTECTED + AFTER IGNITION FEED
AP3	HEATED REAR SCREEN FUSE CONTROL PROTECTED + AFTER IGNITION FEED
AP30	PASSENGER ELECTRIC WINDOW PROTECTED + AFTER IGNITION FEED
AP31	LIQUEFIED PETROLEUM GAS COMPUTER FUSE PROTECTED + AFTER IGNITION FEED
AP32	RIGHT-HAND REAR ELECTRIC WINDOW FUSE PROTECTED + AFTER IGNITION FEED
AP33	LEFT-HAND REAR ELECTRIC WINDOW FUSE PROTECTED + AFTER IGNITION FEED
AP34	PASSENGER ELECTRIC SEAT FUSE PROTECTED + AFTER IGNITION FEED
AP35	CONTROLLED CLUTCH RELAY FUSE PROTECTED + AFTER IGNITION FEED
AP36	ELECTRIC SEAT FUSE PROTECTED + AFTER IGNITION FEED
AP37	DIESEL HEATER FUSE PROTECTED + AFTER IGNITION FEED
AP38	ADDITIONAL BATTERY COMPUTER FUSE PROTECTED + AFTER IGNITION FEED
AP39	DRIVER'S ELECTRIC WINDOW PROTECTED + AFTER IGNITION FEED
AP3A	RIGHT-HAND REAR SCREEN FUSE CONTROL PROTECTED + AFTER IGNITION FEED
AP3B	RIGHT-HAND REAR SCREEN FUSE CONTROL PROTECTED + AFTER IGNITION FEED
AP4	AUTOMATIC TRANSMISSION FUSE PROTECTED + AFTER IGNITION FEED
AP40	ACCESSORIES FUSE PROTECTED + AFTER IGNITION FEED
AP41	AIR CONDITIONING COMPUTER FUSE PROTECTED + AFTER IGNITION FEED
AP42	ELECTRIC RELAY FUSE UNIT > BRAKE FUSE PROTECTED + AFTER IGNITION FEED
AP43	PROTECTED FUSE + AFTER IGNITION FEED
AP44	ELECTRIC POWER ASSISTED STEERING ECU FUSE PROTECTED + AFTER IGNITION FEED
AP5	ABS FUSE PROTECTED + AFTER IGNITION FEED
AP51	ALTIMETRIC CONNECTOR FUSE PROTECTED + AFTER IGNITION FEED
AP5A	ANTI-LOCK BRAKING SYSTEM FUSE PROTECTED + AFTER IGNITION FEED
AP6	DRIVING ASSISTANCE FUSE PROTECTED + AFTER IGNITION FEED
AP7	WINDSCREEN WIPER FUSE PROTECTED + AFTER IGNITION FEED
AP71	WINDSCREEN WIPER FUSE PROTECTED + AFTER IGNITION FEED NUMBER 2
AP8	CIGAR LIGHTER FUSE PROTECTED + AFTER IGNITION FEED
AP9	FUSE PROTECTED + AFTER IGNITION FEED ?
APCB	NORMALLY CLOSED SWITCH STEERING COL LOCK FUSE / PROTECTED + AFTER IGNITN FEED
APR1	RELAY 1 AFTER IGNITION
APR2	RELAY 2 AFTER IGNITION
APS	PROTECTED + AFTER IGNITION FEED > MINIFUSE SHUNT
	+ AFTER IGNITION > RELAY
AR1	GAS RECIRCULTN SOLENOID VALVE BEFORE AFTER TIMER RELAY > + AFTER IGNITN FEED
B	BATTERY + FEED
B1	BATTERY + FEED > CIRCUIT CUT-OUT
B1P1	COURTESY LIGHT FUSE CIRCUIT CUT-OUT > PROTECTED BATTERY + FEED
B1P2	MONITOR FUSE CIRCUIT CUT-OUT > PROTECTED BATTERY + FEED
B1P3	BATTERY 1 VOLTAGE CONTROL FUSE > PROTECTED BATTERY + FEED
B2	MONITOR UNIT > BATTERY + FEED
BA	ADDITIONAL BATTERY + FEED
BAP	PROTECTED ADDITIONAL BATTERY + FEED
BAP1	BATTERY 2 VOLTAGE CONTROL PROTECTED ADDITIONAL BATTERY + FEED
BAPA	ANODE PROTECTED ADDITIONAL BATTERY + FEED
BC	CIRCUIT CUT-OUT BY RELAY BATTERY + FEED
BCP*	UNALLOCATED PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCP1	FRONT FOG LIGHTS RELAY PROTECTED CIRCUIT CUT-OUT BATTERY + FEED

List of connections

CONNECTION CODES	CONNECTION TITLE
BCP2	FOG LIGHTS CONTROL FUSE PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCP3	COURTESY LIGHT FUSE PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCP4	MEMORY FUSE PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCP5	DECODER FUSE PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCP6	FRONT ALARM FUSE PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCP7	CAR PHONE FUSE PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCP8	FAN UNIT CONTROL FUSE PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCP9	CD + K7 FUSE PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCPA	LEFT-HAND COURTESY LIGHTS > PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCPB	TRANSPONDER > PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCPC	LEVEL CORRECTOR FUSE PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCPD	FUSE PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BCPG	TAILGATE COMPUTER > PROTECTED CIRCUIT CUT-OUT BATTERY + FEED
BLF1	HEATED WINDSCREEN FUSE LINE PROTECTED BATTERY + FEED
BP*	UNALLOCATED PROTECTED BATTERY + FEED
BP1	AIR CONDITIONING > PROTECTED BATTERY + FEED
BP10	DIAGNOSTIC SOCKET > PROTECTED BATTERY + FEED
BP11	PASSENGER COMPARTMENT 1 > PROTECTED BATTERY + FEED
BP12	PASSENGER COMPARTMENT 2 > PROTECTED BATTERY + FEED
BP13	PASSENGER COMPARTMENT 3 > PROTECTED BATTERY + FEED
BP14	ANTI-LOCK BRAKING SYSTEM > PROTECTED BATTERY + FEED
BP15	HEATED REAR SCREEN PROTECTED BATTERY + FEED
BP16	ADDITIONAL HEADLIGHT > PROTECTED BATTERY + FEED
BP17	INJECTION PREHEATING > PROTECTED BATTERY + FEED
BP18	HEATED WINDSCREEN > PROTECTED BATTERY + FEED
BP19	CENTRAL FLASHER UNIT TIMER > PROTECTED BATTERY + FEED
BP2	FRONT WIPER PARK POSITION PROTECTED BATTERY + FEED
BP20	HEADLIGHT WASHER PROTECTED BATTERY + FEED
BP21	ENGINE FAN ASSEMBLY 2 FUSE PROTECTED BATTERY + FEED
BP22	LEVEL CORRECTOR PROTECTED BATTERY + FEED
BP23	PASSENGER COMPARTMENT 4 PROTECTED BATTERY + FEED
BP24	DRIVER'S SEAT PROTECTED BATTERY + FEED
BP25	REAR SCREEN WIPER PROTECTED BATTERY + FEED
BP26	CAR PHONE PROTECTED BATTERY + FEED
BP27	ENGINE FUNCTION > PROTECTED BATTERY + FEED
BP28	LEVEL CORRECTOR FUSE PROTECTED BATTERY + FEED
BP29	CLOCK PROTECTED BATTERY + FEED
BP3	ELECTRIC DOOR LOCKING PROTECTED BATTERY + FEED
BP30	INTEGRAL IGNITION POWER MODULE SUPPLY PROTECTED BATTERY + FEED
BP31	FUEL PUMP > INJECTOR FUSE PROTECTED BATTERY + FEED
BP32	HORN FUSE PROTECTED BATTERY + FEED
BP33	LIQUEFIED PETROLEUM GAS FUSE PROTECTED BATTERY + FEED
BP34	DECODER PROTECTED BATTERY + FEED
BP35	PREHEATING UNIT FUSE PROTECTED BATTERY + FEED
BP36	CONTROLLED CLUTCH PUMP ASSEMBLY > PROTECTED BATTERY + FEED
BP37	LOCKING > INJECTOR MEMORY > PROTECTED BATTERY + FEED
BP38	INJECTOR LOCKING > PROTECTED BATTERY + FEED
BP39	CONTROLLED CLUTCH COMPUTER > PROTECTED BATTERY + FEED
BP3A	ELECTRIC DOOR LOCKING FUSE PROTECTED BATTERY + FEED
BP4	HEATED REAR SCREEN FUSE PROTECTED BATTERY + FEED
BP40	ODYSLINE FUSE PROTECTED BATTERY + FEED

List of connections

CONNECTION CODES	CONNECTION TITLE
BP41	AIR PUMP > PROTECTED BATTERY + FEED
BP42	AUTOMATIC TRANSMISSION COMPUTER > PROTECTED BATTERY + FEED
BP43	COMPUTER > PROTECTED BATTERY + FEED
BP44	INJECTOR POWER > PROTECTED BATTERY + FEED
BP45	AUTOMATIC TRANSMISSION COMPUTER SUPPLY > PROTECTED BATTERY + FEED
BP46	L7Y INJECTION POWER > PROTECTED BATTERY + FEED
BP47	TOWING > PROTECTED BATTERY + FEED
BP48	ELECTRIC WINDOW > PROTECTED BATTERY + FEED
BP49	MULTIFUNCTION TIMER > PROTECTED BATTERY + FEED
BP5	SLIDING SUNROOF > PROTECTED BATTERY + FEED
BP50	DRIVING SCHOOL CONTROL FUSE PROTECTED BATTERY + FEED
BP51	BONNET > PROTECTED BATTERY + FEED
BP52	DIESEL FUSE PROTECTED BATTERY + FEED
BP53	CONTROLLED SUSPENSION > PROTECTED BATTERY + FEED
BP54	FRONT FOG LIGHTS FUSE PROTECTED BATTERY + FEED
BP55	DRIVER'S ONE TOUCH WINDOW FUSE PROTECTED BATTERY + FEED
BP56	COMPUTER > FUSE PROTECTED BATTERY + FEED
BP57	COMPUTER B > FUSE PROTECTED BATTERY + FEED
BP58	DISPLAY FUSE PROTECTED BATTERY + FEED
BP59	ELECTRIC DOOR FUSE PROTECTED BATTERY + FEED
BP6	COURTESY LIGHTS > PROTECTED BATTERY + FEED
BP60	POLICE SUN VISOR FUSE PROTECTED BATTERY + FEED
BP61	BLUE LIGHTS FUSE PROTECTED BATTERY + FEED
BP62	ORANGE LIGHTS FUSE PROTECTED BATTERY + FEED
BP63	GYRO SIREN CONTROL FUSE PROTECTED BATTERY + FEED
BP64	COUNTERCHECK MARK RADIO FUSE PROTECTED BATTERY + FEED
BP65	COUNTERCHECK MARK SIREN RELAY > PROTECTED BATTERY + FEED
BP66	COUNTERCHECK MARK GYRO RELAY > PROTECTED BATTERY + FEED
BP67	PORTABLE INFO FUSE PROTECTED BATTERY + FEED
BP68	RECEPTION TRANSMISSION UNIT FUSE PROTECTED BATTERY + FEED
BP69	COMPUTER > INSTRUMENT PANEL > PROTECTED BATTERY + FEED
BP7	FAN UNIT FUSE 1 > PROTECTED BATTERY + FEED
BP70	PASSENGER'S ONE TOUCH WINDOW FUSE PROTECTED BATTERY + FEED
BP71	FAN UNIT FUSE 2 > PROTECTED BATTERY + FEED
BP72	FAN UNIT FUSE 3 > PROTECTED BATTERY + FEED
BP73	FAN UNIT FUSE PROTECTED BATTERY + FEED
BP74	PASSENGER COMPARTMENT FAN UNIT FUSE PROTECTED BATTERY + FEED
BP75	ALARM FUSE > PROTECTED BATTERY + FEED
BP76	LIGHTING CONTROL > PROTECTED BATTERY + FEED
BP77	PASSENGER COMPARTMENT COMPUTER > PROTECTED BATTERY + FEED
BP78	FRONT LIGHTS CLUSTER RELAY > PROTECTED BATTERY + FEED
BP79	ELECTR RELAY FUSE UNIT > PASSENGER COMPARTMNT FUSE 1 PROTECTED BATTERY + FEED
BP8	ANTI-LOCK BRAKING SYSTEM MOTOR > PROTECTED BATTERY + FEED
BP80	ELECTR RELAY FUSE UNIT > PASSENGER COMPARTMENT FUSE 2 PROTECTED BATTERY + FEED
BP81	ELECTRIC POWER ASSISTED STEERING > PROTECTED BATTERY + FEED
BP82	COMPUTER 36 VOLT BATTERY FUSE PROTECTED BATTERY + FEED
BP83	COMPUTER 12 VOLT BATTERY FUSE PROTECTED BATTERY + FEED
BP84	NON BATTERY VOLTAGE ADIVI COMPUTER FUSE PROTECTED BATTERY + FEED
BP85	ALT STARTER POWER 36 VOLT FUSE PROTECTED + BATT FEED BUILT INTO STEERING WHEEL
BP86	AIR CONDITIONING COMPRESSOR FUSES > PROTECTED BATTERY + FEED
BP87	REAR ELECTRIC WINDOWS FUSE PROTECTED BATTERY + FEED

List of connections

CONNECTION CODES	CONNECTION TITLE
BP9	ADDITIONAL HEATING FUSE PROTECTED BATTERY + FEED
BP91	ADDITIONAL HEATING FUSE PROTECTED BATTERY + FEED
BP92	ADDITIONAL HEATING FUSE 3 PROTECTED BATTERY + FEED
BPDA	ALTERNATOR START > PROTECTED BATTERY + FEED
BPP	MAIN PROTECTED BATTERY + FEED
BPP1	CENTRAL CLOCK > MAIN BATTERY + FEED
BPP2	INTER HAZARD LIGHTS > MAIN BATTERY + FEED
BPR1	RELAY > BATTERY + FEED
BPS1	SAFETY PROTECTED BATTERY + FEED
BPT	TIMER PROTECTED BATTERY + FEED
BPT2	TIMED LIGHTING PROTECTED BATTERY + FEED
BUS	TAILGATE COMPUTER > PASSENGER COMPARTMENT COMPUTER SIGNAL
BUSH	PASSENGER COMPARTMENT COMPUTER > INSTRUMENT PANEL H SIGNAL
BUSL	PASSENGER COMPARTMENT COMPUTER > INSTRUMENT PANEL L SIGNAL
C	DIPPED HEADLIGHTS +
CANH	FAULT FINDING SIGNAL CAN H
CANK	FAULT FINDING SIGNAL CAN K
CANL	FAULT FINDING SIGNAL CAN L
CC	DIPPED HEADLIGHTS SWITCH MONITOR CONTROL +
CDO	DUAL LENS DIPPED HEADLIGHTS +
CL	SIDE LIGHTS SWITCH MONITOR CONTROL +
CP	MAIN BEAM HEADLIGHTS SWITCH MONITOR CONTROL +
CP*	DIPPED HEADLIGHTS UNALLOCATED PROTECTED +
CPD	DIPPED HEADLIGHT RIGHT-HAND PROTECTED +
CPG	DIPPED HEADLIGHT LEFT-HAND PROTECTED +
CPGA	DIPPED HEADLIGHTS LEFT-HAND PROTECTED + > DISCHARGE BULB COMPUTER
CSO	SINGLE LENS DIPPED HEADLIGHT +
D	STARTING +
FM	DEAD WIRE
H1	BRAKE FLUID LEVEL > HAND BRAKE WARNING LIGHT - CONTROL
H11	PREHEATING > INJECTION WARNING LIGHT - CONTROL
H12	ANTI-LOCK BRAKING SYSTEM CONNECTION>BRAKE FLUID LEVEL WARNING LIGHT - CONTROL
H13	VISUAL > AUTOMATIC TRANSMISSION PARK > INJECTOR RESETTING SIGNAL
H14	MINIMUM FUEL > DRIVING ASSISTANCE GAUGE SIGNAL
H15	GEARBOX AIR CONDITIONING CUT-OUT > AIR CONDITIONING CUT-OUT SIGNAL
H16	BITRON UNIT > TEMPERATURE SWITCH SIGNAL
H17	SOFTWARE LOCKING > DIESEL > FUEL INJECTION CODE SIGNAL
H171	LOCKING EQUIPMENT SIGNAL
H172	SOFTWARE LOCKING DEFECT MODE SIGNAL
H18	INDICATOR RETURN > DOOR CLOSURE + SIGNAL
H19	PREHEATING CUT-OUT > LOAD LEVER SWITCH CONTROL
H2	SOFTWARE LOCKING > INJECTION > AUTOMATIC TRANSMISSION WARNING LIGHT - CONTROL
H20	OIL LEVEL TEMPERATURE -
H21	ISOLATED > EARTH > ADVANCE CORRECTION CONTROL
H22	START FLAP > CATALYTIC CONVERTER > PREHEATING WARNING LIGHT - CONTROL
H23	WINDSCREEN WASHER > HEADLIGHT WASHER MINIMUM WARNING LIGHT CONTROL
H24	LIGHTS TIMER > ALARM > FRONT DOOR SWITCH - CONTROL
H25	TIMER > ALARM > REAR LIGHTING REBATE - SIGNAL
H26	MEMORY > CONTROLLED CLUTCH DRIVER'S DOOR - CONTROL
H27	ELECTRONIC FAULT WARNING LIGHT -
H28	BRAKE PEDAL > CONTROLLED CLUTCH ACCELERATOR SENSOR SIGNAL

List of connections

CONNECTION CODES	CONNECTION TITLE
H29	INERTIA SWITCH > + AFTER IGNITION FEED
H3	EARTH > TEMPERATURE SWITCH SIGNAL 2 > SPEED 3 CONTROL
H30	FUEL PUMP INFO
H31	FAN UNIT VOLTAGE SIGNAL
H32	AIR CONDITIONING FAN UNIT CTP > FAN UNIT SPEED 1 CONTROL
H33	FAN UNIT RECOMMENDED SPEED > FAN UNIT SPEED 2 CONTROL
H34	HIGH SPED AIR CONDITIONING RECIRCULATION > FAN UNIT SPEED 3 CONTROL
H35	EVAPORATOR SENSOR HOT POINT > FAN UNIT SPEED 3 CONTROL
H36	THROTTLE POTENTIOMETER ANGLE > INJECTION PULSE MODULATION WIDTH SIGNAL
H37	HEATING > FAN UNIT SPEED 3 CONTROL
H38	FAN UNIT SUPPLY RELAY FAN UNIT SPEED 4 CONTROL
H39	FAN UNIT HIGH SPEED RELAY FAN UNIT SPEED 4 CONTROL
H4	HIGH SPEED SIGNAL > SPEED 1 CONTROL
H40	CONTROLLED CLUTCH>AUTOMAT TRANSMISSION>INJECTION FAULT WARNING LIGHT - SIGNAL
H41	RADIO ACCESSORIES + FEED
H42	FUSE > PASSENGER > CENTRAL DOOR LOCKING OPENING + CONTROL
H43	FUSE > CAB > CENTRAL DOOR LOCKING OPENING + CONTROL
H44	HEATED REAR SCREEN + > PROTECTED LEFT-HAND REAR SCREEN
H45	HEATED REAR SCREEN + > PROTECTED RIGHT-HAND REAR SCREEN
H46	BATTERY CUT-OUT RELAY > + > ENGINE FUNCTION FUSE > + AFTER IGNITION
H47	SECONDARY SPEED > VEHICLE SPEED SIGNAL
H48	RIGHT-HAND DRIVE > + PROTECTED LIGHTING > COURTESY LIGHT FUSE > BATTERY + FEED
H5	THE COMPUTER SIGNAL 1 > SPEED CONTROL 2
H51	LOWER CLUTCH PEDAL
H52	TRANSPONDER SIGNAL 1> CENTRAL DOOR LOCKING CLOSURE CONTROL
H53	TRANSPONDER SIGNAL 2 > CENTRAL DOOR LOCKING OPENING CONTROL
H61	LEFT-HAND DRIVE REVERSE > RIGHT HAND DRIVE FOG LIGHT
H62	RIGHT-HAND DRIVE FOG LIGHT > LEFT HAND DRIVE REVERSE LIGHT
H66P	REVERSE LIGHTS + CONTROL
H7	ALTERNATOR > COMPUTER > COIL > TOP DEAD CENTRE > REV COUNTER SIGNAL
H71	AUTOMATIC TRANSMISSION > INJECTION TOP DEAD CENTRE SIGNAL
H72	AUTOMATIC TRANSMISSION > PRE POST TIMER TOP DEAD CENTRE SIGNAL
H8	MULTIPLEX > PRE POST TIMER > COURTESY LIGHT ANGLE SIGNAL
H81	COLUMN SAFETY LOCK > TAILGATE STRIKER PANEL RELAY - CONTROL
H86	AUTOMATIC TRANSMISSION PARK POSITION > CRUISE CONTROL INHIBITOR CONTROL
H9	REAR VIEW MIRROR MOTOR COMMON CONTROL
H91	PASSENGER REAR VIEW MIRROR TOP/BOTTOM POSITION CONTROL
H92	PASSENGER REAR VIEW MIRROR LEFT/RIGHT POSITION CONTROL
H93	COOLANT TEMPERATURE WARNING
H95	FUEL PUMP SUPPLY INFO
H96	FUEL PUMP INFO
HK	FAULT FINDING SIGNAL K
HK7	FAULT FINDING SIGNAL K 2000
HK8	ADDITIONAL HEATING FAULT FINDING SIGNAL
HL	FAULT FINDING SIGNAL L
HRD	RS 485 DATA
HRDB	RS 485 DATA BAR
HRDM	RS 485 SHIELDING
HRSB	RS 232 DATA BAR
HRSD	RS 232 DATA
HRSM	RS 232 SHIELDING

List of connections

CONNECTION CODES	CONNECTION TITLE
KZ	FAULT FINDING SIGNAL KZ
L	SIDE LIGHT +
LP*	SIDE LIGHT UNALLOCATED PROTECTED +
LPD	RIGHT HAND SIDE LIGHT PROTECTED +
LPDA	RIGHT HAND SIDE LIGHT PROTECTED +
LPG	LEFT HAND SIDE LIGHT PROTECTED +
LZ	FAULT FINDING SIGNAL CONNECTION
M	EARTHING POINTS
MPA	IGNITION POWER EARTH
MR	COMPUTER EARTH
MR	GEARBOX ELECTRONIC EARTH
MR	REVERSE LIGHTS EARTH
N	ELECTRONIC EARTH
N*	NON ELECTRONIC EARTH
N*	UNALLOCATED ELECTRONIC EARTH
N1	CONTROLLED CLUTCH ELECTRONIC EARTH
NA	ANALOGUE ELECTRONIC EARTH
NA	PILLAR ELECTRONIC EARTH
NA	RIGHT-HAND FRONT PILLAR ELECTRONIC EARTH
R	MAIN BEAM HEADLIGHT +
R	FRONT ELECTRONIC EARTH
R	ENGINE FRONT ELECTRONIC EARTH
RP	MAIN BEAM HEADLIGHTS PROTECTED +
RP*	MAIN BEAM HEADLIGHT UNALLOCATED PROTECTED +
RPD	MAIN BEAM HEADLIGHT RIGHT-HAND PROTECTED +
RPG	MAIN BEAM HEADLIGHT LEFT-HAND PROTECTED +
RSV	INDUSTRIAL RESERVED CELL
S	ACCESSORIES + FEED
SBP*	ACCESSORIES + FEED > UNALLOCATED PROTECTED BATTERY
SBP1	PROTECTED BATTERY ACCESSORIES + FEED > LEFT-HAND REAR ELECTRIC WINDOW
SBP1	X65 BATTERY COVER +
SBP2	PROTECTED BATTERY ACCESSORIES + FEED>RH FRONT/REAR ELECTRIC WINDOW SHUNT
SBP2	X64 BATTERY COVER
SBP3	PASSENGER/DRIVER ELECTRIC WINDOW PROTECTED BATTERY ACCESSORIES + FEED
SBP3	M2S BATTERY FUSE 2
SP*	UNALLOCATED PROTECTED ACCESSORIES + FEED
SP1	PROTECTED ACCESSORIES + FEED > ENGINE FAN UNIT
SP10	PROTECTED ACCESSORIES + FEED > FRONT PASSENGER ELECTRIC SEAT 2
SP11	PRJT ACCESSORIES + FEED > DRIVER'S ELECTRIC SEAT
SP12	PROTECTED ACCESSORIES + FEED > DRIVER'S ELECTRIC SEAT
SP13	PROTECTED ACCESSORIES + FEED > COLUMN LOCKING FUSE
SP14	COLUMN LOCKING FUSE PROTECTED ACCESSORIES + FEED > RELAY
SP15	ACCESSORIES + FEED PROTECTED FUSE
SP16	PROTECTED ACCESSORIES + FEED / ACCESSORIES FUSE SUPPLY
SP17	PROTECTED ACCESSORIES + FEED / BRAKE LIGHTS FUSE
SP1A	ENGINE FAN UNIT FUSE PROTECTED ACCESSORIES + FEED
SP2	PROTECTED ACCESSORIES + FEED > RADIO >
SP21	PROTECTED ACCESSORIES + FEED > RADIO PRE FITTING
SP2A	RADIO FUSE PROTECTED ACCESSORIES + FEED,"
SP3	PROTECTED ACCESSORIES + FEED > HEATING
SP3A	HEATING FUSE PROTECTED ACCESSORIES + FEED

List of connections

CONNECTION CODES	CONNECTION TITLE
SP3B	HEATING FUSE PROTECTED ACCESSORIES + FEED
SP4	PROTECTED ACCESSORIES + FEED > REAR ACCESSORIES SOCKET
SP6	PROTECTED ACCESSORIES + FEED > PASSENGER SEAT
SP7	LUGGAGE COMPARTMENT SOCKET FUSE PROTECTED ACCESSORIES + FEED
SP8	PROTECTED ACCESSORIES + FEED > HEATED SEAT
SP9	PROTECTED ACCESSORIES + FEED > FRONT PASSENGER ELECTRIC SEAT 1
SPB3	BATTERY ACCESSORIES + FEED > PASSENGER FRONT ELECTRIC WINDOW SHUNT
SPB4	LH REAR RH REAR ELECTRIC WINDOW PROTECTED SHUNT BATTERY ACCESSORIES + FEED
SPB5	BATTERY ACCESSORIES + FEED > LH FRONT RH FRONT ELECTRIC WINDOW PROTECTED SHUNT
TB1	PINKING SENSOR SHIELDING CABLE
TB10	SPEED SENSOR INPUT SHIELDING CABLE
TB11	SPEED SENSOR OUTPUT SHIELDING CABLE
TB2	AUTOMATIC TRANSMISSION THROTTLE BODY SHIELDING CABLE
TB3	12C RADIO BUS SHIELDING CABLE
TB4	IGNITION COIL SHIELDING CABLE
TB5	PINKING SENSOR 1 >2 SHIELDING CABLE
TB6	OXYGEN SENSOR SHIELDING CABLE
TB7	NEEDLE RISE SHIELDING CABLE
TB8	AUTOMATIC TRANSMISSION PRESSURE SENSOR SHIELDING CABLE
TB9	INJECTION PUMP SHIELDING CABLE