

Index of earthing points

CODE	EARTHING POINTS
M1	Right hand front earth
M2	Left hand front earth
M3	Gearbox earth
M4	Body earth
M5	Tailgate earth
M6	RH rear light earth
M7	LH rear light earth
M8	Injection earth
M9	RH front pillar earth
M10	LH front pillar earth
M11	Dashboard earth
M12	Steering column bracket earth
M13	Central console earth
M14	Horn mounting earth
M15	Heating casing earth
M16	Engine/body earth
M17	Body/engine earth
M18	ABS earth
M19	ABS electronic earth
M20	Heated rear screen earth
M21	AEI additional advance electronic earth
MA	RH front electrical earth
MAA	Computer electrical earth
MAB	Rear axle electrical earth
MAC	Gearbox top mounting earth
MAD	Fuel tank sender & pump earth
MAE	Caravan electrical earth
MAG	ABS mounting electrical earth
MAH	ABS earth
MAJ	Fan unit earth
MAK	Driver's air bag earth
MAL	Passenger air bag earth
MB	LH front electrical earth
MC	Automatic transmission earth
MD	Rear shelf electrical earth
ME	Bodywork earth (general)
MF	RH rear electrical earth
MG	LH rear electrical earth
MH	Engine electrical earth
MJ	RH front pillar electrical earth
MJQ	Radiator tank EARTH
MK	LH front pillar electrical earth
ML	Battery electrical earth
MM	Steering column bracket electrical earth
MN	Central console electrical earth
MP	Horn bracket electrical earth
MQ	Heater casing electrical earth
MR	Gearbox electronic earth
MS	Pump unit mounting earth
MT	Radio electrical earth
MU	Screening earth
MV	Audio earth
MW	Front panel electrical earth
MX	Radio telephone earth
MY	Boot electrical earth
MYH	Left tailgate earth
MZ	LH rear panel electrical earth
MZA	electrical windscreen earth
MZB	TUP/TDB electronic earth
NA	RH front pillar electronic earth
NAC	BV upper mounting electronic earth
NB	Heater casing electronic earth
NC	LH front pillar electronic earth
ND	ABS electronic earth
NE	LH rear electronic earth

CODE	EARTHING POINTS
NF	Engine electronic earth
NH	Electronic earth
NG	TPP electronic earth
NJ	RH front pillar electronic earth
NK	Engine electronic earth
NL	Radio electronic earth
NQ	Heater casing electronic earth
NR	Engine electronic earth
NS	RH rear electronic earth
NT	LH front 1 side member electronic earth
NU	LH front 2 side member electronic earth