

# Directory of connections

CODE	CONNECTIONS
R1	Dashboard/RH rear
R2	Dashboard/LH rear
R3	Dashboard/driver's door
R4	Dashboard/passenger door
R5	Dashboard/heater casing
R6	Dashboard/central console
R7	Dashboard/radio
R8	Dashboard/RH roof
R9	Dashboard/front panel
R10	Dashboard/RH side member
R11	Dashboard/LH side member
R12	RH rear/RH rear door
R13	LH rear/LH rear door
R14	RH rear/RH tailgate
R15	LH rear/LH rear tailgate
R16	LH rear/rear cross member
R17	Heater casing/engine
R18	Heater casing/starter positive
R19	Heater casing/engine earth
R20	Engine/ignition
R21	Engine/electric fan unit
R22	Engine/automatic transmission
R23	Engine/emission control
R24	Engine/injection
R25	Engine/starter positive
R26	Engine/engine earth
R27	Engine/RH side member
R28	Engine/LH side member
R29	Engine/anti-percolation
R30	Central console/RH front seat
R31	Central console/LH front seat
R32	Front panel/headlight washer-wipers
R33	Front panel/bumper
R34	Engine/dashboard
R35	Pedal assembly/dashboard
R36	ABS / Dashboard
R37	Engine/injection
R38	Dashboard/LH roof
R39	LH rear/rear cross member
R40	RH rear/rear cross member
R41	Rear cross member/tailgate
R42	Front panel/RH repeater
R43	Front panel/LH repeater
R44	Dashboard/RH earth
R45	Dashboard/LH earth
R46	Engine/body earth
R47	Front panel/RH earth
R48	Front panel/LH earth
R49	RH rear/RH rear earth
R50	RH rear/LH rear earth
R51	Engine/engine earth
R52	Body/engine earth
R53	Body/body earth
R54	Heater casing/manual gearbox
R55	Bonnet catch switch/heater casing
R56	Bonnet/engine
R57	Subframe/dashboard
R58	Fan unit - RH side member
R59	Fan unit/injection
R60	ABS/RH side member
R61	Cruise control/RH side member
R62	Injection/engine regulator
R63	LH side member/injection
R64	Injection/automatic transmission plate
R65	Injection/heater casing

CODE	CONNECTIONS
R66	Injection/RH side member
R67	Front/engine
R68	Injection/temperature sensors
R69	Body/ABS
R70	Injection/turbo bearing coolant pump
R71	Cruise control/heater casing
R72	Dashboard/electric aerial
R73	Fan unit/integral electronic ignition
R74	Engine/oil dual function switch
R75	Fan unit earth/fan unit
R76	LH side repeater/LH headlight
R77	RH side repeater/RH headlight
R78	Additional headlight/LH side member
R79	Injectors/injection
R80	Heater casing/ABS
R81	Heater casing/LH side member
R82	Engine/air conditioning
R83	Additional headlight/RH side member
R84	Passenger compartment injection/engine injection
R85	Engine/reversing lights
R86	Heater casing/ballast coil
R87	Heater casing/headlight wipers
R88	LH side member/choke diode
R89	Dashboard/brake pad wear
R90	Heater casing/passenger compartment injection
R91	Heater casing/heater
R92	Heater casing/blower
R93	Heater casing/ air conditioning
R94	Heater casing/ballast coil relay
R95	Heater casing/automatic transmission
R96	RH rear/auxiliary fuel pump
R97	Heater casing/front windscreen washer
R98	RH side member/headlight washer-wiper
R99	Dashboard/heater
R100	ABS/LH side member
R101	RH side member/RH headlight
R102	LH side member/LH headlight
R103	Boot lid/boot lid switch
R104	Heater casing/ignition coil
R105	Heated rear screen shunt/body
R106	Front/bumper
R107	Dashboard/front
R108	Dashboard/console
R109	RH rear/number plate light
R110	Engine/front additional
R111	Dashboard/front additional
R112	Front/body
R113	Body, battery, engine earth harness/body
R114	Body, battery, engine earth harness/engine
R115	Engine/engine harness
R116	Engine/fuel pump
R117	RH rear/LH rear door
R118	RH rear/body
R119	LH front/sunroof alarm
R120	Heater bulkhead/taxi alarm
R121	RH front/sunroof
R122	Dashboard/fog lights

CODE	CONNECTIONS
R123	Central console/radio
R124	Dashboard/radio shunt
R125	Radio/radio shunt
R126	Fan unit/air conditioning cut-off relay
R127	Injection/air conditioning cut-off relay
R128	Body/fan unit earth
R129	Body/horn compressor
R130	LH side member/horn compressor
R131	Engine harness/horn compressor
R132	Dashboard/running lights
R133	LH front/canister solenoid valve
R134	Dashboard/additional trailer
R135	RH rear additional/dashboard
R136	LH rear door /additional RH rear
R137	RH rear door /additional RH rear
R138	Heater casing/ABS
R139	Engine/ABS
R140	Automatic transmission plate/automatic transmission
R141	Courtesy light/front
R142	Engine/diesel injection pump
R143	RH side repeater/RH side member
R144	LH side repeater/LH side member
R145	Automatic transmission/ballast coil
R146	Dashboard/front seats
R147	Bumper/LH front wing
R148	Fan unit/LH front wing
R149	Engine/LH front wing
R150	Passenger compartment/LH front wing
R151	Engine/RH front wing
R152	Passenger compartment/RH front wing
R153	Passenger compartment/driver's door
R154	Passenger compartment/passenger door
R155	Passenger compartment/LH rear door
R156	Passenger compartment/RH rear door
R157	Passenger compartment/tailgate
R158	Passenger compartment/RH roof
R159	Passenger compartment/central console
R160	Automatic transmission intermediate/injection
R161	Injection/oil cooler
R162	Memory seats/sensors
R163	Injection/throttle switch intermediate
R164	Fan unit/dashboard
R165	Fan unit/fuel pump
R166	Engine/brake pad wear
R167	Heater casing/ignition
R168	Engine/rear lights
R169	Rear lights/compensator
R170	Rear lights/number plate lights
R171	Hand brake/heater casing
R172	Screen washer/dashboard
R173	Dashboard/console

# Directory of connections

CODE	CONNECTIONS
R174	Heater casing/radio
R175	Heater casing/automatic transmission intermediate
R176	Dashboard/glove compartment
R177	LH rear/heater casing intermediate
R178	Heater casing intermediate/boot lid
R179	ABS/LH front wing
R180	Passenger compartment/PAS & managed suspension switch
R181	Passenger compartment/pedal assembly
R182	Passenger compartment/radio
R183	Passenger compartment/ABS
R184	Idle speed choke adjustment/engine
R185	Number plate lights/ number plate intermediate
R186	Dashboard/front fog lights intermediate
R187	Passenger compartment/central courtesy light
R188	Carburettor/engine
R189	Bumper/LH front wing
R190	RH front wing/cruise control
R191	Front/headlight washers
R192	Anti-percolation fan unit intermediate/engine
R193	Boot lid intermediate/RH rear
R194	Additional fuel pump/RH rear
R195	Rear screen wiperconnection
R196	Brake fluid level sensorconnection
R197	Heated seats controlswitches/dashboard
R198	Roof consoleconnection
R199	Front cross member/RH wing
R200	Tailgate/tailgate assistance
R201	Passenger compartment/glove compartment light
R202	RH rear/centre stop light intermediate
R203	Passenger compartment/cigar lighter
R204	Engine/oxygen sensor shunt
R205	Headlight washer pump shunt/ front cross member
R206	Passenger compartment/engine compartment light
R207	LH headlight /additional headlight
R208	LH front wing/heated windscreen
R209	Managed suspension solenoidvalve connection
R210	Dashboard/bumper
R211	Pedal assembly/heater casing
R212	Engine/passenger compartment (Monobloc)
R213	Variable PAS speed sensor/ passenger compartment
R214	Central console/central console intermediate
R215	Central console intermediate/heated seats
R216	LH rear/fuel gauge intermediate

CODE	CONNECTIONS
R217	Fuel gauge intermediate/passenger compartment
R218	Fuel pump/pump intermediate
R219	Dashboard/LH rear door
R220	Dashboard/RH rear door
R221	Dashboard/Monobloc
R222	RH rear/variable shock absorbers
R223	Throttle potentiometer connection
R224	Pinking adjustment earth connection
R225	Dashboard/driving school instructor's pedal assembly
R226	EGR solenoid valve and diesel cold start (KSB) connection
R227	Front panel/headlight washer intermediate
R228	Passenger compartment/kick-down switch
R229	Dashboard/heated jet intermediate
R230	Radio-telephone connection
R231	Courtesy light/courtesy mirror
R232	LH rear/RH rear
R233	Caravan connection
R234	Dashboard/ accelerometers
R235	Dashboard/automatic transmission
R236	LH rear/number platelighting
R237	Engine ABS /under body ABS
R238	LH rear/driver's door
R239	LH rear/passenger door
R240	Heated windscreen/ dashboard
R241	LH rear/centre stop light
R242	Dashboard/variable shock absorbers connection
R243	RH rear door/LH rear harness
R244	LH rear/boot lid
R245	Tailgate/heated rear screen
R246	Tailgate/centre stop light
R247	Variable shock absorber/intermediate
R248	LH rear/self levelling suspension
R249	Automatic transmission/line pressure
R250	Tailgate/number plate lights
R251	Dashboard/radio-telephone
R252	Dashboard/alarm key extension cable
R253	Self levelling suspension intermediate/self levelling suspension(k56)
R254	Dashboard/plenum chamber
R255	ABS/plenum chamber
R256	Heated windscreen/plenum chamber
R257	Dashboard/automatic transmission
R258	Automatic transmission/LH front wing
R259	Passenger compartment/rear bumper
R260	Passenger compartment/LH roof
R261	Passenger compartment/heater casing
R262	Passenger compartment/engine

CODE	CONNECTIONS
R263	Passenger compartment/automatic transmission
R264	Passenger compartment/RH tailgate
R265	Passenger compartment/front panel
R266	Passenger compartment/bumper
R267	Passenger compartment/self levelling suspension
R268	Passenger compartment/pad wear intermediate
R269	Fuel gauge intermediate/ ABS under body
R270	Passenger compartment/RH front seat
R271	Passenger compartment/LH front seat
R272	Engine/locking equipment
R273	Self levelling suspension intermediate/caravan
R274	Self levelling suspension/self levelling suspension intermediate
R275	Passenger compartment/fan unit
R276	Passenger compartment/trailer
R277	Passenger compartment/driver's pretensioner
R278	Passenger compartment/passenger's pretensioner
R279	Passenger compartment/radio display intermediate
R280	Rear/hood cover
R281	RH tailgate/tailgateassistance
R282	Engine/self contained heater
R283	Engine/battery compartment
R284	Engine/charging socket
R285	Dashboard/direction of travel switch
R286	Catalytic converter sensor intermediate/ dashboard
R287	Electronic control unitconnection
R288	High voltage supply/electronic control unit
R289	High voltage supply/ converter
R290	Engine/pedal assemblyharness
R291	Passenger compartment/igniter
R292	Passenger compartment/passenger airbag
R293	Jack plug socketconnection
R294	Light plug socket connection
R295	RH rear/under body
R296	Passenger compartment/RH rear
R297	Passenger compartment/LH rear
R298	Passenger compartment/additional radio
R299	Front/rear equipment harness connection
R300	Heater plugs/engine
R301	Dashboard/courtesy light
R302	Heater casing/roof connection
R303	Navigation aid/passenger compartment
R304	Additional liquid petroleum tank/ passenger compartment
R305	Engine/starter motor solenoid

# Directory of connections

CODE	CONNECTIONS
R309	ABS/ABS intermediate
R326	Engine/liquid petroleum
R442	Siren/RH front wing
R495	Passenger compartment/passenger's pretensioner
R496	Passenger compartment/seat belt warning light
R618	Roof/roof console
R620	LH rear/LH tailgate intermediate
R621	LH tailgate intermediate/LH tailgate
R622	Engine/high voltage supply harness
R715	Dashboard/radio-telephone
R757	Passenger compartment/driver's pretensioner
R758	Passenger compartment/passenger's pretensioner
R900	Dashboard/additional heater casing
R980	Side member D/headlight washer
R981	Passenger compartment/navigation aid
R982	Navigation aid/rear sensors
RA	Front/floor
RB	Front/differential lock switch
RC	Front/headlight washers
RD	Front/dim-dip control
RE	Dashboard/fan unit
RF	Control panel/fan unit
RG	Infrared remote control/ additional alarm harness
RH	Engine/injection pump advance solenoid valve (KSB)
RI	LH side member/canister solenoid valve harness
RJ	RH side member/additional alarm
RK	Dashboard/alarm
RL	Self levelling suspension computer/ compressor unit
RM	Dashboard/additional RH passenger compartment (self levelling suspension)
RN	LH rear/ 3rd brake lightintermediate
RP	Passenger compartment/injection
RQ	Passenger compartment/engine
RS	Front panel/RH headlight
RT	Front panel/LH headlight
RU	Engine/alternator
RV	Fuel pump/fuel gauge
RW	RH passenger compartment/fuel filler flap
RX	Engine compartment/RH brake pads intermediate
RY	Engine compartment/LH brake padsintermediate
RZ	Engine compartment/additional trailer
RBA	Roof console/sunroof
RBC	Self contained heater/engine
RBD	Front/charging socket flap
RBE	Throttle body/engine
RBF	Oxygen sensor/engine

CODE	CONNECTIONS
RBG	Ignition power module/engine
RBH	Dashboard/additional 16 place n°1 bus
RBI	Dashboard/additional 16 and 9 place n°2 bus
RBJ	Additional 16 place n°2 bus/passenger courtesy light
RBK	Lateral RH airbag /passenger compartment
RBL	Lateral LH airbag /passenger compartment
RBM	Driver satellite Airbag /passenger compartment
RBN	Passenger satellite Airbag /passenger compartment