

RENAULT

Technical Note 6516A

Basic document: **M.R 305**

Sub-section concerned: 36B

Electric power assisted steering

This Technical Note cancels and replaces the relevant pages of Technical Note 2492A

77 11 176 022

Edition 1 - SEPTEMBER 2007

EDITION ANGLAISE

"The repair procedures given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The methods may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed."

All copyrights reserved by Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault.

© Renault s.a.s. 2007

Contents

36B

POWER ASSISTED STEERING

	Page
Fault finding - Interpretation of XR25 bargraphs	36B-1
Fault finding - Fault finding charts	36B- 13

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

GENERAL INSTRUCTIONS

Consult this fault chart before beginning the fault finding.

Check that there is an earth on connection **NO** of component **502**.
With the vehicle ignition switched off, check that there is a voltage = **12 V** on connection **BP81** of component **502**.
With the ignition on, check that there is a voltage = **12 V** on connection **AP23** of component **502**.

If these voltages are not present, check that the system fuses are correctly clipped in place.

If the fault persists, check the electrical wiring continuity and insulation to earth and to + **12 V** on:

- The connection **BP81** between components **597** and **502**
- The connection **NO** between the earth **NC** and component **502**
- The connection **AP23** between components **502** and **260**

Repair the faulty electrical wiring.


AFTER REPAIR

Disconnect the battery within = **30 s** to proceed with erasure of the fault.
Reconnect the battery, then switch on the ignition again and wait **10 seconds** (injection initialisation phase).

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

1	Right-hand Bargraph 1 extinguished Card number 37
	<u>XR25 COMMUNICATION KIT</u> XR25 Help: A Bargraph that is extinguished when the ignition is on signifies a diagnostic trace printout fault

NOTES	Before beginning the fault finding procedure, consult the general instructions.
--------------	---

With the ignition off, connect the XR 25 test kit. The test kit should display "r25".

If the test kit does not display "r25", repair the electrical wiring between the diagnostic socket tracks

- 2 and the earth,
- 6 and the fuse box.

Switch on the ignition. With the selector in position S6. Enter D37. The display should read "l.dAE".

Is "l.dAE" displayed?

YES

Start of fault finding procedure.

NO

If the screen displays horizontal lines, check:

- the position of selector S6,
- that the cassette is correct,
- the connection between the XR25 test kit and the diagnostic socket.

Repair the faulty component, if necessary.

Connect bornier **MS 1048** in place of the computer and check the continuity of the electrical wiring on:

The connections **109J** and **109H** between components **225** and **502**.

Repair the electrical wiring.


AFTER REPAIR

Start of fault finding procedure

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

1	Left-hand Bargraph 1 illuminated	Card number 37
	COMPUTER XR25 Help: *01 = 1.DEF: safety relay fault 2.DEF: supply fault 3.DEF: software fault	

NOTES	With the ignition switched off, the Left-hand BG 1 is still illuminated: ignore this. Before beginning the fault finding procedure, consult the general instructions.
--------------	--

1.DEF	NOTES	None
-------	--------------	------

Replace the computer.

2.DEF	NOTES	None
-------	--------------	------

Check the continuity and insulation to earth and to + **12V** of the electrical wiring on:
The connections **109K** and **109L** between components **502** and **850**.

Repair the electrical wiring if necessary.

With the ignition on, check that the voltage = **8 V** on:
the connections **109K** and **109L** between the component **502** and the earth **NC**.
Does the voltage value equal **8 V**?

YES	Change the steering column.
------------	-----------------------------

NO	Replace the computer.
-----------	-----------------------

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

1		
		
CONTINUED		

3.DEF	NOTES	None
-------	-------	------


Replace the computer.

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

2	Left-hand Bargraph 2 illuminated	Card number 37
	TORQUE SENSOR CIRCUIT XR25 Help: *01 = 1.DEF: main torque sensor fault 2.DEF: secondary torque sensor fault 3.DEF: different measurements between the 2 sensors	

NOTES	Before beginning the fault finding procedure, consult the general instructions.
--------------	---

1.DEF	NOTES	None
-------	--------------	------

Check the continuity and insulation to earth and to + 12V of the electrical wiring on: The connections 109K , 109M and 109P between components 502 and 850 .
Repair the electrical wiring if necessary.
With the ignition on, check that the voltage = 8 V on connection 109K between component 502 and the vehicle earth NC . If this voltage is not present, change the computer.
With the ignition on, check that the voltage = 2.5 V on connection 109M between component 502 and the vehicle earth NC . If this voltage is not present, change the computer.
Disconnect the electrical wiring to connection 109M between component 502 , then switch on the ignition and check that the voltage = 6.5 V on connection 109M between component 850 and the vehicle earth NC . Does the voltage value equal 6.5 V ?

YES	Replace the computer.
NO	Change the steering column.

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

2		
		
CONTINUED		

2.DEF	NOTES	None
-------	-------	------

Check the continuity and insulation to earth and to + **12V** of the electrical wiring on:
The connections **109L**, **109N** and **109Q** between components **502** and **850**.
Repair the electrical wiring if necessary.

With the ignition on, check that the voltage = **8 V** on connection **109L** between component **502** and the vehicle earth **NC**.
If this voltage is not present, change the computer.

With the ignition on, check that the voltage = **2.5 V** on connection **109N** between component **502** and the vehicle earth **NC**.
If this voltage is not present, change the computer.

Disconnect the electrical wiring to connection **109N** between component **502**, then switch on the ignition and check that the voltage = **6.5 V** on connection **109N** between component **850** and the vehicle earth **NC**.
Does the voltage value equal **6.5 V**?

YES	Replace the computer.
-----	-----------------------

NO	Change the steering column.
----	-----------------------------

3.DEF	NOTES	If *02 = 1.DEF first, deal with the fault 1.DEF If *02 = 2.DEF first, deal with the fault 2.DEF
-------	-------	--


Change the steering column.

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
--------------	--

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

3	Left-hand Bargraph 3 illuminated	Card number 37
	<u>VEHICLE SPEED SENSOR CIRCUIT</u> XR25 Help: *03 = 1.DEF: no speed signal 2.DEF: signal not plausible	

NOTES	If the speed signal and the kilometre/mileage trip recorder on the instrument panel is not working, consult the relevant fault chart in section 8 of MR 305. Before beginning the fault finding procedure, consult the general instructions.
--------------	--

Set the XR25 test kit to pulse detector mode.
Lift one of the two front wheels and check that there are pulses on connection **47F** of component **502** when turning the wheel, with the ignition on.
Are there any pulses present when turning the wheel?


YES	Replace the computer.								
NO	<p>Check the continuity and insulation to earth and to + 12 V of the following electrical wiring:</p> <table><tr><td rowspan="3">Speed signal 3-track connector</td><td rowspan="3">{</td><td>A1</td><td>fuse box</td></tr><tr><td>B1</td><td>and Connection 47F of component 502</td></tr><tr><td>C1</td><td>vehicle earth</td></tr></table> <p>Repair the faulty electrical wiring.</p>	Speed signal 3-track connector	{	A1	fuse box	B1	and Connection 47F of component 502	C1	vehicle earth
Speed signal 3-track connector	{			A1	fuse box				
				B1	and Connection 47F of component 502				
		C1	vehicle earth						

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

4	Left-hand Bargraph 4 illuminated	Card number 37
	ENGINE CIRCUIT XR25 Help: *04 = <ol style="list-style-type: none"> 1.DEF: electrical wiring fault 2.DEF: excess current 3.DEF: motor seized 4.DEF: servo control fault 	

NOTES	Before beginning the fault finding procedure, consult the general instructions.
--------------	---

1.DEF	NOTES	None
-------	--------------	------

Using a multimeter, and with the ignition switched off, measure the resistance between the connection codes **109R** and **109S** of component **502**.
Is the resistance greater than 1 Ω?

YES	<p>Check the continuity and insulation to earth and to + 12V of the electrical wiring on: The connection codes 109R and 109S between components 502 and 540 Is the wiring sound?</p> <p>If the electrical wiring is in good condition: change the steering column.</p> <p>If the electrical wiring is faulty: repair the electrical wiring.</p>
NO	Replace the computer.

2.DEF	NOTES	None
-------	--------------	------

Replace the computer.

If the fault persists, change the steering column.

AFTER REPAIR	<p>Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).</p>
---------------------	--

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

4		
		
CONTINUED		

3.DEF	NOTES	None
-------	-------	------

Change the steering column.

4.DEF	NOTES	None
-------	-------	------

Using a multimeter, and with the ignition switched off, measure the resistance between the connection codes **109R** and **109S** of component **502**.
Is the resistance greater than **1 Ω**?


YES	Check the continuity and insulation to earth and to + 12V of the electrical wiring on: The connection codes 109R and 109S between components 502 and 540 Is the wiring sound?
	If the electrical wiring is in good condition: change the steering column.
	If the electrical wiring is faulty: repair the electrical wiring.
NO	Replace the computer.

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

5	Left-hand Bargraph 5 illuminated	Card number 37
	<u>CLUTCH CIRCUIT</u> XR25 Help: poor electrical wiring	

NOTES	Before beginning the fault finding procedure, consult the general instructions.
--------------	---

Using a multimeter, and with the ignition switched off, measure the resistance between connection codes **109T** and **109V** of component **502**.
Does the resistance value equal $15 \pm 1 \Omega$?


NO	Check the continuity and insulation to earth and to + 12V of the electrical wiring on: The connection codes 109T and 109V between components 502 and 540 Is the wiring sound?
	If the electrical wiring is in good condition: change the steering column.
	If the electrical wiring is faulty: repair the electrical wiring.
YES	Replace the computer.

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

6	Left-hand Bargraph 6 illuminated	Card number 37
	<u>COMPUTER POWER SUPPLY CIRCUIT</u> XR25 Help: + Battery supply fault	

NOTES	Before beginning the fault finding procedure, consult the general instructions. Check the condition of the battery. Check the condition of fuse.
--------------	--

Check the continuity and insulation to earth and to + **12 V** of the electrical wiring:

- on connection **BP81** between components **502** and **597**,
 - between components **597** and **107**,
 - on connection **NO** between component **502** and the vehicle earth **NC**.
- Repair the electrical wiring.


If the fault persists, change the computer.

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

9	Left-hand Bargraph 9 illuminated when speed > 12 mph (20 km/h) Card number 37	
		
	<u>SPEED SENSOR CIRCUIT</u>	

NOTES	Before beginning the fault finding procedure, consult the general instructions. If BG 3G is illuminated, consult BG 3G.
--------------	--

Set the XR25 test kit to pulse detector mode.
Lift one of the two front wheels and check that there are pulses on connection **47F** between components **502** and **651**, with the ignition on.
Are there any pulses present when turning the wheel?

YES	Replace the computer.
------------	-----------------------


NO	<p>Check the continuity and insulation to earth and to + 12 V of the following electrical wiring:</p> <table><tr><td rowspan="3">Speed signal 3-track connector</td><td rowspan="3">{</td><td>A1</td><td>fuse box</td></tr><tr><td>B1 and</td><td>Connection 47F of component 502</td></tr><tr><td>C1</td><td>vehicle earth</td></tr></table> <p>Repair the faulty electrical wiring.</p>	Speed signal 3-track connector	{	A1	fuse box	B1 and	Connection 47F of component 502	C1	vehicle earth
Speed signal 3-track connector	{			A1	fuse box				
				B1 and	Connection 47F of component 502				
		C1	vehicle earth						

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

POWER ASSISTED STEERING

Fault finding – Interpretation of XR 25 bargraphs

36B

10	Left-hand Bargraph 10 illuminated with the engine running	Card number 37
	<u>ENGINE SPEED INFORMATION CIRCUIT</u>	

NOTES	Before beginning the fault finding procedure, consult the general instructions.
--------------	---

Set the XR25 test kit to pulse detector mode.
With the engine running, check that there are pulses on connection **H7** of component **502**.
Are the pulses present?

YES	Replace the computer.
NO	With the XR25 test kit still in pulse detection mode, and the engine running, are the pulses present on connection code H7 of component 120 ?
	There are pulses present: repair the electrical wiring for connection code H7 between components 502 and 120 .
	There are no pulses present: change the injection computer.

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

ALP1	The electric power-assisted steering warning light is flashing constantly (with the XR25 test kit not connected)
-------------	---

NOTES	Before beginning the fault finding procedure, consult the general instructions. Carry out the tests without the XR25 test kit connected.
--------------	--

Check the insulation to earth of the electrical wiring for connection **109J** between components **502** and **225**.
Is the wiring sound?

YES	Change the diagnostic socket.
	If the fault persists, change the computer.
NO	Repair the electrical wiring.

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	---

ALP2	The electric power-assisted steering warning light never illuminates
-------------	---

NOTES	Before beginning the fault finding procedure, consult the general instructions. Check the condition of the electric power-assisted steering 10A fuse .
--------------	--

Check the continuity and insulation to earth and to + 12 V of the electrical wiring between tracks:	
Instrument panel 15-track connector	<div style="display: flex; align-items: center; justify-content: center;"> <div style="text-align: center;"> <div style="font-size: 2em;">{</div> <div style="margin-top: 10px;">4</div> <div style="margin-top: 10px;">13</div> </div> <div style="margin: 0 10px;">and</div> <div style="text-align: center;"> <div style="margin-top: 10px;">fuse box</div> <div style="margin-top: 10px;">7 of the computer 16-track connector via the dashboard/single unit connection R221</div> </div> </div>
Repair the electrical wiring or connectors, if necessary.	
Route the connection 109H of component 502 to earth. Is the electric power-assisted steering warning light illuminated?	

YES	Replace the computer.
NO	Change the instrument panel warning light strip.

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

ALP3	Power-assisted steering is inactive with no illumination of the electric power-assisted steering warning light
-------------	---

NOTES	Before beginning the fault finding procedure, consult the general instructions.
--------------	---

With the vehicle ignition switched off, check that there is a voltage = **12 V** on connection **BP81** of component **502**.
With the ignition on, check that there is a voltage = **12 V** on connection **AP23** of component **502**.
Does the voltage value equal **12 V**?

YES	Replace the computer.
------------	-----------------------

NO	Repair the electrical wiring for connection BP81 between components 502 and 597 or for connection AP23 between components 502 and 260 .
-----------	---

AFTER REPAIR	Disconnect the battery within = 30 s to proceed with erasure of the fault. Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).
---------------------	--

ALP4	Power-assisted steering is inactive with illumination of the electric power-assisted steering warning light
-------------	--

NOTES	<p>Before beginning the fault finding procedure, consult the general instructions.</p> <p>On card number 37: If BG 1G is illuminated, consult BG 1G.</p> <p>If BG 2G is illuminated, consult BG 2G. If BG 3G is illuminated, consult BG 3G.</p> <p>If BG 4G is illuminated, consult BG 4G. If BG 5G is illuminated, consult BG 5G.</p>
--------------	--

Check the continuity and insulation to earth and to **12 V** of the electrical wiring for connection **H7** between components **502** and **120**.

Repair the electrical wiring or connectors, if necessary.

With the ignition on, check that the voltage = **12 V** on connection **H7** of component **502**.

Does the voltage value equal **12 V**?

YES	Replace the computer.
------------	-----------------------

NO	Replace the injection computer.
-----------	---------------------------------

AFTER REPAIR	<p>Disconnect the battery within = 30 s to proceed with erasure of the fault.</p> <p>Reconnect the battery, then switch on the ignition again and wait 10 seconds (injection initialisation phase).</p>
---------------------	---