

## SPECIAL TOOLING REQUIRED

Mot. 1265      Pliers

### REMOVAL

This operation does not require the refrigerant circuit to be drained.


Disconnect the battery.

Lift the vehicle and remove the engine undertray.

Drain the cooling circuit, removing the temperature switch on the radiator for the engine cooling fan.

Remove:


- the battery,
- the air inlet duct and its mounting (1).



- the injection computer protective housing (2 bolts)

Disconnect and remove all of the connectors on the radiator.


Remove the engine cooling fan (bolts marked 3) and the air conditioning pipe mounting.




Disconnect the coolant hoses from the radiator. The petrol vapour canister will have to be disconnected and removed (4).

To remove the pipe on the side of the canister, use pliers Mot. 1265.

Positioning the pliers




Remove the bolt securing the canister to the radiator (A) and tilt it to remove it.




**ATTENTION :** when reconnecting piping with a union, ensure the union is correctly clicked into position (there are two sealing O rings).

Remove the radiator bolts (5). Release the radiator from its upper guides and lower it.



In this position, remove the 4 bolts (6) which secure the condenser to the radiator and remove the radiator from above.




## REFITTING

Refitting is the reverse of removal.


For:

- precautions,
  - filling,
  - and bleeding,
- refer to Chapter 19 of M.R. 305.

**ATTENTION :** with the ignition on, after reconnecting the battery, wait for 10 seconds before starting the engine (injection computer programming).




### AIR CIRCULATION



95 915 1 R

- A External air inlet
- B Distribution of air in the passenger compartment
- C Extraction of air through the luggage compartment

### AIR DISTRIBUTION



- a Central ventilator outlets
- b Windscreen de-mister / de-icer outlets
- c Side ventilator outlets
- d Footwell ventilator outlets

- A** Passenger compartment
  - B** Engine compartment
  - C** External air
  - D** To air mixing unit
  - E** Scuttle panel
  - F** External or recycled air
- 
- 1** **SANDEN SD 7 H 15** compressor
  - 2** Condenser
  - 3** Freon reservoir
  - 4** Trifunction pressostat
  - 5** High pressure bleed
  - 6** Pressure release valve
  - 7** Pressure release valve thermostatic regulator
  - 8** Evaporator
  - 9** Low pressure bleed
  - 10** Passenger compartment fan
  - 11** Engine cooling fan
  - 12** Engine cooling radiator
  - 13** High pressure liquid
  - 14** Low pressure vapour
  - 15** High pressure vapour

### CONSUMABLES


Refrigerant fluid :

**R 134a : 650 g  $\pm$  35 g**

Compressor oil :


**PAG SP20 : 135 cm<sup>3</sup>  $\pm$  15 cm<sup>3</sup>**

## AIR CONDITIONING PRINCIPLE



## TEMPERATURE CONTROL (A)

This control has the same function as described in the "Heating" section, when the air conditioning control (D) is on position 0.




When the air conditioning control (D) is on position "NORM" or "MAX", the air is first cooled and dried as it passes through the evaporator, then some of the air is heated as it passes through the radiator.

When control (A) is set to the far left, the air is not heated, so the minimum temperature possible is obtained.

Moving the control to the right allows the air temperature to be adjusted.

## AIR DISTRIBUTION KNOB (B)

This control has the same function as described in the "Heating" section.



Operating details (see air distribution diagram)

Position

The air flow is only directed to the dashboard ventilators (a) and (c).

Each ventilator has three settings :

- open or closed,
- up or down,
- left or right.

Position

The air flow is directed to the footwell ventilators (d) and the dashboard ventilators (a) and (c).

Position

The air flow is directed to all the ventilators (a), (b), (c) and (d).

Position

The air flow is directed to the windscreen ventilators (b), and the dashboard ventilators (a) and (c).

For efficient windscreen demisting or de icing ventilators (a) and (c) should be closed.




## FAN SPEED CONTROL (C)

Ventilation is by blown air. The air flow circulating in the passenger compartment is determined by the four positions of the control (C).

### Position 0

The ventilation system is not operating, the air inlet is closed by the recycling flap. The air conditioning system cannot be used.

This position isolates the system, whatever the positions of the other controls.




**NOTE:** to improve the efficiency of the windscreen demisting and de-icing, the fan speed control (C) should be set to the last but one position.

## AIR CONDITIONING CONTROL (D)

This control starts or stops the air conditioning system.

Its use allows :

- the temperature of the air in the passenger compartment to be lowered,
- the humidity of the air blown in the passenger compartment to be reduced (improves de-misting).



### Position 0

The air conditioning system is not operational - the system has the same functions as for a vehicle without air conditioning.

### "NORM" Position

The air conditioning system is operational. This is the normal position for use. Fresh air is taken from outside the vehicle and is constantly renewed.

### "MAX" Position

The air conditioning system is operational. Air is taken from the passenger compartment and is constantly recirculated. No external air is used.

This allows the temperature in the vehicle to be lowered quickly and permits the passenger compartment to be isolated from the external atmosphere (driving in a polluted area)

Prolonged use of this position may cause the air in the passenger compartment to become stale (smokers).

It is therefore advisable to return to the "NORM" position as soon as the polluted area is left behind or the required temperature is reached.

**NOTE :** The air conditioning control only operates the system if the fan speed control (C) is set to a position other than 0.

- + APC : + after ignition
- + AVC : + before ignition
- + Servitudes : + Accessories

**MK** : Front left hand pillar earth

**MH** : Engine earth

**R212** : Engine / passenger compartment earth (monoblock)

**6** : Passenger compartment fan electronic module

**19** : Electronic thermostat

**120** : Injection computer

**164** : Cold air blower

**171** : Air conditioning compressor solenoid clutch

**206** : Trifunction air conditioning pressure switch

**233** : Passenger compartment fan control relay (low speed - marked B\*)

**234** : Main control relay for fan (high speed - marked A\*)

**248** : Fan temperature switch

**260** : Fuse box

**262** : Engine cooling fan

**319** : Control panel

**320** : Passenger compartment fan

**321** : Fan circuit resistance (air conditioning function)

**408** : Evaporator temperature sensor

**475** : Recycling control motor

**597** : Engine fuse box


**659** : Air conditioning / ventilation separation diode

(\*) Marks moulded on the surface of a block which houses two relays.

## AIR CONDITIONING

### Wiring diagram

62



96 513 SL

Starting and stopping the operation of the air conditioning compressor and fan causes important changes in the mechanical engine load.

These variations in power absorbed (from 0 to 5 kW) affect the levels of consumption and depollution and includes engine speed stability.

To manage these effects and to ensure operating safety, a dialogue between the injection and air conditioning computers must be established.

There are two types of communication signal :

- air conditioning to injection (track 9),
- injection to air conditioning (track 24).

To improve engine speed stability when the compressor clutch operates, the injection computer is informed of each change in operation (on/off) so that the idle speed and injection timing may be adjusted a fraction of a second before the compressor clutch operates.

To improve engine performance or in certain cases for safety reasons, the injection computer informs the air conditioning computer of when the compressor clutch should not operate (full load).

This information is given in two signals :

**AIR CONDITIONING STATUS = 0** : the air conditioning compressor clutch may be fed.

**AIR CONDITIONING STATUS = 1** : the air conditioning compressor clutch may not be fed.


This signal allows the injection computer to manage its timing (retarded when the engine is started and turned off)

For more details, refer to Technical Note N° 2024 - Part Number 77 11 096 996.

In order to protect the environment the Authorities have specified that refrigerant R 134a should be used in the air conditioning system fitted to this vehicle

The use of this new product, which was first used on the Twingo, has led to a modification of the design of the air conditioning system components.

A label on the bonnet shows the specifications of the refrigerant fluid.



The section "Air conditioning - New refrigerant R134a" contains more detailed information on this modification.

The most important specification concerns the exclusive use of **SANDEN** oil for the compressor and the fitting of pipes for the circuit. This oil is packaged in cans of 250 ml and is available from the Parts Department under Part Number 77 11 143 700.

**NOTE :** in **R134a** circuits, the oil enters the refrigerant circuit in an emulsion, giving the fluid a milky appearance which prevents fault finding using the filling inspection window.

### CUSTOMER COMPLAINTS




Air distribution fault		Chart 2
Heating efficiency fault		Chart 3
Air flow fault		
Air distribution control on footwell position		Chart 4
Air distribution control on de-icing position		Chart 5
Air distribution control on ventilation position (mixing flap in maximum hot position)		Chart 6
Air distribution control on ventilation position (mixing flap in maximum cold position)		Chart 7
Controls stiff to operate		Chart 8
Passenger compartment smells		Chart 10
Heating fault		(mixing flap in maximum hot position)
No hot air		Chart 11
Too much hot air		Chart 12
De-icing / de-misting efficiency fault		(mixing flap in maximum hot position)
Air conditioning fault		(mixing flap in maximum cold position)
No cold air		Chart 14
Lack of efficiency		Chart 15
Too much cold air		Chart 16
Recycling flap does not work		Chart 17
Ventilation fan does not operate correctly		Chart 18
Cooling fan does not operate correctly		Chart 19

Chart 1 and Chart 9 : only concern versions without air conditioning

e06061 0

Chart 2 : Air distribution fault




Chart 3 : Heating efficiency fault

Before taking any action ensure the customer is using the system correctly  
(see Driver's Handbook and specific M.R.).

Carry out a road test to verify the customer's complaint.  
Is the test satisfactory?

yes

Advise the customer on how to get the best from the heating system : do not set the system to maximum when starting the engine from cold, but increase the setting progressively

no

Visually check that moving the control moves the mixing flap (cable and blue lever).  
Does the flap move?

no

See Chart 2  
"Air distribution fault"  
from (\*)

yes

Visually check that the flap moves as far as it should.  
Is this correct?

no

Readjust the cable

yes

Check the cooling circuit is correctly filled and bled.  
Check the circuit cleanliness, the pipes, connections and conformity.  
Repair if necessary.  
Does the fault persist?

no

Correct

yes

Remove the engine thermostat and check it is not stuck in the open position  
Replace the thermostat if necessary.  
Does the fault persist?

no

Correct

yes



**NOTE :** if, during the test, you note that the heating efficiency is very poor at high speed, replace the engine thermostat as it is opening under pressure.



Chart 3 : Heating efficiency fault (cont)

**A**

Check there is no leak of cold air into the passenger compartment (seals, wire guides, cables...)  
Repair if necessary.  
Does the fault persist?

no → Correct

yes

Carry out a road test, set the temperature control at 3/4 of its travel.  
Note its position and check while driving that it does not move back towards the cold setting.

no → Replace the cable control or the heating assembly and consult any relevant Technical Notes.

yes


Check the air inlets and outlets. If these are partially blocked the air flow through the passenger compartment is reduced.  
Repair if necessary.  
Does the fault persist?


no → Correct


yes

The evaporator upstream of the heating radiator is blocked (leaves, insects ...).  
Remove the evaporator unit and clean or replace the evaporator.

**Chart 4 : Air flow fault**  
(when the air distribution control is on position  )



**Chart 4 : Air flow fault**  
(when the air distribution control is on this position  )



**Chart 6 : Air flow fault**  
(when the air distribution control is on position  
and the air mixing control is on maximum hot.)



Check the air inlet circuit, scuttle panel, passenger compartment fan, heating casing (coolant reservoir)... Repair if necessary. Does the fault persist?

no → **Correct**

yes

Check the air extraction circuit. Repair if necessary. Does the fault persist?

no → **Correct**

yes

Check the presence and connection of the ventilation ducts. Repair if necessary. Does the fault persist?

no → **Correct**

yes

The evaporator upstream of the heating radiator is blocked (leaves, insects ...).  
Remove the evaporator unit and clean or replace the evaporator

**Chart 7 : Air flow fault**  
(when the air distribution control is on position  
and the air mixing control is on maximum cold.)



Check the air inlet circuit, scuttle panel, passenger compartment fan, heating casing (coolant reservoir)... Repair if necessary. Does the fault persist?

no → **Correct**

yes

Check the air extraction circuit. Repair if necessary. Does the fault persist?

no → **Correct**

yes

Check the presence and connection of the ventilation ducts. Repair

Chart 8 : Controls stiff to operate




Chart 10 : Passenger compartment smells




Chart 11 : No hot air




Chart 12 : Too much hot air




Chart 13 : De-icing / de-misting efficiency fault




Chart 14 : No cold air






Chart 14 : No cold air (cont)





Chart 14 A : No cold air



(\*) Operating programming and voltages for control panel connector

Compressor clutch	AC running track A2	AC off track A5
Engaged	12 V	0 V
Not engaged	0 V	5 V

Chart 14 A : No cold air (cont)

A

Check for + 12 volts  
on track A1 of the trifunction pressostat connector.  
Is there + 12 volts ?

yes

Shunt the trifunction pressostat  
between tracks A1 and C1 and check if  
the compressor operates.  
Does the compressor clutch engage?

no

Check the wiring  
between track C1 of the  
pressostat and the  
compressor connector.

yes

Check there is freon in the circuit by pressing  
a filling valve

Note : when the engine is cold (not  
running) the pressure gauges  
should show between 5 and 7 bar  
high pressure and low pressure  
for a workshop temperature of  
20/25 °C.  
Is this correct?

yes

Replace the  
trifunction  
pressostat

no

Renew the freon in  
the circuit.

Chart 14 B : No cold air




Chart 14 C : No cold air






Chart 15 : Lack of efficiency



(\*) If the sensor resistance is incorrect :

- 1) Exceeds maximum limit. : The compressor operates too early which reduces its efficiency.
- 2) Exceeds minimum limit. : The compressor operates too late - the evaporator is icing up which reduces its efficiency and the air flow

Chart 15 : Lack of efficiency (cont)



(1) Note : Excess freon in the circuit will cause the compressor to operate too early and reduces the efficiency of the air conditioning system.

Chart 15 A : Lack of efficiency (cont)






Chart 15 A : Lack of efficiency (cont)

A

Check the pressures with the air conditioning system and passenger compartment fan on maximum.

If low pressure > 4 bar or high pressure = low pressure, the pressure release valve is fully open  
If high pressure = 0 bar, the pressure release valve is closed

Do you read these values?

yes

Replace the pressure release valve and renew the freon in the circuit

no

Renew the freon in the circuit.

Note : Do not use the freon inspection window since with refrigerant 134A there are always bubbles in the fluid, especially for a temperature > 30 °C.

Does the fault persist after repair?

no

Correct

yes

Take care if various operations have been performed on the circuit where oil has been added: there may be too much oil in the circuit. (\*)

If this is the case, remove the compressor and check its oil level (see method in air conditioning M.R. R134A), drain the oil from the pipes and the condenser, replace the dehydrating bottle and renew the freon in the circuit.

Does the fault persist?

no

Correct

yes

Replace the air conditioning compressor.

(\*) Warning : Type 709 compressors allow more oil to circulate in the circuit than compressor types 508 and 510. Do not use the dipstick to check the oil level.

Chart 16 : Too much cold air




CHART 16 : Too much cold air (cont)






Chart 17 : Recycling flap does not work



**Chart 18 :** Ventilation fan does not operate correctly  
(for 1 or more speeds)



**Chart 18 A : Ventilation fan does not operate correctly**  
(for 1 or more speeds)

Check the **20 A** fuse.  
Is the fuse correct?

no

See Chart 18 B.

yes

Does the 4th passenger compartment fan speed  
operate correctly?

no

Repair

yes

Check the control panel feeds on the panel  
connector :  
Tracks { B2 + 12 volts after ignition  
B3 earth  
Is this correct?

no

Repair the wiring between tracks:

Control	{	B2	→	fuse board
Panel		B3	→	AC wire joint → MK vehicle earth

yes

Ignition on.  
On the resistance module connector  
check for  
+ 12 volts between tracks:  
Fan control knob in position  
1st speed between B2 and A6 or A7  
2nd speed between B1 and A6 or A7  
3rd speed between B3 and A6 or A7  
Is this correct?

yes

Replace the electronic module

no

Ignition on  
On the control panel connector check for  
+ 12 volts between tracks :  
Fan control knob in position  
1st speed between A3 and B3  
2nd speed between B1 and B3  
3rd speed between A1 and B3  
Is this correct?

no

Replace the control panel

yes

Repair the wiring between tracks:

Control panel	{	A3	→	B2	}	electronic module
		B1	→	B1		
		A1	→	B3		

**Chart 18 B :** Ventilation fan does not operate correctly  
(for 1 or more speeds)




Chart 19 : Cooling fan does not operate correctly

The compressor operates






Chart 19 : Cooling fan does not operate correctly (cont)





Chart 19A : Cooling fan does not operate correctly ( 1st speed)



### REMOVAL

This operation requires the refrigerant circuit to be drained beforehand (method described in section "Air Conditioning - New Refrigerant R134a").

The dashboard must be removed to reach the evaporator unit.


To do this :

Disconnect the battery.



Remove:

- the steering wheel, after marking its position,
- the half cowl under the steering wheel,


- the upper half cowl,




the steering wheel cover : three bolts (A) and one clip (B),




- the lights / windscreen wiper control, the upper section of the dashboard (three bolts) Clips (C) slide to allow the upper section of the dashboard to be centred




**ATTENTION :** protect or remove the rear view mirror cover trim.



- the ashtray,




96 132 R




96 131 R


- the air conditioning control panel surround,



- the cigar lighter connectors,
- the control unit bolts.




Disconnect the main wiring




Remove the storage tray or radio.

Remove:


- the five upper dashboard mounting bolts,



- the lower side mountings,




- the lower and central mountings.




Disconnect the connectors and remove the dashboard with care.

Remove:

- mounting bolt (B) for the fan in the external air inlet chamber,




- the condensation drain pipe mounted at (E) on a chassis bolt.



Disconnect the refrigerant pipes from the pressure release valve.


Remove

- clip (2) and the pressure release valve protector,




- bolt (3).


Plug the four openings in the pipes and the pressure release valve quickly.



Remove the four mounting nuts (4) securing the evaporator unit to the bulkhead.




Remove the wiring from the evaporator unit and remove nut (F)




Remove:

- the two bolts (G) holding the evaporator unit to the distribution unit,
- the evaporator unit,
- the four bolts holding the recycling flap unit to the evaporator unit.




Separate the two sections of the unit by pulling the clips around the edge and removing bolt (H)



Remove the evaporator from the unit

Remove the pressure release valve which is mounted on the evaporator by two bolts (4)

Plug the refrigerant inlet and outlet openings quickly.





### REFITTING

Refitting is the reverse of removal.

Take care to ensure the flap control cables are correctly repositioned (heating and distribution)

Ensure the flaps operate correctly.

Reconnect the condensation drain pipe.

When fitting pipes to the various components use the recommended compressor oil to lubricate the seals.

Tighten bolt (3) which retains the refrigerant pipes to a torque of 0.9 daN.m.

Fill the air conditioning circuit using the filling station (method described in "Air Conditioning - New Refrigerant R134a").

**IMPORTANT :** the instructions relating to topping up the oil level during operations on the air conditioning circuit must be followed.

**ATTENTION :** ignition on, after reconnecting the battery, wait 10 seconds before starting the engine (injection computer programming).

# AIR CONDITIONING

## Passenger compartment fan


**62**

### REMOVAL


The dashboard does not need to be removed to remove the passenger compartment fan.

Remove :


- the air conditioning control panel surround,



- the lower and central dashboard mountings,




- the lower side mountings.



Tilt the dashboard around the upper mounting and hold it in that position.

Disconnect the fan wire from the electronic module and separate it.




# AIR CONDITIONING

## Passenger compartment fan

62

Turn the fan clockwise to align the tab (1) with lug (2) then extract the fan by pulling downwards



### REFITTING

When refitting reposition the fan in the same position as for extraction.

Lift the tab (1) and turn it anti-clockwise until it rests against the stop (3).

Reconnect the fan and thread the wire in the guides on the evaporator unit.

Refit the dashboard.

### REMOVAL

The refrigerant circuit must be drained before the compressor is removed (method described in section "Air Conditioning - New Refrigerant R134a").



Disconnect the battery

Lift the vehicle on a two post lift

Remove the engine undertray.


Slacken the compressor drive belt :

- tension wheel bolt (A) ,
- lock nut (1),
- tension adjusting bolt (2)



Disconnect the solenoid clutch connector (B)


Remove bolt (C) which secures the refrigerant pipe retaining bracket.



Remove the refrigerant pipes. Plug the four pipe openings quickly.

Loosen, but do not remove, the compressor / gear box tie-rod on the gear box side.

Remove the four compressor mounting bolts.



Release the tie-rod and the drive belt and remove the compressor

### REFITTING

Refitting is the reverse of removal.

Tighten the bolt for the refrigerant pipe retaining bracket (C) to a torque of 3 daN.m.

When fitting pipes to the various components use the recommended compressor oil to lubricate the seals.

Fill the air conditioning circuit using the filling station (method described in "Air Conditioning - New Refrigerant R134a")

**IMPORTANT :** the instructions relating to topping up the oil level during operations on the air conditioning circuit must be followed.


**ATTENTION :** ignition on, after reconnecting the battery, wait 10 seconds before starting the engine (injection computer programming).

SPECIAL TOOLING REQUIRED	
Mat. 1273	Belt tension testing tool
MATERIALS REQUIRED	
Engine - gear box support : DESVIL Part Number 300	

Special notes for removing and adjusting the tension of the compressor drive belt.

Place the vehicle on a vehicle lift.

Using the **DESVIL** tool Part Number 300, or an equivalent tool, support the weight of the engine to ensure its stability.





Lift the vehicle, remove the engine undertray and release the front right hand wheel arch protector by removing two clips.

Undo:

- the tension wheel mounting bolts (A),
- the lock nut (1) and bolt (2) to slacken the belt.

Remove the two front right hand engine mounting bolts (3)



Lower the engine a few centimetres using the engine support tool.

Release the drive belt by sliding it between the engine mounting and the side member

Fit the new belt in the same manner.

When refitting the engine mounting bolts (3) refer to chapter 10 of M.R. 305 to ensure the engine and transmission assembly is correctly positioned.

### Principle

The sensor ensures the belt has a constant deflection value by means of the adjusting button (1), the pressure device (2) and the external brackets (3).

The force of the belt reaction is measured by the test device (4) which is fitted with stress gauges.

Movement of the gauges creates a variation in their electrical resistance. This variation, once converted by the equipment, is displayed as SEEM units (US)


### Calibrating the equipment

The equipment is adjusted in the factory. The calibration settings must be checked every six months, however.

### Procedure

#### Adjusting the zero point :

- Turn the equipment on (switch D) with the adjusting button (1) screwed in fully.
- If the display is zero, the equipment is correctly calibrated.
- If there is no display at all, check the charge condition of the 9 V battery.
- If another value than 0 is displayed, move adjusting screw (E) until 0 is displayed



96 607 R1

- A Sensor
- B Display
- C Connection lead
- D On/off switch

- E Adjustment screw
- a Minimum value
- b Maximum value

### Checking the calibration of the equipment

Turn the equipment on.

Position the calibration spring blade (F) on the sensor as shown on the diagram (checking values are stamped on the calibration blade on the top).

Tighten the adjustment button (1) until it clicks for the third time.

Check the display shows a value "X" between "a" and "b".

**NOTE :** each set of equipment has a calibration spring blade of its own - do not exchange the blade with that belonging to other test equipment.

**NOTE:** several preliminary tests may have to be carried out before the correct value is reached.

If repeated incorrect values are obtained, contact your After Sales Head Office for further information.


#### GENERAL ADVICE:

- Never refit a drive belt once it has been removed - renew it.
- Never retension a belt if its tension value is between the fitting value and the minimum operating value
- If the tension is less than the MINIMUM operating value during a test, replace the belt


### Adjusting the drive belt tension

Fit the belt into place

Move tension adjusting bolt (2) to adjust the value.



Position the belt in tool Mot. 1273.



Turn the sensor wheel until it clicks.

Adjust the value shown on the display of tool Mot. 1273 by moving bolt (2) until a value of 116 US (SEEM units) is obtained.


Tighten the lock nut (1) ensuring that the value remains within a tolerance of  $\pm 7$  US.



Checking drive belt tension without removing the drive belt.

Lift the vehicle on a vehicle lift and remove the engine undertray.

Fit tool **Mot. 1273**.



Turn the sensor wheel until it clicks.

Check the value shown on the display of tool **Mot. 1273** is between :

- 75 → minimum operating tension and
- 116 → fitting value.

### REMOVAL

Disconnect the battery



Drain the refrigerant circuit (method described in "Air Conditioning - New Refrigerant R134a").

Lift the vehicle and remove the engine undertray

Remove:

- the refrigerant pipes on the condenser and plug the four openings quickly,
- the two main radiator mounting bolts (5).

Release the radiator from its upper guide holes and lower it



In this position, remove the four bolts (6) mounting the condenser on the radiator.

Extract the condenser from below to remove it

### REFITTING

Refitting is the reverse of removal.

Tighten the pipe unions on the condenser to a torque of :

- 2 daN.m : inlet (A),
- 1.2 daN.m : outlet (B)

When fitting pipes to the various components use the recommended compressor oil to lubricate the seals.

Fill the air conditioning circuit using the filling station (method described in section used for draining the circuit).

**IMPORTANT :** the instructions relating to topping up the oil level during operations on the air conditioning circuit must be followed.

**ATTENTION :** ignition on, after reconnecting the battery, wait 10 seconds before starting the engine (injection computer programming).


### REMOVAL

Disconnect the battery.


Drain the refrigerant circuit (method described in "Air Conditioning - New Refrigerant R134a").

Disconnect the refrigerant pipes from the pressure release valve.

Remove clip (2).




Remove the bolt (3) and plug the four openings quickly.



Remove the pressure release valve which is mounted on the evaporator by two bolts (4).

Plug the refrigerant inlet and outlet pipes immediately.



### REFITTING

Refitting is the reverse of removal.

When fitting pipes to the various components use the recommended compressor oil to lubricate the seals.

Tighten bolt (3) for the air conditioning pipes to a torque of 0.9 daN.m.

Fill the air conditioning circuit using the filling station (method described in section used for draining the circuit).

**IMPORTANT :** the instructions relating to topping up the oil level during operations on the air conditioning circuit must be followed.

**ATTENTION :** ignition on, after reconnecting the battery, wait 10 seconds before starting the engine (injection computer programming).

### REMOVAL

Disconnect the battery


Drain the refrigerant circuit (method described in "Air Conditioning - New Refrigerant R134a").

Disconnect the refrigerant pipes from the dehydrating bottle, bolt (1).

Plug the four openings quickly.

Remove:

- the trifunction pressostat (2),



- the three bolts, then the dehydrating bottle.

### REFITTING

Refitting is the reverse of removal.

When fitting pipes to the various components use the recommended compressor oil to lubricate the seals

Tighten the pipe retaining bracket to a torque of 0.8 daN.m.


Fill the air conditioning circuit using the filling station (method described in section used for draining the circuit).

**IMPORTANT :** the instructions relating to topping up the oil level during operations on the air conditioning circuit must be followed.

**ATTENTION :** ignition on, after reconnecting the battery, wait 10 seconds before starting the engine (injection computer programming).

### Electronic module (6)

The electronic module is mounted on the evaporator by the bolt (1).



To replace the electronic module, the dashboard must be removed. Refer to the section "Evaporator".

To remove the module, remove

- the various connectors,
- the bolt (1).


### Recycling motor (475)

This motor controls the movements of the recycling flap (re-use of air circulating in the passenger compartment).


It may be reached after removing the dashboard (see section on "Evaporator").

First of all, the evaporator unit must be placed to one side, without disconnecting the refrigerant pipes. To do this, from the engine compartment side, remove


- the nuts (4) which mount the evaporator unit on the bulkhead,




- the fan mounting bolt (B) in the scuttle panel,



- clip (2) and the pressure release protector.



- From the passenger compartment, remove :
- the two bolts (G) which mount the evaporator unit on the air distribution unit,
  - nut (F).




Disconnect the various wires from the electronic module and remove the connectors

Move the evaporator unit towards the rear of the vehicle and then downwards

In this position, remove :


- the recycling flap mounting bolts (L),



- the recycling motor mounting bolts (M) (475) from the flap mounting

### Evaporator sensor (408)

The temperature sensor (408) is mounted on the evaporator unit.



The sensor is sold with its connector

To remove the sensor, the dashboard must be tilted on its upper mountings (see "Removing the passenger compartment fan")

Disconnect the connector (1) on the electronic module and remove the sensor from its position.

### Conditions and values for checking the sensor

The sensor should be checked after removal from the vehicle.

Check the resistance values at the sensor terminals


- 5°C	→	11 400 to 11 900 Ω
0°C	→	8 800 to 9 200 Ω
5°C	→	6 800 to 7 200 Ω
10°C	→	5 300 to 5 600 Ω
15°C	→	4 200 to 4 400 Ω
20°C	→	3 300 to 3 600 Ω
25°C	→	2 600 to 2 800 Ω

**NOTE :** testing at 0°C (when water freezes) and 25°C (ambient temperature) should be enough to demonstrate the sensor is operating correctly.

### Trifunction pressostat (206)

This is mounted on the dehydrating bottle.

The refrigerant circuit does not need to be drained to work on the pressostat. Its mounting is fitted with a non-return valve which closes when the pressostat is removed.




The pressostat is mounted on the dehydrating bottle to a torque of 1 daN.m.

### 1st speed relay (233) and 2nd speed (234) of engine cooling fan (262)

The air conditioning relays are located in the connecting unit next to the battery

They are marked on the surface of the block in which they are connected (moulded marks) :

- A Relay 234 high speed 50A
- B Relay 233 low speed 25 A




As soon as the air conditioning system is operated, the coil of relay 233 is fed. The current passing through this relay and the 0.28  $\Omega$  resistance drops the current in the circuit, and makes the engine cooling fan operate at low speed

If there is excess pressure in the freon circuit or if the engine overheats, the coil of relay 234 is fed. The current passing through this relay feeds the engine cooling fan directly and the fan turns at high speed.


### 0.28 $\Omega$ Resistance (321)

This is mounted on the cooling fan assembly mounting.

The air filter sleeve and its mounting must be removed to reach this resistance



Remove the injection computer shield, bolt (1) then the resistance unit mounting bolts (321)



Disconnect the connector (A) to check the resistance value