



**N.T. 2621 A**

---

**C 066 - C 067 - S 066**

---

Basic manual: M.R. 305

---

# **SPECIAL FEATURES OF THE TWINGO FITTED WITH THE D7F ENGINE**

---

**77 11 190 948**

**September 1996**

**Edition Anglaise**

---

"The repair methods given by the manufacturer in this document are based on the technical specifications current when it was prepared

The methods may be modified as a result of changes by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed".

All copyrights reserved by the Régie Nationale des Usines Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of the Régie Nationale des Usines Renault S.A.



**Régie Nationale des Usines Renault S.A. 1996**

---

Contents

	Pages		Pages
<b>05 DRAIN AND FILL</b>		<b>12 FUEL MIXTURE</b>	
Engine	05-1	Specifications	12-1
		Throttle housing	12-4
		Inlet manifold	12-6
		Exhaust manifold	12-10
<b>07 VALUES AND SETTINGS</b>		<b>13 FUEL SUPPLY</b>	
Capacity	07-1	Injection rail	13-1
Accessories belt tensioning	07-2	Pump flow	13-4
Cylinder head tightening	07-3	Supply pressure	13-5
Front and rear axle angles	07-4		
<b>10 ENGINE AND PERIPHERALS ASSEMBLY</b>		<b>14 ANTI-POLLUTION</b>	
Consumables	10-1	Fuel vapour rebreathing	14-1
Identification	10-1	Oil vapour rebreathing	14-5
Oil pressure	10-2	Catalytic converter - Oxygen sensor	14-7
Engine - Gearbox	10-3	Lead detection test	14-8
Timing end crankshaft seal	10-11		
Sump	10-12	<b>16 STARTING AND CHARGING</b>	
Oil pump	10-13	Alternator	16-1
<b>11 TOP AND FRONT OF ENGINE</b>		Starter	16-3
Timing belt	11-1		
Cylinder head gasket	11-5		

## Contents

Pages

Pages

### 17 IGNITION - INJECTION

#### Ignition

Static ignition	17-1
Spark plugs	17-4

#### Injection

General	17-5
Location of components	17-7
Special features of semi-sequential ignition	17-9
Injection fault warning light	17-11
Engine immobiliser function	17-12
Computer configuration in relation to the type of gearbox	17-13
Injection strategy -	
Air conditioning	17-15
Idle speed adjustment	17-16
Idle speed adaptive adjustment	17-17
Mixture regulation	17-18
Adaptive mixture adjustment	17-20
55-way electrical wiring diagram	17-23
35-way electrical wiring diagram	17-28
Fault-finding for the 35-way computer	17-31
Fault-finding for the 55-way computer	17-119

### 19 RESERVOIR - COOLING - EXHAUST

#### Cooling

Specifications	19-1
Fill and bleed	19-2
Diagram	19-3
Coolant pump	19-5

#### Exhaust

Exhaust down-pipe	19-7
-------------------	------

### 20 CLUTCH

Identification	20-1
Cover - Disc	20-2

### 21 MANUAL GEARBOX

Gears	21-1
Capacity - Lubricants	21-1
Consumables	21-2
Parts which must always be replaced	21-2
Removal - Refitting	21-3

### 23 AUTOMATIC TRANSMISSION

Fault-finding	23-1
Identification	23-2
Gear ratios	23-2
Gear change thresholds	23-2
Consumables	23-3
Parts which must always be replaced	23-3
Oil	23-3
Drain and fill intervals	23-4
Drain - Fill - Levels	23-5
Oil pressure	23-6
Strainer	23-8
Removal - Refitting	23-9
Starter plate	23-18
Computer and wiring	23-20
Electronic control wiring	23-23

### 37 MECHANICAL COMPONENTS CONTROL

Selector control computer	37-1
Selector control	37-3


# DRAIN AND FILL Engine

05


## TOOLS REQUIRED

Engine drain plug wrench

DRAIN: plug (1)




FILL: plug (2)



## DIPSTICK

The dipstick (3) must be released from its clip (4) before it can be removed.

- A Minimum level
- B Maximum level



VALUES AND SETTINGS

Capacity

07

Units	Capacity in litres	Quality	Special features
Engine  D7F	When draining  4 with filter  (0.2 litres for the oil filter)	<div>EU countries</div> <div><div><div><div><div>-30°C</div><div>-20°C</div><div>-15°C</div><div>-10°C</div><div>0°C</div><div>+10°C</div><div>+20 °C</div><div>+25°C</div><div>+30°C</div></div><div><div>CCMC-G4</div><div>ACEA A2-96/A3-96</div><div>15W40-15W50</div><div>15W40-15W50</div></div><div><div>CCMC-G5</div><div>ACEA A2-96/A3-96</div><div>10W30-10W40-10W50</div><div>10W30-10W40-10W50</div></div><div><div>CCMC-G5</div><div>ACEA A2-96/A3-96</div><div>5W30</div><div>5W30</div></div><div><div>CCMC-G5</div><div>ACEA A2-96/A3-96</div><div>5W40-5W50</div><div>5W40-5W50</div></div></div></div></div>	
		<div>Other countries</div> <div><div><div><div><div>-30°C</div><div>-20°C</div><div>-15°C</div><div>-10°C</div><div>0°C</div><div>+10°C</div><div>+20 °C</div><div>+30°C</div></div><div><div>API SH 15W40</div><div>API SH 10W40</div><div>API SH 10W30</div><div>API SH 5W30</div></div></div></div></div>	
Manual gearbox JB1	3.4	Quality	Special features
		All countries :TRANSELF TRX 75 W 80 W ( API G L 5 or MIL - L2105 C or D standards)	
Automatic transmission MB1	4.5	ELF RENAULT MATIC D2 or if this is not available : MOBIL ATF 220	
Braking system	0.7	SAE J 1703 and DOT 4	Brake fluids must be approved by the engineering centre
Engine cooling circuit	5	Glacéol RX (type D) only use coolant	Protection to -25 ± 2 °C for hot, temperate and cold climates. Protection to -37 ± 2 °C for very cold climates.
Fuel tank	40	Unleaded petrol	-

SPECIAL TOOLS REQUIRED

Mot. 1273

Tool for checking belt tension


INSTRUCTIONS FOR TENSIONING

With the engine cold (ambient temperature), fit the new belt.

Fit the sensor of tool **Mot. 1273** as shown (→).

Turn the sensor wheel until it clicks.

The alternator belt is tensioned using the tool made on site, shown below (100mm long threaded rod (X) and three M6 nuts)



Tension the belt until the recommended fitting value shown below is displayed on **Mot. 1273**.

Lock the tensioner, carry out a check, adjust the value.


Rotate the crankshaft three times.

Carry out a check and adjust the value to the recommended fitting tension if necessary.

**Never refit a belt which has been removed, fit a new belt.**

Tension (US = SEEM unit)	Multi-tooth alternator belt
Fitting	$102 \pm 7$
Minimum operating tension	53

Alternator belt



- 1 Crankshaft
- 2 Alternator
- Tension checking point

CYLINDER HEAD

Refresher

In order to correctly tighten the bolts, remove any oil from the cylinder head mounting holes using a syringe.


Lubricate the bolt threads and under the bolt heads using engine oil.

Setting of the rockers and tightening of the cylinder head must be carried out when cold.

CYLINDER HEAD TIGHTENING PROCEDURE

a) Pre-seating the seal

Tighten all the bolts to **2 daN.m** then make an angle of 90° in the order shown below.



Wait for **3 minutes**, to allow stabilisation.

b) Cylinder head tightening

Slacken the bolts marked 1 and 2 until they are completely released.

Tighten bolts 1 and 2 to **2 daN.m**, followed by an angle of **200°**.

Slacken bolts 3-4-5-6 until they are completely released.

Tighten bolts 3-4-5-6 to **2 daN.m**, followed by an angle of **200°**.

Slacken bolts 7-8-9-10 until they are completely released.

Tighten bolts 7-8-9-10 to **2 daN.m**, followed by an angle of **200°**.

The front and rear axle angles are identical to those of vehicle's fitted with engine C.



Type	Quantity	Units
RHODORSEAL 5661	Coat	Coolant pump and oil pump sealing
Loctite FRENBLOC Locking and sealing resin	Coat	Brake caliper mounting bolts
Loctite FRENETANCH Locking and sealing resin	Coat	Crankshaft pulley mounting bolts
MOLYKOTE CU. 7439	Coat	For aligning the wheels.
Exhaust pipes paste	Coat	Exhaust sealing.

Identification

Type of vehicle	Engine	Manual or automatic gearbox	Cubic capacity (cm³)	Bore (mm)	Stroke (mm)	Compression ratio
C 066 S 066 C 067	D7F	JB1 MB1	1149	69	76.8	9.65/1

For engine repairs, refer to fascicule Mot. D (E)


### CHECK

#### SPECIAL TOOLS REQUIRED

Mot. 836-05 Oil pressure connection kit

The oil pressure must be checked while the engine is warm (approximately 80 °C).


Contents of kit **Mot. 836-05**.



### USE:

**Engine D : F + C**

Connect the pressure gauge in place of the pressure switch to the rear of the oil pump.



### Check

- at idle: 0.8 bar
- at 4000 rpm. : 3.5 bars

### SPECIAL TOOLS REQUIRED

B. Vi. 31-01	Roll pin spindles
Mot. 453-01	Pliers for flexible pipes
Mot. 1202	Spring clip pliers
T. Av. 476	Ball joint extractor
Mot. 1272	Engine-Gearbox assembly positioning tool

### TIGHTENING TORQUES (in daN.m)




Brake caliper mounting bolt	3.5
Shock absorber base mounting bolt	11
Steering ball joint	3.5
Driveshaft gaiter mounting bolt	2.5
Gearbox rear mounting mounting bolt	9.5
Mounting bolt which secures the front mounting to the engine	5.5
Mounting bolt which secures the front right mounting to the side member	5.5
Mounting bolt which secures the front left mounting to the side member	4.2
Mounting bolt which secures the front left mounting to the gearbox	3.9

### REMOVAL


Place the vehicle on a two post lift.

Remove:

- the battery,
- the wheels
- the left and right hand mud shields,



- the engine undertray,



- the bumper,
- the exhaust down-pipe mounting bolts disconnecting the oxygen sensor connector and attaching it to the subframe.

### Drain:

- the gearbox oil,
- the engine oil if necessary,
- the cooling circuit (lower radiator hose).

### Right hand side

#### Remove:

- the driveshaft pin with the spindles **B. Vi. 31-01**,
- the steering tie rod ball joint using tool **T. Av. 476**,
- the upper shock absorber base bolt and slacken the lower bolt,

Tilt the stub axle carrier and uncouple the driveshaft.

### Left hand side


#### Remove:

- the two brake caliper mounting bolts then secure the caliper to the shock absorber spring,
- the ABS sensor if fitted,
- the steering ball joint using extractor **T. Av. 476**,
- the driveshaft gaiter fasteners,
- the lower ball joint bolt,
- the two shock absorber base bolts,
- the hub assembly assembled with the driveshaft.


Take care to protect the tripod.

#### Remove:

- the mounting bolt which secures the rear gearbox mounting to the subframe,



- the flexible air pipe on the air filter,
- the injection computer cover,
- the accelerator cable,
- the injection computer and automatic transmission mountings, and disconnect the connector (1) on models with automatic transmission.




- the mounting bolts which secure the injection rail to the inlet manifold.


Unclip the two fuel pipes on the bracket (2).

Disconnect:


- the upper radiator hose,
- the heating hose (3),
- the connector (4) on the thermal switch,



- the fuel supply pipe using tool **Mot.1311-06** (the removal tool is connected to the connector on the vehicle) and the fuel return pipe, then remove them from the injection rail,




- the vacuum connection pipe on the brake servo,
- the upper expansion bottle pipes moving the windscreen washer bottle aside,
- the thermistor connectors (on the radiator) and the fan assembly connectors,
- the two pipes on the canister using pliers **Mot. 1265** for the pipe from the fuel tank.




Remove:

- the gearbox control cable


### Manual gearbox model



### Automatic gearbox model




Disconnect the headlight unit connectors and the right wing repeater connector.




Remove:


- the radiator mountings (A) and remove the radiator,
- the earth strap on the right wing,
- the bonnet opening system mountings (1) and unhook the cable,
- the headlight unit support panel at (C) moving the electrical harness (D) and the bonnet opening system cable aside,




- the engine connection unit mounting bolts (2) and the connectors (3) and ((4) on models with automatic transmission) and the fuse boxes (5) and ((6) on models with automatic transmission), then place the unit on the engine.



- the two earth straps (7),




- the ABS computer mountings, if ABS is fitted, then move the computer aside and disconnect the connectors (8) and (9),



Disconnect the ignition coil connectors.

Remove the ignition coil mounting bolts and move the ignition coil aside.


Fit a chain to the lifting plates and raise the engine-gearbox assembly using a workshop crane.




Disconnect the impact switch connector (1).

Remove:

- the engine pendulum mounting system,



- the gearbox mounting.



Remove the engine-gearbox assembly.


### REFITTING (Special features)

**Please note the importance of correctly positioning the engine -gearbox assembly in the engine compartment.**

Fit the rear mounting bolt.

Fit the front right engine mounting and pretighten the bolts in the following order:


Bolts (1), (2) and (3) then bolt (4).



Fit the gearbox mounting without putting it under stress.




Using tool **Mot, 1272** position the engine-gearbox assembly in relation to the left rear subframe guide hole and the clutch bellhousing guide hole.



Tighten the gearbox mounting mounting bolts.

### CHECK

In order to check that the fan assembly is positioned correctly, the measurement shown below must be taken.



If this measurement is not correct ( $28 \text{ mm} \pm 1$ ), mark the actual position on the side member.

If the measurement is less than 27 mm, loosen the front mounting concerned and push section (A) back.

Retighten.


Check the new position and repeat the operation if necessary.

If the measurement is greater than 29 mm, carry out the same procedure but let section (A) move forward.

Next tighten the gearbox mounting mounting bolts to **4.2 daN.m**, making sure that section (A) is not moved by the tightening torque and that it remains parallel with the vertical surface of the side member.

Tighten the engine mounting in the following order:

Bolts (3), (1) and (2) then bolt (4) to **5.5 daN.m**.



### REFITTING (cont)

Refit in the reverse order to removal.  
Apply **RHODORSEAL 5661** to the driveshaft pin holes.



Fit the caliper mounting bolts coated with loctite **FRENBLOC** and tighten them to the recommended torque.

Press the brake pedal several times so that the pistons come into contact with the brake pads.

Adjust the accelerator cable.

Carry out the following:

- fill the gearbox
- fill the engine if necessary
- fill and bleed the cooling circuit (**refer to section 19, Fill-Bleed**).

# ENGINE AND PERIPHERALS ASSEMBLY

## Timing end crankshaft seal

10

### SPECIAL TOOLS REQUIRED

Mot. 1054	Top dead centre setting rod
Mot. 1272	Engine-gearbox assembly positioning tool
Mot. 1273	Tool for checking belt tension
Mot. 1355	Crankshaft seal installation tool
Mot. 1374	Crankshaft seal removal tool
Mot. 1399	Tool for locating the engine on the subframe

### TIGHTENING TORQUES (in daN.m or in degrees)




Crankshaft outlet mounting bolt	2 + 80°
Mounting bolt which secures the front right mounting to the engine	5.5
Mounting bolt which secures the front right mounting to the side member	5.5
Timing belt tensioner roller nut	5
Wheel bolt	9

### CHANGING

#### REMOVAL

Remove the timing belt (refer to section 11, timing belt).

To remove the crankshaft seal, use **Mot. 1374**.




Screw the body of the tool into the seal via nut (1) then act on bolt (2) to extract the seal.

#### FITTING

Fit the new seal to the crankshaft output shaft without damaging it on passing through the timing gear driving groove.

Fit it using tool **Mot. 1355**.



Fit:

- the new timing belt (refer to the procedure described in section 11, timing belt),
- the new alternator belt (refer to the tensioning procedure and value in section 07, Accessories belt tensioning).

TIGHTENING TORQUES (In daN.m)



Sump mounting bolt

1

### REMOVAL


Place the vehicle on a two post lift.

Disconnect the battery.

Drain off the engine oil.

Remove:

- the engine undertray,




- the engine flywheel protector.

Slacken the electrical harness bracket bolt.

Remove the sump mounting bolts.

Turn the sump towards the rear of the vehicle, following the direction of the arrow shown below, in order to disengage the oil pump strainer from the sump wall.




### REFITTING

Clean the mating surfaces.

**NOTE:** the sump must only be sealed using the special service seal.


Smooth surface, crankcase end.



Refit in the reverse order to removal.

Charge with oil.

SPECIAL TOOLS REQUIRED	
Mot. 1054	Top dead centre setting rod
Mot. 1272	Engine-gearbox assembly positioning tool
Mot. 1273	Tool for checking belt tension
Mot. 1355	Crankshaft seal installation tool
Mot. 1374	Crankshaft seal removal tool
Mot. 1399	Tool for locating the engine on the subframe

TIGHTENING TORQUES (in daN.m or in degrees)		
Crankshaft outlet mounting bolt	2+80°	
Mounting bolt which secures the front right mounting to the engine	5.5	
Mounting bolt which secures the front right mounting to the side member	5.5	
Timing belt tensioner roller nut	5	
Sump mounting bolt	1	
Oil pump mounting bolt	0.9	
Wheel bolt	9	

### REMOVAL

Drain off the engine oil.


Remove:

- the timing belt (refer to the procedure described in **section 11, Timing belt**),
- the dipstick,

Remove:

- the engine flywheel protector.

Slacken the electrical harness mounting bolt and remove the sump mounting bolts.



10077R2

Turn the sump towards the rear of the vehicle, following the direction of the arrow shown above, in order to disengage the oil pump strainer from the sump wall.

Remove the crankshaft seal using **Mot. 1374** (refer to **section 11, Timing end crankshaft seal**)


Remove:

- the oil pump strainer,
- the oil pump.


Clean the mating surfaces without scratching the aluminium surfaces.

#### REFITTING

Always replace the oil pressure supply seal (3).



The oil pump is sealed using **RHODORSEAL 5661**, the bead (5) must be applied as shown in the illustration below.




**WARNING:** the oil pump is driven by the two actuators on the crankshaft.


Refit the oil pump to the engine, tighten it to : **0.9 daN.m.**

Fit the new seal to the crankshaft output shaft without damaging it on passing through timing gear driving groove.

Fit it using tool **Mot. 1355**.




Refit the strainer fitted with its new O-ring.



Refit the sump.

**NOTE:** the sump must only be sealed using the special service seal.

Smooth surface, crankcase end



Tighten the bolts to: **1 daN.m.**

Fit:

- the new timing belt (refer to the procedure described in **section 11, Timing belt**),
- the new alternator belt (refer to the tensioning procedure and values in **section 07, Accessories belt tensioning**).

Charge with engine oil.

# TOP AND FRONT OF ENGINE

## Timing belt

11

### SPECIAL TOOLS REQUIRED

Mot.1054	Top dead centre setting rod
Mot 1135-01	Timing belt tensioner
Mot. 1272	Engine-gearbox assembly positioning tool
Mot. 1273	Tool for checking belt tension
Mot. 1386	Timing belt pre-stressing tool
Mot. 1399	Tool for locating the engine on the subframe

### TIGHTENING TORQUES (In daN.m or degrees)



Crankshaft pulley mounting bolt	2 + 80°
Mounting bolt which secures the front right mounting to the engine	5.5
Mounting bolt which secures the front right mounting to the side member	5.5
Timing belt tensioner roller nut	5
Wheel bolt	9


### REMOVAL

Place the vehicle on a two post lift.


Disconnect the battery.

Remove:


- the engine undertray,



- the front right wheel,
- the front right mud shield.




Fit the engine mounting **Mot. 1399**.







Remove:

- the alternator belt,
- the crankshaft pulley,
- the pendulum mounting system, disconnecting the connector (1) and the diagnostics socket (2).




Position the engine at Top Dead Centre using **Mot. 1054**, aligning the marks on the camshaft and crankshaft gear with the fixed marks.



Remove the timing covers and the timing belt.

**WARNING:** the camshaft gear has five marks, only the rectangular mark on the surface of a tooth represents Top Dead Centre; the other marks are for setting the rockers.



### REFITTING

Align the marks on the timing belt with the marks on the crankshaft and camshaft gear.

# TOP AND FRONT OF ENGINE

## Timing belt


11

### PROCEDURE FOR TENSIONING THE TIMING BELT

Remove the setting rod **Mot. 1054**.

Fit the spacer of **Mot. 1386** (1) and tighten the crankshaft gear bolt.

- a) Fit **Mot. 1273** and using **Mot. 1135-01**, turn the tensioner roller anti-clockwise until a value of **20 US** is obtained (turn the sensor wheel until it clicks three times).



Tighten the tensioner roller nut.

Turn by a minimum of two engine revolutions (without ever turning backwards).

Set the engine at TDC, then remove the setting rod.

Check that the timing setting is correct on the crankshaft and camshaft end.


Slacken the tensioner roller nut and turn the tensioner roller slightly anti-clockwise using **Mot. 1135-01** until the two openings on the tensioner roller are approximately horizontal.

Retighten the tensioner roller nut.

- b) Turn by a minimum of two engine revolutions (without ever turning backwards).

\Set the engine at TDC, then remove the setting rod.

Apply a pre-stress of **10 daN.m** using **Mot. 1386** between the crankshaft gear and the coolant pump.



Fit **Mot. 1273** and read the **tension** value which must be **20 ± 3 US (Fitting tension)**, otherwise adjust it by altering the position of the tensioner roller using **Mot. 1135-01** and restart the tensioning procedure at b).

Tighten the tensioner roller nut to **5 daN.m**.

Fit the new alternator belt (refer to the tensioning procedure and value section 07, Accessories belt tensioning).

### IMPORTANT :

The following is **imperative** :

- turn by a minimum of two engine revolutions after each alteration of the tensioner roller position in order to measure the tension.
- pre-stress to **10 daN.m** in order to eliminate all belt slack.

**NOTE** :-never refit a belt which has been removed,

- change the belt if the tension is **below the minimum operating tension (10 US)**.


# TOP AND FRONT OF ENGINE

## Timing belt


11

Refit in the reverse order to removal.

Fit the engine mounting and pretighten in the following order:  
Bolts (1), (2) and (3), then bolt (4).



Using tool **Mot. 1272** position the engine-gearbox assembly in relation to the left rear subframe guide hole and the clutch bellhousing guide hole.




Tighten bolts (1), (2) and (3) and then bolt (4) to **5.5 daN.m.**

# TOP END FRONT OF ENGINE

## Cylinder head gasket

11

SPECIAL TOOLS REQUIRED	
Mot. 591-04	Angular wrench for tightening the cylinder head and index
Mot. 1054	Top dead centre setting rod
Mot. 1135-01	Timing belt tensioner
Mot. 1202	Spring clip pliers
Mot. 1272	Engine-gearbox assembly positioning tool
Mot. 1273	Tool for checking belt tension
Mot. 1386	Timing belt pre-stressing tool
Mot. 1399	Tool for locating the engine on the subframe
EQUIPMENT REQUIRED	
Sixe 12 torx socket	
Angular tightening locking device	

TIGHTENING TORQUES (in daN.m or in degrees)		
Crankshaft outlet mounting bolt	2 + 80°	
Mounting bolt which secures the front right mounting to the engine	5.5	
Mounting bolt which secures the front right mounting to the side member	5.5	
Timing belt tensioner roller nut	5	
Wheel bolt	9	

### REMOVAL

Place the vehicle on a two post lift.

Disconnect the battery.


Remove:

- the timing belt (refer to the procedure described in **section 11, Timing belt**),
- the dipstick,
- the two air filter air pipes,
- the accelerator cable.

Drain the cooling circuit via the lower radiator hose.

Remove the hoses and the connectors on the thermostat and the cylinder head.

Unclip the two fuel pipes on the bracket (2).




# TOP AND FRONT OF ENGINE

## Cylinder head gasket



11

Disconnect:

- the following connectors:
  - absolute pressure sensor (1),
  - idle regulation stepping motor (2),
  - throttle position potentiometer (5),
  - air temperature sensor (6),
- the vacuum connection pipe (8), the fuel vapour rebreather (9) and the solenoid valve connector,



- the vacuum connection pipe on the brake servo,
- the connectors on the ignition coil and the injection rail,
- the spark plug wires using tool (3) integral with the plastic protector (4).




# TOP AND FRONT OF ENGINE

## Cylinder head gasket

11


Remove:

- the mounting bolts (5) which secures the throttle housing stiffening plate to the cylinder head,
- the mounting nuts (3) which secure the manifold to the cylinder head,
- the mounting bolts (4) which secure the manifold to the cylinder head cover,



Uncouple the manifold from the cylinder head and turn it a half turn.

Remove the injection rail mounting bolts (19) and remove the manifold.



# TOP AND FRONT OF ENGINE

## Cylinder head gasket

11

Remove the air filter.

Remove the coolant pump-heater matrix hose and the electrical harness from the heat shield on the cylinder head cover.

Remove:


- the cylinder head cover,
- the exhaust down-pipe,
- the oxygen sensor connector,
- the cylinder head mounting bolts,
- the cylinder head.

### CLEANING

It is very important that the mating surfaces of the aluminium parts are not scratched.

Use **Décapjoint** to detach the part of the seal which remains attached.

Apply the product to the section to be cleaned. Wait for approximately ten minutes then remove it using a wooden spatula.



You are advised to wear gloves when carrying out this operation.

**Please note that care must be taken when carrying out this operation in order to prevent the entry of foreign bodies into the pipes which supply oil under pressure to the camshaft (pipes located both in the crankcase and in the cylinder head).**

**If this advice is not followed there is a risk that the jets may become clogged and the cams and tappets will quickly become damaged.**

# TOP AND FRONT OF ENGINE

## Cylinder head gasket


11

### CHECKING THE SEAL SURFACE

Using a ruler and a set of shims, check whether the mating surface is deformed.

Maximum deformation: **0.05 mm**

**Grinding of the cylinder head is strictly forbidden.**



### REFITTING

The cylinder head is aligned by two dowel pins at the rear of the engine.

#### Refresher:

In order to correctly tighten the bolts, remove any oil from the cylinder head mounting holes using a syringe.

Lubricate the bolt threads and under the bolt heads using engine oil.


**Setting of the rockers and tightening of the cylinder head must be carried out when cold.**

Tighten the cylinder head using an angular tightening locking device (refer to **section 07, cylinder head tightening**).

Fit:

- the new timing belt (refer to the procedure described in **section 11, Timing belt**).
- the new alternator belt (refer to the tensioning procedure and value **section 07, Accessories belt tensioning**).

**WARNING:** the camshaft gear has five marks, only the rectangular mark on the surface of a tooth represents Top Dead Centre; the other marks are for setting the rockers.



Remove the Top Dead Centre setting rod.



# TOP AND FRONT OF ENGINE

## Cylinder head gasket

11

### ADJUSTMENT OF THE ROCKERS IF NECESSARY

Partially refit the pendulum mounting system timing cover to the engine using two bolts.

Set the engine at Top Dead Centre, cylinder n° 1 at ignition.

Turn the crankshaft clockwise (as seen from the timing end) to reach the first mark.

SET:      exhaust 1  
             exhaust 3

advance to the second mark:


SET:      intake 1  
             intake 3

third mark:

SET:      exhaust 2  
             exhaust 4


fourth mark:

SET:      intake 2  
             intake 4




### CLEARANCE SETTING VALUE AT THE VALVES (mm)

Intake	0.1
Exhaust	0.2



Fit the engine mounting and pretighten the bolts in the following order:

Bolts (1), (2) and (3) then bolt (4).




# TOP AND FRONT OF ENGINE

## Cylinder head gasket

11

Using tool **Mot. 1272** position the engine-gearbox assembly in relation to the left rear subframe guide hole and the clutch bellhousing guide hole.



Tighten bolts (3), (1) and (2), and then bolt (4) to **5.5 daN.m.**

Refit in the reverse order to removal.

Remove the tool for locating the engine on the subframe **Mot. 1399**.

**NOTE :** tightening of the inlet manifold:

- gradually close up the six nuts until the manifold comes into contact with the cylinder head then tighten them to **1.5 daN.m**,
- fit the upper bolts and tighten them to **0.9 daN.m**.

Fill and bleed the cooling circuit (refer to **section 19, Fill and Bleed**).

Adjust the accelerator cable.

# FUEL MIXTURE

## Specifications

# 12

Vehicle	Gear-box	Engine							Anti-pollution standard
		Type	Index	Bore (mm)	Stroke (mm)	Cubic capacity (cm <sup>3</sup> )	Compression ratio	Catalytic converter	
X 066 X 067	JB1	D7F	700	69	76.8	1149	9.65/1	◇ C62	EU 96
X 066 X 067	MB1	D7F	701	69	76.8	1149	9.65/1	◇ C62	EU 96

Engine		Checks to be carried out at idle*					Fuel*** (Minimum octane rating)
		Speed (rpm)	Emission of pollutants **				
Type	Index		CO (%) (1)	CO <sub>2</sub> (%)	HC (ppm)	Lambda (λ)	
D7F	700 701 (2)	740 ± 50	0.5 max	14.5 min	100 max	0.97< λ <1.03	Unleaded (IO 95)

- (1) at 2500 rpm, the CO level must be 0.3 maximum.  
(2) in Park or Neutral.

\* For a coolant temperature greater than 80 °C and following a constant engine speed of 2500 rpm for approximately 30 seconds. Check to be carried out after return to idle.  
\*\* For legislative values, refer to the specification for the country concerned.  
\*\*\* IO 91 compatible unleaded.

Temperature in °C (± 1°)	0	20	40	80	90
Air temperature sensor CTN type Resistance in Ohms	5000 to 7000	1700 to 3300	800 to 1550	-	-
Air temperature sensor CTN type Resistance in ohms	-	3060 to 4045	1315 to 1600	300 to 370	210 to 270

FUEL MIXTURE  
Specifications

DESCRIPTION	BRAND/TYPE	SPECIAL NOTES		
Computer	SAGEM or MAGNÉTI MARÉLLI	35-way vehicle with manual gearbox with no optional equipment 55-way vehicle with automatic transmission or air conditioning		
Injection	-	Regulated semi-sequential monopoint		
Ignition	-	Static with a monobloc with two coils with two outlets Power module integral with the computer. A pinking sensor tightening torque: <b>2.5 daN.m</b>	Tracks	Resistance
			1 - 2	2 Ω
			1 - 4   1 - 3 2 - 3   2 - 4	1.6 Ω
			3 - 4	1.1 Ω
			HT - HT	10 KΩ
Top Dead Centre Sensor	-	Resistance <b>220 Ω</b>		
Spark plugs	EYQUEM/FN 52 LS NGK/BK5 E SZ	Gap: <b>0.9 mm</b> Tightening: <b>2.5 to 3 daN.m</b>		
Air filter	-	Change after every two draining operations		
Fuel filter	-	Secured to the front of the fuel tank under the vehicle Change at every service		
Feed pump	WALBRO	Immersed in the fuel tank Flow: <b>80 l/h</b> minimum with a regulated pressure of <b>3 bars</b> and with a voltage of <b>12 volts</b>		
Pressure regulator	-	Regulated pressure With zero vacuum : <b>3 ± 0.2 bars</b> With 500 mbars vacuum : <b>2.5 ± 0.2 bars</b>		
Electromagnetic injectors	SIEMENS	Voltage : <b>12 Volts</b> Resistance: <b>14.5 ± 1 Ω</b>		

FUEL MIXTURE  
Specifications

12

DESCRIPTION	BRAND/TYPE	SPECIAL NOTES			
Throttle housing	MAGNETI MARELLI 873 633	Ø 36 mm			
Idle regulation stepping motor	AIR PAX	Voltage: <b>12 V</b> (at high frequency) Resistance: Tracks A-D <b>53 ± 5 Ω</b> Tracks B-C <b>53 ± 5 Ω</b>			
Throttle potentiometer	-	Voltage: <b>5 V</b> Resistance:	Track	PL	PF
			AB	1200 Ω	1200 Ω
			AC	1260 Ω	2200 Ω
			BC	2200 Ω	1260 Ω
Canister fuel vapour recirculation Solenoid valve	CAN 01 DELCO REMY	Voltage: <b>12 Volts</b> Resistance: <b>35 ± 5 Ω</b>			
Heated oxygen sensor	BOSCH LSH 24	Voltage supplied at <b>850 °C</b> Rich mixture > <b>625 mvolts</b> Lean mixture : <b>0 to 80 mvolts</b> Heating resistor tracks A-B : <b>3 to 15 Ω</b> Tightening torque : <b>5 daN.m</b>			
Fault-finding	FICHE n° 27 CODE D13 SELECTOR S8	Throttle potentiometer : At idle regulation : <b>10 ≤ # 17 ≤</b> At full load: <b>193 ≤ # 17 ≤240</b> OCR idle: <b>4 % ≤ # 12 ≤15 %</b>  Adaptive OCR idle: - <b>4.3 % ≤ # 21 ≤+3.9 %</b> Adaptive operating richness: <b>96 ≤ # 30 ≤160</b> Adaptive idle richness : <b>96 ≤ # 31 ≤160</b>			

### TIGHTENING TORQUES (in daN.m)



Mounting bolt which secures the throttle housing to the inlet manifold	1
Mounting bolt which secures the throttle housing stiffening plate to the cylinder head	1


### REMOVAL

Disconnect the battery.

Remove the two air pipes on the air filter.

Disconnect:

- the stepping motor (3),
- the air temperature sensor (4),
- the accelerator cable (5),
- the throttle potentiometer (6).




11313R

Remove the three throttle housing mounting bolts

Remove the two mounting bolts (7) which secure the stiffening plate to the cylinder head (leave the plate secured to the throttle housing).

Remove the throttle housing and the stiffening plate.



99942R

The throttle potentiometer and the stepping motor cannot be removed without removing the throttle housing.


The throttle position potentiometer cannot be adjusted.

### REFITTING

Change the seal between the throttle housing and the manifold.

Slacken the two bolts which secure the stiffening plate to the throttle housing. On refitting, tighten the three bolts which secure the throttle housing to the manifold first, then tighten the stiffening plate to the manifold and the throttle. This procedure must be followed in order to avoid a pre-stress on the throttle housing which will result in an air leak.


Other refitting operations are the reverse of removal.



# FUEL MIXTURE

## Inlet manifold

12



TIGHTENING TORQUES (in daN.m)		
Mounting bolt which secures the injection rail to the manifold	1	
Mounting nut which secures the manifold to the cylinder head	1.7	
Mounting stud which secures the manifold to the cylinder head	1	

### REMOVAL

Disconnect the battery.

Remove the two air pipes on the air filter.

Disconnect the spark plug leads using the tool (3) integral with the plastic protector (4).





Remove the upper section of the plastic protector.

Tilt the spark plug leads to the right hand side of the vehicle.

Disconnect:


- the oil vapour rebreather (3) on the manifold,
- the fuel vapour rebreathers (4) on the solenoid valve,
- the pressure connection pipe (5) on the pressure regulator,
- the brake servo vacuum connection pipe (6),
- the pressure sensor vacuum connection pipe (7),
- the fuel supply pipe (8) and the fuel return pipe (9),
- the idle regulation stepping motor connector (10),

- the throttle position potentiometer connector (11),
- the air temperature sensor connector (12),
- the injectors connector (13),
- the accelerator cable (18).

Remove the dipstick (15).

Remove the 6 mounting bolts which secure the manifold to the cylinder head.

Remove the 2 mounting bolts (17) which secure the manifold to the top of the cylinder head.




**NOTE:** on models with air conditioning, the accessories belt must be removed and the accessories must be unscrewed in order to remove the manifold.

# FUEL MIXTURE

## Inlet manifold


12

Remove the 2 bolts which secure the throttle housing stiffening plate to the cylinder head.



Uncouple the manifold from the cylinder head and turn it a half turn.


Remove the 2 bolts (19) which secure the injection rail to the manifold.



Remove the injection rail.

Tilt the fuel supply pipe.

Remove the manifold.




### REFITTING

Change the manifold seal.

Reposition the fuel return pipe and the fuel vapour rebreather before repositioning the injection rail.

On models with air conditioning, change the accessories belt.

Other operations are the reverse of removal.



### TIGHTENING TORQUES (in daN.m)




Manifold mounting nut	2.5
Manifold mounting stud	1
Bolt which secures the exhaust down-pipe	2.2

### REMOVAL

Raise the vehicle.


Secure the exhaust line to the body using string.

Unscrew the clip (1) which secures the catalytic converter to the exhaust line.



Disconnect the oxygen sensor (2).

Remove the two bolts (3) which secure the exhaust manifold to the catalytic converter then remove it.




Remove the 7 bolts which secure the exhaust manifold to the cylinder head, then remove it.

### REFITTING

Change the manifold seal.

Refit in the reverse order to removal.



To align the exhaust down-pipe correctly, the positioning measurements must be observed (Procedure and value described in section 19 Exhaust).

### SPECIAL TOOLS REQUIRED

Mot. 1311-06      Fuel connectors removal tool

### TIGHTENING TORQUES (in daN.m)




Mounting bolt which secures the  
injection rail to the manifold

1

### REMOVAL

Disconnect:


- the battery.
- the pressure regulator pressure connection pipe (1),
- the fuel pipe (2),
- the injectors electrical connector (3).



99937R6


Disconnect:

- the fuel supply pipe (4) using the large cross-section tool **Mot. 1311-06**.



To remove the connectors, pass tool **Mot. 1311-06** between the two branches (A) and (B).

Press the tool to lift the two retaining clips, then pull the connector.



Remove the 2 bolts (5) which secure the injection rail to the manifold.


Slide the injection rail and the injectors between the manifold and the cylinder head.

Remove the injection rail from the right hand side of the vehicle.


### NOTES

The pressure regulator (6) is clipped to the injection rail.

There is an intermediate connector (7) between the injector (8) connector and the computer.



To remove an injector, remove the clips (9) then press clip (10) before pulling the injector.



### REFITTING

Change the O-rings at the base of the injectors (if the injector has been removed, change the seal at the top of the injector as well).


The fuel supply connectors are engaged correctly when a click is heard.

Other refitting operations are the reverse of removal.

### SPECIAL TOOLS REQUIRED

1 2000 ml test tube

It is advisable to check the fuel pump flow via the fuel return pipe connected to the pump-gauge assembly.



### IMPORTANT

When carrying out this operation it is imperative:


- that you do not smoke and that no incandescent objects are present in the working area.
- that you protect yourself from splashes of fuel resulting from the residual pressure in the pipes when they are removed.

### PUMP FLOW CHECK

Disconnect the fuel return pipe (1).

Connect a pipe stub to the hose and extend it into a test tube graduated from 0-2000ml.

Shunt terminals (3) and (5) of the fuel pump relay (located in the engine compartment fuse box). In one minute the pump flow should be at least 1.3 litres at a voltage of 12 volts.



If the flow is low, check the pump supply voltage (the flow decreases by approximately 10% for every 1 volt drop in voltage).





### SUPPLY PRESSURE CHECK


SPECIAL TOOLS REQUIRED	
Mot. 1311-01	Fuel pressure checking equipment (including 0 ; + 10 bars pressure gauge)
Mot. 1311-05	T-piece (connector K)
Mot. 1311-06	Fuel connectors removal tool

#### Disconnect:


- the fuel supply pipe using the large cross-section tool **Mot. 1311-06** (Procedure described in section 13 "Injection rail").




Connect the T-piece **Mot. 1311-05** to the rail, then reconnect the fuel supply pipe to the T-piece.



Fit the 0 ; 10 bars pressure gauge and the flexible pipe **Mot. 1311-01**.



Shunt terminals (3) and (5) of the fuel pump relay located in the engine compartment fuse box.



The pressure should be **3 bars  $\pm$  0.2**.


When a vacuum of 500 mbars is applied to the pressure regulator, the fuel pressure should be **2.5 bars  $\pm$  0.2**.

**PUMP SAFETY VALVE CHECK** (under the same conditions as before)


Shunt terminals (3) and (5) of the fuel pump relay.

When the fuel return pipe is pinched briefly, the pressure should stabilise between **4.5 and 7.5 bars**.

### CIRCUIT DIAGRAM



- 1 Inlet manifold
- 2 Fuel vapour absorber (canister)
- 3 OCR controlled solenoid valve
- 4 Cylinder head
- R Pipes from the fuel tank



PRC14.1

### PRINCIPLE OF OPERATION

The fuel tank is vented via the fuel vapour absorber (canister).

The fuel vapours are retained on passing over the active carbon in the absorber (canister).

In order to prevent the fuel vapours contained in the canister from evaporating into the atmosphere when the fuel tank is opened, a valve isolates the canister from the fuel tank when the fuel filler cap is removed.

The fuel vapours contained in the canister are released and burnt by the engine.

This is done by connecting the canister and the inlet manifold via a pipe. A solenoid valve is fitted to this pipe to permit the canister to be bled.

The principle of the solenoid valve is to allow a passage of variable cross-section (depending on the OCR signal emitted by the injection computer).

The variation in the cross-section of the fuel vapour passage in the solenoid valve is the result of the equilibrium between the magnetic field created by the power supply to the coil and the force of the return spring which closes the solenoid valve.

### CONDITION FOR BLEEDING THE CANISTER

- **At mixture regulation**
- Coolant temperature greater than : + 35 °C
- Air temperature greater than : + 0 °C
- No load position not recognised (in the event of a throttle position sensor fault, the no load position not recognised condition is replaced by an engine speed condition **R > 1500 rpm.**).

**In the event of an oxygen sensor fault, bleeding of the canister is permitted outside the no load condition.**

It is possible to display the canister bleed solenoid valve opening cyclic ratio using the XR25 at #23. The solenoid valve is closed is #23 = 0%.


The status bargraph 7 should be illuminated at idle, this does not mean that the canister bleed solenoid valve is controlled.

For an indication of whether or not the solenoid valve is controlled, you must rely on the value given by the XR25 at #23.

### LOCATION - REMOVAL

#### CANISTER BLEED SOLENOID VALVE

This is secured to the front of the lifting plate.




### CANISTER BLEED OPERATION CHECK

A system malfunction may result in an unstable idle or stalling of the engine.

Check the conformity of the circuit (refer to the circuit diagrams).

**Take care to check that the pipe marked "CAN" on the solenoid valve is connected to the canister correctly.**

Check the condition of the pipes to the fuel tank.



- 1 Inlet manifold
- 2 Canister bleed solenoid valve
- 3 Canister
- 4 Fuel tank

By connecting a pressure gauge (- 3 ; +3 bars) (Mot. 1311-01) to the solenoid valve outlet "CAN", check at idle that there is no vacuum (in the same way, the control value read by the XR25 at #23 remains minimal X = 0 %).

#### Is there a vacuum?

**YES** With the ignition off, apply a vacuum of **500 mbars** to the solenoid valve at (C) using a vacuum pump. This should not vary more than **10 mbars** in **30 seconds**.

#### Does the pressure vary?

**YES** The solenoid valve is faulty, change it. Also, it is necessary to blow into the pipe which connects the solenoid valve to the canister in order to remove any pieces of active carbon.


**NO** There is an electrical problem, check the circuit.

**NO** In bleed condition (not at idle and engine warm), the vacuum should increase (at the same time, the XR25 #23 value increases).

It is also possible to check the fuel tank breather. After removing the fuel filler cap, apply a vacuum to the pipe at (B) using a vacuum pump. The fact that a vacuum can be created in this pipe shows that the over-filling prevention valve is sealed correctly.

When the fuel filler cap is replaced, the vacuum should quickly disappear showing that the pipe is not blocked and that it is in correct communication with the degassing spaces inside the fuel tank.


### INTRODUCTION TO THE CIRCUIT



- 1 Cylinder head cover
- 2 Manifold
- 3 Oil vapour rebreather connected upstream of the throttle housing (the circuit is used for medium and high loads)
- 4 Oil vapour rebreather connected downstream of the throttle housing
- 5 Air pipe
- 6 Throttle housing

### CHECK

To ensure correct operation of the anti-pollution system, the oil vapour rebreathing circuit must be kept clean and in good condition.





### CHECKS TO BE CARRIED OUT BEFORE THE ANTI-POLLUTION TEST

Check:

- that the ignition system is operating correctly (conformity and correct setting of the spark plugs, high voltage harness in good condition and connected correctly),
- that the injection system is operating correctly (correct supply, conformity check using the **XR25**),
- the conformity and sealing of the exhaust line.

If possible, obtain information about the previous history of the vehicle (running out of fuel, lack of power, use of the wrong kind of fuel).

### ANTI-POLLUTION SYSTEM CHECK

Warm up the vehicle until the cooling fan cuts in twice.

Connect a correctly calibrated four gas analyser to the exhaust outlet.

Maintain the engine speed at **2500 rpm**. for approximately thirty seconds, then return to idle and read the pollutant level values:

**CO** ≤ **0.3 %**  
**CO<sub>2</sub>** ≥ **14.5 %**  
**HC** ≤ **100 ppm**  
**0.97** ≤ **λ** ≤ **1.03**

**NOTE** :  $\lambda = \frac{1}{\text{richness}}$

$\lambda > 1 \rightarrow$  **lean mixture**  
 $\lambda < 1 \rightarrow$  **rich mixture**

If these values are correct after tests, the anti-pollution system is operating correctly.

If the values obtained are not correct, additional tests must be carried out.

It is necessary to:

- check the condition of the engine (oil condition, valve clearances, timing, etc.),
- check the correct operation of the oxygen sensor (refer to section 17),
- carry out the lead detection test (refer to the following page).

If this test is positive, it is necessary to wait until the vehicle has consumed two or three full tanks of unleaded petrol before changing the oxygen sensor.


Finally, when all of these tests have been carried out and if the values read are still not correct, the catalytic converter must be changed.

This test can only be carried out using the lead detection kit supplied by NAUDER .

To obtain a kit, send your order to:

NAUDER  
Tooling Department  
5, avenue Francis de Pressensé  
B.P. 09  
93211 LA PLAINE SAINT DENIS  
Tel. : 00 33 1 4946 3000  
Fax : 00 33 1 4946 3336

- Quoting part number:    -    For the complete kit : **T900**  
                                     -    For the refill of forty test papers: **T900/1**



### INSTRUCTIONS

#### LEAD DETECTION AT THE EXHAUST

- a - Test conditions :**
  - Engine off.
  - Exhaust pipes warm but not hot.
  - Do not carry out the test in temperatures below **0 °C**.
- b -** If necessary, gently clean the inside of the exhaust outlet with a dry cloth in order to remove any soot deposits.
- c -** Put on a pair of gloves, take a piece of test paper and moderately dampen it with distilled water (if it is too wet, the paper will be ineffective).
- d -** Immediately after damping it, press the test paper onto the cleaned part of the exhaust and maintain pressure on it for approximately one minute.
- e -** Remove the test paper and leave it to dry. If lead is present, the test paper will turn red or pink.

**WARNING:** the lead detection test must be carried out on the rear exhaust outlet and never on the oxygen sensor.

STARTING - CHARGING  
Alternator

IDENTIFICATION

Vehicle	Engine	Alternator	Amperage
C 066 S 066 C 067	D7F	CS 130 D	75 A

CHECK

After 15 minutes of heating with a voltage of 13.5 volts.

RPM	75 amps
1300	28 A
2000	40 A
2700	60 A

SPECIAL TOOLS REQUIRED	
Mot. 1273	Belt tensioning tool

### REMOVAL

Disconnect the battery.


Remove:

- the alternator belt,
- the alternator electrical connections,
- the alternator.

### REFITTING (Special features)

Refit in the reverse order to removal.

The alternator belt is tensioned using the tool made on site, shown below (100 mm long threaded rod (X) and 3 nuts M6).




Refer to **section 07, Accessories belt tensioning** for the belt tensioning values.

Vehicle	Engine	Starter
C 066 S 066 C 067	D7F	VALEO D7E1

### REMOVAL

Disconnect:

- the battery,
- the starter electrical connectors.



Remove the 2 starter mounting bolts.

### REFITTING

Refit in the reverse order to removal.

The differences between two coil static ignition and timed ignition are:

- the elimination of the high voltage distributor,
- the introduction of a monobloc with two coils with two outlets.

### INTRODUCTION

The system is made up of:

- the injection computer (the ignition power stage is integral with the computer),
- a monobloc with two coils with two outlets (they are moulded into a single part),
- four spark plugs
- an interference suppression capacitor

### DESCRIPTION - PRINCIPLE OF OPERATION

#### THE COMPUTER

Depending on the information received from the various sensors, but mainly depending on the engine speed and engine load, the injection computer determines:

- the number of degrees of advance to apply and consequently the point of ignition
- which cylinders are at top dead centre and consequently which coil to control

It causes a spark at the two cylinders at top dead centre by breaking the connection to earth of the coil concerned.

#### THE COILS (1)


There are two coils. They are of the two outlet monobloc type (they cannot be separated).

They are controlled separately by the computer.

They create two simultaneous sparks.

They are located on the spark plugs.

The two coils are connected to an interference suppression capacitor.



Electrical connector

Tracks	Description
1	control of the coil of cylinders 1-4
2	control of the coil of cylinders 3-2
3	+ after ignition
4	+ interference suppression capacitor


Coil connector track marking

Track n° 1 of the coil is on the bulkhead end.

The allocations of the high voltage wires are marked next to the coil mounting bolts.

Check to be carried out between tracks	Resistance
1 - 2	2 $\Omega$
1 - 3	1.6 $\Omega$
1 - 4	1.6 $\Omega$
2 - 3	1.6 $\Omega$
2 - 4	1.6 $\Omega$
3 - 4	1.1 $\Omega$
HT - HT	7.2 k $\Omega$

WIRING DIAGRAM



PRC11824


LIST OF UNITS

- 120 Injection computer
- 260 Fuse box
- 679 Radio interference suppression capacitor
- 778 Two coil monobloc with four outlets

### SPECIAL FEATURE OF THE ENGINE FLYWHEEL

#### Description

The engine flywheel has 60 teeth spaced at regular intervals. Two teeth have been removed to create an absolute mark at  $84^\circ$  or 14 full teeth before top dead centre of cylinders 1 and 4. Therefore, there are actually 58 teeth remaining.



Cylinders 1 and 4 are at top dead centre when the arrow marked (A) passes in front of the engine speed sensor (169).

Cylinders 2 and 3 are at top dead centre when the arrow marked (B) passes in front of the engine speed sensor (169).

#### Principle of operation

The computer knows that the top dead centre of cylinders 1 and 4 is located on the leading edge of the 15th tooth after the long tooth. Consequently, depending on the degree of advance to be applied, it can locate the ignition point exactly by counting the number of teeth.

The top dead centre of cylinders 2 and 3 is located on the leading edge of the 45th tooth after the long tooth.



**NOTE:** advance correction in relation to the signal transmitted by the pinking sensor is described in section 17 Injection.

**Cylinder 1 is on the engine flywheel end.**



Engine	Brand	Type
D7F	EYQUEM NGK	FN 52 LS BK5 E SZ
Flat reach with seal		
Gap: 0.9 mm		
Tightening: 2.5 to 3 daN.m		

To disconnect the spark plug leads, use tool (3) integral with the plastic protector (4) on the cylinder head.




### **SPECIAL FEATURES OF THE MULTIPPOINT INJECTION**

- 35-way SAGEM or MAGNETI MARELLI computer on models with manual gearbox with no optional accessories.
- 55-way SAGEM computer, SAFIR or MAGNETI MARELLI type on models with automatic transmission or air conditioning.
- Semi-sequential multipoint injection. Two by two control of injectors (injectors of cylinders 1 and 4 then injectors of cylinders 2 and 3).
- Static ignition with monobloc with two coils.
- Canister bleed solenoid valve controlled by opening cyclic ratio.
- Configuration of the computer in relation to the type of gearbox (manual or automatic).
- Idle speed adjustment depending on:
  - the battery voltage,
  - the air conditioning.
- Injection warning light on the instrument panel not operational.
- Use of fault-finding fiche N°27.


**INTRODUCTION OF A 2ND GENERATION CODED ENGINE IMMOBILISER INVOLVES THE USE OF A SPECIAL PROCEDURE FOR CHANGING THE COMPUTER.**

### LOCATION OF COMPONENTS




- 1 Injection computer
- 2 Pinking sensor
- 3 Coolant temperature sensor
- 4 Top dead centre sensor
- 5 Fuel vapour recirculation solenoid valve
- 7 Idle regulation stepping motor
- 8 Throttle position potentiometer
- 9 Air temperature sensor
- 10 Absolute pressure sensor
- 11 Fuel vapour absorber (canister)
- 12 Coil
- 13 Locking relay
- 14 Fuel pump relay
- 16 Air filter
- 17 Oxygen sensor
- 18 Pressure regulator
- 19 Spark plug wires removal tool


- 1 Injection computer




- 2 Pinking sensor  
(tightening torque: 2.5 daN.m)



- 7 Idle regulation stepping motor  
8 Throttle position potentiometer  
9 Air temperature sensor  
10 Absolute pressure sensor



- 3 Coolant temperature sensor  
5 Fuel vapour recirculation solenoid valve




# INJECTION


## Location of components

17


1 Coil



13 locking relay,  
14 fuel pump relay,



17 Oxygen sensor  
(tightening torque: 5 daN.m)



### PRINCIPLE OF OPERATION

The engine is fitted with a semi-sequential type injection system.

Fuel is injected simultaneously into cylinders 1-4 and cylinders 2-3.

To make this possible, the two pairs of injectors are connected to two tracks of the injection computer:

- the injectors of cylinders **1** and **4** are connected to track **33** of the **35**-way computer or to track **30** of the 55-way computer,
- the injectors of cylinders **2** and **3** are connected to track **32** of the **35**-way computer or to track **4** of the 55-way computer,


For each cylinder, there is one injection per revolution, therefore there are two injections per engine cycle. These injections take place during the compression and exhaust phases.

The injection computer uses the same system as that used for controlling the ignition coils to determine when and which injector to control. By analysing the engine flywheel signal, it also determines the Top Dead Centre of cylinder 1-4 and 2-3 (see the principle described in section 17 "Ignition"). By counting the number of teeth, it determines the engine phases which precede Top Dead Centre.

# INJECTION

## Special features of the semi-sequential injection

17



ignition

injection of fuel

### PRINCIPLE OF ILLUMINATION OF THE INJECTION FAULT WARNING LIGHT ON THE INSTRUMENT PANEL

- **Vehicle without engine immobiliser**

When the ignition is switched on, the warning light illuminates for 3 seconds and then extinguishes.

- **Vehicle with engine immobiliser deactivated**

When the ignition is switched on, the warning light illuminates for 3 seconds and then extinguishes.

When the doors are unlocked, the red engine immobiliser indicator light, which was flashing previously, extinguishes. When the ignition is switched on, it illuminates for 3 seconds then extinguishes.

- **Vehicle with engine immobiliser active**

When the ignition is switched on, the computer does not recognise the code and prohibits starting. The injection warning light illuminates for 3 seconds then extinguishes.

Before the ignition is switched on, the red engine immobiliser indicator light flashes. When the ignition is switched on, this indicator light flashes more rapidly.

If a fault is detected in the engine immobiliser system while the engine is running, the injection warning light flashes at an engine speed between idle and approximately **1500 rpm**.

- **Injection system component fault**

If a component of the injection system is faulty this will not cause the warning light to illuminate.



This vehicle is fitted with a 2nd generation engine immobiliser system.

### CHANGING THE INJECTION COMPUTER

The computers are not coded when they are supplied but all of them can be coded.

When changing the computer, the new computer must be programmed with the vehicle code and the operation of the engine immobiliser function must then be checked.

To check the operation of the engine immobiliser, simply carry out the following operations:

- **Vehicle fitted with an infra-red remote control engine immobiliser**
  - Lock and unlock the doors using the infra-red remote control.
  - Switch on the ignition for a few seconds.
  - Lock the doors using the infra-red remote control, the engine immobiliser function is operational.
- **Vehicle fitted with a coded key engine immobiliser**
  - Switch on the ignition for a few seconds and then switch it off.
  - When the key is removed, the engine immobiliser function is operational.

### CHECKING THE ENGINE IMMOBILISER FUNCTION

- **Vehicle fitted with an infra-red remote control engine immobiliser system**
  - Switch off the ignition, lock the doors from inside using the infra-red remote control. The red engine immobiliser indicator light should flash.
  - Switch on the ignition, the red engine immobiliser indicator light should flash more rapidly.
- **Vehicle fitted with a coded key engine immobiliser system**

Remove the key from the ignition, after 10 seconds the red engine immobiliser indicator light should flash.

**For the special features of injection computer tests (parts test), refer to the engine immobiliser technical note.**

## Computer configuration in relation to the type of gearbox

### CONFIGURATION OF THE COMPUTER IN RELATION TO THE TYPE OF GEARBOX (MANUAL OR AUTOMATIC)

Each time the injection computer is changed, it must be programmed for the type of gearbox (manual or automatic) which is fitted to the vehicle. The computer is designed to operate with both types of gearbox.

Computer configuration procedure:

Connect the XR25.

Selector at S8

Switch on the ignition

Enter **D13** then

**If the vehicle is fitted with a manual gearbox:**

Enter **G50\* 2\***

**If the vehicle is fitted with automatic transmission:**

Enter **G50\* 1\***

The following will be displayed:

d	E	F
---	---	---

If the computer is not configured

b	a	n
---	---	---

F	i	n
---	---	---

then

1	0	n	J
---	---	---	---

if the computer is configured

## Computer configuration in relation to the type of gearbox

---

To check that the computer has been programmed correctly, switch the ignition on again using the fault-finding fiche n°27, left hand fault bargraph 20 should be extinguished, right or left hand status bargraph 19 should be illuminated.

There is also a computer configuration procedure which does not require the use of the XR25. The procedure is as follows:

- switch on the ignition,
- start the engine,
- rev the engine to **2500 rpm** for **10 seconds**,
- switch off the ignition,
- switch the ignition on again and start the engine,
- rev the engine to **2500 rpm** for **10 seconds**,
- switch off the ignition.

The programming procedure is identical to that described previously.

**NOTE :** the configuration procedure using the XR25 can be used to reconfigure an incorrectly configured computer from scratch (automatic transmission instead of manual gearbox). However, the configuration procedure which does not use the XR25 will only work for an unprogrammed injection computer from the warehouse.

### THE COMPRESSOR IS OF THE VARIABLE CYLINDER TYPE

### AIR CONDITIONING / INJECTION COMPUTER CONNECTION

The electrical connection:

- from the air conditioning computer to the injection computer is via a wire (track 5). In reality only air conditioning cycle information is transmitted along this track. The injection computer deduces the air conditioning selection information from this (track 6 is connected to the air conditioning computer, but no information is transmitted along this track).
- from the injection computer to the air conditioning computer is via a wire (track 5). Compressor operation authorisation and prohibition information is transmitted along this track

### COMPRESSOR OPERATION

During certain phases of operation, the injection computer prohibits operation of the compressor.

#### On starting the engine

Operation of the compressor is prohibited for 10 seconds after starting the engine.

#### Heat protection

The compressor clutch is not engaged if the coolant temperature is greater than or equal to: + 119 °C.

The compressor clutch is not engaged if the coolant temperature is greater than or equal to 105°C, if the engine speed is greater than 5792 rpm and the manifold pressure is greater than 1017 mbars.

#### Over-revving protection

The compressor clutch is released if the engine speed is greater than: 6000 rpm.

Engagement of the compressor clutch is prohibited if the engine speed is greater than 5500 rpm and if the vehicle speed is less than 50 mph (80 km/h).

### RESTORATION OF PERFORMANCE

The compressor clutch is released for 12 seconds at full load, at an engine speed greater than 5984 rpm and at a vehicle speed less than 30 mph (45 km/h). If one of the conditions is no longer complied with, the compressor clutch is immediately engaged again.

### ANTI-STALL PROTECTION

If the no load position is recognised and the engine speed is less than 608 rpm, the compressor clutch is released.

The compressor clutch is engaged again:

- if the no load position is recognised when the engine speed reaches 864 rpm,
- if the no load position is not recognised when the engine speed reaches 1800 rpm.

### ADJUSTMENT OF THE IDLE SPEED IN RELATION TO THE BATTERY VOLTAGE

The purpose of this adjustment is to compensate for the low voltage caused by the operation of a power-consuming unit when the battery is at low charge. This is done by increasing the idle speed which allows increased rotation of the alternator and consequently an increased charging voltage.

The lower the voltage, the greater the adjustment. The engine speed adjustment is therefore variable. Adjustment begins when the voltage falls below **12.7 volts**. The adjustment starts from the nominal engine speed and can reach a maximum of **880 rpm**.

### ADJUSTMENT OF THE IDLE SPEED IN RELATION TO THE AIR CONDITIONING

If the air conditioning is selected from the instrument panel, the idle speed is increased to **880 rpm**.

## Adaptive adjustment of the idle speed

### PRINCIPLE

Under normal operating conditions when warm, the idle OCR value at #12 varies between an upper value and a lower value in order to obtain the nominal idle speed.

Following abnormalities (running in, clogging of the engine...), it is possible that the idle OCR value will be close to the upper or lower value.

Adaptive adjustment (#21) of the idle OCR (#12) allows compensation for the slow variations in engine air requirements, which realigns the OCR (#12) with an average nominal value.

This adjustment is only effective if the coolant temperature is greater than 70°C, 30 seconds after starting the engine and if the vehicle is in the nominal idle regulation phase.

### IDLE OCR VALUES AND IDLE OCR ADAPTIVE ADJUSTMENT VALUES

Idle speed nominal (#06)	$X = 740 \text{ rpm}$
Idle OCR (#12)	$4 \% \leq X \leq 15 \%$
Adaptive idle (#21)	Limit: - minimum : - 4.3 % - maximum : +3.9 %

### INTERPRETATION OF THESE VALUES

If there is an excess of air (air leak, throttle stop misadjusted...) the idle speed increases, the idle OCR value at #12 decreases in order to return to the nominal idle speed; the idle OCR adaptive adjustment value at #21 decreases in order to realign the idle OCR at #12.

If there is a lack of air (clogging etc.), the logic is reversed:

The idle OCR at #12 increases and the adaptive adjustment at #21 also increases in order to realign #12 with an average nominal value.

**IMPORTANT :** after erasing the computer memory (disconnection of the battery), it is imperative to allow the engine to run at idle before returning it to the customer so that the adaptive adjustment can reset itself correctly.

### OXYGEN SENSOR VOLTAGE (#05)

Reading of **#05** on the **XR25** : the value read represents the voltage supplied to the computer via the oxygen sensor; it is expressed in volts (in fact, the value varies between **0** and **1000** millivolts).

When the engine is running, the voltage should fluctuate rapidly and should be between **50±50 mV** (lean mixture) and **850 ± 50 mV** (rich mixture) and vice versa.

The smaller the difference between maximum and minimum, the less reliable the sensor data (this difference is usually at least **500 mV**).

### MIXTURE ADJUSTMENT (#35)

The value read at **#35** on the **XR25** represents the average of the mixture adjustments made by the computer in relation to the richness of the fuel mixture as determined by the oxygen sensor (the oxygen sensor actually analyses the oxygen content of the exhaust gases, directly related to the richness of the fuel mixture).

The mid-point of the adjustment value is 128 and its limits are 0 and 255 (by experience, under normal operating conditions **#35** is situated at and varies slightly around a value close to 128).

- Value less than 128 : mixture too rich
- Value greater than 128 : mixture too lean

### ENTERING MIXTURE REGULATION MODE

#### Loop phase

Entry to mixture regulation mode is effective after a start delay:

- with no load if the coolant temperature has reached **40 °C**
- outside the no load condition if the coolant temperature is greater than **22 °C**

The start delay depends on the coolant temperature:

- at **20°C** it is at most 1 minute 20 seconds,
- at **80°C** it is at most 35 seconds.

when the vehicle is no longer in mixture regulation mode, **#35 = 128**

### Unloop phase

When the vehicle is in mixture regulation mode, the phases of operation during which the computer ignores the voltage supplied by the sensor are:

- full load: #35 = variable and greater than 128,
- rapid acceleration : #35 = variable and greater than 128,
- deceleration with no load information (injection cut-off\*) : #35 = 128,
- oxygen sensor fault : #35 = 128,
- deceleration depending on the manifold depression : #35 = 128.

\* there is no injection cut-off in first gear.

### DOWNGRADED MODE IN THE EVENT OF AN OXYGEN SENSOR FAULT

If the voltage supplied by the oxygen sensor is incorrect (#05 varying very little or not at all) in the mixture regulation phase, the computer will only pass into downgraded mode (#35 = 128) if the fault has been recognised as being present for 3 to 5 minutes. Only if this is the case will the fault be stored in memory.

When the presence of an oxygen sensor fault is detected and if the fault has already been stored in memory, the vehicle passes directly to an open loop (#35 = 128)



PRINCIPLE

In the loop phase (refer to section 17 "Mixture regulation"), the mixture regulation (#35) adjusts the injection time in order to obtain a dose as close as possible to mixture 1. The adjustment value is close to 128 with limits of 0 and 255.

However, abnormalities may act on the components of the injection system and cause the adjustment to be move towards 0 or 255 in order to obtain mixture 1.

Adaptive adjustment allows the injection mapping to be moved to realign the mixture regulation around 128 and allow it to maintain a constant authority of adjustment towards making the mixture richer or leaner.

- Mixture regulation adaptive adjustment is broken down into two parts:
- adaptive adjustment mainly for average and high engine loads (reading of #30)
  - adaptive adjustment mainly for idle and low engine loads (reading of #31)

Adaptive adjustments take 128 as an average value after initialisation (erasing of the memory) and have the following limit values:

$96 \leq \#30 \leq 160$
$96 \leq \#31 \leq 160$

Adaptive adjustments only operate when the engine is warm in the loop phase (#35 variable) and within a given manifold pressure range.

The engine must have been operating in loop mode over several **pressure ranges** for the adaptive adjustments to start to make modifications to compensate for the engine operation mixture abnormalities.

Following reinitialisation of the computer (return to 128 of #30 and #31) it will therefore be necessary to carry out a special road test.

ROAD TEST

Conditions

- Engine warm (coolant temperature > 75 °C)
- Do not exceed an engine speed of **4 000 rpm**.

For this test, it is advisable to start from a fairly low engine speed, in 3rd or 4th gear with very gradual acceleration **in order to stabilise the pressure required for 10 seconds in each range** (see table).

**NOTE:** for example, try to maintain an average of **280 mbars** for at least 10 seconds for range n°1.

Pressure ranges to be covered during the test (reading #01)

Range n° 1 (mbars)	Range n° 2 (mbars)	Range n° 3 (mbars)	Range n° 4 (mbars)	Range n° 5 (mbars)
220 ----- 340 ----- 460 ----- 580 ----- 700 ----- 930				
Average 280	Average 400	Average 520	Average 640	Average 815

Following this road test, the adjustments are operational.

#31 varies more significantly at idle and low loads, and #30 varies more significantly at average and high loads, but both operate over all of the manifold pressure ranges.

The test must be continued over a distance of 3 to 6 miles (5 to 10 kilometres) with normal, smooth, varied driving.

After the test, read the #30 and #31 values. Initially at 128, they should have changed. If not, repeat the test taking care to observe the test conditions.

### INTERPRETATION OF THE VALUES OBTAINED FOLLOWING A ROAD TEST

In the event of a lack of fuel (clogged injectors, pressure and flow of fuel too low...), the mixture regulation at #35 increases in order to obtain the mixture closest to 1 and the adaptive adjustment at #30 and #31 increases until the mixture adjustment again fluctuates around 128.

In the event of excess fuel, the logic is reversed:

The mixture regulation at #35 decreases and the adaptive adjustment at #30 and #31 decreases as well in order to realign the mixture adjustment around 128.

**NOTE:** the possible analysis of #31 remains unreliable as this adjustment operates mainly at idle and low engine loads and is also very sensitive.


Hasty conclusions must not therefore be drawn from this, the position of #30 must be analysed.

The information supplied by #31 and #30 therefore gives an idea of the engine operating mixture thus allowing fault-finding to be focused. In order for them to be useful in fault-finding, no conclusion can be drawn from their value unless they are at the minimum or maximum adjustment limit and they have both moved in the same direction.

<p><b>IMPORTANT:</b> #30 and #31 must only be processed and analysed following a customer complaint, an operational fault and if they are at the limit with movement of #35 (#35 varies above 175 or below 80).</p>
---

**KEY TO WIRING DIAGRAM**

UNIT N°	DESCRIPTION
119	Automatic transmission computer
120	Injection computer
146	Pinking sensor
147	Absolute pressure sensor
149	Top Dead Centre sensor
193 to 196	Injectors
218	Fuel pump
222	throttle position potentiometer
225	Diagnostics socket
236	Fuel pump relay
238	Locking relay
242	Oxygen sensor
244	Coolant temperature sensor
247	Instrument panel
250	Vehicle speed sensor
260	Fuse box
272	Air temperature sensor
319	Air conditioning control panel
371	Fuel vapour recirculation solenoid valve
503	Decoding computer
597	Engine compartment fuse box
649	Idle regulation stepping motor
679	Radio interference suppression capacitor
730	Automatic clutch computer
778	Monobloc with two coils, 4 outlets
927	Impact detector
MH	Engine earth




**COMPUTER TRACK ALLOCATION LIST**

<b>Tracks</b>	<b>DESCRIPTION</b>
<b>1</b>	+ 12 volts after ignition supply from the locking relay
<b>2</b>	Power earth n° 1
<b>3</b>	Power earth n° 2
<b>4</b>	Injector n° 2 and n° 3 control via earth
<b>5</b>	Air conditioning on/off information and compressor operation authorisation request (0 - 12 V)
<b>6</b>	Not used (this track is connected to the air conditioning computer, no information is transmitted along it)
<b>7</b>	Park/neutral/torque damping information
<b>8</b>	Stepping motor control (0 - 12 volts at high frequency) track D
<b>9</b>	Stepping motor control (0 - 12 volts at high frequency) track B
<b>10</b>	Not used
<b>11</b>	Bidirectional fault-finding line K used for entry into fault-finding mode (computer search), transmission of fault-finding information from the computer, application of the control modes (G..*), memory erasing (G0**) and end of fault-finding (G13*) modes
<b>12</b>	Vehicle speed information
<b>13</b>	Not used
<b>14</b>	Not used
<b>15</b>	Coolant temperature sensor information
<b>16</b>	Manifold pressure information re-processed by the absolute pressure sensor
<b>17</b>	Voltage supplied by the oxygen sensor information
<b>18</b>	Earth
<b>19</b>	Throttle position potentiometer information
<b>20</b>	Air temperature sensor information
<b>21</b>	Not used
<b>22</b>	Not used
<b>23</b>	Not used
<b>24</b>	Not used

Tracks	DESCRIPTION
25	Not used
26	Not used
27	Not used
28	Control of the coil of cylinders 1 and 4
29	Control of the coil of cylinders 2 and 3
30	Control of injector n° 1 and° 4 via earth (n° 1 engine flywheel end)
31	Pinking sensor shielded cable
32	Not used
33	Top dead centre sensor signal (track B)
34	Top dead centre sensor signal (track A)
35	Stepping motor control (0 - 12 at high frequency) track A
36	Stepping motor control (0 - 12 at high frequency) track C
37	Electronic ignition cut-off coded line input
38	Unidirectional fault-finding line L used only for entry to fault-finding mode (computer search)
39	Not used
40	Control (by connection to earth) of the locking relay
41	Throttle angle information for the automatic transmission and automatic clutch computer
42	OCR control (sequential earth time of the canister bleed solenoid valve OCR)
43	Control of the injection fault warning light on the instrument panel
44	Common earth for the pinking sensor, the coolant temperature sensor and the absolute pressure sensor
45	+ 5 V supply for the absolute pressure sensor and the throttle position potentiometer
46	Common earth for the air temperature sensor, and the throttle position potentiometer
47	Not used
48	Control (by earth) of the fuel pump relay and engine speed information
49	Not used

Tracks	DESCRIPTION
50	Not used
51	Air conditioning compressor clutch control prohibition (0 V → authorisation ; 12 V →prohibition)
52	Not used
53	Not used
54	Pinking sensor signal
55	Not used





COMPUTER TRACK ALLOCATION LIST

Tracks	DESCRIPTION
1	Pinking sensor signal
2	Air temperature sensor information
3	Throttle position potentiometer information
4	Earth
5	+ 5 V supply for the absolute pressure sensor and the throttle position potentiometer
6	Coolant temperature sensor information
7	Not used
8	Vehicle speed data
9	Bidirectional fault-finding line K used for entry into fault-finding mode (computer search), transmission of fault-finding information from the computer, application of the control modes (G..*), memory erasing (G0**) and end of fault-finding (G13*) modes
10	Unidirectional fault-finding line L used only for entry to fault-finding mode (computer search)
11	Stepping motor control, (0 - 12 volts at high frequency) track D
12	Stepping motor control, (0 - 12 volts at high frequency) track A
13	Top dead centre sensor signal (track B)
14	Not used
15	Common earth for the pinking sensor, the throttle position sensor the manifold pressure sensor, air temperature sensor and the coolant temperature sensor
16	Power earth N° 1
17	Control of the coil of cylinders 2 and 3
18	Locking relay + 12 volts information

COMPUTER TRACK ALLOCATION LIST (cont)

Tracks	DESCRIPTION
19	Control of the injection fault warning light on the instrument panel
20	Control by earth of the fuel pump relay and engine speed information
21	Not used
22	Voltage supplied by the oxygen sensor information
23	Manifold pressure information re-processed by the absolute pressure sensor
24	Control of the canister bleed solenoid valve by OCR signal (sequential earth time)
25	Not used
26	Control (by earth) of the locking relay
27	Not used
28	Stepping motor control (0 - 12 V at high frequency) track B
29	Stepping motor control (0 - 12 V at high frequency) track C
30	Electronic ignition cut-off coded line input
31	Top Dead Centre sensor signal (Track A)
32	Control of injector N° 2 and 3 (by connection to earth)
33	Control of injector N° 1 and 4 (by connection to earth)
34	Power earth N° 2
35	Control of the coil of cylinders 1 and 4

## ESTABLISHING XR25/COMPUTER DIALOGUE

- Connect the XR25 to the diagnostics socket.
- Ignition on.
- Selector in position S8
- Enter **D13**

9.INJ

## COMPUTER IDENTIFICATION

Computer identification is not linked to the reading of a fault code but to direct reading of the computer part number. After entering into dialogue with the computer:

ENTER    **G70\***

7700

XXX

XXX

The part number then appears on the central display in three sequences.


Each sequence is displayed for approximately two seconds. The display is repeated twice. (For the number, refer to part number section 12).

## ERASING THE MEMORY (engine stopped, ignition on)

Following work on the injection system, the computer memory can be erased using the code GO\*\*. (Erasing stored fault codes in fault-finding mode D13, enter GO\*\* with the selector in position S8).

This operation will not erase the memory of any other equipment on the vehicle.

If the information obtained by the XR25 requires checking of the electrical continuity, connect the bornier **MS 1048**.



(The **MS 1048** is made up of a 35-way base integral with a printed circuit on which there are 35 copper plated surfaces numbered 1 to 35).

Using the wiring diagrams, the tracks which connect the components to be checked can be easily identified.

**IMPORTANT :**

- All of the checks , using the bornier **MS 1048**, must be carried out with the battery disconnected.
- The bornier is designed to be used only with an ohmmeter. Under no circumstances must 12 volts be applied to the check points.

## TEST PROCEDURE

Connect the XR25, ignition off.

Switch on the ignition, enter into dialogue with the injection computer.

Make a note of which fault bargraph is illuminated or flashing.

Erase the computer memory.

Switch off the ignition.

### **1/ Carry out an XR25 test with the ignition on**

Switch off the ignition, connect the XR25 and switch on the ignition.

Enter into dialogue with the injection computer.

Process the illuminated fault bargraph.

### **2/ Carry out an XR25 test with the engine running or at starter speed**

Switch off the ignition, connect the XR25 and switch on the ignition.

Enter into dialogue with the injection computer.

Switch on the engine.

Process the illuminated fault bargraph.

### **3/ Carry out an XR25 test while driving**

Switch off the ignition, connect the XR25 and switch on the ignition.

Enter into dialogue with the injection computer.

Drive the vehicle.

Process the illuminated fault bargraph.

- NOTE :**
- If illumination of a fault bargraph can be reproduced, it must be processed as an illuminated bargraph even if it has started flashing.
  - If no fault bargraph has been illuminated, check the connectors of the faulty circuit.

FICHE N° 27 SIDE 1/2 WITH FAULT BARGRAPHS

N°27 1/2		S8 code : D 1 3		read : 9 n J	
1	<input type="checkbox"/> ILLUMINATED → <input type="checkbox"/> EXTINGUISHED →	FAULT TEST TURN CARD		CODE PRESENT <input type="checkbox"/>	
2	<input type="checkbox"/>	COMPUTER		ENG. IMMOB. * 22 <input type="checkbox"/>	
3	<input type="checkbox"/>	AIR TEMPERATURE		O2 SENSOR * 23 <input type="checkbox"/>	
4	<input type="checkbox"/>	COOLANT TEMP		VEHICLE SPEED <input type="checkbox"/>	
5	<input type="checkbox"/>	PRESSURE		FLYWHEEL SIGNAL * 25 <input type="checkbox"/>	
6	<input type="checkbox"/> * 06 PINKING	SENSOR CIRCUITS		THROTTLE POSITION <input type="checkbox"/>	
7	<input type="checkbox"/>	CAMSHAFT		FUEL TANK PRESSURE <input type="checkbox"/>	
8	<input type="checkbox"/> * 08 FUEL PUMP	RELAY CTRL CIRC.		BLOCKING * 28 <input type="checkbox"/>	
9	<input type="checkbox"/> * 09 ANTI-PERCOLATION			AIR PUMP * 29 <input type="checkbox"/>	
10	<input type="checkbox"/> * 10 O2 SENSOR OVERHEAT			BI MODE * 30 <input type="checkbox"/>	

INJECTION (FAULTS)	
Erase fault memory : G 0 ** Status check request : G01 *	
11 <input type="checkbox"/> * 11 INJECTOR CIRCUIT	CONNECTION A.T. → INJ <input type="checkbox"/>
12 <input type="checkbox"/> * 12 WARN. LAMP CIRC. DEF.	FUEL PUMP + INFO <input type="checkbox"/>
13 <input type="checkbox"/> SAVE DATA IN MEMORY	ADAC * 33 <input type="checkbox"/>
14 <input type="checkbox"/> * 14 IDLE SPEED REG. CIRC.	BLEED CANISTER CIRC. * 34 <input type="checkbox"/>
15 <input type="checkbox"/> * 15 CONNECTION INJ. → AC	EGR CIRCUIT * 35 <input type="checkbox"/>
16 <input type="checkbox"/> * 16 IGNITION COILS	COLD START INJECTORS * 36 <input type="checkbox"/>
17 <input type="checkbox"/> * 17 MIL WARN. LIGHT	
18	
19	
20 <input type="checkbox"/> * 20 COMPUTER CONFIGURATION	XR25 MEMORY 0 <input type="checkbox"/>

ADDITIONAL CHECKS : # . .	
01 PRESSURE	mb
02 Coolant temp.	°C
03 Air temp.	°C
04 Computer feed	V
05 O2 sensor	V
06 Engine speed	rpm
12 Idling RCO	%
13 Pinking signal	
14 Engine speed gap	rpm
15 Pinking correct.	
16 Atmos. pressure	mb
17 Throttle pot.	
18 Vehicle speed	km/h
21 Auto correct. of RCO idlespeed	%
23 Canister purge RCO	%
24 RCO EGR	%
30 Auto correct. clutch under high loads	
31 Auto correct. clutch under low loads	
35 Corr. richesse	
44 P. absorbed by AC compressor	W

End of test: G 13 *	
Part No : G 70 *	
Diagnosed faults : Press V and 9	
Return to diagnostic mode : D	

16	ANG
----	-----

FI21627-1

FICHE N° 27 SIDE 2/2 WITH STATUS BARGRAPHS

N°27 2/2		read : 10hJ
1	<input type="checkbox"/> EXTINGUISHED <input type="checkbox"/> ILLUMINATED	STATUS TEST TURN CARD
2	<input type="checkbox"/> PG ← THROTTLE POSITIONS → PL <input type="checkbox"/>	CODE PRESENT <input type="checkbox"/>
3	<input type="checkbox"/> FLYWHEEL SIGNAL	ACTIVE ENG. IMMOB. <input type="checkbox"/>
4	<input type="checkbox"/> PARK/NEUTRAL POSITION	+ APC COMPUTER <input type="checkbox"/>
5	<input type="checkbox"/> TORQUE ADJUSTMENT	RELAY CONTROL LOCKING <input type="checkbox"/>
6	<input type="checkbox"/> RICHNESS REGULATION	IDLING REGULATION <input type="checkbox"/>
7	<input type="checkbox"/> FUEL PUMP CONTROL	BLEED CANISTER AUTHOR. <input type="checkbox"/>
8	<input type="checkbox"/> ANTI-PERCOL. CTRL	ELEC. W/SCREEN REQUESTED <input type="checkbox"/>
9	<input type="checkbox"/> SELECTION	ACCEL. IDLE SPEED
10	<input type="checkbox"/> REQUEST	AIR COND. COMPRESSION AUTHOR. OR PROHIBITED <input type="checkbox"/>
(WARNING : monitor bar graph 20 left)		
<b>INJECTION (STATUS)</b>		
Erase fault memory : G 0 ** Request fault test : G 02 *		
11	<input type="checkbox"/> CAMSHAFT SIGNAL	BLEED CANISTER + ACTIVE SOL VALVES <input type="checkbox"/>
12	<input type="checkbox"/> EGR SV CONTROL	MEMORISED FAULTS <input type="checkbox"/>
13	<input type="checkbox"/> AIR PUMP CONTROL	POWER STEERING PRESSOSTAT <input type="checkbox"/>
14	<input type="checkbox"/> BI-MODE INLET CTRL	COLD START INJECTORS <input type="checkbox"/>
15		
16		
17		
18		
19	<input type="checkbox"/> Veh. with AT	COMPUTER CONFIGURATION Veh. with man. g/box <input type="checkbox"/>
20	<input type="checkbox"/> FAULT PRESENT	XR25 MEMORY 0 <input type="checkbox"/>
		<b>CONTROL MODES : G.. (IF ENGINE STOPPED)</b>
		10* Fuel pump relay
		11* Blocking relay
		12* AC compressor
		14* Idle speed reg. valve
		16* Bleed canister valve
		17* Anti percolation relay
		21*1* Warn. light def.
		22* Air pump relay
		23* EGR valve
		24* Bi-mode inlet valve
		31* Injector control
		50*x* Computer set-up
		57*x* Idle speed adj.
		58*x* Computer configuration
		59*x* INJ Lock/Unlock
		60* Zapping validation
		<b>G..x*</b> See procedure on REMINDER CARD D
		<b>ADDITIONAL CHECKS : # . .</b>
		01 Pressure mb
		02 Coolant temp. °C
		03 Air temp. °C
		04 Computer feed V
		05 O2 Sensor V
		06 Engine speed rpm
		12 Idling RCO %
		13 Pinking signal
		14 Eng. speed gap rpm
		15 Pinking correct. °
		16 Atmos. pressure mb
		17 Throttle pos.
		18 Vehicle speed km/h
		21 Auto. corr. RCO idle speed %
		23 RCO bleed canister %
		24 RCO EGR %
		30 Auto. corr. dich. underhighbds
		31 Auto. corr. of richness
		35 Mixture regulation
		44 P. absorbed by W AC compressor
		<b>End of test : G 13 *</b>
		<b>Part No : G 70 *</b>
		<b>Diagnosed faults :</b> Press V and 8
		<b>Return to diagnostic mode : D</b>
		<b>16 ANG</b>

FI21627-2



REPRESENTATION OF BARGRAPHS




Illuminates when dialogue is established with the computer. If it remains extinguished:

- the code does not exist,
- there is a line fault or a fault in the equipment or computer

REPRESENTATION OF FAULTS (always on a coloured background)



When illuminated, this indicates a fault on the product being checked, the associated text defines the fault.




When extinguished, this indicates that no fault has been detected on the product being checked.

REPRESENTATION OF STATUS (always on a white background)


With the engine stopped, ignition on, no action by the operator

The status bargraphs on the fiche are represented in the status in which they should be with the engine stopped, ignition on, no action by the operator

- If on the fiche, the bargraph is represented
- If on the fiche, the bargraph is represented
- If on the fiche, the bargraph is represented



the XR25 should display




the XR25 should display



the XR25 should display

either  or 

Engine running



Extinguished when the function or the condition specified on the fiche is no longer carried out.



Illuminated when the function or the condition specified on the fiche is carried out.

FUNCTION V9

Fiche n° 27 side 1/2 and side 2/2 is a generic fiche used for several engine types. The different engines do not use all of the bargraphs. For information regarding the bargraphs processed by the injection computer, press keys V and 9 simultaneously after establishing dialogue. The bargraphs processed will illuminate:

- permanently, in the case of fault bargraphs which cannot be stored or for status bargraphs,
- flashing, in the case of fault bargraphs which can be stored.

To return to fault-finding mode, press key D.

<div>1</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 1 extinguished</div> <div>Fiche n° 27 side 1/2</div> <div><u>XR25 CIRCUIT</u></div> <div>XR25 :        no connection, CO, CC TO EARTH, CC + 12</div>
--	---

<div>INSTRUCTIONS</div>	<div>For this fault-finding procedure, this bargraph should be illuminated.</div>
-------------------------	---

<div>Check:</div> <div><div>- the Injection fuses, Engine and Passenger Compartment,</div><div>- the connection between the XR25 and the diagnostics socket,</div><div>- the position of the selector (S8),</div><div>- the conformity of the cassette.</div></div> <div>Rectify if necessary.</div>	
<div>Check:</div> <div><div>- the presence of+ 12 V on track 6 and earth on track 2 of the diagnostics socket.</div><div>- the connection between the XR25 and the diagnostics socket</div></div> <div><div>Diagnostics socket</div><div>10 —————&gt; 4      XR25</div><div>11 —————&gt; 8      socket</div></div> <div>Rectify if necessary.</div>	
<div>Connect the bornier <b>MS 1048</b> in place of the computer and check the insulation and continuity between tracks:</div> <div><div>Bornier</div><div>10 —————&gt; 10      Diagnostics socket</div><div>9 —————&gt; 11      Diagnostics socket</div><div>18 —————&gt; C5      Main relay</div><div>26 —————&gt; C2      Main relay</div><div>20 —————&gt; D2      Fuel pump relay</div></div> <div>Rectify.</div>	

<div>Check the presence of + 12 V on the track:</div> <div><div>C1    of the main relay</div><div>C3    of the main relay</div><div>D1    of the fuel pump relay.</div></div> <div>Change the relay(s) if necessary.</div>	
--	--

<div>AFTER REPAIR</div>	<div>Carry out a conformity check</div>
-------------------------	---

<div>2</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 2 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>COMPUTER CIRCUIT</div> <div>XR25 :      Computer not operational if left-hand bargraph 2 is illuminated</div>
--	--

INSTRUCTIONS	None
--------------	------

Computer not correct to specification or faulty.

Change the injection computer.

AFTER REPAIR	Carry out a conformity check
--------------	------------------------------

<div>2</div> <div><div></div><div></div></div>	Right-hand bargraph 2 illuminated		Fiche n° 27 side 1/2
	<u>ENGINE IMMOBILISER CIRCUIT</u>		
	XR25 :	*22 = 1dEF CO, CC TO EARTH or CC +12 V LINE 30 OF THE COMPUTER	
		*22 = 2 dEF	If the vehicle is fitted with an engine immobiliser, refer to the engine immobiliser fault-finding information

INSTRUCTIONS	<p>If the vehicle is not fitted with an engine immobiliser, right-hand bargraph 2 is illuminated and *22 = 2dEF.</p> <p>In this case, ignore right-hand bargraph 2.</p>
--------------	---

<p>Connect bornier <b>MS 1048</b> in place of the computer and the check the insulation and continuity of the line:</p> <div><div>Bornier</div><div>30</div><div>→</div><div>9 of the infra-red transmitter</div></div> <p>Rectify if necessary.</p>	
If the fault persists, refer to "Engine immobiliser fault-finding"	

AFTER REPAIR	<p>Erase the computer memory using GO**.</p> <p>Carry out a conformity check</p>
--------------	--

<div>3</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 3 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>AIR TEMPERATURE SENSOR CIRCUIT</div> <div>XR25 :       #03 = -40       CO LINE 2 OR 15 ; CC + 5V LINE 2</div> <div>                  #03 = 119       CC TO EARTH LINE 2</div>
--	--

INSTRUCTIONS	Refer to "Fault-finding - Help" for the resistance values.
--------------	--

Check the resistance of the air temperature sensor.	
The resistance is not correct	
	Change the air temperature sensor.
The resistance is correct	
	<div>Connect bornier <b>MS 1048</b> in place of the computer and check the continuity and insulation of the electrical wiring between the tracks:</div> <div>1 sensor connector           15 bornier</div> <div>2 sensor connector           2 bornier</div>
If the electrical wiring is good, change the computer.	

AFTER REPAIR	Erase the computer memory using GO**. Carry out a conformity check
--------------	---

<div>3</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 3 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>OXYGEN SENSOR CIRCUIT</u></div> <div>XR25 :       None</div>
--	---

<div>INSTRUCTIONS</div>	<div>Right-hand bargraph 3 may illuminate with the engine running in the event of a fault.</div>
-------------------------	--

<div>Check the connection and condition of oxygen sensor connector.</div>
<div>With the engine running, check the presence of + 12V between tracks A and B on the oxygen sensor connector.</div>
<div>If there is no 12V supply, repair the sensor heating circuit electrical wiring.</div>
<div>With the ignition off, connect bornier <b>MS 1048</b> in place of the computer and check the continuity and insulation of line between track 22 of the bornier and track C of the connector.</div>
<div>If necessary, repair the electrical wiring.</div>
<div>The fault persists! Change the oxygen sensor.</div>
<div>The fault persists! Change the computer.</div>

<div>AFTER REPAIR</div>	<div>Erase the computer memory (engine cold) using GO**.</div> <div>Carry out a conformity check</div>
-------------------------	--

<div>4</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 4 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>COOLANT TEMPERATURE SENSOR CIRCUIT</div> <div>XR25 :      #02 = -40°C CC + 5V LINE 6 ; CO LINE 6 or 15</div> <div>                 #02 = 119°C CC TO EARTH LINE 15</div>
--	---

INSTRUCTIONS	Refer to "Fault-finding - Help" for the resistance values.
--------------	--

Check the resistance of the coolant temperature sensor.

The resistance is not correct	Change the sensor
-------------------------------	-------------------

The resistance is correct	<div>Connect bornier <b>MS 1048</b> in place of the computer and check the continuity and insulation of the electrical wiring between the tracks:</div> <div>1 coolant temperature sensor                      15 bornier</div> <div>2 coolant temperature sensor                      6 bornier</div>
	Repair if necessary.
	The fault persists! Change the computer.

AFTER REPAIR	Erase the computer memory using GO**. Carry out a conformity check
--------------	---

<div>4</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 4 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>VEHICLE SPEED SENSOR CIRCUIT</u></div> <div>XR25 : CO or CC LINE 12</div>
--	--


<i>INSTRUCTIONS</i>	Refer to "Fault-finding - Help" for the resistance values.
---------------------	--

Carry out a road test and check the speed on the speedometer.
If the speed is zero, repair the wiring between track 12 of the computer and B1 of the sensor.
With the ignition on, check the connection of the speed sensor and its supply: + 12V on track A earth on track B2
Rectify if necessary.
The fault persists! Change the speed sensor.

<i>AFTER REPAIR</i>	Erase the computer memory using GO** Carry out a road test Carry out a conformity check
---------------------	---



5



Left-hand bargraph 5 illuminated

Fiche n° 27 side 1/2

ABSOLUTE PRESSURE SENSOR CIRCUIT

XR25 :      #01 = 103 mb      CO LINE 23 or 5    CC - LINE 23  
                 #01 ≥ 1020 mb    CC+ LINE 8 or 23

INSTRUCTIONS

Left-hand bargraph 5 may illuminate with the engine running in the event of a fault.

Refer to "Fault-finding - Help" for the resistance values.

If the vehicle has idling problems, check that the line between track 8 of the computer and track B1 of the speed sensor is insulated from 12 V.

Check whether the pressure sensor is electrically and pneumatically connected and check the conformity of the pipe. It must not be clogged, punctured...

With the ignition on, check the presence of 5V between track C and the earth at track A.

5V is not present between track C and track A

Connect the bornier **MS 1048** in place of the computer and check the insulation and continuity between the tracks:

A sensor connector      15 bornier  
C sensor connector      5 bornier

Rectify if necessary.

5V is present between track C and track A

With the ignition on, check the return voltage on track B of the sensor.

**Note :** To take this reading, a vacuum pump could be used to check the variation in the voltage.

The voltage does not vary

Change the sensor.

The voltage varies

Connect bornier **MS 1048** in place of the computer and check the insulation and continuity between track B of the sensor and track 23 of the bornier.

Rectify if necessary.

The fault persists! Change the computer.

AFTER REPAIR

Erase the computer memory using GO\*\*

Carry out a conformity check

<div>5</div> <div><div></div><div></div></div>	<b>Right-hand bargraph 5 illuminated or flashing</b> <span>Fiche n° 27 side 1/2</span>
	<u>FLYWHEEL SIGNAL CIRCUIT</u> <b>XR25 :</b> *25 = dEF      FAULT STORED, to be confirmed *25 = C00      CC - LINE 13 / 31 or 5 *25 = In      INVERSION OF SENSOR WIRES

<b>INSTRUCTIONS</b>	If right-hand bargraph 5 is flashing, erase the computer memory using GO**. At starter speed for 10 seconds or with the engine running for 10 seconds minimum, if right-hand bargraph 5 is illuminated or flashing, fault-finding can be carried out. Refer to "Fault-finding - Help" for the resistance values.
---------------------	--


Disconnect the sensor connector and check the resistance of the sensor between terminals A and B.
---

The resistance is not correct	Change the sensor.
-------------------------------	--------------------

The resistance is correct	Connect the bornier <b>MS 1048</b> in place of the computer and check the continuity and insulation of the wiring between the tracks: <div><div>Flywheel signal sensor</div><div>Flywheel signal sensor</div><div>Throttle position sensor</div><div>Pressure sensor</div><div>Earth</div><div>Earth</div><div>Earth</div></div> <div><div>A</div><div>B</div><div>B</div><div>C</div><div>earth</div><div>earth</div><div>earth</div></div> <div><div>→</div><div>→</div><div>→</div><div>→</div><div>→</div><div>→</div><div>→</div></div> <div><div>31</div><div>13</div><div>5</div><div>5</div><div>16</div><div>4</div><div>34</div></div> <div><div>bornier</div><div>bornier</div><div>bornier</div><div>bornier</div><div>bornier</div><div>bornier</div><div>bornier</div></div>
---------------------------	---

<b>AFTER REPAIR</b>	Erase the computer memory using GO** Carry out a conformity check
---------------------	--

Fault-finding - Interpretation of XR25 bargraphs

<div>6</div> <div></div>	<div>Left-hand bargraph 6 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>PINKING SENSOR CIRCUIT</u></div> <div>XR25 : CC TO EARTH LINE 1 or CO LINE 1 and 15</div>
--	---

<i>INSTRUCTIONS</i>	Left-hand bargraph 6 may illuminate in the event of a fault with the engine running at an engine speed of 2500 rpm.
---------------------	---

Check the connectors of the faulty sensor.
Rectify if necessary.
Connect the bornier <b>MS 1048</b> in place of the computer and check the insulation and continuity of the electrical wiring between the tracks: <div>1 sensor15 bornier</div> <div>2 sensor1 bornier</div>
Rectify if necessary.
The fault persists! Change the pinking sensor.

<i>AFTER REPAIR</i>	Erase the computer memory using GO** Carry out a conformity check
---------------------	--

<div>6</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 6 illuminated or flashing</div> <div>Fiche n° 27 side 1/2</div> <div>THROTTLE POTENTIOMETER CIRCUIT</div> <div>XR25 :<div>CO LINE 3</div><div>CC- LINE 3</div><div>CC+ LINE 3 or 34 or 35 or 17</div></div>
--	--

<div>INSTRUCTIONS</div>	<div>If right-hand bargraph 6 is flashing, erase the computer memory using GO**.</div> <div>With the ignition on, at starter speed or with the engine running, if right-hand bargraph 6 is flashing or illuminated, fault-finding can be carried out.</div>
-------------------------	---

<div>Check the resistance of the throttle potentiometer between tracks A and B.</div>
<div>Check the variation of the throttle potentiometer between tracks B and C.</div>

<div>R between A and B is not correct or B-C does not vary</div>
--

<div>Change the throttle potentiometer.</div>
---

<div>R between A and B is correct and B-C varies.</div>
---

<div>Connect the bornier <b>MS 1048</b> in place of the computer and check the insulation and continuity between the tracks:</div> <div><div>A potentiometer</div><div>B potentiometer</div><div>C potentiometer</div><div>Earth</div><div>1 coil</div><div>2coil</div></div> <div><div>→</div><div>→</div><div>→</div><div>→</div><div>→</div><div>→</div></div> <div><div>15 bornier</div><div>5 bornier</div><div>3 bornier</div><div>34 bornier</div><div>35 bornier</div><div>17 bornier</div></div>
---

<div>Check the resistance of the coil.</div> <div>If the coil is not good, it must be changed before the computer is changed.</div>
---

<div>Change the computer.</div>
---------------------------------

<div>AFTER REPAIR</div>	<div>Erase the computer memory using GO**</div> <div>Carry out a conformity check</div>
-------------------------	---

<div>8</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 8 illuminated</div> <div>FICHE n° 27 side 1/2</div> <div>FUEL PUMP RELAY CONTROL CIRCUIT</div> <div>XR25 : CC + 12 V LINE 20</div>
--	--

INSTRUCTIONS	Refer to "Fault-finding - Help" for the resistance values.
--------------	--

Check the operation of the impact sensor.
With the fuel pump relay in place, check the presence of + 12V during the timing phase between tracks 1 and 2 when the ignition is switched on.

+12 V is present between 1 and 2	Change the relay.
+1 2 V is not present between 1 and 2	With the ignition on, check the presence of + 12 V on track 1 of the fuel pump relay.
+12V is not present on track 1	Check the line of track 1 as far as the fuse.
+ 12V is present on track 1	Connect the bornier <b>MS 1048</b> in place of the computer and check the continuity and insulation between track 2 of the relay and track 20 of the bornier.
	Rectify if necessary.

The fault persists! Change the injection computer.
--

AFTER REPAIR	Erase the computer memory using GO** Carry out a conformity check
--------------	--

<div>11</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 11 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>INJECTION CIRCUIT</div> <div>XR25 :      *11 = XX.CO      CO or CC - LINE 32 or 33</div> <div>                 *11 = XX.CC      CC + LINE 32 or 33</div> <div>                 *11 = Def      FAULT STORED</div>
---	--

INSTRUCTIONS	<div>X represents the number of cylinder.</div> <div>Refer to "Fault-finding - Help" for the resistance values.</div>
--------------	---

Check the resistance of the injectors concerned.	
The resistance is not correct	Change the faulty injector(s).
The resistance is correct	Connect the bornier <b>MS 1048</b> in place of the computer and check the continuity and insulation between track 2 of the injector connectors and tracks 32 and 33.
	Repair the wiring if necessary.
	During the timing phase, check the presence of 12 V on track 1 of the injector concerned.
	Repair the wiring if necessary.
The fault persists! Change the computer.	

AFTER REPAIR	<div>Erase the computer memory using GO**</div> <div>Carry out a conformity check</div>
--------------	---

<div>12</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 12 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>FAULT WARNING LIGHT CIRCUIT</u></div> <div>XR25 : CC - or CC + LINE 19</div>
---	---

INSTRUCTIONS	None
--------------	------

<div>Check the insulation and continuity of the line:</div> <div>computer 19 —————&gt; warning light fuse</div>
The fault persists! Change the computer.

AFTER REPAIR	<div>Erase the computer memory using GO**</div> <div>Carry out a conformity check</div>
--------------	---


<div>13</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 13 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>STORED MEMORY CIRCUIT</div> <div>XR25 :        Injection computer supply cut off.</div>
---	---

<div>INSTRUCTIONS</div>	<div>Has the battery has been removed?</div> <div>Left-hand bargraph 13 may illuminate after repair work, ignore it.</div>
-------------------------	--

<div>Check:</div> <div><div>- the battery charge,</div><div>- the injection fuses,</div><div>- the battery wiring.</div><div>- the computer supply.</div></div> <div>Rectify.</div>
<div>Switch off the ignition for 2 minutes.</div> <div>Switch on the ignition.</div> <div>The fault bargraph should be extinguished.</div>
<div>The fault persists! Change the computer.</div>

<div>AFTER REPAIR</div>	<div>Erase the computer memory using GO**</div> <div>Carry out a conformity check</div>
-----------------------------	---



<div>14</div> <div></div>	<div>Left-hand bargraph 14 illuminated or flashing</div> <div>Fiche n° 27 side 1/2</div> <div>IDLE REGULATION VALVE CIRCUIT</div> <div>XR25 : CO LINE 11 or 28 or 12 or 29</div> <div>CC - LINE 11 or 28 or 12 or 29</div> <div>CC + LINE 12 or 29</div>
---	--

<div>INSTRUCTIONS</div>	<div>Left-hand bargraph 14 may illuminate with the engine running in the event of a fault.</div> <div>Refer to "Fault-finding - Help" for the resistance values.</div>
-------------------------	--

<div>Check the resistance of the stepping motor coils between tracks A-D and B-C.</div>
<div>If the resistance is not correct, change the stepping motor.</div>
<div>Connect the bornier <b>MS 1048</b> in place of the computer and check the insulation and continuity of the line:</div> <div><div>Bornier</div><div><div>11</div><div>28</div><div>12</div><div>29</div></div><div><div>→</div><div>→</div><div>→</div><div>→</div></div><div><div>D stepping motor</div><div>B</div><div>A</div><div>C</div></div></div>
<div>The fault persists! Change the computer.</div>

<div>AFTER REPAIR</div>	<div>Erase the computer memory using GO**</div> <div>Carry out a conformity check</div>
-------------------------	---

<div>14</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 14 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>CANISTER BLEED CIRCUIT</div> <div>XR25 : CO or CC - or CC + LINE 24 and #23 = 00</div>
---	---

INSTRUCTIONS	Refer to "Fault-finding - Help" for the resistance values.
--------------	--

Check the conformity of the pipes, rectify if necessary.
Check the resistance of the canister bleed valve between track A and B.

The resistance is not correct	Change the canister bleed valve.
-------------------------------	----------------------------------

The resistance is correct	With the engine running at idle, check the presence of + 12 V on track A of the canister bleed valve.
+ 12 V is not present on track A	Repair the electrical wiring between track A of the canister bleed valve and track 5 of the fuel pump relay.
+ 12 V is present on track A	Connect the bornier <b>MS 1048</b> in place of the computer and check the insulation and continuity of the electrical wiring between track B of the canister bleed valve and track 24 of the bornier.
	Rectify if necessary.

The fault persists! Change the injection computer.
--

AFTER REPAIR	Erase the computer memory using GO** Carry out a conformity check
--------------	--

<div>16</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 16 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>IGNITION COIL CIRCUIT</div> <div>XR25 :      *16 = 1.4 CO      CO / CC TO EARTH LINE 35</div> <div>                 *16 = 2.3 CO      CO / CC TO EARTH LINE 17</div>
---	--

INSTRUCTIONS	Refer to "Fault-finding - Help" for the resistance values.
--------------	--

Check the resistance of the coil.	
The resistance is not correct	Change the coil.
The resistance is correct	<div>Connect the bornier <b>MS 1048</b> in place of the computer and check the insulation and continuity of the line:</div> <div>bornier 35 —————&gt; 1 coil</div> <div>bornier 17 —————&gt; 2 coil</div> <div>Check the presence of + 12 V on track 3 of the coil and check the insulation and continuity of line 4 of the coil.</div>
	Repair the faulty line.
The fault persists! Change the computer.	

AFTER REPAIR	Erase the computer memory using GO** Carry out a conformity check
--------------	--

<div>2</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 2, right-hand bargraph 2, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>THROTTLE POSITION CIRCUIT</u></div> <div>XR25 :<div>Left-hand bargraph 2 illuminated at full load</div><div>Right-hand bargraph 2 illuminated at no load</div><div>Left-hand bargraph 2 and right-hand bargraph 2 extinguished at an intermediate position.</div></div>
--	--

<div>INSTRUCTIONS</div>	<div>No fault bargraph should be illuminated.</div>
-------------------------	---

<div>If not fault bargraph is illuminated, the problem is not electrical. Check the mechanics of the accelerator circuit (cable, accelerator pedal,...).</div>
--

<div>AFTER REPAIR</div>	<div>Carry out a conformity check</div>
-------------------------	---

Fault-finding - Interpretation of XR25 bargraphs

<div>3</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 3, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>FLYWHEEL SIGNAL CIRCUIT</u></div> <div>XR25 :      Left-hand bargraph 3 illuminated with the engine running</div>
--	---

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>3</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 3, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>ENGINE IMMOBILISER CIRCUIT</u></div> <div>XR25 :      Left-hand bargraph 3 illuminated, engine immobiliser active</div>
--	--

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>4</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 4, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>+ AFTER IGNITION CIRCUIT</u></div> <div>XR25 :      Right-hand bargraph 4 illuminated at+ after ignition</div>
--	---

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>AFTER REPAIR</div>	<div>No action</div>
-----------------------------	----------------------

Fault-finding - Interpretation of XR25 bargraphs

<div>5</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 5, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>LOCKING RELAY CIRCUIT</u></div> <div>XR25 :      Right-hand bargraph 5 illuminated if the locking relay is controlled</div>
--	--

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>6</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 6, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>MIXTURE REGULATION CIRCUIT</u></div> <div>XR25 :      Left-hand bargraph 6 illuminated when the mixture is regulated (engine running)</div>
--	---

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>AFTER REPAIR</div>	<div>No action</div>
-------------------------	----------------------

<div>6</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 6, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>IDLE SPEED REGULATION CIRCUIT</u></div> <div><div>XR25 :</div><div>Right-hand bargraph 6 illuminated with engine running under no load</div></div>
--	---

<div>INSTRUCTIONS</div>	<div>No fault bargraph should be illuminated.</div>
-------------------------	---

<div>Check the insulation of lines 11 and 28 of the injection computer.</div>
<div>If the fault persists and no other bargraph is to be processed, change the computer.</div>

<div>AFTER REPAIR</div>	<div>No action</div>
-------------------------	----------------------

<div>7</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 7, incorrect illumination<div>Fiche n° 27 side 2/2</div></div> <div><u>FUEL PUMP CONTROL CIRCUIT</u></div> <div>XR25 :      Left-hand bargraph 7 illuminated with the ignition on during the timing phase and with the engine running</div>
INSTRUCTIONS	Covered in the fault bargraphs.

AFTER REPAIR	No action
--------------	-----------



Fault-finding - Interpretation of XR25 bargraphs

<div>11</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 11, incorrect illumination<div>Fiche n° 27 side 2/2</div></div> <div><u>CANISTER BLEED CIRCUIT ACTIVE</u></div> <div>XR25 :      Right-hand bargraph 11 illuminated when the canister bleed is active</div>
---	--

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>12</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 12 illuminated or extinguished<div>Fiche n° 27 side 2/2</div></div> <div><u>ERASING MEMORIED FAULTS</u></div> <div>XR25 :      This bargraph is illuminated when the faults have been erased.</div>
---	--

<div>INSTRUCTIONS</div>	<div>None.</div>
-------------------------	------------------

<div>AFTER REPARATION</div>	<div>No action</div>
-----------------------------	----------------------

### INSTRUCTIONS

Only refer to these customer complaints following a full check using the XR25  
Refer to "Fault-finding - Help" for the resistance values.

#### STARTING PROBLEMS

Does not start	CHART 1
Starts but stalls	CHART 2
Starting takes too long	CHART 3

#### IDLE SPEED PROBLEMS

Too high	CHART 4
Too low	CHART 5
Engine speed unstable	CHART 6
Hunting	CHART 7

#### HANDLING

Lack of performance	CHART 8
Flat spots and hesitation	CHART 9

#### FUMES - POLLUTION

CO and/or HC levels too high	CHART 10
------------------------------	----------

#### HIGH FUEL CONSUMPTION

CHART 11

#### ENGINE NOISE

Pinking	CHART 12
---------	----------

#### FAULT WARNING LIGHT PROBLEMS

Carry out the left-hand  
bargraph 12  
illuminated fault-  
finding procedure



The procedure which does not use the OPTIMA is not suitable as an adequate quality criteria.  
Follow the procedure using the OPTIMA to obtain this quality criteria.

## Fault-finding - Chart not using OPTIMA

## CHART 1

## STARTING PROBLEMS

Does not start

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Check the injection fuses in the passenger compartment fuse box and in the engine compartment fuse box.

Check the continuity of the line:

- 16 of the computer
- 4 of the computer
- 13 of the computer
- 31 of the compute

Rectify if necessary.

Does the customer complaint persist?

no

End of fault-finding

yes

Can the fuel pump be heard when the ignition is switched on?

yes

Refer to Chart 1A

no

Carry out the fuel pump relay control procedure and check whether the relay makes a noise (several knocks).  
Is the relay good?

no

Change the relay.

yes

Check the presence of 12 V on track 3 of the relay. Rectify if necessary.  
If the customer complaint persists

no


Change the relay.

yes

AFTER  
REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 1 CONT	
-----------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--

## Fault-finding - Chart not using OPTIMA

### CHART 1A

### STARTING PROBLEMS

Does not start

### INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Connect the fault-finding equipment and check the presence of a High Voltage on the spark plug wires when the starter is operated.  
Is there a High Voltage?

yes →

Check the flow of fuel and the fuel pressure  
(Refer to vehicle Workshop Repair Manual).  
Repair the fuel circuit  
if necessary  
(pump, filter, pipes,  
regulator, injectors...).  
If the customer complaint persists

no ↓

Check the high voltage circuit.  
Rectify if necessary.  
If the customer complaint persists

It is an engine problem,  
the injection system is no longer implicated.

With the ignition on, check the presence of  
+ 12 V on track 2 of the coils.  
Is + 12 V present?

no →

Check the continuity of the electrical wiring  
between track 2 (coils) and the + after  
ignition fuse in the engine connection unit.  
Rectify.

yes ↓

With the ignition on,  
check the resistance of the coil.  
Is it correct?

no →

Change the faulty coil(s).

yes ↓


Connect the bornier **MS 1048** in place of  
the computer and check the insulation  
and continuity between the tracks:  
1 / coil      35 / bornier  
2 / coil      17 / bornier  
Rectify if necessary.  
If the customer complaint persists

Change the injection computer.

### AFTER REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check


<b>CHART 2</b>	<b>STARTING PROBLEMS</b> The engine starts but stalls
<b>INSTRUCTIONS</b>	Only refer to this customer complaint following a full check using the XR25



<b>AFTER REPAIR</b>	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
---------------------	--


Fault-finding - Chart not using OPTIMA

CHART 3	STARTING PROBLEMS Starting takes too long
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--


CHART 4	IDLE SPEED PROBLEMS Idle speed too high
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--



CHART 5	IDLE SPEED PROBLEMS Idle speed too low
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

## Fault-finding - Chart not using OPTIMA


## CHART 6

## IDLE SPEED PROBLEMS

Engine speed unstable


## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

AFTER  
REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 6 CONT	
-----------------	--



<b>AFTER REPAIR</b>	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
---------------------	--

## Fault-finding - Chart not using OPTIMA

## CHART 7

## IDLE SPEED PROBLEMS

## Hunting

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Check the value of the pollutants and Lambda

- CO < 0.3 %
- HC ≤ 100 ppm
- CO<sub>2</sub> ≥ 14.5 %
- 0.97 ≤ Lambda ≤ 1.03

Are the values correct?

no

Check:

- Catalytic converter (melted, clogged, ...).
- Oxygen sensor (contaminated, heating faulty, ...).
- Air leak upstream of the oxygen sensor.
- Sealing of the exhaust line.
- Type of fuel used.
- Ignition (spark plugs, high voltage wires, coils).
- General condition of the engine (timing, ...).

yes

Disconnect the oxygen sensor and wait until #35 stabilises at 128, #05 stabilises at ≈ 0.402, and right-hand fault bargraph 3 illuminates .

Is the engine stable?

no

Check that there is no leak on the inlet manifold (caps, seals, take-offs, ...).  
Rectify if necessary.

yes

Change the oxygen sensor.

**AFTER  
REPAIR**

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

## Fault-finding - Chart not using OPTIMA

## CHART 8

HANDLING  
Lack of performance

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25




AFTER  
REPAIRCheck the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 9	<div>HANDLING</div> <div>Flat spots and hesitation</div>
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



# Fault-finding - Chart not using OPTIMA

## CHART 9 CONT



### AFTER REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check


## Fault-finding - Chart not using OPTIMA

### CHART 10

**FUMES - POLLUTION**  
CO and/or HC level too high

#### INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25



#### AFTER REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check



CHART 10  
CONT

A

Check the fuel return pressure and flow (refer to vehicle Workshop Repair Manual). Rectify or change the faulty parts (fuel pump, pressure regulator, pipes). If the customer complaint persists

Ask the customer whether there have been any ignition or starting problems. Was there a problem?

yes

Change the catalytic converter.

no

It is an engine problem and the injection system is no longer implicated.

B

Check the oxygen sensor heating (+ 12 volts between A and B). Is it good?

no

Repair the electrical circuit.

yes

Check:


- Catalytic converter (melted, clogged,...).
- Oxygen sensor (contaminated, heating faulty,...).
- Air leak upstream of the oxygen sensor.
- Sealing of the exhaust line.
- Type of fuel used.
- Ignition (spark plugs, wires, distributor)
- General condition of the engine (timing, ...).

**AFTER  
REPAIR**

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check


CHART 11	HIGH FUEL CONSUMPTION
----------	-----------------------

INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25
--------------	---



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--


CHART 11 CONT	
------------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--

CHART 12	ENGINE NOISE Pinking
----------	-------------------------

INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25
--------------	---



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25 Refer to "Fault-finding - Help" for the resistance values
--------------	--

STARTING PROBLEMS

Does not start	CHART 1
Starts but stalls	CHART 2
Starting takes too long	CHART 3

IDLE SPEED PROBLEMS

Too high	CHART 4
Too low	CHART 5
Engine speed unstable	CHART 6
Hunting	CHART 7

HANDLING

Lack of performance	CHART 8
Flat spots and hesitation	CHART 9

FUMES- POLLUTION

Gases analysis incorrect	CHART 10
Oxygen sensor check	CHART 11

HIGH FUEL CONSUMPTION

CHART 12

ENGINE NOISE

Pinking	CHART 13
---------	----------

FAULT WARNING LIGHT PROBLEMS

Carry out the left-hand  
bargraph 12  
illuminated fault-  
finding procedure

## Fault-finding - Chart using OPTIMA

## CHART 1

## STARTING PROBLEMS

Does not start

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Check all of the passenger and engine compartment injection fuses.

Check the continuity of the line:

- 16 of the computer
- 4 of the computer
- 13 of the computer
- 31 of the computer

Rectify if necessary.

Does the customer complaint persist?

no

End of fault-finding.

yes

Check the operation of the engine immobiliser.

Does the customer complaint persist?

no

End of fault-finding.

yes

Can the fuel pump be heard when the ignition is switched on?

yes

Refer to Chart 1A

no

When the ignition is switched on, can the fuel pump relay be heard?

no

Check the presence of + 12 V at 1 of this relay. Rectify.

yes




Connect the bornier in place of the injection computer and check the insulation and continuity of line between track 20 of the bornier and track 2 of the relay. Rectify.

If the customer complaint persists, change the relay.

## AFTER REPAIR


Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 1 CONT	
-----------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--


CHART 1A	STARTING PROBLEMS Does not start
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--



CHART 2	STARTING PROBLEMS The engine starts but stalls
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

## Fault-finding - Chart using OPTIMA

## CHART 3

## STARTING PROBLEMS

Starting takes too long

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25




AFTER  
REPAIRCheck the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 4	IDLE SPEED PROBLEMS Idle speed too high
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--


CHART 5	IDLE SPEED PROBLEMS Idle speed too low
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out conformity check
--------------	--


CHART 6	IDLE SPEED PROBLEMS Engine speed unstable
---------	--

INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25
--------------	---




AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

CHART 6 CONT	
-----------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity test
-----------------	---

CHART 7	IDLE SPEED PROBLEMS Hunting
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

## Fault-finding - Chart using OPTIMA

### CHART 8

### HANDLING Lack of performance

#### INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Check whether the throttle opens fully  
(full load bargraph illuminated).  
Check the setting of the accelerator control.  
Rectify if necessary.  
If the customer complaint persists

Check the air filter: dirt, deformation.  
Rectify if necessary.  
If the customer complaint persists

Connect the OPTIMA 5800 fault-finding  
equipment and carry out an ignition test with  
the engine running.  
Does the equipment detect a fault?

yes

Follow the instructions.

no

Analyse the gases  
(refer to Chart 10 - fumes/pollution).  
If the customer complaint persists

Connect the OPTIMA 5800 fault-finding  
equipment and carry out an engine  
compression test.  
Are the compressions normal?

no

It is an engine problem.

yes




#### AFTER REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check




CHART 8 CONT	
-----------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--


CHART 9	HANDLING Flat spots and hesitation
---------	---------------------------------------

INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25
--------------	---



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

CHART 9 CONT	
-----------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

## Fault-finding - Chart using OPTIMA

## CHART 10

FUMES/POLLUTION  
Analysis of gases incorrect

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Connect the OPTIMA 5800 fault-finding equipment and connect it to a 4 gas analyser, type 4040, 5040 or AGM 1500.  
Carry out an anti-pollution/ gases analysis test.  
Does the equipment detect a fault?

no

End of fault-finding of Chart 10  
NOTE: a correct gases analysis indicates correct operation of the catalytic converter.

yes

Is the CO level too high (CO > 0.5 at idle speed or CO > 0.3 at 2500 rpm)?

yes

Check the oxygen sensor (refer to Chart 11 -fumes/pollution).  
If the customer complaint persists

no

Check whether it is an engine problem using the compressions test (OPTIMA 5800 fault-finding equipment).


Check the catalytic converter (efficiency, melting, presence of lead, ...), the air supply (filter, manifold, ...), and the condition of the engine (abnormal oil consumption).

A

AFTER  
REPAIR


Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 10 CONT 1	
--------------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--


### CHART 10 CONT 2



### AFTER REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 10 CONT 3	
--------------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

## Fault-finding - Chart using OPTIMA


## CHART 11

FUMES- POLLUTION  
Oxygen sensor check

## INSTRUCTIONS

Only refer to this chart following a full check using the XR25, checking the following parameters in particular:


- #35 (mixture adjustment) : it should fluctuate around 128
- #30 and #31 (adaptive mixture regulation) : values must never be at the limit.

AFTER  
REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check




## Fault-finding - Chart using OPTIMA

CHART 11  
CONT 1**AFTER  
REPAIR**


Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 11 CONT 2	
--------------------	--




AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--

CHART 12	FUEL CONSUMPTION HIGH
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25




AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

CHART 12 CONT	
------------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--

CHART 13	ENGINE NOISE Pinking
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

INSTRUCTIONS	Engine cold, ignition on
--------------	--------------------------

Order of operations	Function to be checked	Action	Bargraph	Display and notes
1	XR25 dialogue	D13 (selector in position S8)		<div>9.NJ</div> Use of fiche n° 27 fault test side
2	Interpretation of normally illuminated bargraphs		<div>1</div> <div><div></div><div></div></div> <div>1</div> <div><div></div><div></div></div>	 Fault test   Code present
3	Engine immobiliser		<div>2</div> <div><div></div><div></div></div>	If the vehicle does not have an engine immobiliser, this bargraph should be illuminated
4	Conformity of the computer	G70*		<div>X X X X</div> Display in three sequences of the part number (refer to section 12)
5	Changing to status test mode	G01*		<div>10.NJ</div> Use of fiche n° 27 status test side

INSTRUCTIONS	Engine cold, ignition on.
--------------	---------------------------

Order of operations	Function to be checked	Action	Bargraph	Display and notes
6	Interpretation of normally illuminated bargraphs		<div>1</div> <div><div></div><div></div></div> <div>2</div> <div><div></div><div></div></div> <div>4</div> <div><div></div><div></div></div> <div>5</div> <div><div></div><div></div></div> <div>12</div> <div><div></div><div></div></div> <div>19</div> <div><div></div><div></div></div>	<div>Code present</div> <div>No load position recognised</div> <div>Reception of + after ignition information</div> <div>Locking relay control effective</div> <div>Illuminates after the memories have been erased to confirm that the operation has been carried out correctly</div> <div>Computer configured to operate with a:  manual gearbox (G50*2*)</div>

INSTRUCTIONS	Engine cold, ignition on
--------------	--------------------------

Order of operations	Function to be checked	Action	Bargraph	Display and notes
7	Throttle position potentiometer	No load # 17	<div>2</div> <div><div></div><div></div></div>	10 < X < 36
		Accelerator pedal slightly pressed	<div>2</div> <div><div></div><div></div></div>	
		Full load # 17	<div>2</div> <div><div></div><div></div></div>	193 < X < 240
8	Absolute pressure sensor	# 01		X = Local atmospheric pressure
9	Coolant temperature sensor	# 02		X =Ambient temperature ± 5°C
10	Air temperature sensor	# 03		X = Ambient temperature ± 5°C
11	Idle regulator stepping motor	# 12		The value varies in relation to the coolant temperature: 19% ≤ X ≤ 80%
12	Engine speed	# 06		X = 0 rpm.
13	Canister bleeding	# 23		X = 0 %



INSTRUCTIONS	Engine warm at idle after the fan assembly has cut in at least once.
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
1	Changing to status test mode	G01*		<div>10.NJ</div> Use of fiche n° 27 status test side
2	No fault		<div>20</div> <div><div></div><div></div></div>	<p>Check that this bargraph is not flashing; if it is, type GO2* and turn the fiche over.</p> <p><b>Warning:</b> This bargraph may flash if the vehicle is not fitted with an engine immobiliser. Ignore this bargraph if fault right-hand bargraph 2 is illuminated with *22 = 2dEF.</p> <p>Repair the faulty component and then erase the fault memory (GO**) and return to status test mode (GO1*).</p>
3	Battery voltage	# 04  if at # 04  then at # 06		<p>13 volts &lt; X &lt; 14.5 volts</p> <p>X &lt; 12.7 volts</p> <p>Nominal &lt; X &lt; 930 rpm. speed</p>

INSTRUCTIONS	Engine warm at idle after the fan assembly has cut in at least once.
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
4	Interpretation of normally illuminated bargraphs	-	<div>1</div> <div><div></div><div></div></div>	Code present
			<div>2</div> <div><div></div><div></div></div>	No load position recognised
			<div>3</div> <div><div></div><div></div></div>	Reception of engine speed information
			<div>4</div> <div><div></div><div></div></div>	Reception of + after ignition information
			<div>5</div> <div><div></div><div></div></div>	Locking relay control effective
			<div>6</div> <div><div></div><div></div></div>	Idle regulation active
			<div>6</div> <div><div></div><div></div></div>	Mixture regulation active

INSTRUCTIONS	Engine warm at idle after the fan assembly has cut in at least once.
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
4 (cont)	Interpretation of normally illuminated bargraphs (cont)	-	<div>7</div> <div><div></div><div></div></div> <div>12</div> <div><div></div><div></div></div> <div>19</div> <div><div></div><div></div></div>	<div>Fuel pump activated</div> <div>Illuminates after the memories have been erased to confirm that the operation has been carried out correctly</div> <div>Computer configured to operate with a:</div> <div>manual gearbox (G50*2*)</div>

INSTRUCTIONS	Engine warm at idle after the fan assembly has cut in at least once.
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
5	Idle speed	# 06  # 12	<div>6</div> <div><div></div><div></div></div>	X = 740 ± 50 rpm.  4 % < X < 15 %
6	Anti-pinking noise measurement	# 13 (3500 rpm. with no load)		X variable and not zero

Engine warn at idle after the fan assembly has cut in at least once.

JSA031.1

INSTRUCTIONS	Check to be carried out during a road test
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
1	Changing to status test mode	G01*		<div>10.NJ</div> Use of fiche n° 27 status test side
2	No fault		<div>20</div> <div><div></div><div></div></div>	Check that this bargraph is not flashing; if it is, type GO2* and turn the fiche over. <b>Warning:</b> This bargraph may flash if the vehicle is not fitted with an engine immobiliser. Ignore this bargraph if fault right-hand bargraph 2 is illuminated with *22 = 2dEF. Repair the faulty component and then erase the fault memory (GO**) and return to status test mode (GO1*).
3	Canister bleeding	# 23		Canister bleeding is authorised X = variable
4	Vehicle speed information	# 18	<div>11</div> <div><div></div><div></div></div>	X = vehicle speed displayed on the speedometer
5	Pinking sensor	Vehicle with load at an engine speed of 2000 rpm.  # 13  # 15		X = variable and not zero  $0 \leq X \leq 6$ (in the event of a sensor fault the advance is automatically reduced by 4°, not shown at# 15)



Injector resistance	=	14.5 Ω	
Idle regulation stepping motor resistance	=	A - D = 53 ± 5 Ω	
		B - C = 53 ± 5 Ω	
Canister bleed valve resistance	=	35 ± 5 Ω	
Ignition coil resistance	:	1-2 = 2 Ω	2-3 = 1.6 Ω
		1-3 = 1.6 Ω	2-4 = 1.6 Ω
		1-4 = 1.6 Ω	3-4 = 1.1 Ω
		HT-HT= 7.2 kΩ	
Flywheel signal resistance	=	220 Ω	
Air temperature sensor resistance	=	800 to 1500 Ω at 40°C	
Throttle position potentiometer	:	PL C-A 1260 Ω PF C-A2200 Ω	
		C-B 2200 Ω	C-B 1260 Ω
		B-A 1200 Ω	B-A 1200 Ω
Coolant temperature sensor resistance	=	210 to 270 Ω at 90°C	
Oxygen sensor resistance	:	A-B = 3 to 15 Ω	
Fuel pressure	=	3 bars or 2.5 bars at idle	
Value of:	CO	= 0.3 % maximum	
	HC	= 100 ppm maximum	
	CO2	= 14.5 % minimum	
	Lambda (λ)	= 0.97 < λ < 1.03	



## EQUIPMENT REQUIRED

OPTIMA 5800 fault-finding equipment  
4 gas analyser 4040-5040 or AGM 1500

## ANALYSIS OF EXHAUST GASES USING THE FAULT-FINDING EQUIPMENT

Connecting the OPTIMA 5800 fault-finding equipment to an analyser (SOURIAU 4040-5040 or SAGEM AGM 1500) allows the gases to be checked in accordance with the legislation relating to vehicles fitted with catalytic converters. This check assumes measurement at half load and at idle, with the following requirements:

Idle	2 500 rpm
CO < 0.5 %	CO < 0.3 %
HC < 100 ppm	HC < 100 ppm

Irrespective of the legislation, the other measurements given by the analyser are the subject of a tolerance interval:

Idle	2 500 rpm
CO <sub>2</sub> > 13.5 %	CO <sub>2</sub> > 13.5 %
O <sub>2</sub> < 0.8 %	O <sub>2</sub> < 0.8 %
0.97 < Lambda < 1.03	0.97 < Lambda < 1.3

**NOTE :** Lambda = 1 / Mixture

- Lambda > 1 → Lean mixture
- Lambda < 1 → Rich mixture

The condition Lambda = 1 is essential for correct operation of the catalytic converter.

The equipment combines the following phases:

- Bringing the engine up to operating temperature (oil temperature greater than 60°C).
- Constant speed of 2500 rpm for one minute to activate the mixture regulation and simultaneous measurement of the gases.
- If the gases analysis at 2500 rpm is correct, measurement at idle.

If the equipment considers the analysis to be incorrect, fault-finding messages appear, the order of gas priority being:

1) CO    2) Lambda    3) HC    4) O<sub>2</sub>    5) CO<sub>2</sub>

**NOTE :** It is possible to print the results of the anti-pollution tests.

## EQUIPMENT REQUIRED

OPTIMA 5800 fault-finding equipment

## OXYGEN SENSOR CHECK USING THE FAULT-FINDING EQUIPMENT

Straight-forward oxygen sensor faults are detected by the XR25.

- Open circuit.
- Short circuit to earth.
- Short circuit to + 12 V.

The fault-finding equipment allows operational faults which are not detected by the XR25 to be highlighted. A sensor check can be carried out for the following customer complaints:


- Excessive consumption.
- Irregular idle speed, hunting.
- Hesitation.
- Gases analysis not correct to specification.

The equipment check scenario assumes connection in parallel with the signal transmitted by the oxygen sensor. This signal is analysed at a constant engine speed (2500 rpm), when the mixture regulation conditions are joined (engine warm...).

## CONNECTION:

The 4-way sensor connector is located under the vehicle.

During normal operation, the signal is represented as a sinusoid.



The characteristic parameters of this signal are the maximum voltage, the minimum voltage and the period. Whatever the engine type, the correct values are:

- Maximum voltage > 600 mV.
- Minimum voltage < 200 mV.
- Gap (maximum voltage - minimum voltage) > 500 mV.
- Period < 1 second.

## EQUIPMENT REQUIRED

OPTIMA 5800 fault-finding equipment

**IGNITION CHECK USING THE FAULT-FINDING EQUIPMENT**

The OPTIMA 5800 fault-finding equipment allows the ignition to be checked under two conditions:

- **TEST ON STARTING:** if the vehicle will not start. When fault-finding using the XR25 is not possible, this option checks the presence and the quality of the ignition when the starter is operated.
- **ENGINE RUNNING TESTS:** These measurements are an addition to the XR25 in the event of customer complaints such as: hesitation, ignition misfiring, incorrect gases analysis, unstable idle speed...

Also, the equipment's measuring module allows the static ignition to be checked using two high voltage clips, the coils having two outlets (when one ignition order is given, two sparks occur simultaneously: one in the combustion chamber, the other in the exhaust cylinder). While these measurements are being taken, the two clips must be moved from one coil to the other.

Their power is controlled directly by the computer (the amplifier module is integral with the computer): the equipment is therefore connected at the inlet of the coils.

**CONNECTIONS:**

- **DZF engine:** Connection to the two coils (bloc located to the left of the rocker cover).

**MEASUREMENTS:**

The ignition is characterised by the following values:

*Engine running:*

- Duration of spark.
- Priming voltage (or ionisation voltage).
- Priming voltage during the exhaust phase (static ignition).

*Test on starting:*

- Ignition supply voltage.
- TDC signal sensor.
- Control signal (MPA).
- Duration of spark.
- Priming voltage (or ionisation voltage).
- Priming voltage during the exhaust phase (static ignition).

The equipment checks the consistency of the values obtained for each cylinder and compares the measurements with a database categorised by engine type.

## ESTABLISHING XR25/COMPUTER DIALOGUE

- Connect the XR25 to the diagnostics socket.
- Ignition on.
- Selector in position S8
- Enter **D13**

9.INJ

## COMPUTER IDENTIFICATION

Computer identification is not linked to the reading of a fault code but to direct reading of the computer part number. After entering into dialogue with the computer:

ENTER    **G70\***

7700

XXX

XXX

The part number then appears on the central display in three sequences.


Each sequence is displayed for approximately two seconds. The display is repeated twice. (For the number, refer to part number section 12).

## ERASING THE MEMORY (engine stopped, ignition on)

Following work on the injection system, the computer memory can be erased using the code GO\*\*. (Erasing stored fault codes in fault-finding mode D13, enter GO\*\* with the selector in position S8).

This operation will not erase the memory of any other equipment on the vehicle.

If the information obtained by the XR25 requires checking of the electrical continuity, connect the bornier **Sus 1228**.



(The **Sus 1228** is made up of a 55-way base integral with a printed circuit on which there are 55 copper plated surfaces numbered 1 to 55).

Using the wiring diagrams, the tracks which connect the components to be checked can be easily identified.

**IMPORTANT :**

- All of the checks , using the bornier **Sus 1228**, must be carried out with the battery disconnected.
- The bornier is designed to be used only with an ohmmeter. Under no circumstances must 12 volts be applied to the check points.

## TEST PROCEDURE

Connect the XR25, ignition off.

Switch on the ignition, enter into dialogue with the injection computer.

Make a note of which fault bargraph is illuminated or flashing.

Erase the computer memory.

Switch off the ignition.

### **1/ Carry out an XR25 test with the ignition on**

Switch off the ignition, connect the XR25 and switch on the ignition.

Enter into dialogue with the injection computer.

Process the illuminated fault bargraph.

### **2/ Carry out an XR25 test with the engine running or at starter speed**

Switch off the ignition, connect the XR25 and switch on the ignition.

Enter into dialogue with the injection computer.

Switch on the engine.

Process the illuminated fault bargraph.

### **3/ Carry out an XR25 test while driving**

Switch off the ignition, connect the XR25 and switch on the ignition.

Enter into dialogue with the injection computer.

Drive the vehicle.

Process the illuminated fault bargraph.

- NOTE :**
- If illumination of a fault bargraph can be reproduced, it must be processed as an illuminated bargraph even if it has started flashing.
  - If no fault bargraph has been illuminated, check the connectors of the faulty circuit.

FICHE N° 27 SIDE 1/2 WITH FAULT BARGRAPHS

N°27 1/2		S8		code :	D	1	3	read :	9nJ
1	<input type="checkbox"/> ILLUMINATED → <input type="checkbox"/> EXTINGUISHED →	FAULT TEST TURN CARD		CODE PRESENT <input type="checkbox"/>					
2	<input type="checkbox"/> COMPUTER			ENG. IMMOB. * 22 <input type="checkbox"/>					
3	<input type="checkbox"/> AIR TEMPERATURE			O2 SENSOR * 23 <input type="checkbox"/>					
4	<input type="checkbox"/> COOLANT TEMP			VEHICLE SPEED <input type="checkbox"/>					
5	<input type="checkbox"/> PRESSURE			FLYWHEEL SIGNAL * 25 <input type="checkbox"/>					
6	<input type="checkbox"/> * 06 PINKING			THROTTLE POSITION <input type="checkbox"/>					
7	<input type="checkbox"/> CAMSHAFT			FUEL TANK PRESSURE <input type="checkbox"/>					
8	<input type="checkbox"/> * 08 FUEL PUMP			BLOCKING * 28 <input type="checkbox"/>					
9	<input type="checkbox"/> * 09 ANTI-PERCOLATION			AIR PUMP * 29 <input type="checkbox"/>					
10	<input type="checkbox"/> * 10 O2 SENSOR OVERHEAT			BI MODE * 30 <input type="checkbox"/>					

## INJECTION (FAULTS)

Erase fault memory : G 0 \*\*  
Status check request : G01 \*

11	<input type="checkbox"/> * 11 INJECTOR CIRCUIT	CONNECTION A.T. → INJ <input type="checkbox"/>
12	<input type="checkbox"/> * 12 WARN. LAMP CIRC. DEF.	FUEL PUMP + INFO <input type="checkbox"/>
13	<input type="checkbox"/> SAVE DATA IN MEMORY	ADAC * 33 <input type="checkbox"/>
14	<input type="checkbox"/> * 14 IDLE SPEED REG. CIRC.	BLEED CANISTER CIRC. * 34 <input type="checkbox"/>
15	<input type="checkbox"/> * 15 CONNECTION INJ. → AC	EGR CIRCUIT * 35 <input type="checkbox"/>
16	<input type="checkbox"/> * 16 IGNITION COILS	COLD START INJECTORS * 36 <input type="checkbox"/>
17	<input type="checkbox"/> * 17 MIL WARN. LIGHT	
18		
19		
20	<input type="checkbox"/> * 20 COMPUTER CONFIGURATION	XR25 MEMORY <input type="checkbox"/> <input type="checkbox"/>

## ADDITIONAL CHECKS : # . .

01	PRESSURE	mb
02	Coolant temp.	°C
03	Air temp.	°C
04	Computer feed	V
05	O2 sensor	V
06	Engine speed	rpm
12	Idling RCO	%
13	Pinking signal	
14	Engine speed gap	rpm
15	Pinking correct.	
16	Atmos. pressure	mb
17	Throttle pot.	
18	Vehicle speed	km/h
21	Auto correct. of RCO idl. speed	%
23	Canister purge RCO	%
24	RCO EGR	%
30	Auto correct. clutch under high loads	
31	Auto correct. clutch under low loads	
35	Corr. richesse	
44	P. absorbed by AC compressor	W

End of test: G 13 \*

Part No : G 70 \*

Diagnosed faults :

Press V and 9

Return to diagnostic mode : D

16 ANG

FI21627-1

FICHE N° 27 SIDE 2/2 WITH STATUS BARGRAPHS

N°27 2/2		read : 100J	
1	EXTINGUISHED → STATUS TEST ILLUMINATED → TURN CARD	CODE PRESENT	
2	PG ← THROTTLE POSITIONS → PL	CONTROL MODES : G.. (IF ENGINE STOPPED)	
3	FLYWHEEL SIGNAL	ACTIVE ENG. IMMOB.	
4	PARK/NEUTRAL POSITION	+ APC COMPUTER	
5	TORQUE ADJUSTMENT	RELAY CONTROL LOCKING	
6	RICHNESS REGULATION	IDLING REGULATION	
7	FUEL PUMP CONTROL	BLEED CANISTER AUTHOR.	
8	ANTI-PERCOL. CTRL	ELEC. W/SCREEN REQUESTED	
9	SELECTION	ACCEL. IDLE SPEED	
10	REQUEST	AIR COND. COMPRESSION AUTHOR. OR PROHIBITED	
(WARNING : monitor bar graph 20 left)			
<b>INJECTION (STATUS)</b>			
Erase fault memory : G 0 ** Request fault test : G 02 *			
11	CAMSHAFT SIGNAL	BLEED CANISTER + ACTIVE SOL VALVES	
12	EGR SV CONTROL	MEMORISED FAULTS	
13	AIR PUMP CONTROL	POWER STEERING PRESSOSTAT	
14	BI-MODE INLET CTRL	COLD START INJECTORS	
15			
16			
17			
18			
19	Veh. with AT	COMPUTER CONFIGURATION	Veh. with man. g/box
20	FAULT PRESENT	XR25 MEMORY	0
01 Pressure mb 02 Coolant temp. °C 03 Air temp. °C 04 Computer feed V 05 O2 Sensor V 06 Engine speed rpm 12 Idling RCO % 13 Pinking signal 14 Eng. speed gap rpm 15 Pinking correct. g" 16 Atmos. pressure mb 17 Throttle pos. 18 Vehicle speed km/h 21 Auto. corr. RCO idle speed % 23 RCO bleed canister % 24 RCO EGR % 30 Auto. corr. clutch underhighbids 31 Auto. corr. of richness 35 Mixture regulation 44 P absorbed by W AC compressor			
End of test : G 13 *			
Part No : G 70 *			
Diagnosed faults : Press V and 9 Return to diagnostic mode : D			
16 ANG			

FI21627-2



### REPRESENTATION OF BARGRAPHS




Illuminates when dialogue is established with the computer. If it remains extinguished:

- the code does not exist,
- there is a line fault or a fault in the equipment or computer

### REPRESENTATION OF FAULTS (always on a coloured background)



When illuminated, this indicates a fault on the product being checked, the associated text defines the fault.




When extinguished, this indicates that no fault has been detected on the product being checked.

### REPRESENTATION OF STATUS (always on a white background)


With the engine stopped, ignition on, no action by the operator

The status bargraphs on the fiche are represented in the status in which they should be with the engine stopped, ignition on, no action by the operator

- If on the fiche, the bargraph is represented



the XR25 should display



- If on the fiche, the bargraph is represented



the XR25 should display




- If on the fiche, the bargraph is represented



the XR25 should display


either



or



### Engine running



Extinguished when the function or the condition specified on the fiche is no longer carried out.



Illuminated when the function or the condition specified on the fiche is carried out.

### FUNCTION V9

Fiche n° 27 side 1/2 and side 2/2 is a generic fiche used for several engine types.

The different engines do not use all of the bargraphs. For information regarding the bargraphs processed by the injection computer, press keys V and 9 simultaneously after establishing dialogue. The bargraphs processed will illuminate:

- permanently, in the case of fault bargraphs which cannot be stored or for status bargraphs,
- flashing, in the case of fault bargraphs which can be stored.

To return to fault-finding mode, press key D.

<div>1</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 1 extinguished</div> <div>Fiche n° 27 side 1/2</div> <div><u>XR25 CIRCUIT</u></div> <div>XR25 :        no connection, CO, CC TO EARTH, CC + 12</div>
--	---

<div>INSTRUCTIONS</div>	<div>For this fault-finding procedure, this bargraph should be illuminated.</div>
-------------------------	---

<div>Check:</div> <div><div>- the Injection fuses, Engine and Passenger Compartment,</div><div>- the connection between the XR25 and the diagnostic socket,</div><div>- the position of the selector (S8),</div><div>- the conformity of the cassette.</div></div> <div>Rectify if necessary.</div>	
<div>Check:</div> <div><div>- the presence of+ 12 V on track 6 and earth on track 2 of the diagnostic socket.</div><div>- the connection between the XR25 and the diagnostics socket</div></div> <div><div><div>Diagnostics socket</div><div>10   →  4</div><div>11   →  8</div></div><div><div>XR25 socket</div></div></div> <div>Rectify if necessary.</div>	
<div>Connect the bornier <b>Sus 1228</b> in place of the computer and check the insulation and continuity between tracks:</div> <div><div><div>Bornier</div><div>38   →  10</div><div>11   →  11</div><div>1   →  C5</div><div>40   →  C2</div><div>48   →  D2</div></div><div><div>Diagnostic socket</div><div>Diagnostic socket</div><div>Main relay</div><div>Main relay</div><div>Fuel pump relay</div></div></div> <div>Rectify.</div>	

<div>Check the presence of + 12 V on the track:</div> <div><div>C1   of the main relay</div><div>C3   of the main relay</div><div>D1   of the fuel pump relay.</div></div> <div>Change the relay(s) if necessary.</div>	
---	--

<div>AFTER REPAIR</div>	<div>Carry out a conformity check</div>
-------------------------	---

<div>2</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 2 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>COMPUTER CIRCUIT</div> <div>XR25 :      Computer not operational if left-hand bargraph 2 is illuminated</div>
--	--

INSTRUCTIONS	None
--------------	------

Computer not correct to specification or faulty.

Change the injection computer.

AFTER REPAIR	Carry out a conformity check
--------------	------------------------------

<div>2</div> <div><div></div><div></div></div>	Right-hand bargraph 2 illuminated		Fiche n° 27 side 1/2
	<u>ENGINE IMMOBILISER CIRCUIT</u>		
	XR25 :	*22 = 1dEF	CO, CC TO EARTH or CC +12 V LINE 37 OF THE COMPUTER
		*22 = 2 dEF	If the vehicle is fitted with an engine immobiliser, refer to the engine immobiliser fault-finding information

INSTRUCTIONS	<p>If the vehicle is not fitted with an engine immobiliser, right-hand bargraph 2 is illuminated and *22 = 2dEF.</p> <p>In this case, ignore right-hand bargraph 2.</p>
--------------	---

<p>Connect bornier <b>Sus 1228</b> in place of the computer and the check the insulation and continuity of the line:</p> <div><div>Bornier</div><div>37</div><div>→</div><div>9 of the infra-red transmitter</div></div> <p>Rectify if necessary.</p>	
If the fault persists, refer to "Engine immobiliser fault-finding"	

AFTER REPAIR	<p>Erase the computer memory using GO**.</p> <p>Carry out a conformity check</p>
--------------	--

<div>3</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 3 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>AIR TEMPERATURE SENSOR CIRCUIT</div> <div>XR25 :      #03 = -40      CO LINE 20 OR 46 ; CC + 5V LINE 20</div> <div>                 #03 = 119      CC TO EARTH LINE 20</div>
--	---

<div>INSTRUCTIONS</div>	<div>Refer to "Fault-finding - Help" for the resistance values.</div>
-------------------------	---

Check the resistance of the air temperature sensor.

<div>The resistance is not correct</div>	<div>Change the air temperature sensor.</div>
--	---

<div>The resistance is correct</div>	<div>Connect bornier <b>Sus 1228</b> in place of the computer and check the continuity and insulation of the electrical wiring between the tracks:</div> <div>1 sensor connector    46 bornier</div> <div>2 sensor connector    20 bornier</div>
	<div>If the electrical wiring is good, change the computer.</div>

<div>AFTER REPAIR</div>	<div>Erase the computer memory using GO**.</div> <div>Carry out a conformity check</div>
-------------------------	--

<div>3</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 3 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>OXYGEN SENSOR CIRCUIT</u></div> <div>XR25 :        None</div>
--	--

<div>INSTRUCTIONS</div>	<div>Right-hand bargraph 3 may illuminate with the engine running in the event of a fault.</div>
-------------------------	--

<div>Check the connection and condition of oxygen sensor connector.</div>
<div>With the engine running, check the presence of + 12V between tracks A and B on the oxygen sensor connector.</div>
<div>If there is no 12V supply, repair the sensor heating circuit electrical wiring.</div>
<div>With the ignition off, connect bornier Sus 1228 in place of the computer and check the continuity and insulation of line between track 17 of the bornier and track C of the connector.</div>
<div>If necessary, repair the electrical wiring.</div>
<div>The fault persists! Change the oxygen sensor.</div>
<div>The fault persists! Change the computer.</div>

<div>AFTER REPAIR</div>	<div>Erase the computer memory (engine cold) using GO**.</div> <div>Carry out a conformity check</div>
-------------------------	--

<div>4</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 4 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>COOLANT TEMPERATURE SENSOR CIRCUIT</div> <div>XR25 :<div>#02 = -40°C CC + 5V LINE 15 ; CO LINE 15 or 44</div><div>#02 = 119°C CC TO EARTH LINE 15</div></div>
--	--

INSTRUCTIONS	Refer to "Fault-finding - Help" for the resistance values.
--------------	--

Check the resistance of the coolant temperature sensor.

The resistance is not correct	Change the sensor.
-------------------------------	--------------------

The resistance is correct	<div>Connect bornier <b>Sus 1228</b> in place of the computer and check the continuity and insulation of the electrical wiring between the tracks:<div>1 coolant temperature sensor44 bornier</div><div>2 coolant temperature sensor15 bornier</div></div> <div>Repair if necessary.</div> <div>The fault persists! Change the computer.</div>
---------------------------	--

AFTER REPAIR	Erase the computer memory using GO**. Carry out a conformity check
--------------	---

<div>4</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 4 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>VEHICLE SPEED SENSOR CIRCUIT</u></div> <div>XR25 : CO or CC LINE 12</div>
--	--


<b>INSTRUCTIONS</b>	Refer to "Fault-finding - Help" for the resistance values.
---------------------	--

Carry out a road test and check the speed on the speedometer.
If the speed is zero, repair the wiring between track 12 of the computer and B1 of the sensor.
With the ignition on, check the connection of the speed sensor and its supply: + 12V on track A earth on track B2
Rectify if necessary.
The fault persists! Change the speed sensor.

<b>AFTER REPAIR</b>	Erase the computer memory using GO** Carry out a road test Carry out a conformity check
---------------------	---



5



Left-hand bargraph 5 illuminated

Fiche n° 27 side 1/2

ABSOLUTE PRESSURE SENSOR CIRCUIT  
XR25 :      #01 = 103 mb      CO LINE 16 or 45    CC - LINE 16  
                 #01 ≥ 1020 mb    CC+ LINE 12 or 16

INSTRUCTIONS

Left-hand bargraph 5 may illuminate with the engine running in the event of a fault.  
Refer to "Fault-finding - Help" for the resistance values.

If the vehicle has idling problems, check that the line between track 12 of the computer and track B1 of the speed sensor is insulated from 12 V.

Check whether the pressure sensor is electrically and pneumatically connected and check the conformity of the pipe. It must not be clogged, punctured...

With the ignition on, check the presence of 5V between track C and the earth at track A.

5V is not present between track C and track A

Connect the bornier **Sus 1228** in place of the computer and check the insulation and continuity between the tracks:  
A sensor connector    44 bornier  
C sensor connector    45 bornier

Rectify if necessary.

5V is present between track C and track A

With the ignition on, check the return voltage on track B of the sensor.  
**Note :**      To take this reading, a vacuum pump could be used to check the variation in the voltage.

The voltage does not vary

Change the sensor.

The voltage varies

Connect bornier **Sus 1228** in place of the computer and check the insulation and continuity between track B of the sensor and track 16 of the bornier.

Rectify if necessary.

The fault persists! Change the computer.

AFTER REPAIR

Erase the computer memory using GO\*\*  
Carry out a conformity check

<div>5</div> <div><div></div><div></div></div>	<b>Right-hand bargraph 5 illuminated or flashing</b> <span>Fiche n° 27 side 1/2</span>
	<u>FLYWHEEL SIGNAL CIRCUIT</u> <b>XR25 :</b> *25 = dEF      FAULT STORED, to be confirmed *25 = C00      CC - LINE 33 / 34 or 45 *25 = In      INVERSION OF SENSOR WIRES

<b>INSTRUCTIONS</b>	If right-hand bargraph 5 is flashing, erase the computer memory using GO**. At starter speed for 10 seconds or with the engine running for 10 seconds minimum, if right-hand bargraph 5 is illuminated or flashing, fault-finding can be carried out. Refer to "Fault-finding - Help" for the resistance values.
---------------------	--


Disconnect the sensor connector and check the resistance of the sensor between terminals A and B.
---

The resistance is not correct	Change the sensor.
-------------------------------	--------------------

The resistance is correct	Connect the bornier <b>Sus 1228</b> in place of the computer and check the continuity and insulation of the wiring between the tracks: <div><div>Flywheel sensor signal</div><div>Flywheel sensor signal</div><div>Throttle position sensor</div><div>Pressure sensor</div><div>Earth</div><div>Earth</div><div>Earth</div></div> <div><div>A</div><div>B</div><div>B</div><div>C</div><div>earth</div><div>earth</div><div>earth</div></div> <div><div>→</div><div>→</div><div>→</div><div>→</div><div>→</div><div>→</div><div>→</div></div> <div><div>34</div><div>33</div><div>45</div><div>45</div><div>2</div><div>3</div><div>18</div></div> <div><div>bornier</div><div>bornier</div><div>bornier</div><div>bornier</div><div>bornier</div><div>bornier</div><div>bornier</div></div>
---------------------------	---

<b>AFTER REPAIR</b>	Erase the computer memory using GO** Carry out a conformity check
---------------------	--

Fault-finding - Interpretation of XR25 bargraphs

<div>6</div> <div></div>	<div>Left-hand bargraph 6 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>PINKING SENSOR CIRCUIT</u></div> <div>XR25 : CC TO EARTH LINE 54 or CO LINE 54 and 44</div>
--	---

<b>INSTRUCTIONS</b>	Left-hand bargraph 6 may illuminate in the event of a fault with the engine running at an engine speed of 2500 rpm.
---------------------	---

Check the connectors of the faulty sensor.
Rectify if necessary.
Connect the bornier <b>Sus 1228</b> in place of the computer and check the insulation and continuity of the electrical wiring between the tracks: 1 sensor 44 bornier 2 sensor 54 bornier
Rectify if necessary.
The fault persists! Change the pinking sensor.

<b>AFTER REPAIR</b>	Erase the computer memory using GO** Carry out a conformity check
---------------------	--

Fault-finding - Interpretation of XR25 bargraphs

<div>6</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 6 illuminated or flashing</div> <div>Fiche n° 27 side 1/2</div> <div><u>THROTTLE POTENTIOMETER CIRCUIT</u></div> <div>XR25 :<div>CO LINE 19</div><div>CC- LINE 19</div><div>CC+ LINE 19 or 18 or 28 or 29</div></div>
--	--

<div>INSTRUCTIONS</div>	<div>If right-hand bargraph 6 is flashing, erase the computer memory using GO**.</div> <div>With the ignition on, at starter speed or with the engine running, if right-hand bargraph 6 is flashing or illuminated, fault-finding can be carried out.</div>
-------------------------	---

<div>Check the resistance of the throttle potentiometer between tracks A and B.</div>
<div>Check the variation of the throttle potentiometer between tracks B and C.</div>

<div>R between A and B is not correct or B-C does not vary</div>	<div>Change the throttle potentiometer.</div>
--	---

<div>R between A and B is correct and B-C varies.</div>	<div>Connect the bornier <b>Sus 1228</b> in place of the computer and check the insulation and continuity between the tracks:</div> <div><div>A potentiometer</div><div>B potentiometer</div><div>C potentiometer</div><div>Earth</div><div>1 coil</div><div>2 coil</div></div> <div><div>→ 46 bornier</div><div>→ 45 bornier</div><div>→ 19 bornier</div><div>→ 18 bornier</div><div>→ 28 bornier</div><div>→ 29 bornier</div></div>
	<div>Check the resistance of the coil.</div> <div>If the coil is not good, it must be changed before the computer is changed.</div>
	<div>Change the computer.</div>

<div>AFTER REPAIR</div>	<div>Erase the computer memory using GO**</div> <div>Carry out a conformity check</div>
-------------------------	---

<div>8</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 8 illuminated</div> <div>FICHE n° 27 side 1/2</div> <div>FUEL PUMP RELAY CONTROL CIRCUIT</div> <div>XR25 : CC + 12 V LINE 48</div>
--	--

INSTRUCTIONS	Refer to "Fault-finding - Help" for the resistance values.
--------------	--

Check the operation of the impact sensor.
With the fuel pump relay in place, check the presence of + 12V during the timing phase between tracks 1 and 2 when the ignition is switched on.

+12 V is present between 1 and 2	Change the relay.
+1 2 V is not present between 1 and 2	With the ignition on, check the presence of + 12 V on track 1 of the fuel pump relay.
+12V is not present on track 1	Check the line of track 1 as far as the fuse.
+ 12V is present on track 1	Connect the bornier <b>Sus 1228</b> in place of the computer and check the continuity and insulation between track 2 of the relay and track 48 of the bornier.
	Rectify if necessary.
The fault persists! Change the injection computer.	

AFTER REPAIR	Erase the computer memory using GO** Carry out a conformity check
--------------	--

<div>11</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 11 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>INJECTION CIRCUIT</div> <div>XR25 :<div><div>*11 = XX.CO</div><div>CO or CC - LINE 4 or 30</div></div><div><div>*11 = XX.CC</div><div>CC + LINE 4 or 30</div></div><div><div>*11 = Def</div><div>FAULT STORED</div></div></div>
---	---

INSTRUCTIONS	X represents the number of cylinder. Refer to "Fault-finding - Help" for the resistance values.
--------------	--

Check the resistance of the injectors concerned.	
The resistance is not correct	Change the faulty injector(s).
The resistance is correct	Connect the bornier <b>MS 1048</b> in place of the computer and check the continuity and insulation between track 2 of the injector connectors and tracks 4 and 30.
	Repair the wiring if necessary.
	During the timing phase, check the presence of 12 V on track 1 of the injector concerned.
	Repair the wiring if necessary.
The fault persists! Change the computer.	

AFTER REPAIR	Erase the computer memory using GO** Carry out a conformity check
--------------	--

<div>12</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 12 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>FAULT WARNING LIGHT CIRCUIT</u></div> <div><b>XR25 :</b>      CC - or CC + LINE 43</div>
---	---

<i>INSTRUCTIONS</i>	None
---------------------	------

<div>Check the insulation and continuity of the line:</div> <div>computer    43    —————&gt;    warning light fuse</div>
The fault persists! Change the computer.

<i>AFTER REPAIR</i>	<div>Erase the computer memory using GO**</div> <div>Carry out a conformity check</div>
---------------------	---

<div>13</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 13 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>STORED MEMORY CIRCUIT</div> <div>XR25 :      Injection computer supply cut off.</div>
---	---

<div>INSTRUCTIONS</div>	<div>Has the battery has been removed?</div> <div>Left-hand bargraph 13 may illuminate after repair work, ignore it.</div>
-------------------------	--

<div>Check:</div> <div><div>- the battery charge,</div><div>- the injection fuses,</div><div>- the battery wiring.</div><div>- the computer supply.</div></div> <div>Rectify</div>
<div>Switch off the ignition for 2 minutes.</div> <div>Switch on the ignition.</div> <div>The fault bargraph should be extinguished.</div>
<div>The fault persists! Change the computer.</div>

<div>AFTER REPAIR</div>	<div>Erase the computer memory using GO**</div> <div>Carry out a conformity check</div>
-----------------------------	---



Fault-finding - Interpretation of XR25 bargraphs


<div>1</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 1 extinguished</div> <div>Fiche n° 27 side 1/2</div> <div><u>XR25 CIRCUIT</u></div> <div>XR25 :        no connection, CO, CC TO EARTH, CC + 12</div>
--	---

<div>INSTRUCTIONS</div>	<div>For this fault-finding procedure, this bargraph should be illuminated.</div>
-------------------------	---

<div>Check:</div> <div><div>- the Injection fuses, Engine and Passenger compartment,</div><div>- the connection between the XR25 and the diagnostic socket,</div><div>- the position of the selector (S8),</div><div>- the conformity of the cassette..</div></div> <div>Rectify if necessary.</div>	
<div>Check:</div> <div><div>- the presence of+ 12 V on track 6 and earth on track 2 of the diagnostic socket.</div><div>- the connection between the XR25 and the diagnostic socket.</div></div> <div><div><div>Diagnostics socket</div><div>10    →    4</div><div>11    →    8</div></div><div><div>XR25 socket</div></div></div> <div>Rectify if necessary.</div>	
<div>Connect the bornier <b>Sus 1228</b> in place of the computer and check the insulation and continuity between the tracks:</div> <div><div><div>Bornier</div><div>38    →    10</div><div>11    →    11</div><div>1    →    C5</div><div>40    →    C2</div><div>48    →    D2</div></div><div><div>Diagnostic socket</div><div>Diagnostic socket</div><div>Main relay</div><div>Main relay</div><div>Fuel pump relay</div></div></div> <div>Rectify.</div>	

<div>Check the presence of + 12 V on track:</div> <div><div>C1    of the main relay</div><div>C3    of the main relay</div><div>D1    of the fuel pump relay.</div></div> <div>Change the relay(s) if necessary.</div>	
--	--

<div>AFTER REPAIR</div>	<div>Carry out a conformity check</div>
-------------------------	---

<div>14</div> <div></div>	<div>Left-hand bargraph 14 illuminated or flashing</div> <div><u>IDLE REGULATION VALVE CIRCUIT</u></div> <div>XR25 : CO LINE 8 or 9 or 35 or 36 CC - LINE 8 or 9 or 35 or 36 CC + LINE 35 or 36</div>	Fiche n° 27 side 1/2
---	---	----------------------

<b>INSTRUCTIONS</b>	<p>Left-hand bargraph 14 may illuminate with the engine running in the event of a fault.</p> <p>Refer to "Fault-finding - Help" for the resistance values.</p>
---------------------	--

Check the resistance of the stepping motor coils between tracks A-D and B-C.
If the resistance is not correct, change the stepping motor.
Connect the bornier <b>Sus 1228</b> in place of the computer and check the insulation and continuity of the line: <div><div>Bornier</div><div>8 9 35 36</div><div><div>→ → → →</div><div>D stepping motor B A C</div></div></div>
The fault persists! Change the computer.

<b>AFTER REPAIR</b>	<p>Erase the computer memory using GO**</p> <p>Carry out a conformity check</p>
---------------------	---

14

Right-hand bargraph 14 illuminated

Fiche n° 27 side 1/2

CANISTER BLEED CIRCUIT

XR25 : CO or CC - or CC + LINE 42 and #23 = 00

INSTRUCTIONS

Refer to "Fault-finding - Help" for the resistance values.

Check the conformity of the pipes, rectify if necessary.

Check the resistance of the canister bleed valve between track A and B.

The resistance is not correct

Change the canister bleed valve.

The resistance is correct

With the engine running at idle, check the presence of + 12 V on track A of the canister bleed valve.

+ 12 V is not present on track A

Repair the electrical wiring between track A of the canister bleed valve and track 5 of the fuel pump relay.

+ 12 V is present on track A

Connect the bornier **Sus 1228** in place of the computer and check the insulation and continuity of the electrical wiring between track B of the canister bleed valve and track 42 of the bornier.

Rectify if necessary.

The fault persists! Change the injection computer.

AFTER REPAIR

Erase the computer memory using GO\*\*  
Carry out a conformity check

<div>15</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 15 illuminated</div> <div>AC INJECTION CONNECTION CIRCUIT</div> <div>Fiche n° 27 side 1/2</div> <div>XR25 : CC + 12 V on line 51 of the computer</div>
---	--

INSTRUCTIONS	Check that the vehicle is fitted with air conditioning. If there is no air conditioning fitted, study the other prioritised bargraphs
--------------	---

<div>Connect the bornier <b>Sus 1228</b> in place of the computer and check the insulation and continuity of the line:</div> <div><div>Bornier</div><div>51</div><div>→</div><div>A5</div><div>AC control panel</div></div> <div>Rectify if necessary.</div>	<div>If the fault persists, refer to the air conditioning fault-finding information.</div>
--	--

AFTER REPAIR	Erase the computer memory using GO** Carry out a conformity check
--------------	--

<div>16</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 16 illuminated</div> <div>Fiche n° 27 side 1/2</div> <div>IGNITION COIL CIRCUIT</div> <div>XR25 :      *16 = 1.4 CO      CO / CC TO EARTH LINE 28</div> <div>                 *16 = 2.3 CO      CO / CC TO EARTH LINE 29</div>
---	--

INSTRUCTIONS	Refer to "Fault-finding - Help" for the resistance values.
--------------	--

Check the resistance of the coil.	
The resistance is not correct	Change the coil.
The resistance is correct	Connect the bornier <b>Sus 1228</b> in place of the computer and check the insulation and continuity of the line: bornier 28 —————> 1 coil bornier 29 —————> 2 coil Check the presence of + 12 V on track 3 of the coil and check the insulation and continuity of line 4 of the coil.
	Repair the faulty line.
The fault persists! Change the computer.	

AFTER REPAIR	Erase the computer memory using GO** Carry out a conformity check
--------------	--

<div>2</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 2, right-hand bargraph 2, incorrect illumination</div> <div>THROTTLE POSITION CIRCUIT</div> <div>XR25 :<div>Left-hand bargraph 2 illuminated at full load</div><div>Right-hand bargraph 2 illuminated at no load</div><div>Left-hand bargraph 2 and right-hand bargraph 2 extinguished at an intermediate position.</div></div>	<div>Fiche n° 27 side 2/2</div>
--	---	---------------------------------

<div>INSTRUCTIONS</div>	<div>No fault bargraph should be illuminated.</div>
-------------------------	---

<div>If not fault bargraph is illuminated, the problem is not electrical. Check the mechanics of the accelerator circuit (cable, accelerator pedal,...).</div>
--

<div>AFTER REPAIR</div>	<div>Carry out a conformity check</div>
-------------------------	---

<div>3</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 3, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>FLYWHEEL SIGNAL CIRCUIT</u></div> <div>XR25 :      Left-hand bargraph 3 illuminated with the engine running</div>
--	---

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>3</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 3, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>ENGINE IMMOBILISER CIRCUIT</u></div> <div>XR25 :      Left-hand bargraph 3 illuminated, engine immobiliser active</div>
--	--


<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>4</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 4, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>+ AFTER IGNITION CIRCUIT</u></div> <div>XR25 :      Right-hand bargraph 4 illuminated at+ after ignition</div>
--	---

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>AFTER REPAIR</div>	<div>No action</div>
-----------------------------	----------------------

Fault-finding - Interpretation of XR25 bargraphs

<div>4</div> 	<div>Left-hand bargraph 4, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div>PARK/NEUTRAL POSITION CIRCUIT</div> <div>XR25 :        Illuminated in the Park/Neutral position</div>
---	--

<div>INSTRUCTIONS</div>	<div>Only with automatic gearbox.</div> <div>No fault bargraph should be illuminated.</div>
-------------------------	---

<div>XR25 at voltmeter <div>V</div> and Vin.</div> <div>Connect a wire to Vin and track 7 of the injection computer.</div> <div>With the ignition on, engage the selector lever in position P/N and then disengage it. The voltage should change from 0 V to 5 V .</div>
<div>If the voltages are correct, change the injection computer.</div>
<div>If the voltages are not 0 V / 5 V, check the insulation and continuity of the line:</div> <div>Injection computer        7   —————&gt;   Automatic transmission computer</div> <div>Rectify if necessary.</div>
<div>If the fault persists, refer to the automatic transmission fault-finding information.</div>

<div>AFTER REPAIR</div>	<div>Carry out a continuity check</div>
-------------------------	---



<div>5</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 5, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>TORQUE DAMPING CIRCUIT</u></div> <div>XR25 :      Illuminated each time the automatic transmission gear is changed</div>
--	--

<div>INSTRUCTIONS</div>	<div>Only with automatic gearbox.</div> <div>Left-hand status bargraph 4 illuminates correctly.</div> <div>No fault bargraph should be illuminated.</div>
-------------------------	---

As left-hand status bargraph 4 illuminates correctly, the injection computer is no longer implicated.

Refer to the automatic transmission fault-finding information.

<div>AFTER REPAIR</div>	<div>Carry out the automatic transmission fault-finding procedure if left-hand status bargraph 4 illuminates correctly.</div>
-----------------------------	---

Fault-finding - Interpretation of XR25 bargraphs

<div>5</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 5, incorrect illumination<div>Fiche n° 27 side 2/2</div></div> <div><u>LOCKING RELAY CIRCUIT</u></div> <div>XR25 :      Right-hand bargraph 5 illuminated if the locking relay is controlled</div>
--	---

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>6</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 6, incorrect illumination<div>Fiche n° 27 side 2/2</div></div> <div><u>MIXTURE REGULATION CIRCUIT</u></div> <div>XR25 :      Left-hand bargraph 6 illuminated when the mixture is regulated (engine running)</div>
--	--

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>AFTER REPAIR</div>	<div>No action</div>
-------------------------	----------------------

<div>6</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 6, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>IDLE SPEED REGULATION CIRCUIT</u></div> <div><div>XR25 :</div><div>Right-hand bargraph 6 illuminated with engine running under no load</div></div>
--	---

<div>INSTRUCTIONS</div>	<div>No fault bargraph should be illuminated.</div>
-------------------------	---

<div>Check the insulation of lines 8 and 9 of the injection computer.</div>
<div>If the fault persists and no other bargraph is to be processed, change the computer.</div>

<div>AFTER REPAIR</div>	<div>No action</div>
-------------------------	----------------------

<div>7</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 7, incorrect illumination<div>Fiche n° 27 side 2/2</div></div> <div><u>FUEL PUMP CONTROL CIRCUIT</u></div> <div>XR25 :      Left-hand bargraph 7 illuminated with the ignition on during the timing phase and with the engine running</div>
--	---

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>8</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 8, incorrect illumination<div>Fiche n° 27 side 2/2</div></div> <div><u>ANTIPERCOLATION CONTROL CIRCUIT</u></div> <div>XR25 :      Left-hand bargraph 8 illuminated when the antipercolation function is active</div>
--	--

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>AFTER REPAIR</div>	<div>No action</div>
-------------------------	----------------------

Fault-finding - Interpretation of XR25 bargraphs

<div>9</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 9, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>ACCELERATED IDLE CIRCUIT</u></div> <div>XR25 :        This bargraph should not be illuminated</div>
--	--

<div>INSTRUCTIONS</div>	<div>No fault bargraph should be illuminated</div>
-------------------------	--

Check the insulation of track 5 of the computer.  
If the fault persists, change the computer.

<div>AFTER REPAIR</div>	<div>No action</div>
-----------------------------	----------------------

<div>9</div> <div><div></div><div></div></div> <div>10</div> <div><div></div><div></div></div>	<div>Left-hand bargraph 9, left-hand bargraph 10, right-hand bargraph 10, incorrect illumination</div> <div>AC CIRCUIT</div> <div>XR25 :      Left-hand 9      illuminated if AC selected                  Left-hand 10      illuminated if AC requested                  Right-hand 10      illuminated if AC authorised</div>	Fiche n° 27 side 2/2
--	---	----------------------

INSTRUCTIONS	Check that the vehicle is fitted with air conditioning. No fault bargraph should be illuminated.
--------------	---

Connect bornier <b>Sus 1228</b> in place of the computer and check the insulation and continuity between the tracks:.			
Injection computer	5	→	B4 of the 13-way connector    AC control panel
	51	→	A1 of the 13-way connector    AC control panel
Rectify if necessary.			
If the fault persists, refer to the air conditioning fault-finding information.			

AFTER REPAIR	Carry out a conformity check
--------------	------------------------------

Fault-finding - Interpretation of XR25 bargraphs

<div>11</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 11, incorrect illumination<div>Fiche n° 27 side 2/2</div></div> <div><u>CANISTER BLEED CIRCUIT ACTIVE</u></div> <div>XR25 :      Right-hand bargraph 11 illuminated when the canister bleed is active</div>
---	--

<div>INSTRUCTIONS</div>	<div>Covered in the fault bargraphs.</div>
-------------------------	--

<div>12</div> <div><div></div><div></div></div>	<div>Right-hand bargraph 12 illuminated or extinguished<div>Fiche n° 27 side 2/2</div></div> <div><u>ERASING MEMORISED FAULTS</u></div> <div>XR25 :      This bargraph is illuminated when the faults have been erased.</div>
---	---

<div>INSTRUCTIONS</div>	<div>None.</div>
-------------------------	------------------

<div>AFTER REPAIR</div>	<div>No action</div>
-------------------------	----------------------

## Fault-finding - Customer complaints not using OPTIMA

### INSTRUCTIONS

Only refer to these customer complaints following a full check using the XR25  
Refer to "Fault-finding - Help" for the resistance values.

#### STARTING PROBLEMS

Does not start	CHART 1
Starts but stalls	CHART 2
Starting takes too long	CHART 3

#### IDLE SPEED PROBLEMS

Too high	CHART 4
Too low	CHART 5
Engine speed unstable	CHART 6
Hunting	CHART 7

#### HANDLING

Lack of performance	CHART 8
Flat spots and hesitation	CHART 9

#### FUMES - POLLUTION

CO and/or HC level too high	CHART 10
-----------------------------	----------

#### HIGH FUEL CONSUMPTION

CHART 11

#### ENGINE NOISE

Pinking	CHART 12
---------	----------

#### FAULT WARNING LIGHT PROBLEMS

Carry out the left-hand  
bargraph 12  
illuminated fault-  
finding procedure



The procedure which does not use the OPTIMA is not suitable as an adequate quality criteria.  
Follow the procedure using the OPTIMA to obtain this quality criteria.



## Fault-finding - Chart not using OPTIMA

## CHART 1

## STARTING PROBLEMS

Does not start

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Check the injection fuses in the passenger compartment fuse box and in the engine compartment fuse box.

Check the continuity of the line:

- 2 of the computer
- 3 of the computer
- 33 of the computer
- 34 of the computer

Rectify if necessary.

Does the customer complaint persist?

no

End of fault-finding

yes

Can the fuel pump be heard when the ignition is switched on?

yes

Refer to Chart 1A

no

Carry out the fuel pump relay control procedure and check whether the relay makes a noise (several knocks).

Is the relay good?

no

Change the relay.

yes

Check the presence of 12 V on track 3 of the relay. Rectify if necessary. If the customer complaint persists

no

Change the relay.

yes


During the timing phase, check the presence of 12 V on track 5 of the relay. Is 12 V present?

AFTER  
REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

Fault-finding - Chart not using OPTIMA

CHART 1 CONT	
-----------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--

## Fault-finding - Chart not using OPTIMA

## CHART 1A

## STARTING PROBLEMS

Does not start

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Connect the fault-finding equipment and check the presence of a High Voltage on the spark plug wires when the starter is operated.  
Is there a High Voltage?

yes →

Check the flow of fuel and the fuel pressure (refer to vehicle Workshop Repair Manual).  
Repair the fuel circuit if necessary (pump, filter, pipes, regulator, injectors...).  
If the customer complaint persists

no ↓

Check the high voltage circuit.  
Rectify if necessary.  
If the customer complaint persists

It is an engine problem,  
the injection system is no longer implicated.

With the ignition on, check the presence of + 12 V on track 2 of the coils.  
Is + 12 V present?

no →

Check the continuity of the electrical wiring between track 2 (coils) and the + after ignition fuse in the engine connection unit.  
Rectify.

yes ↓

With the ignition on,  
check the resistance of the coil.  
Is it correct?

no →

Change the faulty coil(s).

yes ↓


Connect the bornier **Sus 1228** in place of the computer and check the insulation and continuity between the tracks:  
1 / coil      28 / bornier  
2 / coil      29 / bornier  
Rectify if necessary.  
If the customer complaint persists

Change the injection computer.

AFTER  
REPAIR


Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 2	STARTING PROBLEMS The engine starts but stalls
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--


<b>CHART 3</b>	<b>STARTING PROBLEMS</b> Starting takes too long
<b>INSTRUCTIONS</b>	Only refer to this customer complaint following a full check using the XR25



<b>AFTER REPAIR</b>	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-------------------------	--


Fault-finding - Chart not using OPTIMA

CHART 4	IDLE SPEED PROBLEMS Idle speed too high
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

<b>CHART 5</b>	<b>IDLE SPEED PROBLEMS</b> Idle speed too low
<b>INSTRUCTIONS</b>	Only refer to this customer complaint following a full check using the XR25



<b>AFTER REPAIR</b>	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-------------------------	--

## Fault-finding - Chart not using OPTIMA


## CHART 6

## IDLE SPEED PROBLEMS

Engine speed unstable

## INSTRUCTIONS


Only refer to this customer complaint following a full check using the XR25

AFTER  
REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check




CHART 6 CONT	
-----------------	--



<b>AFTER REPAIR</b>	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
---------------------	--

Fault-finding - Chart not using OPTIMA

CHART 7	IDLE SPEED PROBLEMS Hunting
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--


## Fault-finding - Chart not using OPTIMA

## CHART 8

HANDLING  
Lack of performance

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

AFTER  
REPAIRCheck the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check


## Fault-finding - Chart not using OPTIMA

## CHART 9

HANDLING  
Flat spots and hesitation


## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

AFTER  
REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 9  
CONT



<b>AFTER REPAIR</b>	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
---------------------	--

## Fault-finding - Chart not using OPTIMA

## CHART 10

FUMES - POLLUTION  
CO and/or HC level too high

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Using the XR25, check #05 and #35.  
Check, refer to the Workshop Repair Manual.  
Are the values correct?

yes

Check the High Voltage circuit  
(spark plugs, spark plug wires).  
Rectify if necessary.  
If the customer complaint persists

Check the air supply,  
the air filter, the pipes...  
Does the customer complaint persist after  
rectification?

yes

Check the conformity of the gauge and the  
condition of the absolute pressure sensor  
pipe.  
Rectify if necessary.  
If the customer complaint persists

Check the sealing of the connectors  
(O-rings in particular).  
Rectify if necessary.  
Does the customer complaint persist?

yes

A

no

Carry out the lead detection test  
(refer to the Workshop Repair Manual).  
Is there lead present?

yes

no

B

Check the type of fuel used.  
If the customer has used leaded petrol, the  
vehicle must consume several full tanks of  
unleaded petrol before the catalytic  
converter and the oxygen sensor are  
changed.

no

End of fault-finding.

no

End of fault-finding.

AFTER  
REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

Fault-finding - Chart not using OPTIMA

CHART 10 CONT	
------------------	--

A

Check the fuel return pressure and flow (refer to vehicle Workshop Repair Manual). Rectify or change the faulty parts (fuel pump, pressure regulator, pipes). If the customer complaint persists

Ask the customer whether there have been any ignition or starting problems. Was there a problem?

yes

Change the catalytic converter.

no

It is an engine problem and the injection system is no longer implicated.

B

Check the oxygen sensor heating (+ 12 volts between A and B). Is it good?

no

Repair the electrical circuit.


yes

Check:

- Catalytic converter (melted, clogged, ...).
- Oxygen sensor (contaminated, heating faulty, ...).
- Air leak upstream of the oxygen sensor.
- Sealing of the exhaust line.
- Type o fuel used.
- Ignition (spark plugs, wires, distributor)
- General condition of the engine (timing, ...).

AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--


CHART 11	HIGH FUEL CONSUMPTION
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--




CHART 11 CONT	
------------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--

CHART 12	ENGINE NOISE Pinking
----------	-------------------------

INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25
--------------	---



AFTER {REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
------------------	--

INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25 Refer to "Fault-finding - Help" for the resistance values
--------------	--

STARTING PROBLEMS

Does not start	CHART 1
Starts but stalls	CHART 2
Starting takes too long	CHART 3

IDLE SPEED PROBLEMS

Too high	CHART 4
Too low	CHART 5
Engine speed unstable	CHART 6
Hunting	CHART 7

HANDLING

Lack of performance	CHART 8
Flat spots and hesitation	CHART 9

FUMES - POLLUTION

Gases analysis incorrect	CHART 10
Oxygen sensor check	CHART 11

HIGH FUEL CONSUMPTION

CHART 12

ENGINE NOISE


Pinking	CHART 13
---------	----------

FAULT WARNING LIGHT PROBLEMS

Carry out the left-hand  
bargraph 12  
illuminated fault-  
finding procedure


CHART 1	STARTING PROBLEMS Does not start
---------	-------------------------------------

INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25
--------------	---



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

CHART 1 CONT	
-----------------	--




AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

Fault-finding - Chart using OPTIMA


CHART 1A	STARTING PROBLEMS Does not start
----------	-------------------------------------

INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25
--------------	---



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--


CHART 2	STARTING PROBLEMS The engine starts but stalls
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

CHART 3	STARTING PROBLEMS Starting takes too long
---------	--


INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25
--------------	---



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--




CHART 4	IDLE SPEED PROBLEMS Idle speed too high
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

CHART 5	IDLE SPEED PROBLEMS Idle speed too low
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out conformity check
--------------	--

## Fault-finding - Chart using OPTIMA

### CHART 6

### IDLE SPEED PROBLEMS Engine speed unstable

#### INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Analyse the gases.  
(refer to Chart 10 - fumes/pollution).  
If the customer complaint persists

Connect the OPTIMA 5800 fault-finding  
equipment and carry out an ignition test with  
the engine running.  
Does the equipment detect a fault?

yes

Follow the instructions.

no

Check the operation of the oxygen sensor  
(refer to Chart 11 - fumes/pollution).  
If the customer complaint persists

With the engine at idle speed, check the  
consistency of #01 (the value should be less  
than 500 mbars). Is the value correct?

no

Check the absolute pressure sensor  
and its harness. Rectify,  
change the sensor if necessary.

yes


Check the flow of fuel and the fuel pressure  
(refer to vehicle Workshop Repair  
Manual). Repair the fuel circuit if necessary  
(pump, filter, pipes,  
regulator, injectors,...).  
If the customer complaint persists



#### AFTER REPAIR


Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 6 CONT	
-----------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity test
-----------------	---

CHART 7	IDLE SPEED PROBLEMS Hunting
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

## Fault-finding - Chart using OPTIMA

## CHART 8

HANDLING  
Lack of performance

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Check whether the throttle opens fully  
(full load bargraph illuminated).  
Check the setting of the accelerator control.  
Rectify if necessary.  
If the customer complaint persists

Check the air filter: dirt, deformation.  
Rectify if necessary.  
If the customer complaint persists

Connect the OPTIMA 5800 fault-finding  
equipment and carry out an ignition test with  
the engine running.  
Does the equipment detect a fault?

yes

Follow the instructions.

no

Analyse the gases  
(refer to Chart 10 - fumes/pollution).  
If the customer complaint persists

Connect the OPTIMA 5800 fault-finding  
equipment and carry out an engine  
compression test.  
Are the compressions normal?

no


It is an engine problem.

yes

AFTER  
REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 8 SUITE	
------------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--







CHART 9 CONT	
-----------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--

## Fault-finding - Chart using OPTIMA

## CHART 10

FUMES/POLLUTION  
Analysis of gases incorrect

## INSTRUCTIONS

Only refer to this customer complaint following a full check using the XR25

Connect the OPTIMA 5800 fault-finding equipment and connect it to a 4 gas analyser, type 4040, 5040 or AGM 1500.  
Carry out an anti-pollution/  
gases analysis test.

Does the equipment detect a fault?

no

End of fault-finding of Chart 10  
NOTE: a correct gases analysis indicates  
correct operation  
of the catalytic converter.

yes

Is the CO level too high (CO > 0.5 at idle  
speed or CO > 0.3 at 2500 rpm)?

yes

Check the oxygen sensor  
(refer to Chart 11 -fumes/pollution).  
If the customer complaint persists

no

Check whether it is an engine problem using  
the compressions test  
(OPTIMA 5800 fault-finding equipment).


Check the catalytic converter (efficiency,  
melting, presence of lead, ...), the air supply  
(filter, manifold, ...), and the condition of the  
engine (abnormal oil consumption).

A

AFTER  
REPAIR


Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 10 CONT 1	
--------------------	--




AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

## Fault-finding - Chart using OPTIMA

CHART 10  
CONT 2**AFTER  
REPAIR**

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check

CHART 10 CONT 3	
--------------------	--




AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--

**CHART 11****FUMES- POLLUTION**  
**Oxygen sensor check****INSTRUCTIONS**


Only refer to this chart following a full check using the XR25, checking the following parameters in particular:

- #35 (mixture adjustment) : it should fluctuate around 128
- #30 and #31 (adaptive mixture regulation) : values must never be at the limit.

**AFTER REPAIR**

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check


### CHART 11 CONT 1



#### AFTER REPAIR

Check the connection of all of the sensors disconnected during the operation  
Erase the computer memory using GO\*\*  
Carry out a conformity check


CHART 11 CONT 2	
--------------------	--



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
-----------------	--




CHART 12	FUEL CONSUMPTION HIGH
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25




AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

CHART 12 CONT	
------------------	--






AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

CHART 13	ENGINE NOISE Pinking
INSTRUCTIONS	Only refer to this customer complaint following a full check using the XR25



AFTER REPAIR	Check the connection of all of the sensors disconnected during the operation Erase the computer memory using GO** Carry out a conformity check
--------------	--

INSTRUCTIONS	Engine cold, ignition on
--------------	--------------------------

Order of operations	Function to be checked	Action	Bargraph	Display and notes
1	XR25 dialogue	D13 (selector in position S8)		<div>9.NJ</div> Use of fiche n° 27 fault test side
2	Interpretation of normally illuminated bargraphs		<div>1</div> <div></div> <div>1</div> <div></div>	 Fault test   Code present
3	Engine immobiliser		<div>2</div> <div></div>	If the vehicle does not have an engine immobiliser, this bargraph should be illuminated
4	Computer conformity	G70*		<div>X X X X</div> Display in three sequences of the part number (refer to section 12)
5	Changing to status check mode	G01*		<div>10.NJ</div> Use of fiche n° 27 status test side

INSTRUCTIONS	Engine cold, ignition on.
--------------	---------------------------

Order of operations	Function to be checked	Action	Bargraph	Display and notes
6	Interpretation of normally illuminated bargraphs		1 <div><div></div><div></div></div>	Code present
			2 <div><div></div><div></div></div>	No load position recognised
			4 <div><div></div><div></div></div>	Reception of + after ignition information
			4 <div><div></div><div></div></div>	Illuminated in Park/Neutral position
			5 <div><div></div><div></div></div>	Locking relay control effective
			12 <div><div></div><div></div></div>	Illuminates after the memories have been erased to confirm that the operation has been carried out correctly
			19 <div><div></div><div></div></div>	Computer configured to operate with a: manual gearbox (G50*2*)
			19 <div><div></div><div></div></div>	automatic transmission (G50*1*)

INSTRUCTIONS	Engine cold, ignition on
--------------	--------------------------

Order of operations	Function to be checked	Action	Bargraph	Display and notes
7	Throttle position potentiometer	No load # 17	<div>2</div> <div><div></div><div></div></div>	10 < X < 36
		Accelerator pedal slightly pressed	<div>2</div> <div><div></div><div></div></div>	
		Full load # 17	<div>2</div> <div><div></div><div></div></div>	193 < X < 240
8	Absolute pressure sensor	# 01		X = Local atmospheric pressure
9	Coolant temperature sensor	# 02		X = Ambient temperature ± 5°C
10	Air temperature sensor	# 03		X = Ambient temperature ± 5°C
11	Idle regulator stepping motor	# 12		The value varies in relation to the coolant temperature: 19% ≤ X ≤ 80%
12	Engine speed	# 06		X = 0 rpm.
13	Canister bleeding	# 23		X = 0 %

INSTRUCTIONS	Engine warn at idle after the fan assembly has cut in at least once (air conditioning and electric windscreen not selected, automatic transmission in Park or Neutral).
--------------	---

Order of operations	Function to be checked	Action	Bargraph	Display and notes
1	Changing to status test mode	G01*		<div>10.NJ</div> Use of fiche n° 27 status test side
2	No fault		<div>20</div> <div><div></div></div>	<p>Check that this bargraph is not flashing; if it is, type GO2* and turn the fiche over.</p> <p><b>Warning:</b> This bargraph may flash if the vehicle is not fitted with an engine immobiliser. Ignore this bargraph if fault right-hand bargraph 2 is illuminated with *22 = 2dEF.</p> <p>Repair the faulty component and then erase the fault memory (GO**) and return to status test mode (GO1*).</p>
3	Battery voltage	# 04  if at# 04  then at# 06		<p>13 volts &lt; X &lt; 14,5 volts</p> <p>X &lt; 12.7 volts</p> <p>Nominal &lt; X &lt; 930 rpm. speed</p>

INSTRUCTIONS	Engine warn at idle after the fan assembly has cut in at least once (air conditioning and electric windscreen not selected, automatic transmission in Park or Neutral).
--------------	---

Order of operations	Function to be checked	Action	Bargraph	Display and notes
4	Interpretation of normally illuminated bargraphs	-	<div>1</div> <div><div></div><div></div></div>	Code present
			<div>2</div> <div><div></div><div></div></div>	No load position recognised
			<div>3</div> <div><div></div><div></div></div>	Reception of engine speed information
			<div>4</div> <div><div></div><div></div></div>	Reception of + after ignition information
			<div>4</div> <div><div></div><div></div></div>	Illuminated in Park or Neutral
			<div>5</div> <div><div></div><div></div></div>	Locking relay control effective
			<div>6</div> <div><div></div><div></div></div>	Idle regulation active
			<div>6</div> <div><div></div><div></div></div>	Mixture regulation active



INSTRUCTIONS	Engine warn at idle after the fan assembly has cut in at least once (air conditioning and electric windscreen not selected, automatic transmission in Park or Neutral).
--------------	---

Order of operations	Function to be checked	Action	Bargraph	Display and notes
4 (cont)	Interpretation of normally illuminated bargraphs (cont)	-	<div>7</div> <div><div></div><div></div></div> <div>12</div> <div><div></div><div></div></div> <div>19</div> <div><div></div><div></div></div> <div>19</div> <div><div></div><div></div></div>	<div>Fuel pump activated</div> <div>Illuminates after the memories have been erased to confirm that the operation has been carried out correctly</div> <div>Computer configured to operate with a:</div> <div>manual gearbox (G50*2*)</div> <div>automatic transmission (G50*1*)</div>



Engine warn at idle after the fan assembly has cut in at least once (air conditioning and electric windscreen not selected, automatic transmission in Park or Neutral).

JSA021.2

INSTRUCTIONS	Check to be carried out during a road test
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
1	Changing to status test mode	G01*		<div>10.NJ</div> Use of fiche n° 27 status test side
2	No fault		<div>20</div> <div><div></div><div></div></div>	Check that this bargraph is not flashing; if it is, type GO2* and turn the fiche over. <b>Warning:</b> This bargraph may flash if the vehicle is not fitted with an engine immobiliser. Ignore this bargraph if fault right-hand bargraph 2 is illuminated with *22 = 2dEF. Repair the faulty component and then erase the fault memory (GO**) and return to status test mode (GO1*).
3	Canister bleeding	# 23	<div>11</div>	Canister bleeding is authorised X = variable
4	Vehicle speed information	# 18	<div><div></div><div></div></div>	X = vehicle speed displayed on the speedometer
5	Pinking sensor	Vehicle with load at an engine speed of 2000 rpm.  # 13  # 15		X = variable and not zero  $0 \leq X \leq 6$ (in the event of a sensor fault the advance is automatically reduced by 4°, not shown at# 15)



Injector resistance	=	14.5 Ω
Idle regulation stepping motor resistance	=	A - D = 53 ± 5 Ω B - C = 53 ± 5 Ω
Canister bleed valve resistance	=	35 ± 5 Ω
Ignition coil resistance	:	1-2 = 2 Ω 2-3 = 1.6 Ω 1-3 = 1.6 Ω 2-4 = 1.6 Ω 1-4 = 1.6 Ω 3-4 = 1.1 Ω HT-HT= 7.2 kΩ
Flywheel signal resistance	=	220 Ω
Air temperature sensor resistance	=	800 to 1500 Ω at 40°C
Throttle potentiometer resistance	:	PL C-A 1260 Ω PF C-A 2200 Ω C-B 2200 Ω C-B 1260 Ω B-A 1200 Ω B-A 1200 Ω
Coolant temperature sensor resistance	=	210 to 270 Ω at 90°C
Oxygen sensor resistance	:	A-B = 3 to 15 Ω
Fuel pressure	=	3 bars or 2.5 bars at idle
Value of:		
CO	=	0.3 % maximum
HC	=	100 ppm max
CO2	=	14.5 % minimum
Lambda (λ)	=	0.97 < λ < 1.03

## EQUIPMENT REQUIRED

**OPTIMA 5800 fault-finding equipment**  
**4 gas analyser 4040-5040 or AGM 1500**

**ANALYSIS OF EXHAUST GASES USING THE FAULT-FINDING EQUIPMENT**

Connecting the OPTIMA 5800 fault-finding equipment to an analyser (SOURIAU 4040-5040 or SAGEM AGM 1500) allows the gases to be checked in accordance with the legislation relating to vehicles fitted with catalytic converters. This check assumes measurement at half load and at idle, with the following requirements:

Idle	2 500 rpm
CO < 0.5 %	CO < 0.3 %
HC < 100 ppm	HC < 100 ppm

Irrespective of the legislation, the other measurements given by the analyser are the subject of a tolerance interval:

Idle	2 500 rpm
CO <sub>2</sub> > 13.5 %	CO <sub>2</sub> > 13.5 %
O <sub>2</sub> < 0.8 %	O <sub>2</sub> < 0.8 %
0.97 < Lambda < 1.03	0.97 < Lambda < 1.03

**NOTE :** Lambda = 1 / Mixture

- Lambda > 1 → Lean mixture
- Lambda < 1 → Rich mixture

The condition Lambda = 1 is essential for correct operation of the catalytic converter.

The equipment combines the following phases:

- Bringing the engine up to operating temperature (oil temperature greater than 60°C)
- Constant speed of 2500 rpm for one minute to activate the mixture regulation and simultaneous measurement of the gases.
- If the gases analysis at 2500 rpm is correct, measurement at idle.

If the equipment considers the analysis to be incorrect, fault-finding messages appear, the order of gas priority being:

1) CO    2) Lambda    3) HC    4) O<sub>2</sub>    5) CO<sub>2</sub>

**NOTE :** It is possible to print the results of the anti-pollution tests.

## EQUIPMENT REQUIRED

OPTIMA 5800 fault-finding equipment

## OXYGEN SENSOR CHECK USING THE FAULT-FINDING EQUIPMENT

Straight-forward oxygen sensor faults are detected by the XR25.

- Open circuit
- Short circuit to earth.
- Short circuit to + 12 V.

The fault-finding equipment allows operational faults which are not detected by the XR25 to be highlighted. A sensor check can be carried out for the following customer complaints:


- Excessive consumption.
- Irregular idle speed, hunting.
- Hesitation.
- Gases analysis not correct to specification.

The equipment check scenario assumes connection in parallel with the signal transmitted by the oxygen sensor. This signal is analysed at a constant engine speed (2500 rpm), when the mixture regulation conditions are joined (engine warm...).

## CONNECTION:

The 4-way sensor connector is located under the vehicle.

During normal operation, the signal is represented as a sinusoid.



The characteristic parameters of this signal are the maximum voltage, the minimum voltage and the period. Whatever the engine type, the correct values are:

- Maximum voltage > 600 mV.
- Minimum voltage < 200 mV.
- Gap (maximum voltage - minimum voltage) > 500 mV.
- Period < 1 second.



## EQUIPMENT REQUIRED

OPTIMA 5800 fault-finding equipment

**IGNITION CHECK USING THE FAULT-FINDING EQUIPMENT**

The OPTIMA 5800 fault-finding equipment allows the ignition to be checked under two conditions:

- **TEST ON STARTING:** if the vehicle will not start. When fault-finding using the XR25 is not possible, this option checks the presence and the quality of the ignition when the starter is operated.
- **ENGINE RUNNING TESTS:** These measurements are an addition to the XR25 in the event of customer complaints such as: hesitation, ignition misfiring, incorrect gases analysis, unstable idle speed...

Also, the equipment's measuring module allows the static ignition to be checked using two high voltage clips, the coils having two outlets (when one ignition order is given, two sparks occur simultaneously: one in the combustion chamber, the other in the exhaust cylinder). While these measurements are being taken, the two clips must be moved from one coil to the other.

Their power is controlled directly by the computer (the amplifier module is integral with the computer): the equipment is therefore connected at the inlet of the coils.

**CONNECTIONS:**

- **DZF engine:** Connection to the two coils (bloc located to the left of the rocker cover).

**MEASUREMENTS:**

The ignition is characterised by the following values:

*Engine running:*

- Duration of spark.
- Priming voltage (or ionisation voltage).
- Priming voltage during the exhaust phase (static ignition).

*Test on starting:*

- Ignition supply voltage.
- TDC signal sensor.
- Control signal (MPA).
- Duration of spark.
- Priming voltage (or ionisation voltage).
- Priming voltage during the exhaust phase (static ignition).

The equipment checks the consistency of the values obtained for each cylinder and compares the measurements with a database categorised by engine type.

**QUANTITY AND QUALITY OF ANTIFREEZE**

Engine	Quantity (in litres)	Quality	Special features
D7F	5	GLACEOL RX (type D) only use coolant	Protection to - 25 ± 2 °C for hot, temperate and cold countries.  Protection to - 37 ± 2 °C for very cold countries.

**THERMOSTAT**

Engine type	Start of opening (in °C)	End of opening (in °C)	Stroke (in mm)
D7F	88	≤ 100	9

There is no heater matrix tap.

Circulation is continuous in the heater matrix which contributes to the cooling of the engine.

### FILLING

Check the tightening of the drain plug(s).

Open the two bleed screws.

Charge the circuit via the opening in the expansion bottle.

Close the bleed screws when the liquid flows in a continuous stream.

Start the engine (**2500 rpm**).

Adjust the overflow level for approximately **4 minutes**.

Close the bottle.


### BLEEDING

Leave the engine running for **10 minutes** at **2500 rpm**, until the fan(s) cut in (time required for automatic degassing).

Check that the liquid level is near to the "**Maximum**" mark.





**DO NOT OPEN THE BLEED SCREW(S) WHILE THE ENGINE IS RUNNING.**

**RETIGHTEN THE EXPANSION BOTTLE CAP WHILE THE ENGINE IS WARM.**




11635-1R

- 1 Engine
- 2 Radiator
- 3 Bottle "warm" with permanent degassing
- 4 Heater matrix





-  Coolant pump
-  Thermostat
-  Bleed screw
-  Temperature switch

The expansion bottle cap is brown, the rating value is 1.2 bar .



11635R

- 1 Engine
- 2 Radiator
- 3 Bottle "warm" with permanent degassing
- 4 Heater matrix
- 5 Automatic transmission oil temperature exchanger

-  Coolant pump
-  Thermostat
-  Bleed screw
-  Temperature switch

The expansion bottle cap is brown, the rating value is **1.2 bar** .

SPECIAL TOOLS REQUIRED

Mot. 1054	Top dead centre setting rod
Mot. 1202	Spring clip pliers
Mot. 1273	Belt tension checking tool
Mot. 1399	Tool for locating the engine on the subframe

TIGHTENING TORQUES  
(in daN.m or in degrees)



Crankshaft outlet mounting bolt	2 + 80°
Mounting bolt which secures the front right mounting to the engine	5.5
Mounting bolt which secures the front right mounting to the side member	5.5
Timing belt tensioner roller nut	5
Coolant pump mounting bolt	0.9

DEPOSE


Place the vehicle on a two post lift.

Disconnect the battery.

Remove the timing belt (refer to the procedure described in **section 11, Timing belt**).  
Drain the cooling circuit via the lower radiator hose.

Remove:

- the two coolant pump hoses,
- the tensioner roller and the coolant pump.




Clean the mating surfaces without scratching the aluminium surfaces.

### REFITTING

#### Special features

The coolant pump is sealed using **RHODORSEAL 5661**, the bead (J) must be applied in accordance with the illustration below.

Fit a new seal to the surface (L) (coolant pump inlet elbow) or apply a bead of **LOCTITE 518** in accordance with the sealing seen on removal.



10272R

Refit in the reverse order to removal.

Fit:

- the new timing belt (refer to the procedure described in **section 11, timing belt**).
- the new alternator belt (refer to the tensioning procedure and value in **section 07, accessories belt tensioning**).

Do not forget to remove the top dead centre setting rod.

Fill and bleed the cooling circuit (refer to **section 19, Fill - Bleed**).

### EXHAUST DOWNPIPE POSITIONING

To check that the exhaust downpipe is positioned correctly, two measurements must be checked.

A measurement (X) in the vertical axis of the vehicle.




A measurement (Y) horizontal in the transverse axis of the vehicle.

Measurement X is taken on the exhaust line and not on the downpipe, after the clip, just after the elbow.



From the lower section of the exhaust to the level section to the rear of the gear lever, the measurement should be **145 mm**.

Measurement Y is taken at the same level of the exhaust as measurement X, after the elbow. The only difference is that the measurement is not taken under the exhaust but on its right-hand side.

Measurement Y should be **347 mm** between the exhaust and the vertical surface of the right-hand side member.






ENGINE TYPE	COVER	DISC
D7F	<div><p>85873S</p><p>180 DST 3050</p></div>	<div><p>90693-4R1</p><p>76906R</p><p>26 grooves E = 7.8 mm D = 181.5 mm</p><p>R = Red BL= White B = Blue N = Black</p></div>

### CHANGING

This operation is carried out after uncoupling the gearbox.


SPECIAL TOOLS REQUIRED	
Mot. 582	Locking tool

TIGHTENING TORQUES (in daN.m)	
Cover mounting bolt $\varnothing 7$	2.5

### REMOVAL

Fit locking tool **Mot. 582**.

Remove the cover mounting bolts and remove the cover and the clutch disc.



### Visually check:

- that there are no scratches on the on the surface of the engine flywheel,
- the wear of the engine flywheel,
- the condition of the starter crown wheel,
- the sealing at the crankshaft and gearbox guide tube lip seal.

Change the faulty parts and clean the clutch shaft grooves.

JB1									
Index	Vehicle	Differential ratio	Speedo drive gear	1st	2nd	3rd	4th	5th	Reverse
132	X 066 C 067	$\frac{15}{56}$	$\frac{21}{20}$	$\frac{11}{37}$	$\frac{22}{41}$	$\frac{28}{37}$	$\frac{30}{29}$	$\frac{41}{31}$	$\frac{11}{39}$ 26

Capacity - Lubricants


CAPACITY (in litres)

5 speed gearbox JB1 : 3, 4

Quality, viscosity

TRANSELF TRX 75W 80W

LEVEL



Fill to the level of the opening.

JB and JC

TYPE	PACKAGING	PART NUMBER	UNIT
MOLYKOTE BR2	1 kg box	77 01 421 145	Right-hand sun wheel grooves Fork pivot Stop guide Fork pads } Clutch
Loctite 518	24 ml syringe	77 01 421 162	Casing assembly surfaces
RHODORSEAL 5661	100 g tube	77 01 404 452	Threaded caps and switches Bearing plug Ends of the spring pins on the drive shafts
LOCTITE FRENBLOC (locking and sealing resin).	24 cc bottle	77 01 394 071	Input and output shaft nuts Fixed gear and 5th gear hub Clawing driver

Parts which must always be changed

When they have been removed:


- the paper seals,
- the lip seals,
- the differential housing mounting bolts,
- the spring pins,
- the reverse gear inverter bolt,
- the O-ring,
- the stop rings,
- the stop guide tubes,
- the input and output gear nuts,
- the speedometer gear,
- the brake caliper bolts.

# MANUAL GEARBOX

## Gearbox (Removal - Refitting)

21

SPECIAL TOOLS REQUIRED		
B.Vi.	31-01	Set of brushes
T.Av.	476	Ball joint extractor
EQUIPMENT REQUIRED		
Engine support		

TIGHTENING TORQUES (in daN.m)	
Mounting bolt and nut which secure the clutch cover to the engine	5
Clutch protector mounting bolt	2.5
Drain cap	1.8
Filler cap	0.15
Left-hand driveshaft gaiter mounting bolt	2.5
Brake caliper mounting bolt	10
Shock absorber base mounting bolts	11
Steering ball joint nut	3.5
Stub axle carrier cotter nut	5.5
Mounting mounting bolt	4 - 5
Wheel bolts	9

### REMOVAL

Place the vehicle on a lift.

Disconnect:

- the battery.
- the air inlet sleeve.

Remove the plastic engine undertray.


Drain the gearbox.

Remove:

- the front wheels,
- the left-hand driveshaft,
- the left-hand mud shield.


Tilt the stub axle carrier and uncouple the right-hand drive shaft.

Uncouple the gear control cable at the gearbox outlet lever after detaching the protective gaiter.




Attach the gear lever to the exhaust pipe, to the rear.

Remove the pin (E) and disconnect the speedometer cable.




Remove:


- the clutch protective plate,
- the mounting nut which secures the engine to the gearbox,




- the exhaust down-pipe,



- the torque pickup central bracket
- the starter,
- the top dead centre sensor,
- the earth strap and connectors




Position the engine support and strap the engine to it.



Disconnect the clutch cable.

Remove:

- the gearbox surround bolts,
- the complete front left mounting.




Disconnect the reversing light connector.

Position a unit jack without the gearbox.

Remove the two dowel pins.

Uncouple the gearbox. To remove the gearbox, move the engine/gearbox assembly forwards and lower the gearbox rotating it a quarter turn clockwise.



### REFITTING

#### IMPORTANT

The front left mounting setting instructions must be strictly observed on refitting, refer to section 19.

Refit in the reverse order to removal.

Change the brake caliper mounting bolts and tighten them to the specified torque.

Press the brake pedal several times to bring the pistons into contact with the brake pads.



Tighten the nuts and bolts to the specified torques.

Refill the gearbox.

The Twingo fitted with type M automatic transmission is fitted with the latest generation of computer (M4-3).

Configuration with the D7F engine is identical to that of vehicles fitted with the E7J:

- the "load" information (throttle opening) is transmitted by the injection computer (there is not special load potentiometer on the automatic transmission),
- the engine speed information is transmitted by the injection computer,
- there is no kickdown switch.

Fault-finding for this function using the XR25 is with fiche No. 26. The basic manual for interpretation of the bargraphs and the processing of customer complaints is memo Diag. No. 7.

### DIFFERENCES IN RELATION TO FAULT-FINDING IN E7J CONFIGURATION

The only differences relating to the connections between the automatic transmission and injection computers are:

- the load information is transmitted on track 41 of the injection computer connector (track 22 for E7J),
- the Park/neutral/damping information is received on track 7 of the injection computer connector (track 8 for E7J),
- the engine speed information is transmitted on track 48 of the injection computer connector (track 12 for E7J).

This track also controls the fuel pump relay.

The engine speed information is taken on terminal D2 of the fuel pump relay bracket.



# AUTOMATIC TRANSMISSION

## Identification

**23**

Vehicle	AT type	Index	Final drive	Intermediate drive	Speedo drive gear	Oil pressure (in bars)	Computer no.
C 06	MB1	033	15/58	29/24	21/20	4.15 ± 0.05	143

## Gear ratios

Gear	1st	2nd	3rd	Reverse
Gear ratios Axle only	2.5	1.5	1	2
Gear ratios Axle +Down-pipe	2.069	1.241	0.827	1.655
Gear ratios Axle + Down-pipe + Drive axle	8	4,8	3,2	6,4
Speed in mph(Km/h)for 1000 rpm	7.78 (12.52)	12.97 (20.87)	19.456 (31.31)	9.73 (15.656)

Tyres : 155/70 R 13

## Gear change thresholds

Load level	1 → 2	2 → 1	2 → 3	3 → 2
No load	12	6	41	19
Full load	43	18	111	61
Kickdown switch	44	23	112	71

**No load:** Accelerator pedal released.

**Full load:** pedal fully pressed.

The figures shown in the tables are the theoretical average gear change speed values (timed speeds). These values may vary depending on the tolerances permitted on the equipment and also with the tyres.

Description	Unit concerned
RHODORSEAL 5661	Sealing of the driveshaft dowel pins
MOLYKOTE BR 2 grease	- Sun wheel grooves - Tool for aligning the drive plate on the converter
Loctite FRENBLOC	Brake caliper mounting bolts

Parts which must always be changed

Parts to be changed when they have been removed:

- the spring pins.
- the self-locking nuts.
- the copper seals.

Oil

**MB1** automatic transmission

**MECHANISM** : ELF RENAULTMATIC D2.

If not available:

**MOBIL** ATF 220 D.

# AUTOMATIC TRANSMISSION

## Drain and fill intervals

---

23

### CAPACITY IN LITRES:

Theoretical total : 4.5

After draining : 2

**NOTE: if the automatic transmission is changed,  
the new unit must be refilled as it is supplied  
empty by the Parts Department.**

# AUTOMATIC TRANSMISSION


## Drain- Fill - Levels

23

### DRAIN - FILL

Draining must be carried out when cold, dipstick and cap (A) removed.

Change the strainer.



Refit the cap with a new seal.

Filling with the recommended oil is via the dipstick tube.

Use a funnel with a 15/100 filter in order to prevent the introduction of impurities.

Run the engine at idle.

Check the level and top up if necessary.

### OIL LEVEL CHECK WHEN COLD

Place the vehicle with no load on a flat, horizontal area.

Place the selector lever at "**PARK**" (P).

Start the engine and wait one or two minutes for filling of the converter and the cooler.

The oil is at an ambient temperature of **20°C**.

Remove the dipstick, engine running.

The level must not be below the mark (1) **MINIMUM COLD** (risk of damage) and it must not exceed the mark (2) **MAXIMUM COLD** (risk of damage).

**Never exceed the "MAXIMUM COLD" level.**


### WARNING:

Too much oil will result in:

- abnormal heating of the oil
- leaks

Too little oil will result in:

- a damage to the mechanism.



**Read the level when cold**

**1 - MINIMUM COLD**

**2 - MAXIMUM COLD**

### SPECIAL TOOLS REQUIRED

B. Vi. 466-06	Cylindrical end piece
B.Vi. 466-07	Oil pressure gauge

### CHECK


#### Measuring condition

Ensure that:

- the normal operating temperature is 80°C,
- the accelerator cable is adjusted correctly.

Connect the fluid pressure gauge

**B. Vi. 466-07** to the end piece **B. Vi. 466-06** at (A).



### Measurement

Place the selector lever in the 2nd gear imposed position.


Accelerate fully and brake at the same time to stabilise the speed at **50 mph (80 km/h)**.

The pressure should be **4.15 ± 0.05 bars**.

### ADJUSTMENT

Remove the stop (1) and turn the capsule.

Tightening the capsule increases the pressure and vice versa.




### NOTE :

**2 notches = approximately 0.1 bar.**

A tool can be made to make the operation easier.

A = washer  $\varnothing$  8/30 mm, thickness 1.5 mm.

B = round pin  $\varnothing$  6 mm.



### CHANGING


Place the vehicle on a two post lift.

Disconnect the battery.

Drain the automatic transmission.


### REMOVAL

Remove the sump (A) and the strainer with its seal.



### REFITTING

Clean the sump and its magnets (remove them before cleaning).



Fit the new strainer with its seal and tighten to **0.9 daN.m.**

Refit the sump and refill with oil.

# AUTOMATIC TRANSMISSION

## Removal - Refitting

23

### SPECIAL TOOLS REQUIRED

B. Vi.	31-01	Set of brushes
T. Av.	476	Ball joint extractor
Mot.	582	Engine flywheel locking tool
Mot. 1272		Engine - Automatic transmission assembly positioning tool

### SPECIAL EQUIPMENT REQUIRED

Engine support

### TIGHTENING TORQUES (in daN.m)



Brake caliper mounting bolt	3.5
Shock absorber base mounting bolt	11
Steering ball joint nut	3.5
Stub axle carrier cotter nut	5.5
Left-hand driveshaft gaiter mounting bolt	2.5
Central connecting rod bolt	6.5
Mounting bolt which secures the automatic transmission mounting to the side member	4.2
Front left automatic transmission mounting bolt	3.9
Oil cooler bolt	2.5
Bolt which secures the drive plate to the converter	2.8
Automatic transmission retaining surround bolt	5
Front subframe mounting bolt	6
Rear subframe mounting bolt	11
Drain cap	1.8
Filler cap	0.15


### REMOVAL

Place the vehicle on a two post lift.

#### Remove:

- the battery,
- the air pipe,
- the computer protective housing.

Disconnect and detach the automatic transmission computer (1).




Remove the mounting and the injection computer (2)

Unclip the electrical harness and the cooling hose.


Remove and detach the oil cooler (3).



Remove and detach the oil cooler (3).




Disconnect the coolant temperature sensor (4) and remove the TDC sensor (5).




Remove:


- the earth strap and the harness bracket (6),



- the 2 starter bolts (A) and the 2 upper gearbox surround bolts (B).




Using the engine support tool, relieve the engine and ensure that the tool is stable.




Remove:


- the front wheels,
- the left and right hand mud shields,



- the plastic engine undertray




Drain the automatic transmission (A).




From the right-hand side of the vehicle remove:

- the steering connection rod ball joint using tool T. Av. 476.




Remove and detach the multi-function switch (1).




Remove:


- the three driveshaft gaiter mounting bolts,



- the two caliper mounting bolts, securing the caliper to the suspension spring in order to prevent tensioning of the pipe,
- the two shock absorber base mounting bolts (1)
- the cotter bolt and nut (2),




- the driveshaft/stub axle carrier assembly at the lower ball joint.




Check that the driveshaft rollers do not come off by hand. If they do, check on refitting that the needles have not fallen into the gearbox.

**From the right-hand side of the vehicle remove:**


- the driveshaft dowel pin using tool  
**B. Vi. 31-01**



- the two shock absorber base mounting bolts (1),
- the cotter bolt and nut(2),




- the driveshaft/stub axle carrier assembly at the lower ball joint.




Disconnect the oxygen sensor.

Remove:

- the catalytic converter,
- the heat shield (A)




Remove the pin and remove the speedometer housing.




Remove the gear control cable at the attachments.

Remove the earth strap (1).


Disconnect the oil pressure gauge (2).



Remove the converter protective plate (3).




Fit locking tool **Mot. 582** at (4) and remove the bolts (A) which secure the drive plate to the converter.




Remove:

- the rear central bracket bolt (B),




- the steering box bolts (D) and suspend the steering box.



Unclip the brake and fuel pipes from the sub-frame.


Remove:

- the engine half section mounting bolts (1) and (2),
- the front central bracket bolts and remove the bracket,
- the front left mounting bolts (3) which secure the automatic transmission mounting to the side member.




Lower the engine/automatic transmission assembly slightly loosening the DESVIL bracket bolt (for example).


Position the DESVIL V 703 ST 01 unit jack (for example).



Remove the dowel pins (3) and the bolt (4) from the gearbox surround.



Remove the automatic transmission.  
Fit the converter retaining plate **B. Vi. 465** at (X).



### Refitting (special features)

Check that the engine/automatic transmission centring rings are present and that they are positioned correctly.

Refit the automatic transmission locating the converter on the drive plate in relation to its mounting bolts.

Tighten the gearbox surround bolts and dowel pins to the specified torque.

**IMPORTANT:** The setting values must be strictly observed when refitting the engine half section and the front left mounting. Refer to section 19.

Refit in the reverse order to removal.

# AUTOMATIC TRANSMISSION


## Removal - Refitting

23

**NOTE:** observe the procedure for refitting the automatic transmission mounting on the side member.

Fit the automatic transmission mounting without placing it under stress.


Using tool **Mot. 1272** position the engine/ automatic transmission assembly in relation to the left rear subframe guide hole and the clutch bellhousing guide hole.



Tighten the automatic transmission mounting mounting bolts.

### CHECK

In order to check that the fan assembly is positioned correctly, the measurement shown below must be taken.



If this measurement is not correct ( $28 \text{ mm} \pm 1$ ), mark the actual position on the side member.

If the measurement is less than 27 mm, loosen the front mounting concerned and push section (A) back.

Retighten.

Check the new position and repeat the operation if necessary.

If the measurement is greater than 29 mm, follow the same procedure but allow section (A) to move forwards.

Then tighten the automatic transmission mounting mounting bolts to **4.2 daN.m**, ensuring that section (A) is not moved by the tightening torque and that it remains parallel with the vertical surface of the side member.

Tighten the front and rear subframe mounting bolts to the specified torque.



Tighten all of the bolts nuts and screws to the specified torque.

Fit the caliper mounting bolts with **Loctite Frenbloc**.

Press the brake pedal several times to bring the pistons into contact with the brake pads.

Refill the automatic transmission with oil.

**NOTE :** Seal the ends of the driveshaft dowel pin with **Rhodorseal 5661**.

In order to ensure correct sealing, the oil cooler O-rings must be replaced and the bolts must then be tightened gradually to a torque of **2.5 daN.m**.



# AUTOMATIC TRANSMISSION

## Starter plate

23

### SPECIAL TOOLS REQUIRED

Mot. 1054	TDC setting rod
Mot. 582	Locking tool
Mot. 1388	Starter plate centring tool

### SPECIAL EQUIPMENT REQUIRED

Engine support


### TIGHTENING TORQUES (in daN.m)



Starter plate bolt	3.8
--------------------	-----

This operation can only be carried out after removal of the automatic transmission (refer to the relative section)

### REMOVAL




Position the engine at the setting point (refer to the relative section) position **Mot. 1054** in mark (R), which has a different diameter of 8.25 mm. In order to avoid any risk of the drive plate falling, position centring tool **Mot. 1388**.

Position **Mot. 582** at (A).

### Remove:

- the six eccentric bolts (4),
- the starter plate



The maximum offset permitted on the starter plate is 0.5 mm.

### REFITTING


#### Refit:


Fit the starter plate, check that it is positioned in relation to the mark (R) and engage centring tool **Mot. 1388**.

**NOTE** : lubricate the bolt threads (4) before refitting them.

Bring the bolts (4) into contact with the starter plate and tighten them to **3.8 daN.m**.

In order to lock the starter plate, fit tool **Mot. 582** at (A).





- 1 Vehicle speed sensor
- 2 Electronic control connector
- 3 6-way socket
- 4 Fault-finding fault warning light connector
- 5 3-way connector linking TDC information and torque reduction
- 6 Multi-function switch and earth
- 7 injection computer housing

The computer controls the earthing of the electronic controls in accordance with the peripheral information and correct operational check of all of the automatic transmission electrical components.


### REMOVAL

Place the vehicle on a two post lift.

Disconnect the battery.


Remove:

- the front left wheel,
- the front left mud shield,



- the plastic engine undertray.


Drain the automatic transmission (caps A).




## Computer and wiring

Remove:



- the multi-function switch (1) and detach it,
- the earth strap and the harness bracket,



- the vehicle speed sensor (2),



- the battery,
- the air pipe,
- the computer protective housing,
- disconnect the connectors and detach the automatic transmission computer (D),
- detach the injection computer bracket,
- the earth strap and its bracket.




Unclip the wiring and remove it from the top of the vehicle.

### REFITTING

Refitting is the reverse of removal.

Check that the O-rings (I) are present on the speed sensor and the multi-function switch.



**NOTE:** there are no special features for the changing of the speed sensor and the multi-function switch.

For the procedure, refer to the automatic transmission manual TAM.


### REMOVAL

Place the vehicle on a two post lift.

Disconnect the battery.

#### Remove:

- the front left wheel,
- the left mud shield,




- the plastic engine undertray,

Drain the automatic gearbox.


#### Remove:

- the battery,
- the computer protective housing,
- the air pipe,
- the earth strap and its harness bracket.

Using the engine support tool, relieve the engine and ensure that the tool is stable.



Remove the automatic transmission bolts (O) and (P).




The switch (2) can only be detached after removal of the strainer housing (refer to the relative section on the previous page).

The operation has no special features for electronic controls, refer to the automatic transmission manual TAM.

Refit in the reverse order to removal.

Tighten the bolts to the specified torque.

### BREAKDOWN



PRC37.7

- 1 - Selector handle
- 2 - Gear grille
- 3 - Console
- 4 - Control computer
- 5 - Control cable
- 6 - Control on the automatic transmission.
- 7 - Control cable clip
- 8 - Clip for the control on the automatic transmission.

- A - Handle retaining bolt
- B - Console retaining bolt
- D - Computer protective cover
- E - Control computer mounting nut


## Selection control computer

## REMOVAL

## Passenger compartment end:

## Remove:

- the selector handle (1) secured by the bolt (A),
- the gear grille (2) unclipping it,
- the console (3) bolt (B).




## Under the vehicle:


Disconnect the oxygen sensor.

## Remove:

- the exhaust down-pipe,
- the heat shield,
- the computer protective cover mounting bolts,
- the four control computer nuts (4) and remove the computer from the top,



- the clip (F) retaining the cable on the computer.



## REFITTING

The automatic transmission must be placed in position D.

Check and if necessary adjust the control on the automatic transmission (refer to the relative section on the following page).

Refit in the reverse order to removal.


Adjust the cable on the computer (refer to the section on the following page).

Check that the gear changes are correct.




### Control cable

The control cable can only be removed after removal of the control assembly (refer to the relative section).




### REFITTING

Unclip the cable (F) and unhook it from the control lever ball joint.



Free the cable from its clip.

Unclip the control cable (5) lifting it upwards and unhook it from the ball joint.



Thread the cable on the engine half section and brake hoses.

Refitting is the reverse of removal.


Check and adjust the control (6) (refer to the following page).

### CHECKING AND ADJUSTING

#### Adjusting the cable on the gearbox

The automatic transmission and the control computer must be in position (D) (control computer removed or in place, as the positions are written on the computer).

Unlock the cable stop (G) by rotating it by 90 degrees, and ensure that the cable moves without restriction.



Check the setting (G) by turning the ring to stop lateral movement of the cable cover.

Check:


- that the gear changes are correct.
- the engagement of the starter in position P and N.

Check that the vehicle is correctly immobilised with the Park function engaged.

If the setting is incorrect, unlock the cable cover stop (G) by rotating it by a quarter turn and pull or push the cable depending on the adjustment to be made.

Do not forget to lock the cable cover stop (G) at the end of the operation.

### SETTING THE CONTROL ON THE AUTOMATIC TRANSMISSION



The automatic transmission must be in position (D).

Check the measurement (A) between the contact surface of the cable with the cable cover (1) and the mounting ball joint pin (2).

**A=138.6 mm**

This operation can be carried out with the automatic transmission removed or in place.