



---

**N.T. 3038A**

---

**X06X**

---

## **Air conditioning Twingo phase II**

---

**For the sections not described in this note, refer to M.R. 305.**

---

**77 11 200 624**

**JUNE 1998**

**Edition Anglaise**

"The repair methods given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The methods may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed."

All copyrights reserved by Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault.



**Renault 1998**

---

**Contents**

Page

**62 HEATING AND AIR CONDITIONING**

Fault finding - Customer complaints	62-1
Fault finding - Fault charts	62-2





Air distribution fault		<b>Chart 1</b>
Heating efficiency fault		<b>Chart 2</b>
Air flow fault		
Air distribution control in footwell position		<b>Chart 3</b>
Air distribution control in de-icing position		<b>Chart 4</b>
Air distribution control in vent position		<b>Chart 5</b>
Controls stiff		<b>Chart 6</b>
Smell in passenger compartment		<b>Chart 7</b>
Heating fault		
No hot air		<b>Chart 8</b>
Too much hot air		<b>Chart 9</b>
De-icing / de-misting efficiency fault		<b>Chart 10</b>
Air conditioning fault	 (Air mixing flap in maximum cold position)	
No cold air		<b>Chart 11</b>
Lack of efficiency		<b>Chart 12</b>
Too much cold air		<b>Chart 13</b>
Recycling flap does not work		<b>Chart 14</b>
Passenger compartment fan does not work		<b>Chart 15</b>
Cooling fan does not work		<b>Chart 16</b>
Cooling fan does not work at slow speed		<b>Chart 17</b>

Chart 1	AIR DISTRIBUTION FAULT
---------	------------------------


NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



\* From this asterisk, the text also applies to Chart 2, Chart 8, Chart 9, Chart 11A, Chart 13.

AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--


Chart 2	HEATING EFFICIENCY FAULT
NOTES	Only consult this customer complaint after a complete check using the XR25.




AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--


Chart 2	HEATING EFFICIENCY FAULT (cont)
---------	---------------------------------

NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---





AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 3	AIR FLOW FAULT (WHEN THE AIR DISTRIBUTION CONTROL IS IN POSITION  )
NOTES	Only consult this customer complaint after a complete check using the XR25.




AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 4	AIR FLOW FAULT (WHEN THE AIR DISTRIBUTION CONTROL IS IN POSITION  )
NOTES	Only consult this customer complaint after a complete check using the XR25.




AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--




Chart 5	AIR FLOW FAULT (WHEN THE AIR DISTRIBUTION CONTROL IS IN POSITION  )
---------	---

NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--


Chart 6	STIFF CONTROLS
NOTES	Only consult this customer complaint after a complete check using the XR25.



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 7	SMELL IN PASSENGER COMPARTMENT
---------	--------------------------------


NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--


Chart 8	NO HOT AIR
---------	------------

NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--


Chart 9	TOO MUCH HOT AIR
NOTES	Only consult this customer complaint after a complete check using the XR25.



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--


Chart 10	DE-ICING / DE-MISTING EFFICIENCY FAULT
----------	--

NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--


Chart 11	NO COLD AIR
NOTES	Only consult this customer complaint after a complete check using the XR25.



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 11A	NO COLD AIR
-----------	-------------

NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---




AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--




Chart 11A	NO COLD AIR (cont)
-----------	--------------------

NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--


Chart 11B	NO COLD AIR
NOTES	Only consult this customer complaint after a complete check using the XR25.



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 11B	NO COLD AIR (cont)
-----------	--------------------


NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 11B	NO COLD AIR (cont)
-----------	--------------------


NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 12	LACK OF EFFICIENCY
----------	--------------------


NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--


Chart 12	LACK OF EFFICIENCY (cont)
----------	---------------------------

NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---




AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 12 A	LACK OF EFFICIENCY
NOTES	Only consult this customer complaint after a complete check using the XR25.



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 12A	LACK OF EFFICIENCY (cont)
NOTES	Only consult this customer complaint after a complete check using the XR25.



(\*) Warning - Type 709 compressors allow more oil to circulate in the circuit than compressor types 508 and 510.

AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--



Chart 13	TOO MUCH COLD AIR
NOTES	Only consult this customer complaint after a complete check using the XR25.






Chart 13	TOO MUCH COLD AIR (cont)
NOTES	Only consult this customer complaint after a complete check using the XR25.



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--


Chart 14	THE RECYCLING FLAP DOES NOT WORK
NOTES	Only consult this customer complaint after a complete check using the XR25.



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 15	THE PASSENGER COMPARTMENT FAN DOES NOT WORK
----------	---


NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 15A	THE PASSENGER COMPARTMENT FAN DOES NOT WORK
-----------	---


NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 16 THE COOLING FAN DOES NOT WORK


NOTES Only consult this customer complaint after a complete check using the XR25.



AFTER REPAIR Carry out a road test then check using the XR25.

Chart 16	THE COOLING FAN DOES NOT WORK (cont)
----------	--------------------------------------


NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--

Chart 17	THE COOLING FAN DOES NOT WORK AT SLOW SPEED
----------	---

NOTES	Only consult this customer complaint after a complete check using the XR25.
-------	---



AFTER REPAIR	Carry out a road test then check using the XR25.
--------------	--