

LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
R37	ENGINE/INJECTION CONNECTION
R153	PASSENGER COMPARTMENT/DRIVER'S DOOR CONNECTION
R154	PASSENGER COMPARTMENT/PASSENGER DOOR CONNECTION
R179	ANTI-LOCK BRAKING SYSTEM/LEFT-HAND FRONT WING CONNECTION
R183	PASSENGER COMPARTMENT/ANTI-LOCK BRAKING SYSTEM CONNECTION
R212	ENGINE/PASSENGER COMPARTMENT (SINGLE UNIT) CONNECTION
R221	DASHBOARD/SINGLE UNIT CONNECTION
R235	DASHBOARD/AUTOMATIC GEARBOX CONNECTION
R266	PASSENGER COMPARTMENT/BUMPER CONNECTION
R277	PASSENGER COMPARTMENT/DRIVER'S PRETENSIONER CONNECTION
R278	PASSENGER COMPARTMENT/PASSENGER PRETENSIONER CONNECTION
R306	ENGINE/AUXILIARY LPG CONNECTION
R309	ABS/INTERMEDIATE ABS CONNECTION
R320	PASSENGER COMPARTMENT/GEARBOX CONNECTION