



Organ Model PT 237

Two Manual Lighted Tab Console

PEDAL

1 Sub Bourdon	32
2 Principal	16
3 Bourdon	16
4 Gedeckt	16
5 Dulciana	16
6 Octave	8
7 Bass Flute	8
8 Choral Bass	4
9 Mixture	IV
10 Bombarde	32
11 Trombone	16
12 Trumpet	8

(i) Great to Pedal

(ii) Swell to Pedal

GREAT

1 Open Diapason	8
2 Chimney Flute	8
3 Unda Maris II	8
4 Principal	4
5 Stopped Flute	4
6 Nazard	2-2/3
7 Fifteenth	2
8 Block Flute	2
9 Tierce	1-3/5
10 Fourniture	IV
11 Clarinet	8
12 Trumpet	8

13 Chimes

(i) Tremulant

(ii) Swell to Great

SWELL

1 Principal	8
2 Stopped Flute	8
3 Salicional	8
4 Voix Celeste	8
5 Octave	4
6 Traverse Flute	4
7 Flageolet	2
8 Mixture	III-IV
9 Contra Fagotto	16
10 Cornopean	8
11 Oboe	8
12 Clarion	4

(i) Tremulant

ACCESSORIES

Program Display (LCD)

Four Specifications

Multi-program Lexicon MPX110 reverb unit

Expression pedal to the Swell

Expression pedal to the Great & Pedal

Pedal light

COMBINATION ACTION

4 Thumb pistons to the Swell organ

4 Thumb pistons to the Great organ

4 Thumb pistons to the Pedal

6 General thumb pistons

1 reversible thumb piston Swell to Great

1 reversible thumb piston Swell to Pedal

1 reversible thumb piston Great to Pedal

1 thumb piston General Cancel

1 thumb piston Set

3 thumb pistons 'FN', +, -.

16 combination memories

TECHNICAL DATA

Manuals: 2 x 61 notes

Pedals: 32 notes AGO

Audio: 2 audio channels

Midi: In, Out, Thru sockets

Headphones socket