

MAINTENANCE

Filament change

This operation is needed when you want to print with a different color or when the filament available in the spool is not enough.

1

Change filament now

Calibrate

This operation is needed to ensure the quality of your 3D prints.

2

Calibrate now

0 prints have been made since the last calibration.

Extruder Maintenance

This operation enables you to unlog the nozzle using the Maintenance Kit.

3

Start extruder maintenance

Replace nozzle

This operation is for replacing the extruder nozzle with a spare from your Maintenance Kit.

4

Replace nozzle now

Ok











