



# LINKYO®

## LINKYO Compatible Brother TN450 Toner Cartridge Reset Instructions

Please perform the following steps to maximize the usage of your **LINKYO Compatible Brother TN450 Toner Cartridge**. You can also use these steps if your new toner cartridge is giving you an error message or if the low toner LED light is on or flashing after installation.

### **For HL Series (2130, 2220, 2230, 2240, 2250, 2270) Printers;**

- a. With the power on, open the front cover.
- b. Turn the printer off.
- c. Press and Hold the '**GO**' Button while turning the printer on. (All the LED lights should be on.)
- d. Release the '**GO**' Button
- e. Press the '**GO**' Button **2 times**.
- f. Pause 10 seconds.
- g. Press the '**GO**' Button **5 times**.  
(The TONER LED light should be off and the ERROR LED light should be on or flashing)
- h. Close the cover. (The **READY** LED light should be the only light that is on.)
- i. Turn off the printer, then turn the printer on.

Your printer should be ready to print!

### **For MFC Series (7360, 7460, 7470, 7860) Printers;**

- a. Press '**CLEAR/BACK**'.
- b. The LCD Screen will show '**Replace Drum? 1.Yes 2.No**'.
- c. Press \* **0 0** (The keys have to be entered quickly and in order).
- d. Press '**OK**'.
- e. The LCD Screen will show '**Accepted**' or '**Cover is open**'.
- f. Close the cover

Your printer should be ready to print!

### **For HL-2280 & DCP Series (7055, 7057, 7060, 7062, 7070) Printers;**

- a. Press '**CLEAR/BACK**'.
- b. Press '**Start**'.
- c. Press '**Down**' or '**Down Arrow**'.
- d. Press '**Up**' or '**Up Arrow**'.
- e. The LCD Screen will show '**0 0**'.
- f. Press '**OK**'.
- g. Close the cover

Your printer should be ready to print.!

**For more assistance, please contact  
LINKYO Customer Service  
1-888-434-1888**

**LINKYO®**

## LINKYO Compatible Brother DR420 Drum Unit Reset Instructions

---

Please perform the following steps in order to maximize the usage of your **LINKYO Compatible Brother DR420 Drum Unit**. You can also use the following steps if the new drum unit is giving you an error message or if the drum LED light is on or flashing after installation.

### **For HL Series Printers;**

- a. With the power on, open the front cover.
- b. Press and hold the '**GO**' Button for a few seconds. (All the LED Lights should be on.)
- c. Release the '**GO**' Button.
- d. Wait for 2 to 3 minutes.
- e. Close the front cover

Your printer should be ready to print!

### **For MFC Series Printers;**

- a. With the power on, open the front cover.
- b. Press the **Options** (or **Clear** or **Back**) Key.
- c. The LCD will display "Replace Drum" with options of **1 for Yes** and **2 for No**.  
Press 1 for Yes.
- d. The LCD will display "Accepted" followed by "Cover is open".
- e. Close the front cover

Your printer should be ready to print!

**For more assistance, please contact  
LINKYO Customer Service  
1-888-434-1888**