

SYMBOLS

NUL - NULL	DLE - DATA LINK ESCAPE
SOH - START OF HEADER	DC - DEVICE CONTROL
STX - START OF TEXT	NAK - NEGATIVE ACKNOWLEDGE
ETX - END OF TEXT	SYN - SYNCHRONOUS IDLE
EOT - END OF TRANSMISSION	ETB - END OF TRANSMISSION BLOCK
ENQ - ENQUIRY	CAN - CANCEL
ACK - ACKNOWLEDGE	EM - END OF MEDIUM
BEL - BELL	SUB - SUBSTITUTE
BS - BACKSPACE	ESC - ESCAPE
HT - HORIZONTAL TABULATION	FS - FILE SEPARATOR
LF - LINE FEED	GS - GROUP SEPARATOR
VT - VERTICAL TABULATION	RS - RECORD SEPARATOR
FF - FORM FEED	US - UNIT SEPARATOR
CR - CARRIAGE RETURN	SPC - SPACE (BLANK)
SO - SHIFT OUT	
SI - SHIFT IN	