

1. Getting Started

To power on the SmartClean X1000, press and hold the main power button located on the top of the device for 3 seconds.

Ensure the device is placed on a flat surface before starting. Charging time is approximately 4 hours for a full charge.

2. Cleaning Modes

- Auto Mode: Default mode; the vacuum will clean the entire floor space using its AI mapping system.
- Edge Mode: Focuses on cleaning along walls and corners.
- Spot Mode: For deep cleaning a specific area. Activate this mode by double-pressing the "Mode" button.

3. Maintenance

- Dustbin Cleaning: Remove the dustbin from the back compartment and empty after every 2-3 cleaning cycles.
- Filter Replacement: Replace the HEPA filter every 3 months or when visibly dirty.
- Brush Cleaning: Detach the main brush and side brushes and clean once a week.

4. Troubleshooting

- Error Code E01: Indicates a wheel obstruction. Remove debris and restart the device.
- Error Code E04: Battery malfunction. Contact support if this error persists after rebooting.

5. Safety Information

- Do not submerge the vacuum in water.

- Keep away from open flames.
- Use only the original charging adapter provided with the device.