




UDM-Pro Quick Start Guide

Package Contents

The following components will be required for:

- **HDD Installation:** Components D or E
- **Rack Mounting:** Components A, B, C, and F
- **Flat Surface Staging:** Component G



UniFi Dream Machine Pro



Power Cord



A- Bracket Screws (Qty. 8)



B- Mounting Screws (Qty. 4)



C- Nuts (Qty. 4)



D- Security Screw



E- 2.5" HDD Screws (Qty. 4)



F- Rack-Mount Brackets
(Qty. 2)




G- Rubber Feet (Qty. 4)

Hardware Overview



UDM-Pro Quick Start Guide



1 Touchscreen Display	
Bootup Animation	A display message of "UDM-Pro is Starting..."
Location Animation	This indicates that you clicked Locate in the UniFi Network Application. The software will also display the location of the device on the map.
2 HDD LED	
Flashing White	Indicates Read/Write Activity
Steady Amber	Indicates HDD Error
3 RJ-45 Speed/Link/Activity LED (Ports 1 - 9)	
Off	No Link
Amber	Link Established at 10/100 Mbps Flashing Indicates Activity
Green	Link Established at 1 Gbps Flashing Indicates Activity
4 SFP+ Speed/Link/Activity LED (Ports 10 - 11)	
Off	No Link
Green	Link Established at 1 Gbps Flashing Indicates Activity




UDM-Pro Quick Start Guide

Flashing Indicates Activity	
5	HDD Bay
Install a 3.5" or 2.5" HDD (not included) to use the device as an NVR for UniFi Protect.	
6	RJ45 LAN (Ports 1 - 8)
The RJ45 ports support 10/100/1000 Ethernet connections. By default, they are set to DHCP Server with the fallback IP address, 192.168.1.1/24.	
7	RJ45 Internet (Port 9)
The RJ45 port supports a 10/100/1000 Ethernet connection. Set to DHCP Client by default.	
8	SFP+ Internet (Port 10)
The SFP+ port supports a 1/10G Ethernet connection. Set to DHCP Client by default.	
9	SFP+ LAN (Port 11)
The SFP+ port supports a 1/10G Ethernet connection. By default, it is set to DHCP Server with the fallback IP address, 192.168.1.1/24.	
10	Reset Button
Resets to factory defaults. The device should be running after bootup is complete. Press and hold the Reset button for about 10 seconds until the display indicates that the device has reset itself. After a few seconds, the LED will turn off, and the device will automatically reboot.	
11	USB RPS LED
Reserved for future use.	
12	USB Connect DC Input
Reserved for future use.	
13	Power Port
Connect the included Power Cord to the Power port.	



UDM-Pro Quick Start Guide

1. Ensure that your UDM-Pro is fully powered down and unplugged prior to installing your 2.5" or 3.5" HDD.
2. Press the right end of the HDD bay cover inward to unlatch it, then pull the plastic tab out to release the HDD mounting tray.



3. Insert your 3.5" HDD into the mounting tray:




Note: If you are installing a 2.5" HDD, proceed to Step 4.

- a. Position your 3.5" HDD inside the mounting tray so that the device's side threading hole is aligned with that of the tray.



UDM-Pro Quick Start Guide



- b. Fasten the security screw (D) into the aligned threading hole with a Phillips screwdriver until secure.




- c. Proceed to Step 5.



UDM-Pro Quick Start Guide


- a. Position your 2.5" HDD inside the mounting tray so that the device's threading holes are aligned with those at the bottom of the tray.
- b. Fasten the mounting screws (D) into the aligned threading holes with a Phillips screwdriver until secure.



5. Reinsert the tray back into the HDD bay, then push the right end of the bay's front panel in until it clicks into place.



UDM-Pro Quick Start Guide




HDD Removal:

1. Ensure that your UDM-Pro is fully powered down and unplugged prior to removing your HDD.
2. Open your UDM-Pro's front panel and pull out the HDD mounting tray.
3. Remove all screws attaching the HDD's chassis to the tray, then remove the device.
4. Reinsert the tray into HDD bay and close the front panel tab.



UDM-Pro Quick Start Guide



Rack Mounting the UDM-Pro

Installation Requirements

- Phillips screwdriver
- Standard-sized, 19" wide rack with a minimum of 1U height available
- For indoor applications, use Category 5 (or above) UTP cabling approved for indoor use.
- For outdoor applications, shielded Category 5 (or above) cabling should be used for all wired Ethernet connections and should be grounded through the AC ground of the power supply.




Note: Although the cabling can be located outdoors, the UDM-Pro itself should be housed inside a protective enclosure.

1. Position the first rack-mount bracket (F) so that its four holes align with the four threading holes on either side of the UDM-Pro.
2. Fasten the first rack-mount bracket using four bracket screws (A), then repeat the process with the second rack-mount bracket.




UDM-Pro Quick Start Guide



3. Align the front-facing holes of the rack-mount brackets with those of the wide rack's support legs.

a. **If your mounting rack's holes are circular**, fasten two mounting screws (B) through the rack-mount bracket and the rack's support legs.




b. **If your mounting rack's holes are rectangular:**

- i. Fasten two cage nuts (C) to each of the mounting rack's support legs.
- ii. Thread the mounting screws (B) through the rack-mount brackets and the circular ends of the cage nuts.



UDM-Pro Quick Start Guide



Powering the UDM-Pro

IMPORTANT! We strongly recommend connecting the UDM-Pro to an Uninterruptible Power Supply (UPS), or battery backup device, to prevent power instability issues and hardware damage that may result from relying on the local AC power of a standard outlet.

1. Insert the power cord into the back of the UDM-Pro.
2. Connect the power cord to a standard AC outlet, surge-protected power strip, or a UPS device.



UDM-Pro Quick Start Guide




Note: The UDM-Pro's voltage output range is 100-240 volts. Ensure that your power source can accommodate this, as well as any other devices sharing the UDM-Pro's power supply.

Connecting the UDM-Pro to Your Internet Modem or Router

1. Connect one end of your Ethernet cable to your modem or router, then connect the other end to the RJ45 Internet port on the front of the UDM-Pro (Port 9 in the Hardware Overview table).



UDM-Pro Quick Start Guide



Connecting the UDM-Pro with a Fiber Internet Adapter

1. Connect one end of your fiber optic cable to your modem or router.
2. Remove the rubber plug from the SFP+ Internet port (Port 10 in the Hardware Overview table).





UDM-Pro Quick Start Guide



4. Connect the other end of your fiber optic cable to the SFP Fiber Module.



Note: For more information about compatible fiber SFP modules, refer to our [Help Center](#) article.



UDM-Pro Quick Start Guide



Note: A LAN, or Local Area Network, connection will directly connect, or "hard line," an individual device (e.g., laptop, game console, etc.) to your UDM-Pro via a separate Ethernet cable. The advantage of this wired configuration is often stronger, steadier download and upload speeds.

1. Connect one end of your Ethernet cable to the desired device.
2. Connect the other end of your Ethernet cable into one of the eight RJ-45 ports (Ports 1-8 in the Hardware Overview table).




Connecting Devices to the UDM-Pro via Fiber LAN Adapter


1. Connect one end of your fiber optic cable to the desired device.
2. Remove the rubber plug from the SFP+ LAN port (Port 11 in the *Hardware Overview* table).



UDM-Pro Quick Start Guide




3. Insert your SFP Fiber Module (or compatible third-party equivalent) into Port 11.



4. Connect the other end of your fiber optic cable to the SFP Fiber Module.



UDM-Pro Quick Start Guide



Note: For more information about compatible fiber SFP modules, refer to our [Help Center](#) article.

Configuring and Connecting Devices to the UDM-Pro

To finish setting up your UDM-Pro, please read [UniFi - Set Up a Dream Machine Pro](#).

This guide will take you through the process of configuring your UDM-Pro and connecting all of your UniFi devices. Please check the system requirements below before proceeding to the guide.

System Requirements

Either of the following is required:

- An iOS or Android™ mobile device with the UniFi Network Mobile app installed.
- The Google Chrome web browser.



Note: Other browsers may offer limited functionality.

Specifications



UDM-Pro Quick Start Guide

Dimensions	442.4 x 43.7 x 283.6 mm (17.42 x 1.72 x 11.24")
Weight	3.90 kg (8.60 lb)
With Mount Brackets	3.99 kg (8.80 lb)
Interfaces	
Networking	(8) 10/100/1000 RJ45 LAN Ports (1) 10/100/1000 RJ45 WAN Ports (1) 1/10G SFP+ LAN Port (1) 1/10G SFP+ WAN Port
Management	Ethernet In-Band (1) Bluetooth BLE
Max. Power Consumption	33W
Power Method	(1) Universal AC Input, 100 to 240VAC (1) RPS DC Input
Power Supply	Internal 50W/12V
Supported Voltage Range	100 - 240VAC
Display	1.3" Color Touch Panel
LED	
System	Status
HDD	Activity
RJ45	Link/Speed/Activity
SFP+	Link/Speed/Activity
Processor	Quad ARM Cortex-A57 Core at 1.7 GHz
System Memory	4 GB DDR4
On-Board Flash Storage	16 GB eMMC
Operating Temperature	-10 to 40° C (14 to 104° F)
Operating Humidity	5 to 95% Noncondensing
Certifications	CE, FCC, IC

Safety Notices

- 1. Read, follow, and keep these instructions.
- 2. Heed all warnings.
- 3. Only use attachments/accessories specified by the manufacturer.



WARNING: Do not use this product in location that can be submerged by water.



WARNING: Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.



UDM-Pro Quick Start Guide

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.
2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.
 - a. Do not substitute the power cord with one that is not the provided approved type. Never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
 - b. The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
 - c. Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
 - d. Protective earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.
 - e. Protective bonding must be installed in accordance with local national wiring rules and regulations.

Limited Warranty

ui.com/support/warranty

The limited warranty requires the use of arbitration to resolve disputes on an individual basis, and, where applicable, specify arbitration instead of jury trials or class actions.

Compliance

FCC

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operations of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This radio transmitter has been approved by FCC.



UDM-Pro Quick Start Guide

CAN ICES-3(A)/NMB-3(A)

This device complies with ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This radio transmitter has been approved by ISED Canada.

CAN ICES-3(A)/NMB-3(A)

Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. l'appareil ne doit pas produire de brouillage;
2. l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le présent émetteur radio a été approuvé par ISDE Canada.

IMPORTANT NOTE

Radiation Exposure Statement

- This equipment complies with radiation exposure limits set forth for an uncontrolled environment.
- This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

AVIS IMPORTANT

Déclaration sur l'exposition aux rayonnements

- Cet équipement est conforme aux limites prévues pour l'exposition aux rayonnements dans un environnement non contrôlé.
- Lors de l'installation et de la mise en fonctionnement de l'équipement, assurez-vous qu'il y ait une distance minimale de 20 cm entre l'élément rayonnant et vous.
- Cet émetteur ne doit être installé à proximité d'aucune autre antenne ni d'aucun autre émetteur, et ne doit être utilisé conjointement à aucun autre de ces appareils.

Australia and New Zealand



Warning: This equipment is compliant with Class A of CISPR 32. In a residential environment this equipment may cause radio interference.

Brazil



UDM-Pro Quick Start Guide



nao pode causar interferencia em sistemas devidamente autorizados.

CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.



Country List



AT	BE	BG	CY	CZ	DE	DK	EE	EL	ES	FI	FR	HR	HU
IE	IT	LV	LT	LU	MT	NL	PL	PT	RO	SE	SI	SK	UK

 BFWA (Broadband Fixed Wireless Access) members noted in blue



Note: This device meets Max. TX power limit per ETSI regulations.

The following apply to products that operate in the 5 GHz frequency range:



Note: This device is restricted to indoor use only when operating in the 5150 - 5350 MHz frequency range within all member states.



Note: All countries listed may operate at 30 dBm. BFWA member states may operate at 36 dBm.



Note: Operation in the 5.8 GHz frequency band is prohibited in BFWA member states. Other countries listed may use the 5.8 GHz frequency band.

WEEE Compliance Statement

Declaration of Conformity

Online Resources



UDM-Pro Quick Start Guide



© 2024 Ubiquiti Inc. All rights reserved.