

# Frequency response of second order system

Batch no : 16

511821,511845,511873,511875,511880

MATLAB R2020a

HOME PLOTS APPS EDITOR PUBLISH VIEW

New Open Save Find Files Compare Print Go To Find Insert Comment Indent Breakpoints Run Run and Advance Run Section Advance Run and Time

FILE NAVIGATE EDIT BREAKPOINTS RUN

Current Folder: C:\Windows\System32

Editor - D:\New folder\CS\_Lab\lab20.m

```

1 w=input('enter the natural frequency');
2 e=input('enter the damping ratio');
3 num=[w*w];
4 den=[1 2*w*e w*w];
5 g=tf(num,den);
6
7 figure(1)
8 bode(g);
9 margin(g);

```

Command Window

New to MATLAB? See resources for [Getting Started](#)

unrecognized function or variable 'w'.

Error in lab20 (line 1)  
num=[w\*w];

>> lab20  
enter the natural frequency10  
enter the damping ratio0.5  
fx >>

Workspace

Name	Value
den	[1,10,100]
e	0.5000
g	1x1 tf
num	100
w	10

Figure 1

Bode Diagram

Gm = Inf dB (at Inf rad/s) , Pm = 90 deg (at 10 rad/s)

Magnitude (dB)

Phase (deg)

Frequency (rad/s)

U: 1.11 kbit/s  
D: 0.86 kbit/s

ENG IN 1:10 PM 28-Jan-21

MATLAB R2020a

HOME PLOTS APPS EDITOR PUBLISH VIEW

New Open Save Find Files Compare Print Go To Find Comment Indent Breakpoints Run Run and Advance Run Section Advance Run and Time

FILE NAVIGATE EDIT BREAKPOINTS RUN

Current Folder: C:\Windows\System32

Editor - D:\New folder\CS\_Lab\lab20.m

```
lab20.m lab21.m
w=input('enter the natural frequency');
e=input('enter the damping ratio');
num=[w*w];
den=[1 2*w*e w*w];
g=tf(num,den);

figure(1)
bode(g);
margin(g);
```

Figure 1

File Edit View Insert Tools Desktop Window Help

**Bode Diagram**  
Gm = Inf dB (at Inf rad/s) , Pm = -180 deg (at 0 rad/s)

Magnitude (dB)

Phase (deg)

Frequency (rad/s)

Select a file to view details

Command Window

New to MATLAB? See resources for [Getting Started](#).

sys =

$$\frac{100}{s^2 + 10s + 100}$$

Continuous-time transfer function

mr =

1.1547

wr =

7.0610

wb =

12.7119

>> lab20  
enter the natural frequency3.464  
enter the damping ratio1.01  
fx >>

U: 0.00 kbit/s  
D: 0.00 kbit/s

ENG 1:22 PM  
IN 28-Jan-21

MATLAB R2020a

HOME PLOTS APPS EDITOR PUBLISH VIEW

New Open Save Find Files Go To Find Insert Comment Indent Breakpoints Run Run and Advance Run and Time

FILE NAVIGATE EDIT BREAKPOINTS RUN

C: Windows System32

Current Folder

0409 1033 AdvancedInstallers am-et AppLocker appraiser ar-SA bg-BG Boot Bthprops catroot2 CatRoot CodeIntegrity Com config Configuration ContainerSettingsProviders cs-CZ da-DK DDFs de-DE DiagSvc Dism downlevel

Details

Select a file to view details

Editor - D:\New folder\CS\_Lab\lab21.m

lab20.m lab21.m

```
1 num=[12]
2 den=[1 7 12]
3 sys=tf(num,den)
4 [mr,wr]=getPeakGain(sys)
5 wb=bandwidth(sys)
6 bode(sys)
7 margin(sys)
8
```

Command Window

New to MATLAB? See resources for [Getting Started](#).

den =

$$\frac{12}{s^2 + 7s + 12}$$

Continuous-time transfer function.

mr =

1

wr =

0

wb =

2.1927

fx >>

Type here to search

U: 0.00 kbit/s D: 0.00 kbit/s

ENG IN 1:16 PM 28-Jan-21

MATLAB R2020a

HOME PLOTS APPS EDITOR PUBLISH VIEW

New Open Save Find Files Go To Find Insert Comment Indent Breakpoints Run Run and Advance Run Section Advance Run and Time

FILE NAVIGATE EDIT BREAKPOINTS RUN

C:\Windows\System32

Current Folder

Name

- 0409
- 1033
- AdvancedInstallers
- am-et
- AppLocker
- appraiser
- ar-SA
- bg-BG
- Boot
- Bthprops
- catroot2
- CatRoot
- CodeIntegrity
- Com
- config
- Configuration
- ContainerSettingsProviders
- cs-CZ
- da-DK
- DDFs
- de-DE
- DiagSvc
- Dism
- downlevel

Details

Select a file to view details

Editor - D:\New folder\CS\_Lab\lab21.m

```
1 num=[100]
2 den=[1 10 100]
3 sys=tf(num,den)
4 [mr,wr]=getPeakGain(sys)
5 wb=bandwidth(sys)
6 bode(sys)
7 margin(sys)
8
```

Command Window

New to MATLAB? See resources for [Getting Started](#).

den =

1 10 100

sys =

100

-----

$s^2 + 10s + 100$

Continuous-time transfer function

mr =

1.1547

wr =

7.0610

wb =

12.7119

fx >>

U: 0.00 kbit/s  
D: 0.00 kbit/s

ENG IN 1:19 PM 28-Jan-21