



SPREAD: Chopper mode selection
 GND or Pin open / not available=StealthChop. Automatic switching to SpreadCycle in dependence of the step frequency can be programmed via OTP;
 VCC_IO=SpreadCycle.
 MS1、MS2: Microstep resolution configuration (internal pull-down resistors)MS2, MS1: 00: 1/8, 01: 1/32, 10: 1/64 11: 1/16