

Transparent three legged sensors must be fitted with the flat surface at the rear and the little dome pointing over the board and towards the laser. Connecting them incorrectly WILL destroy them.

Caution
To avoid sensor damage, wire up the rx modules BEFORE plugging the transparent sensors into them. Double check wiring BEFORE powering up the board & ensure LEDs light. Then de-power the board and insert sensors ENSURING the sensor is fitted the correct way round.

