



AccurET Modular 48 Position Controllers

Hardware Manual

Version J

ETEL

THIS PAGE IS INTENTIONALLY LEFT BLANK

Table of contents

1	Introduction	6
1.1	Safety	6
1.2	Presentation	7
1.2.1	Working principle	7
1.2.2	Applications	7
1.2.3	General operating conditions	7
1.2.4	Transport and storage conditions	7
1.2.5	Unpacking, packing and handling	8
1.2.6	Installation and initial operation	8
1.2.7	Maintenance operations	8
1.3	Connection diagram	9
1.3.1	Top view	9
1.3.2	Front view	9
2	Models characteristics	10
2.1	Outline and dimensions	10
2.1.1	Controller without optional board slot	10
2.1.2	Controller with optional board slot	11
2.2	Block schematics	12
2.3	Ratings	13
2.4	Mounting	15
2.4.1	Hardware mounting	15
2.4.2	Fan power, control input and power input wiring	17
2.5	Ordering information	20
2.5.1	Position controller	20
2.5.2	Cooling unit	21
2.5.3	Mounting bar	21
2.5.4	AccurET kits	21
3	Electrical interface	22
3.1	Communication connectors	23
3.1.1	USB communication (connector X00)	23
3.1.2	TransnET / Ethernet input (connector X01)	23
3.1.3	TransnET output (connector X02)	23
3.2	Encoder connectors (connectors X10 and X20)	23
3.2.1	Incremental analog encoder (1 Vpp)	24
3.2.2	Absolute encoder (EnDat 2.1)	25
3.2.3	Absolute encoder (EnDat 2.2)	26
3.2.4	TTL encoder	26
3.2.5	Dual encoder feedback	27

3.3	Inputs / outputs connectors (connectors X11 and X21)	28
3.3.1	Digital inputs (connectors X11 and X21)	28
3.3.2	Digital outputs (connectors X11 and X21)	30
3.4	Motor connectors (connectors X12 and X22)	32
3.5	Power connectors	32
3.5.1	At the position controller level	33
3.5.2	At the fan input	34
3.6	Download key (connector X102)	34
3.7	Axis number selection (connector X101)	34
3.8	Optional board	35
3.9	Ground connection	35
3.10	Cables manufacturing	36
3.10.1	Encoder and input/output cables	36
3.10.2	Motor cable	37
3.11	LEDs meaning	37
3.11.1	Communication	37
3.11.2	Motor	38
4	Service and support	39

Record of revisions:

Document revisions		
Version	Date	Main modifications
Ver A	18.01.10	First version
Ver B	10.01.11	Updated version: - New UL certification laboratory (TUV) - Minor changes
Ver C	14.06.13	Updated version: - Addition of the specific points concerning the hardware revision 2 (EA-P2M-048-xxxxxx-xxxx- 01)
Ver D	08.05.14	Updated version: - Minor changes
Ver E	05.12.14	Updated version: - Dual encoder feedback connection (refer to §3.2.5) - Technical details added
Ver F	06.07.16	Updated version: - EMC Directive 2004/108EC replaced by 2014/30/EU - Minor changes
Ver G	30.11.18	Updated version: - Inductance calculation (refer to §2.3) - Include new product codification for EtherCAT variant (refer to §2.5.1)
Ver H	17.05.19	Updated version: - Minor modification concerning Hall effect sensor (refer to §3.3.1)
Ver I	26.11.19	Updated version: - I/O commutation times updated (refer to §3.3.1 & §3.3.2)
Ver J	14.09.21	Updated version: - Minor changes

Documentation concerning the AccurET Modular 48:

- | | |
|-------------------------------|---|
| • Hardware Manual | Specifications & electrical interfaces |
| • Operation & Software Manual | AccurET setup, use & programming |
| • Service Manual | Maintenance of the fuse |



UL 508C The AccurET Modular 48 position controllers have been successfully tested and evaluated to meet the UL 508C for US market.

This standard describes the fulfillment by design of minimum requirements for electrically operated power conversion equipment which is intended to eliminate the risk of fire, electrical shock, or injury to persons being caused by such equipment.

1. Introduction

This document concerns a two axes position controller of ETEL's AccurET family: the AccurET Modular 48 (EA-P2M-048-xxxxxA-xxxx-xx) also called 'controller' in this document.

The purpose of this manual is to give details regarding the specifications, installation, interfacing and hardware items. All details for proper connections are provided herein. Detailed information concerning the programming of the controller is provided in the corresponding '**Operation & Software Manual**'.



Remark: The updates between two successive versions are highlighted with a modification stroke in the margin of the manual.


1.1 Safety

The user must have read and understood this documentation before carrying out any operation on an AccurET Modular controller. Please contact ETEL or authorized distributors in case of missing information or doubt regarding the installation procedures, safety or any other issue.



ETEL SA disclaims all responsibility to possible industrial accidents and material damages if the procedures & safety instructions described in this manual are not followed (including the ones given in the manuals listed [page 5](#)).

- Never use the controller for purposes other than those described in this manual.
- A competent and trained technician must install and operate the controller, in accordance with all specific regulations of the respective country concerning both safety and EMC aspects.
- Troubleshooting and servicing are permitted only by ETEL's technicians and agreed distributors.
- The customer must provide at anytime the appropriate protections against electrical direct contact and moving parts of the connected system. Operating the controller will make the motor move.
- The safety symbols placed on the controller or written in the manuals ([page 5](#)) must be respected.
- If the controller is integrated into a machine, the manufacturer of this machine must establish that it fulfils the 2014/30/EU directive on EMC before operating the controller.



Signals a danger of electrical shock to the operator.
Can be fatal for a person.



Signals a danger for the controller. Can be destructive for the material. A danger for the operator can result from this.



Indicates electrostatic discharges (ESD), dangerous for the controller.
The components must be handled in an ESD protected environment, only.

Remark: The controller associated to its motor connector complies with the 2014/30/EU directive on EMC.

1.2 Presentation



1.2.1 Working principle

AccurET position controllers are proposed in a modular format dedicated to multi-axis applications where a single power supply unit (not provided) is able to power many AccurET units to minimize the space required for the Electronics. Their modular cooling unit as well as their versatile design allow several configurations. These controllers include on a single board, the control circuits, the power bridge and all the necessary interfaces for the communication, the encoders and the inputs/outputs for two motors.

1.2.2 Applications



The AccurET modular 48 can drive two, single-phase, two-phase or/and three-phase motors. This controller can drive brushless motors, DC motors, steppers, etc. They must also be implemented with analog incremental 1 Vpp encoder, or absolute encoder (EnDat 2.1 and EnDat 2.2) or TTL encoders. Digital Hall effect sensor can also be connected to the controller. It is also possible to drive stepper motors in open loop (no need of encoder in this case).

1.2.3 General operating conditions

	<ul style="list-style-type: none"> - The AccurET controller is an open type device and must be installed in an enclosure providing electrical, mechanical and fire protection as well as controlled environment such as temperature, humidity, and pollution degree 2,...(refer to UL 508C and EN 61800-5-1 standards for more information). - Never switch the unit ON outside of the enclosure. - The controllers supply inputs (X100 and X104) must be connected to power supplies that ensure the reinforced insulation between mains and output and provide overvoltage category II (refer to EN 61800-5-1 and UL 508C standards for more information). - All control voltages or all connections (except Mains) must fulfill requirements for Limited Voltage Circuits/ Isolated Secondary Circuits. - The controllers must have its control input (X100) connected to a power supply with SELV outputs (Isolated secondary output) and its power input (X104) connected to a power supply of maximum +48V DC (isolated secondary) with a maximum short circuit current of 500 A. - The control input 0 VDC is internally connected to the Protective Earth (PE).
	<ul style="list-style-type: none"> - The AccurET modular 48 are designed to operate in a non-aggressive and clean environment, within a humidity range of 10 % and 85 %, an altitude < 2000 m (6562 ft), and a temperature range between +10 °C (50 °F) and +40 °C (104 °F). - The AccurET modular 48 are intended for use in the second environment⁽¹⁾. - The AccurET modular 48 are not designed or intended for use in the on-line control of air traffic, aircraft navigation and communications as well as critical components in life support systems or in the design, construction, explosive atmosphere, operation and maintenance of any nuclear facility. - ETEL recommends limiting the vibration level of AccurET controllers by not mounting them on highly dynamic moving parts.

⁽¹⁾: Definition of Second Environment in product standard EN 61800-3 (2004): Environment that includes all establishments other than those directly connected to a low-voltage power supply network which supplies buildings used for domestic purposes (industrial areas and technical areas of any building fed from a dedicated transformer are examples of second environment locations).

1.2.4 Transport and storage conditions

	<ul style="list-style-type: none"> - During the transport and the storage, the controller and the corresponding power supply must remain inside their original packaging which complies with the ESD standard.
	<ul style="list-style-type: none"> - The transport conditions must respect the class 2K3 of the IEC 60721-3-2 standard (temperature between -25 °C (-13 °F) and +70 °C (+158 °F), and humidity < 95 % without condensation). - The storage conditions must respect the class 1K2 of the IEC 60721-3-1 standard (temperature between +5 °C (+41 °F) and +45 °C (+113 °F), and humidity between 5 and 85 % without condensation).

1.2.5 Unpacking, packing and handling

When removed from the original packaging, the controller shall be manipulated with ESD protective equipment. The housing of the controller protects the inner components, but discharges might occur when touching the connectors, which are in direct contact with the electronic components.

If the controller must be transferred or shipped (including returns to ETEL for service and repair), it must be packed in the original package.

Before unpacking the controller, the unit shall be placed in the room at working environmental conditions (in accordance with the requirements stated in §1.2.3) during at least 2 hours. This is to avoid damages due to condensation. If the controller is transferred in the operating room within a complete system, the acclimation time shall be adapted to the thermal inertia of the complete system.

1.2.6 Installation and initial operation

- Mechanical mounting: refer to §2.4.
- Electric Interface: refer to §3.
- Operating and software: refer to “Operation & Software Manual”.

The AccurET modular 48 is intended to move axes, and this can lead to some risks at the machine level:

Warning



Faulty machine performance

Collision with persons, property damage to machine

- Inappropriate use may cause considerable damage to persons or property. ETEL does not accept any responsibility for direct or indirect damage caused to persons or property through improper use or incorrect operation of the machine.
- Before switch-on, close the electrical cabinet
- Commissioning is to be performed only by qualified personnel
- Remember that kinetic energy is stored in the movable parts of a machine and that it may continue to move without braking if the servo drives suddenly fail.
- During initial switch-on after installation, maintain a safe distance from the inverters or power stages and drives. If malfunctions occur, switch off the power supply of the system, and contact qualified personnel.

Notice



Prior to the following tests, the machine or system must be disconnected from the power supply and tested for zero voltage!


- The continuity of the protective conductor circuit is to be inspected (10 A testing current is recommended), EN 60204-1.
- Check the protective conductor contact resistance according to EN 60204-1, EN 61800-5-1 or a nationally valid standard.
- Conduct a visual inspection on the security of all connections, in particular of the protective conductor connections.
- For the correct grounding of protective conductor of the controller, please refer to §3.9.
- Ensure that no flammable objects are near the vent openings.

1.2.7 Maintenance operations


No maintenance operation is required. No replacement of safety-related components is necessary during the lifetime of the product.

1.3 Connection diagram

1.3.1 Top view



1.3.2 Front view




Remark: Refer to [§3](#) for more information. A wider version also exist to include an optional board.

2. Models characteristics

Depending on the possibility to have or not an optional board, there are two different widths for the controller AccurET 48 (50 mm and 75 mm).

2.1 Outline and dimensions


2.1.1 Controller without optional board slot



Remark:


If the user needs the ETEL's cooling system, the center-to-center distance between the screws at the top of the controller and the bottom screws used to fix the mounting bar is 169 mm (refer to §2.4). It is recommended to leave 100 mm above and under the controller to guarantee an air flow (the fan power depends on the user application). **Caution: some magnetic components like the fans (not those present in ETEL's cooling unit) may perturb the current measurement of the controller if they are too close.** If this problem occurs, use another type of fan or increase the distance between **the fan and the controller** while ensuring the following minimum air flow: 30 m³/h for a 50 mm width and 45 m³/h for a 75 mm width. **A fan is compulsory with a 05/10 A controller but optional with a 2.5/5 A if the ambient air flow is enough.**

2.1.2 Controller with optional board slot



Remark: If the user needs the ETEL's cooling system, the center-to-center distance between the screws at the top of the controller and the bottom screws used to fix the mounting bar is 169 mm (refer to §2.4). It is recommended to leave 100 mm above and under the controller to guarantee an air flow (the fan power depends on the user application). **Caution: some magnetic components like the fans (not those present in ETEL's cooling unit) may perturb the current measurement of the controller if they are too close.** If this problem occurs, use another type of fan or increase the distance between the fan and the controller while ensuring the following minimum air flow: 30 m³/h for a 50 mm width and 45 m³/h for a 75 mm width. **A fan is compulsory with a 05/10 A controller but optional with a 2.5/5 A if the ambient air flow is enough.**

2.2 Block schematics



2.3 Ratings

All the specifications are given for an ambient temperature ranging from +10 °C (50 °F) to +40 °C (104 °F). **A fan is compulsory with a 05/10 A controller but optional with a 2.5/5 A if the ambient air flow is enough.**

EA-P2M-048 POWER FEATURES				
Characteristics		EA-P2M-048-2.5/5A	EA-P2M-048-05/10A	
Output to the motor (per axis)	Bus voltage	Max. 48 VDC		
	Current range on product label	2.5 / 5 Arms	05 / 10 Arms	
	Measurable current - full range	8.5 A	17 A	
	Motor ripple at 40 kHz (PWM at 20 kHz)	Three-phase motor Max. full load current	3.5 A (2.5 Arms)	7 A (5 Arms)
		Three-phase motor Max. overload current	7 A (5 Arms) (2 s)	14.1 A (10 Arms) (2 s)
	Motor ripple at 20 kHz (PWM at 10 kHz)	Three-phase motor Max. full load current	3.5 A (2.5 Arms)	7 A (5 Arms)
		Three-phase motor Max. overload current	7 A (5 Arms) (2 s)	14.1 A (10 Arms) (2 s)
	Motor ripple at 40 kHz (PWM at 20 kHz)	Two-phase motor Max. full load current	3.5 A (2.5 Arms)	7 A (5 Arms)
		Two-phase motor Max. overload current	7 A (5 Arms) (2 s)	14.1 A (10 Arms) (2 s)
	Motor ripple at 20 kHz (PWM at 10 kHz)	Two-phase motor Max. full load current	3.5 A (2.5 Arms)	7 A (5 Arms)
		Two-phase motor Max. overload current	7 A (5 Arms) (2 s)	14.1 A (10 Arms) (2 s)
	Motor ripple at 40 kHz (PWM at 20 kHz)	One-phase motor Max. full load current	3.5 A (2.5 Arms)	7 A (5 Arms)
		One-phase motor Max. overload current	7 A (5 Arms) (2 s)	14.1 A (10 Arms) (2 s)
	Motor ripple at 20 kHz (PWM at 10 kHz)	One-phase motor Max. full load current	3.5 A (2.5 Arms)	7 A (5 Arms)
		One-phase motor Max. overload current	7 A (5 Arms) (2 s)	14.1 A (10 Arms) (2 s)
Power input (X104 connector)	DC voltage	15 - 48 VDC		
	Max. continuous input current	10 Arms		
	Max. peak input current	18 A (40 ms)		
	DC bus capacitor	440 µF		
Control input (X100 connector)	DC voltage	24 VDC (±10%)		
	Max. current at 24 VDC	Typ. 1.3 A ⁽¹⁾ / Max. 2.5 A		
	DC bus capacitor	2200 µF		

(1): The current can change depending on the type(s) of encoder(s), the type of optional board as well as the number of inputs/outputs used. A current equal to about twice the above-mentioned typical value can be necessary to switch on the controller (because of the inrush pulse).

Remark: The values of current in the table above are given for a two or three-phase sinusoidal current. If a DC current is requested (motor at standstill, or very low speed), these values can be divided by a factor up to $\sqrt{2}$.

When the current ripple in the motor becomes too important, it could limit the performance of the control loops or even overheat the motor. To avoid this, the inductance of the motor must comply with the following formula:

$$\frac{L1 \cdot I_p \cdot \sqrt{2}}{\alpha} \geq \frac{V_{PWR}}{f_{PWM}}$$

Where:

- L1: inductance of the motor [mH] (terminal to terminal)
- I_p: peak current of the motor [Arms]
- V_{pwr}: DC bus voltage of the position controller [V]
- f_{PWM}: controller PWM frequency [kHz]
- α: constant, depending on use cases:
 - α = 2 when f_e ≤ 100Hz
 - α = 4 when f_e > 100Hz
- f_e: electrical frequency of motor phases [Hz]

For a rotary motor, it is defined as:

$$f_e = \frac{n}{60} \cdot p$$

n: speed of the rotary motor [rpm]
p: number of pair of poles (2p is the number of poles)

For a linear motor, it is defined as:

$$f_e = \frac{v}{2T_p}$$

v: speed of the motor [mm/s]
2T_p: magnetic period [mm]

Remark: In case the formula is not complying, the user could add external inductance on each phase of the motor.

Example using an ETEL ironless linear motor (ILF03-030):

2T_p = 32 mm
L1 = 3.22 mH
R = 5.0 Ω
I_p = 7.11 Arms
v = 1000 mm/s
f_{PWM} = 20 kHz
V_{pwr} = 48 V

Electrical frequency:

$$f_e = \frac{1000}{32} = 31.25 \text{ Hz}$$

Constant α = 2 (as f_e < 100 Hz)

Verification that the inductance of the motor is big enough:

$$\frac{3.22 \cdot 7.11 \cdot \sqrt{2}}{2} \geq \frac{48}{20} \Rightarrow 16.2 \geq 2.4 \Rightarrow \text{There is no risk}$$

EA-P2M-048 CONTROL FEATURES		
General	Motion profile and command management sampling time	400 μ s
	Digital current loop sampling time	50 μ s
	Position loop sampling time	50 μ s
	Motion profiles	Trapezoidal / S-curve / sine / look-up table / ... / interpolated (UltimET)
	Processor	SHARC Digital Signal Processor, 40 bits floating point
Standard interfaces	USB 2.0 (for setting only)	Full speed (12 Mbps)
	TransnET Ethernet	1 Gbps 10 / 100MHz
Position encoders interfaces	Analog 1Vpp	Max. 500kHz in. / Up to 2'048 (x4) interpolation factor
	EnDat 2.1 and 2.2 (absolute encoder)	RS485
	Encoder limit switch (EHO/L1 & ELS/L2 signals)	TTL signal
	Digital (TTL high speed)(*)	Max. 10MHz input frequency
User's inputs / outputs	Digital input	4 per motor
	Fast digital input	6 (common to both motors)
	Digital output	2 per motor
	Fast digital output	4 (common to both motors)
	Analog input	0
	Analog output	0
Software / programmability	ComET commissioning software	For software compatibility, refer to the ComET manual
	EDI (DLL files for C and C++)	For software compatibility, refer to the EDI manual
	Firmware update	USB and TransnET

(*): the period frequency (2.5MHz) is one fourth of the counter frequency (10MHz)

2.4 Mounting





The controller has the following electrical safety degree: IP 20 (according to EN 60529 standard). The AccurET controller must be installed in an enclosure providing electrical, mechanical and fire protection as well as adapted environment such as temperature, humidity, pollution degree 2,...(refer to UL 508C and EN 61800-5-1 standards for more information).


2.4.1 Hardware mounting


The controller should be protected against any splashes of liquid and any contacts with smoke and dust. It must be installed inside a closed cabinet and mounted as mentioned below. The ground must be connected prior to any other connections (refer to §3.9 for more information). Fresh air is necessary to cool the controller (05/10 A) inside the cabinet. It is recommended to leave 100 mm above and under the controller to guarantee an air flow (the fan power depends on the user application). **Caution: some magnetic components like the fans** (not those present in ETEL's cooling unit) **may perturb the current measurement of the controller if they are too close**. If this problem occurs, use another type of fan or increase the distance between **the fan and the controller** while ensuring the following minimum air flow: 30 m³/h for a 50 mm width and 45 m³/h for a 75 mm width.



There are three different ways to fasten the controller:

- The ETEL's cooling system is required. In that case, the procedure described hereafter must be followed.
- The user does not need the ETEL's cooling system as well as the mounting bar. In that case, only 4 screws are needed to fasten it. Refer to §2.1 to have the dimensions.
- The user does not need the ETEL's cooling system but wants to use the mounting bar. In that case, the step 1 and 2 of the procedure mentioned below must be followed (refer also to §2.1 to have the dimensions).

Step 1	Step 2
	
<p>The drilling must be realized. The center-to-center distance between the screws at the top of the controller and the bottom screws used to fix the mounting bar is 169 mm. The pitch between each screw belonging to the same row is 25 mm.</p>	<p>Fasten the mounting bar with M5 screws</p>

Step 3

<p>Put the fans in position and fix them with the black clamp pins (2 per fan)</p>

Step 4

<p>Screw, half way, the top screws</p>









Remark: A fan is compulsory with a 05/10A controller but optional with a 2.5/5A as the ambient air flow is enough.


The mounting bar and ETEL's fans are identical whatever the AccurET modular product.

2.4.2 Fan power, control input and power input wiring

All connectors corresponding to the power input voltage of the fans as well as the control and power input voltage of the controller (going to the top of each connected controllers) are connected all together with the type of connector delivered by ETEL. These connectors are self-strip connectors and are delivered only if the connectors kit is ordered. The user must correctly size his power supply according to the number of controller (with or without optional board) connected together.

Here is the procedure to manufacture the wiring:

 <p>Front view</p>  <p>Side view</p>	<p>1) Insert the cable in the slot.</p> <p>Caution: Use only wire with a section from 0.5 mm² (AWG 20) to 1 mm² (AWG 18).</p>
 <p>Before</p>  <p>After</p>	<p>2) Push down the upper part (orange) with a screwdriver for example.</p> <p>Caution: It is forbidden to realize this operation with the connector plug on the controller. It must be done before plugging it into the controller.</p> <p>Be careful, not to get your finger caught when pushing down.</p>
	<p>3) To check if the upper part has been pushed enough, the orange pin must be visible in the black cut-out.</p> <p>4) Repeat the steps 1 to 3 for the other wires. 4 wires are needed per control input connector, 3 per power input connector and 2 for the fan power connector.</p> <p>5) Repeat the steps 1 to 4 for the other connectors. There are as many control and power input connectors as controllers. The number of fan power connectors depends on the width of the fan (refer to §2.5.2).</p> <p>6) The wires after the last connectors must be cut short.</p>
	<p>Here is an example with two controllers.</p> <p>Caution: the length of the wires between 2 connectors must take into account the length lost inside the connector and the fact that the distance may change depending on the controller's width.</p>



2.5 Ordering information

Here is the ordering information describing the meaning of each digit present on each product:

2.5.1 Position controller

	EA	-	P	2	M	-	048	-	2.5/5A	-	0	0	0	0	-	0	0
Family code: EA = Electronics AccurET																	
Product type / technology: P = PWM																	
Axis number: 2 = Dual axis																	
Format: M = Modular																	
Maximum operating DC voltage: 048 = 48VDC																	
Continuous / peak current: 2.5/5A = 2.5 / 5 Arms 05/10A = 05 / 10 Arms																	
Reserved																	
Optional board slot: 0 = No 1 = Yes																	
Standard: 0 = UL 508C compliant(*) 9 = Not UL 508C compliant(**)																	
EtherCAT Option (or future software option) 0 = No EtherCAT 2 = EtherCAT supported																	
Customer's specification: 00 = Standard product: hardware revision 1 01 = Standard product: hardware revision 2 (compatible from firmware version 2.06A of November 2012 software package)																	

(*): By default, all products are compliant.

(**): May exceptionally occur during product life time. Should this happen, customer would be officially notified in case it may be unacceptable.

2.5.2 Cooling unit

	EA	-	CU	M	-	125	-	BT	-	0	0
Family code: EA = Electronics AccurET											
Product type / technology: CU = Cooling Unit											
Format: M = modular											
Size: 75 = 75 mm 100 = 100 mm 125 = 125 mm											
Type: BT = Bottom to Top air flow (by default) TB = Top to Bottom air flow (performances 25% lower compared to BT)											
Reserved											
Reserved											

Remark: The width of the fans depends on the width of the selected controllers.
A fan is compulsory with a 05/10 A controller but optional with a 2.5/5 A as the ambient air flow is enough.
ETEL's fans are identical whatever the AccurET modular product.

2.5.3 Mounting bar

EA										-	MB		M	-	300	-	0	0
Family code:										EA = Electronics AccurET								
Product type / technology:										MB = Mounting Bar								
Format:										M = modular								
Size:										300 = 300 mm								
Reserved																		
Reserved																		

Remark: The mounting bar is identical whatever the AccurET modular product.

2.5.4 AccurET kits

	EA	-	BCK	-	P2M	-	48	-	00
Family code: EA = Electronics AccurET									
Product type / technology: BCK = Black Connectors Kit STK = Starting Kit SHK = Shielding kit									
Product type: P2M = Modular position controller 2 axes									
Voltage: 048 = suitable for 48 VDC controller									
Reserved									

3. Electrical interface

This chapter describes the pin assignment for every connector. More detailed explanations for proper connections are given in each case.

Here is the list of the groups of connectors, according to their function:

Communication connectors (refer to [§3.1](#)).

Encoders connectors (refer to [§3.2](#)).

Inputs / outputs connectors (refer to [§3.3](#)).

Motor connectors (refer to [§3.4](#)).

Power connectors (refer to [§3.5](#)).





Download key connector (refer to [§3.6](#)).

Node number switch (refer to [§3.7](#)).



Optional board slot (refer to [§3.8](#)).

Remark: **Avoid misalignment of male and female connector as well as insertion of other connector than the one intended to receive it.**

In the next paragraphs, connectors with male pins are indicated with the • symbol (full), and female pins are represented with the ○ symbol (empty).

	Before connecting or disconnecting a cable on one of these connectors or touching the controller, turn off all the power supplies and wait 2 minutes to allow the internal DC bus capacitors to discharge. Always connect the ground prior to any other connection.
	Low voltage and data signals are not insulated from Protective Earth (PE). The motor connectors must always be correctly screwed onto the controller.
	All the connectors must be handled in an ESD protected environment, only.
	This is a product of the restricted distribution class according to IEC61800-3. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

3.1 Communication connectors

	Signals are not insulated from Protective Earth (PE).
	The communication connectors must be handled in an ESD protected environment, only.

The communication between a host (PC) and a controller is obtained via a USB protocol (connector X00). The communication between the controllers and the master (UltimET) is obtained via a TransnET (ETEL's property) protocol. To do so, the connectors X01 and X02 are used to make a daisy chain with standard RJ-45 cables.

3.1.1 USB communication (connector X00)

The USB 2.0 (full speed) communication is used for the setting and the monitoring of the controller. The USB connector is a «Type B» connector.

3.1.2 TransnET / Ethernet input (connector X01)

This input, mentioned «COM IN» (COMmunication INput) on the front panel of the controller, is used to connect the input cable of the ETEL TransnET or the Ethernet communication. **Both communications are not possible at the same time.** The Ethernet connection is used to directly connect the PC to a single controller.



Remark: The RJ-45 cable must meet the following characteristics: 1:1 shielded cable, category 5E SFTP with 8 wires. The cumulated length of all TransnET cables must not exceed 100m.

3.1.3 TransnET output (connector X02)

The TransnET output, mentioned «COM OUT» (COMmunication OUTput) on the front panel of the controller is used to connect the output cable of ETEL's TransnET communication. For the last controller, this connector is not used as the incoming and outgoing data run through the same cable.

Remark: The RJ-45 cable must meet the following characteristics: 1:1 shielded cable, category 5E SFTP with 8 wires. The cumulated length of all TransnET cables must not exceed 100m.

3.2 Encoder connectors (connectors X10 and X20)


	Signals are not insulated from Protective Earth (PE). Avoid proximity with noisy power cable.
	The encoder connectors must be handled in an ESD protected environment, only.

Remark: The encoder cable(s) connected to the controller must be shielded (refer to [§3.10.1](#)).
The connector X10 is used to connect the encoder of motor 1 and X20 for the one of motor 2.

Three different types of encoder can be connected to the encoder connectors: either an incremental analog 1 Vpp encoder or an absolute encoder (EnDat 2.1 and 2.2) or a true TTL encoder.

3.2.1 Incremental analog encoder (1 Vpp)

The incremental analog encoder has 1Vpp signals with a load resistor $R_0=120\Omega$. It determines the motor position thanks to two sinusoidal signals with a 90° phase-shift (sine and cosine). A third signal, the index (also called reference mark) gives the absolute motor position:



D-SUB, 15 pins, high density, female				
Encoder	Pin #	Signal	Function	Interface
	1	Reserved	Do not connect	
	2	Reserved	Do not connect	
	3	Reserved	Do not connect	
	4	+5VDC	Encoder supply output (protected by fuse F5 of 1.5 A)	
	5	GND	Encoder supply output (0V)	
	6	COS -	Cosine - signal input	
	7	SIN -	Sine - signal input	
	8	IDX -	Index - signal input	
	9	Reserved	Do not connect	
	10	EHO/L1	Encoder home switch input EHO or encoder limit switch L1 (TTL signal)	
	11	ELS/L2	Encoder limit switch input ELS or encoder limit switch L2 (TTL signal)	
	12	GND	Encoder supply output (0V)	
	13	COS +	Cosine + signal input	
	14	SIN +	Sine + signal input	
	15	IDX +	Index + signal input	



Remark: The +5VDC encoder supply output is protected by the fuse F5 (1.5 A) on X10 and X20. On the hardware revision 2 (EA-P2M-048-xxxxxx-xxxx-**01**), the fuse F5 has been replaced by a resettable fuse.

Refer to the corresponding 'Operation & Software Manual' for more information about the use of the EHO/L1 and ELS/L2 signals.

The connector X10 is used to connect the encoder of motor 1 and X20 for the one of motor 2.

3.2.2 Absolute encoder (EnDat 2.1)

The EnDat 2.1 is an **absolute encoder**. It has 1Vpp signals with a load resistor $R_0=120\Omega$. Its signals are similar to the incremental encoders (without the index), but it additionally includes a RS485 serial link (EIA standard, EnDat 2.1 interface) for the absolute position measure: EDT (serial data) and ECL (clock). The ECL (clock) signal is received from the controller. From its first falling edge (latch signal), the **absolute position will be defined within one incremental signal period** (depends on the encoder type)

D-SUB, 15 pins, high density, female				
Encoder	Pin #	Signal	Function	Interface
	1	EDT +	EnDat serial data I/O + / RS485	
	2	ECL +	EnDat clock output + / RS485	
	3	ECL -	EnDat clock output - / RS485	
	4	+5VDC	Encoder supply output (protected by fuse F5 of 1.5 A)	
	5	GND	Encoder supply output (0V)	
	6	COS -	Cosine - signal input	
	7	SIN -	Sine - signal input	
	8	Reserved	Do not connect	
	9	EDT -	EnDat serial data I/O - / RS485	
	10	Reserved	Do not connect	
	11	Reserved	Do not connect	
	12	GND	Encoder supply output (0V)	
	13	COS +	Cosine + signal input	
	14	SIN +	Sine + signal input	
	15	Reserved	Do not connect	


Remark: The +5VDC encoder supply output is protected by the fuse F5 (1.5 A) on X10 and X20. On the hardware revision 2 (EA-P2M-048-xxxxxx-xxxx-01), the fuse F5 has been replaced by a resettable fuse.

The cable used with an absolute encoder (EnDat 2.1) must have power wires with a minimum section to guarantee a sufficient voltage at the terminals of the encoder (refer to the data sheet of the encoder for more information).

The connector X10 is used to connect the encoder of motor 1 and X20 for the one of motor 2.

3.2.3 Absolute encoder (EnDat 2.2)

The EnDat 2.2 is an **absolute encoder**. It includes a RS485 serial link (EIA standard, EnDat 2.2 interface) for the absolute position measure: EDT (serial data) and ECL (clock). The ECL (clock) signal is received from the controller. Refer to the Heidenhain documentation for more information about the EnDat 2.2.

D-SUB, 15 pins, high density, female			
Encoder	Pin #	Signal	Function
	1	EDT +	EnDat serial data I/O + / RS485
	2	ECL +	EnDat clock output + / RS485
	3	ECL -	EnDat clock output - / RS485
	4	+5VDC	Encoder supply output (protected by fuse F5 of 1.5 A)
	5	GND	Encoder supply output (0V)
	6	Reserved	Do not connect
	7	Reserved	Do not connect
	8	Reserved	Do not connect
	9	EDT -	EnDat serial data I/O - / RS485
	10	Reserved	Do not connect
	11	Reserved	Do not connect
	12	GND	Encoder supply output (0V)
	13	Reserved	Do not connect
	14	Reserved	Do not connect
	15	Reserved	Do not connect


Remark: The +5VDC encoder supply output is protected by the fuse F5 (1.5 A) on X10 and X20. On the hardware revision 2 (EA-P2M-048-xxxxxx-xxxx-**01**), the fuse F5 has been replaced by a resettable fuse.


The cable used with an absolute encoder (EnDat 2.2) must have power wires with a minimum section to guarantee a sufficient voltage at the terminals of the encoder (refer to the data sheet of the encoder for more information) and a length of maximum 40m.

The connector X10 is used to connect the encoder of motor 1 and X20 for the one of motor 2.

3.2.4 TTL encoder

TTL encoders measure the motor position with 2 phase-shifted TTL signals. Each change of state of one of the signals corresponds to an increment of the motor position. A third signal (index) gives the motor reference position. The encoder TTL signals have to be compatible with the EIA standard RS422. These signals have the following form:




D-SUB, 15 pins, high density, female			
Encoder	Pin #	Signal	Function
	1	UA1 +	TTL1 + signal input
	2	UA2 +	TTL2 + signal input
	3	UA2 -	TTL2 - signal input
	4	+5VDC	Encoder supply output (protected by fuse F5 of 1.5 A)
	5	GND	Encoder supply output (0V)
	6	Reserved	Do not connect
	7	Reserved	Do not connect
	8	Reserved	Do not connect
	9	UA1 -	TTL1 - signal input
	10	UA0 -	TTL0 - signal input
	11	UA0 +	TTL0 + signal input
	12	GND	Encoder supply output (0V)
	13	Reserved	Do not connect
	14	Reserved	Do not connect
	15	Reserved	Do not connect

Remark: The +5VDC encoder supply output is protected by the fuse F5 (1.5 A) on X10 and X20. On the hardware revision 2 (EA-P2M-048-xxxxxx-xxxx-01), the fuse F5 has been replaced by a resettable fuse.

The connector X10 is used to connect the encoder of motor 1 and X20 for the one of motor 2. The period frequency (2.5MHz) is one fourth of the counter frequency (10MHz).



3.2.5 Dual encoder feedback

The dual encoder feedback is only possible with 1Vpp, TTL and absolute EnDat 2.2 encoders. Here are the 3 possible configurations:

D-SUB, 15 pins, high density, female			
Encoder	Pin #	1 Vpp / TTL (K76=1)	1 Vpp / EnDat 2.2 (K76=2) & EnDat 2.2 / 1 Vpp (K76=3)
		Signal	Signal
	1	UA1 +	EDT +
	2	UA2 +	ECL +
	3	UA2 -	ECL -
	4	+5VDC	+5VDC
	5	GND	GND
	6	COS -	COS -
	7	SIN -	SIN -
	8	IDX -	IDX -
	9	UA1 -	EDT -
	10	EHO/L1 or UA0 -	EHO/L1
	11	ELS/L2 or UA0 +	ELS/L2
	12	GND	GND
	13	COS +	COS +
	14	SIN +	SIN +
	15	IDX +	IDX +

Remark: Refer to the corresponding encoder table to know the function of each signal.

3.3 Inputs / outputs connectors (connectors X11 and X21)

	Signals are not insulated from Protective Earth (PE).
	The inputs/outputs connectors must be handled in an ESD protected environment, only.

Remark: The inputs/outputs cable(s) connected to the controller must be shielded (refer to [§3.10.1](#)).

The controller has:

- 4 standard digital inputs (DIN1, DIN2, DIN9 and DIN10) per motor and 6 **fast** digital inputs (FDIN1 to FDIN6) for both motors.
- 2 standard digital outputs (DOUT1 and DOUT2) per motor and 4 **fast** digital outputs (FDOUT1 to FDOUT4) for both motors.

Only inputs and outputs **interface** is considered here. Refer to the corresponding '**Operation & Software Manual**' for more information about the use of these inputs and outputs.

3.3.1 Digital inputs (connectors X11 and X21)


• Standard digital inputs

The digital inputs switch to '1' when a voltage ranging between +14VDC and +28VDC is applied between pins DIN+ of the corresponding input and GND.

The digital inputs switch to '0' when a voltage ranging between 0VDC and +3VDC to is applied between pins DIN+ of the corresponding input and GND. Any voltage between +3VDC and +14VDC will give an uncertain input value.

Remark: When using an external 'positive limit switch', connect it to DIN10.
When using an external 'negative limit switch', connect it to DIN9.
When using an external 'home switch', connect it to DIN2.

The auxiliary supply can be external to the controller, as shown below:



The commutation times of the above-mentioned inputs are as follows:

	Status	Maximum	Unit
DINs	0 => 1	30	ns
	1 => 0	30	ns

Remark: The above-mentioned times takes only the hardware into account and are measured with a driver with low output impedance. With a non-null impedance, the internal input capacitance (1nF) slow down the commutation time.

- **Fast digital inputs**

The fast digital inputs are common to both motors and can be used by the customer for synchronization, position capture, etc. The digital inputs switch to '1' when a voltage ranging between +2VDC and +5VDC is applied between pins DIN+ of the corresponding input and GND.

The digital inputs switch to '0' when a voltage ranging between 0VDC and +0.8VDC is applied between pins DIN+ of the corresponding input and GND. Any voltage between +0.8VDC and +2VDC will give an uncertain input value.


The commutation times of the above-mentioned inputs are as follows:

	Status	Maximum	Unit
FDINs	0 => 1	30	ns
	1 => 0	30	ns


Remark: The above-mentioned times takes only the hardware into account and are measured with a driver with low output impedance. With a non-null impedance, the internal input capacitance (1nF) slow down the commutation time.

- **Digital Hall effect sensor**

3 digital inputs (H1+, H2+ and H3+) which correspond to the 3 fast digital inputs, are used to connect a digital Hall effect sensor. This sensor is used for the motor commutation thanks to three digital signals (one for each Hall effect sensor). On the following graph, the Hall signals and the sine voltages between the motor phases are displayed:



The digital Hall effect sensors (H1, H2 and H3) must be connected as shown below:




External pull up resistors are not required. As described in §3.3.2, H1+, H2+, H3+ are connected internally to +5V through a 3K Ω pull up.

Remark: The connector X11 is used to connect the inputs/outputs of motor 1 and X21 for the ones of motor 2.

3.3.2 Digital outputs (connectors X11 and X21)

- **Standard digital outputs**

The +Vaux voltage used to supply the digital output is the same as the one present on the control input connector (X100). **Do not supply Vaux voltage on connector X11 or X21 but only on connector X100.** The maximum total current provided per digital output is limited to 500 mA but 800 mA all together.



Remark: This diagram shows the use of DOUT1, but it is the same with DOUT2.

The commutation times of the above-mentioned outputs are as follows:

	Status	Maximum	Unit
DOUTs	0 => 1	500	μ s
	1 => 0	500	μ s

Remark: The above-mentioned times takes only the hardware into account.

- **Fast digital outputs**






The fast digital outputs are common to both motors and can be used by the customer for triggers, encoder signals outputs, etc.

The commutation times of the above-mentioned outputs are as follows:

	Status	Maximum	Unit
FDOUTs	0 => 1	30	ns
	1 => 0	30	ns




Remark: The above-mentioned times takes only the hardware into account and not the output cable capacitance.

The connector X11 is used to connect the inputs/outputs of motor 1 and X21 for the ones of motor 2

D-SUB, 15 pins, high density, male				
I / O	Pin #	Signal	Function	Interface
	1	FDIN1 (X11) / FDIN4 (X21)	Fast digital input 1 + (H1+)	
	2	FDIN3 (X11) / FDIN6 (X21)	Fast digital input 3 + (H3+)	
	3	GND	External supply input (0V) for FDIN and FDOU (linked to the 0VDC of the connector X100)	
	4	DIN2 +	Digital input 2 +	
	5	DIN10 +	Digital input 10 +	
	6	FDIN2 (X11) / FDIN5 (X21)	Fast digital input 2 + (H2+)	
	7	+5VDC	Power supply output for Hall sensor (max 100 mA)	
	8	GND	External supply input (0V) for DIN and DOUT (linked to the 0VDC of the connector X100)	
	9	DIN1 +	Digital input 1 +	
	10	DIN9 +	Digital input 9 +	
	11	FDOU1 (X11) / FDOU3 (X21)	Fast digital output 1 + (±24 mA)	
	12	FDOU2 (X11) / FDOU4 (X21)	Fast digital output 2 + (±24 mA)	
	13	+Vaux	Power supply output provided by +24 VDC on connector X100 (fuse F2, 3.5 A - limits user's input current)(*)	
	14	DOUT1	Digital output 1 +	
	15	DOUT2	Digital output 2 +	


(*): On the hardware revision 2 (EA-P2M-048-xxxxxx-xxxx-01), the fuse F2 has been replaced by a resettable fuse.

3.4 Motor connectors (connectors X12 and X22)

	<p>Before connecting or disconnecting the motor cable or touching the controller, turn off all the power supplies and wait 2 minutes to allow the internal DC bus capacitors to discharge. When the power input voltage is higher than 26.4V, and since the motor output is non DC voltage, this is considered as an hazardous voltage according to IEC61800-5-1. Therefore there is a risk of electrical shock and adequate precautions have to be taken to avoid direct contact with motor output connections.</p> <p>Always connect the ground prior to any other connection.</p>
	<p>The motor connectors must be insulated (no contact) from the power and the mains. The motor connectors must always be correctly screwed onto the controller to respect the EMC standard.</p>
	<p>The motors connectors must be handled in an ESD protected environment, only.</p>



Remark: The motor cables connected to the controller must be shielded (refer to [§3.10.1](#)).

The controller can drive single-phase, two-phase and three-phase motors. Connectors X12 and X22 enable the supply of the motor phase(s).

Phoenix Contact MC 1.5/5-G-3.81 BK (plastic connector)					
MOTOR CONNECTION	Pin #	Signal	Function		
			Single-phase motor	Two-phase motor	three-phase motor
	1	PE	Protective earth	Protective earth	Protective earth
	2	PH1	Motor phase1 +	Motor phase1 +	Motor phase1
	3	PH2	Motor phase1 -	Motor phase1 -	Motor phase2
	4	PH3	Do not connect	Motor phase2 +	Motor phase3
	5	PH4	Do not connect	Motor phase2 -	Do not connect

Remark: The connector X12 is used to connect the motor 1 and X22 for the motor 2. It is compulsory to use the metallic bracket described in [§3.10.2](#). The associated connector can be ordered through the connector kit (refer to [§2.5.4](#)). If not, be sure to use a connector compatible with the above-mentioned one.


3.5 Power connectors

	<p>Before connecting or disconnecting the power cables or touching the controller, turn off all the power supplies and wait 2 minutes to allow the internal DC bus capacitors to discharge. Always connect the ground prior to any other connection.</p>
	<p>The power connectors must be handled in an ESD protected environment, only.</p>

Remark: The power cables connected to the controller must be shielded (refer to [§3.10.1](#)).

3.5.1 At the position controller level


3.5.1.1 Control input (connector X100)

Phoenix Contact MSTBA 2.5/4-G BK (plastic connector)			
Control	Pin #	Signal	Function
	1	+24VDC	Control input (24VDC (±10%))
	2	0VDC	Control input (0VDC)
	3	PS RDY	Power supply ready input
	4	PS OPEN	Power supply opened output


For safety reasons, always connect first the ground!

Remark: To ensure proper operation of the controller, it is recommended to wait for 1 second between two successive ON or OFF cycles (1 s minimum for the OFF state when ON/OFF/ON cycle and 1 s minimum for the ON state when OFF/ON/OFF).
The control input shall be supplied by an isolated power supply with SELV outputs (Isolated secondary output), rated 24VDC (±10%). The power supply must ensure the reinforced insulation between mains and output and provide overvoltage category II (refer to EN 61800-5-1 and UL 508C standards for more information).
The control input connector is located on the top of the controller.
The associated connector can be ordered through the connector kit (refer to [§2.5.4](#)). If not, be sure to use a connector compatible with the above-mentioned one.

The 'PS RDY' (Power Supply ReaDY) signal comes from the power supply and indicates that the voltage present on the DC bus can be used (with +24VDC) or not (with 0V). This signal must be connected to +24VDC. It is then possible to link pin 3 with pin 1.
The 'PS OPEN' (Power Supply OPENed) signal comes from each controller asking for a power interrupt (with +24VDC). The normal state is when the signal is at 0V.




3.5.1.2 Power input (connector X104)

Phoenix Contact MSTBA 2.5/3-G BK (plastic connector)			
Control	Pin #	Signal	Function
	1	+Vpwr	Power input (15VDC to 48VDC (±5%))
	2	0VDC	Power input (0VDC)
	3	PE	Protective earth

For safety reasons, always connect first the ground!

Remark: The power input shall be supplied by an isolated power supply with SELV outputs (Isolated secondary output), rated 48VDC (maximum). The power supply must ensure the reinforced insulation between mains and output and provide overvoltage category II (refer to EN 61800-5-1 and UL 508C standards for more information).
The power input connector is located on the top of the controller.
The associated connector can be ordered through the connector kit (refer to [§2.5.4](#)). If not, be sure to use a connector compatible with the above-mentioned one.

3.5.2 At the fan input

Phoenix Contact DFK-MSTB 2.5/2-G BK (plastic connector)			
Power input	Pin #	Signal	Function
	2	0VDC	Supply input (0VDC)
	1	+24VDC	Supply input (24VDC (±10%))

Remark: The current requirement according to the fan's width is as follows:
0.2 A for the 75 mm, 0.3 A for the 100 mm and 0.5 A for the 125 mm.
A fan is compulsory with a 05/10 A controller but optional with a 2.5/5 A as the ambient air flow is enough.

3.6 Download key (connector X102)

If the controller does not switch to 'wait for program' when the user wants to download a new firmware, there is an hardware override possibility to force this mode. To do so, plug the jumper (in any horizontal or vertical position) on the X102 connector, switch off and on the power, and the controller will switch to 'wait for program' to download a new firmware.

Remark: The download key jumper is located on the top of the controller.

3.7 Axis number selection (connector X101)

On top of the software possibility, it is possible to assign or to change the axis number of the controller with a DIP switch. After each starting, the controller takes the axis number given by the DIP switch except when all the switches are in the down position which means set to 1 (like in the picture below). In this case the axis number is set by the AXI command or the value previously saved in the controller or by the default value always equal to 1 (this default value is used when no AXI command has been executed or no save has been done).



The value given on the DIP switch represents a binary value (64 possibilities). The axes are numbered from 0 to 62 because the node 63 is reserved. If the DIP switch is not used, all the bit must be set to 1 (low position).

Example:




The axis number given by this DIP switch is equal to: $2^0 + 2^1 = 3$. Then, the second axis of the controller will have the number 4.

Remark: Each axis number must be different from all the others connected to the same TransnET communication bus. It is forbidden to have twice the same axis number on the same TransnET communication bus.
The DIP switch is located on the top of the controller.

3.8 Optional board

To install an optional board (like the UltimET light motion controller for example) inside the position controller, the user must use the following procedure:

- Work in an ESD protected environment, ground connected yourself.
- Turn off all the power supplies (main and control) and wait 2 minutes to allow the internal DC bus capacitors to discharge.
- Unplug all the cables connected to the position controller.
- Unscrew the two screws fastening the cover of the optional board area on the front panel of the controller (step 1).
- Slide carefully the optional board inside the controller by putting the PCB in the two cutouts (step 2).
- Push the board until the connection with the internal back panel connector is done.
- Screw the two screws present on the front panel of the optional board (step 3)




Remark: Follow in the reverse order the opposite actions of the above-mentioned steps to remove the UltimET light from the controller.
Refer to the ordering information ([§2.5](#)) to know which controller can accept an optional board.

3.9 Ground connection

The ground connection of the controllers is realized with the power input (PE signal of X104 connector).

Remark: If the ETEL cooling unit (refer to [§2.5.2](#)) is not used, it is possible to connect the ground cable to the M4 threaded hole present under the controller instead of the wire present on the X104 connector. In this case, the length of the screw (not provided) must not exceed 4 mm from the external surface of the controller box.



3.10 Cables manufacturing

If you do not use the cables delivered by ETEL, follow the shield recommendations below for those cables:


- The encoder cables: X10 and X20
- The inputs/outputs cables: X11 and X21
- The motor cables: X12 and X22

Simple shielded cable must be linked to the connector shells on both cable ends. Only full metallic conductive shells connector must be used. Shield with only aluminum foil (metallized plastic film) is forbidden!. Use only copper braid (85% covering shield). The shield must entirely cover all wires. 'Pig tails' connections are forbidden! The shield contact on 360° and a metallic cable clamp is necessary.


Remark: All the cables connected to the controller must have copper conductors only and an insulation standing at least 75 °C.
A bad shielding connection can perturb the encoder signal, phasing, etc.

3.10.1 Encoder and input/output cables

Here is an example of good shielding connection:




Here are two examples of bad shielding connections:



3.10.2 Motor cable

To respect the EMC standard, the following shielding bracket must be used with the motor connector. **It is compulsory to completely screw the two screws to the front panel of the controller.**



To remove the shielding bracket, slightly unscrew both screws (it is not necessary to remove them completely) fastening it to the controller and slide the bracket to the right.

Remark: The cable's radius of curvature must be taken into account to adjust the distance between the front plate of the controller and the cabinet.
The shielding bracket can be ordered through the connector kit (refer to [§2.5.4](#)).

3.11 LEDs meaning

The different LEDs present on the controller have the following meaning:

3.11.1 Communication


- The position controller is switched on without connection to a communication bus

LED regarding the communication	Meaning
<div style="display: flex; align-items: center; justify-content: space-around;"> <div style="text-align: center;"> COM IN X02 </div> <div style="text-align: center;"> COM OUT X02 </div> </div>	Orange LED is ON => The controller is switched on.

- The position controller is switched on and connected to a TransnET communication bus

LED regarding the communication	Meaning
<div style="display: flex; align-items: center; justify-content: space-around;"> <div style="text-align: center;"> COM IN X02 </div> <div style="text-align: center;"> COM OUT X02 </div> </div>	<p>Green LEDs is ON => The connection (link) is detected on each connector. Yellow LEDs is ON => The TransnET data are running on each connector.</p> <p>The 'COM OUT' connector of the last controller on the TransnET bus is not connected, however, the green and yellow LEDs are also on to indicate that the TransnET bus loops correctly on itself.</p>

- The position controller is switched on and connected to an Ethernet communication bus

LED regarding the communication		Meaning
COM IN X02		COM OUT X02
		<p>Orange LED is ON => The controller is switched on.</p> <p>Green LED is ON => The connection (link) is detected.</p> <p>Green LED is blinking => The controller is waiting for an IP address from a DHCP server.</p> <p>Yellow LED is flashing => An activity is running on the Ethernet.</p>

3.11.2 Motor

LED regarding motor 1 / 2	Status	Meaning
Red LED 'ERROR'	ON	Error on motor 1 / 2 => check monitoring M64
	OFF	No error on motor 1 / 2
Green LED 'POWER ON'	ON	Motor 1 / 2 is in 'power ON'
	OFF	Motor 1 / 2 is in 'power OFF' (*)

Remark: If the red LED 'ERROR' and the green LED 'POWER ON' are ON at the same time (not blinking), then the controller is waiting for the end of a firmware download ('Wait for program' mode). Refer to the corresponding 'Operation & Software' for more information.

The red LED 'ERROR' and the green LED 'POWER ON' can be OFF together when the motor 1 / 2 is without error and in power OFF

(*): If the dynamic braking is activated due to an error (refer to the Operation & Software manual), the power bridge transistors **are still switching** (shortcut at the motor phases output) while the 'POWER ON' green LED is OFF.

4. Service and support

For any inquiry regarding technical, commercial and service information relating to ETEL S.A. products, please contact your ETEL S.A. representative:

HEADQUARTER / SWITZERLAND	BELGIUM	CHINA
ETEL S.A. Zone industrielle CH-2112 Môtiers Phone: +41 (0)32 862 01 00 E-mail: etel@etel.ch http://www.etel.ch	HEIDENHAIN nv/sa Pamelse Klei 47 1760 Roosdaal Phone: +32 54 34 31 58 E-mail: sales@heidenhain.be	DR. JOHANNES HEIDENHAIN (CHINA) Co., Ltd No. 6, Tian Wei San Jie, Area A, Beijing Tianzhu Airport, Industrial Zone Shunyi District, Beijing 101312 Phone: +86 400 619 6060 E-mail: sales@heidenhain.com.cn
CZECH Republic	FRANCE	GERMANY
HEIDENHAIN s.r.o. Dolnomecholupská 12b 102 00 Praha 10 - Hostivar Phone: +420 272 658 131 E-mail: heidenhain@heidenhain.cz	HEIDENHAIN FRANCE SARL 2 avenue de la cristallerie 92310 Sèvres Phone: +33 (0)1 41 14 30 09 E-mail: sales@heidenhain.fr	DR. JOHANNES HEIDENHAIN GmbH Technisches Büro Südwest II Verkauf ETEL S.A. Schillgasse 14 78661 Dietingen Phone: +49 (0)741 17453-0 E-mail: tbsw.etel@heidenhain.de
GREAT-BRITAIN	ISRAEL (Representative)	ITALY
HEIDENHAIN (GB) Ltd. 200 London Road, Burgess Hill, West Sussex RH 15 9RD Phone: +44 (0)1444 247711 E-mail: sales@heidenhain.co.uk	MEDITAL COMOTECH Ltd. 36 Shacham St., P.O.B 7772, Petach Tikva Israel 4951729 Phone: +972 3 923 3323 E-mail: comotech@medital.co.il	ETEL S.A. Piazza della Repubblica 11 28050 Pombia Phone: +39 0321 958 965 E-mail: etel@etelsa.it
JAPAN	KOREA	SINGAPORE
HEIDENHAIN K.K. Hulic Kojimachi Bldg. 9F 3-2 Kojimachi, Chiyoda-ku Tokyo - 102-0083 Phone: +81 3 3234 7781 E-mail: sales@heidenhain.co.jp	HEIDENHAIN KOREA Ltd. 75, Jeonpa-ro 24beon-gil, Manan-gu, Anyang-si Gyeonggi-do, 14087, Korea Phone: + 82 31-380-5304 E-mail: etelsales@heidenhain.co.kr	HEIDENHAIN PACIFIC PTE. LTD 51 Ubi Crescent, Singapore 408593 Phone: +65 6749 3238 E-mail: info@heidenhain.com.sg
SPAIN (Representative)	SWEDEN	SWITZERLAND
Farresa Electronica, S.A. C/ Les Corts, 36 bajos ES-08028 Barcelona Phone: +34 93 409 24 91 E-mail: farresa@farresa.es	HEIDENHAIN Scandinavia AB Storsätragränd 5 127 39 Skärholmen Phone: +468 531 93 350 E-mail: sales@heidenhain.se	HEIDENHAIN (SCHWEIZ) AG Vieristrasse 14 CH-8603 Schwerzenbach Phone: +41 (0)44 806 27 27 E-mail: verkauf@heidenhain.ch
TAIWAN	THE NETHERLANDS	UNITED STATES
HEIDENHAIN CO., LTD. No. 29, 33rd road, Taichung Industrial Park Taichung 40768, Taiwan, R.O.C. Phone: +886 4 2358 8977 E-mail: info@heidenhain.tw	HEIDENHAIN NEDERLAND B.V. Copernicuslaan 34 6716 BM Ede Phone: +31 (0)318 581800 E-mail: verkoop@heidenhain.nl	HEIDENHAIN CORPORATION 333 E. State Parkway Schaumburg, IL 60173 Phone: +1 847 490 1191 E-mail: info@heidenhain.com

The technical hotline, based in ETEL S.A.'s headquarters, can be reached by:

- Phone: +41 (0)32 862 01 12.
- Fax: +41 (0)32 862 01 01.
- E-mail: support@etel.ch.

Please refer to your corresponding ETEL S.A. representative for more information about the technical documentation. ETEL S.A. organizes training courses for customers on request, including theoretical presentations of our products and practical demonstrations at our facilities.