

ASUSTeK COMPUTER INC.	EAH5750 Standard Operation Procedure	Doc. No:	
		Date: Mar.21, 2011 Revision:1.10	
		Page: 11	Grade:

Rev.	Modified Chapters	Modification Description	Issued Dept.	Issued by	Revised Date
1.00		First Release	GTC	Ariel_wang	Nov.9,2009
1.01		Add new P/N C1CNU0(A01)	GTC	Ariel_wang	Dec.4,2009
1.02		Add new P/N C1CNU5(A01)	GTC	Ariel_wang	Dec.10,2009
1.03		Add new PCBA C1CNU5(B01)	GTC	Ariel_wang	Apr.6,2010
1.04		Add new PCBA C1CNU5(B11)	GTC	Ariel_wang	Apr.20,2010
1.05		Add new P/N C1CNPK(A01)	GTC	Ariel_wang	Apr.22,2010
1.06		Add new PCBA C1CNU0(A15)	GTC	Chongling	May.5,2010
1.07		Add new P/N C1CNPP(A01)	GRMA	Ariel_wang	Feb.22,2011
1.08		Add new P/N C1CNUF(A01)	GRMA	Ariel_wang	Mar.15,2011
1.09		Add new PCBA C1CNUF(B01)	GRMA	Ariel_wang	Mar.21,2011
1.10		Add new PCBA C1CNPP(B01)	GRMA	Ariel_wang	Mar.21,2011

Authorize by		Review by		Originator By	Ariel
-----------------	--	--------------	--	------------------	-------

ASUSTeK COMPUTER INC	EAH5750 Standard Operation Procedure	Doc. No:
		Date: Mar. 21, 2011
		Rev. : 1.10 Page: 1

1.Objectives

Create test procedure.

2.Scope

Model: EAH5750

PN: C1CNP0(A01) C1CNU0(A01&A15) C1CNU5(A01&B01&B11)
C1CNPk(A01) C1CNPP(A01&B01) C1CNUF(A01&B01)

3.Test Item

3.1 Diagnostic test in 32-bit Linux system

3.2 3DMark06(contain HDMI test)

3.3 Temperature test

4.Relevant Document

None.

5.Definition : 1. If the model name contains P, please test HDCP function.

Ex: EAH***/HTDP/512M/A

2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI contains HDCP function.

3. System Memory: 1GB for a single GPU test station; please add an additional 512MB of system memory for each additional GPU used for the test configuration

ASUSTeK COMPUTER INC	EAH5750 Standard Operation Procedure	Doc. No:
		Date: Mar. 21, 2011
		Rev. : 1.10 Page: 2

6. Operation Procedures:

6.1 Attention

- 6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.
- 6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.
- 6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.
- 6.1.4 Some test items should be tested under Windows environment. **(Please install windows test environment by yourself).**

ASUSTeK COMPUTER INC	EAH5750 Standard Operation Procedure	Doc. No: Date: Mar. 21, 2011 Rev. : 1.10 Page: 3
----------------------	---	--

6.2 Fixture connect

6.2.1 Install Intel P5 CPU & CPU Fan.

6.2.2 Install DDR2 1GB Memory to DIMM1~4. **(a minimum memory of 2GB for Linux test)**

6.2.3 Plug USB Mouse and PS/2 Keyboard into MB.

6.2.4 Plug VGA Card EAH5750 into PCIEX16_1.

6.2.5 Connect power con of VGA card & Power supply via bundled power cable.

(6 PIN of Power supply to 6 PIN of VGA card)



C1CNP0

6.2.6 Connect SATA HDD & SATA con via SATA cable




SATA



6.2.7 Plug 4PIN 12V power **(a minimum power of 600W)** cable into CON12V.


6.2.8 Plug ATX Power on Power **(a minimum power of 600W)** Connector.




6.3 Certain test.

6.3.1 Diagnostic test in 32-bit Linux system

6.3.1.1 Please connect LCD monitor & card's DVI CON via a DVI cable.




Please connect LCD monitor & card's D-SUB CON via a D-SUB cable.



6.3.1.2 Press Power Switch then turn on power button.

6.3.1.3 Press "Del" to enter CMOS setup menu while boot screen is displaying.

EXIT -> Load Setup Defaults.



6.3.1.4 Run test program in linux.

Path: eah5750\c1cnp0a0.sh

Path: eah57501\c1cnu0a0.sh c1cnu5a0.sh c1cnu5b0.sh c1cnu5b1.sh c1cnpka0.sh

Path: eah57502\c1cnu0a1.sh

Path: eah57503\c1cnppa0.sh c1cnufa0.sh c1cnppb0.sh c1cnufb0.sh

Please enter into the file of eah5750, enter the following command: `cd ./eah5750`

Please enter into the file of eah57501, enter the following command: `cd ./eah57501`

Please enter into the file of eah57502, enter the following command: `cd ./eah57502`

Please enter into the file of eah57503, enter the following command: `cd ./eah57503`

ASUSTeK COMPUTER INC	EAH5750 Standard Operation Procedure	Doc. No: Date: Mar. 21, 2011 Rev. : 1.10 Page: 5
----------------------	---	--

```
root@diagtc:~#cd ./eah5750
```

Then, please run `./c1cnp0a0.sh`

Then, please run `./c1cnu0a0.sh c1cnu5a0.sh c1cnu5b0.sh c1cnu5b1.sh c1cnpka0.sh`

Then, please run `./c1cnu0a1.sh`

Then, please run `./c1cnppa0.sh c1cnufa0.sh c1cnppb0.sh c1cnufb0.sh`

6.3.1.5 Memory test

If you want to test memory, please run `./tserver-exec -test=memfa1.1`

Path: eah5750\

Path: eah57501\

Path: eah57502\

If you want to test memory, please run `./tserver -test=memfa`

Path: eah57503\

6.3.1.6 BIOS Version

If you want to see the version of bios, please run `./atiflash -ai 0.`

Path: eah5750\

Path: eah57501\

Path: eah57502\

Path: eah57503\

6.3.1.7 BIOS flash

Please use the following command to flash bios and notice the size of character.

Path: eah5750\

Path: eah57501\

Path: eah57502\

Path: eah57503\

Command: `./atiflash -p -f 0 xxx.rom`

Notice:


If you can not flash bios because of the bios locked, please use `./atiflash -unlockrom 0` to unlock bios. And then, please use `./atiflash -lockrom 0` to lock bios after updating latest bios.

6.3.1.8 After finish Linux testing, please enter Windows environment to test 3DMark.

6.3.2 3DMark test(contain HDMI test)

6.3.2.1 Please install 3DMark program by yourself.

6.3.2.2 Please connect VGA card to LCD via HDMI cable.




HDMI CON


6.3.2.3 Please install VGA card driver in Windows(You must use individual driver of this card).

6.3.2.4 Please run 3DMark06 base on this card (please test 1 cycle).

6.3.2.5 Press “Select” to enter Select test menu. You can choose “HDR1” for default setting.



6.3.2.6 Press “Demo” to enter Demo menu. You can choose “Sounds” for default setting.



6.3.2.7 Please pay attention to check if there is flickering, discolor, crash and so on.

If there's no problem, it can be judged OK!

6.3.2.8 Please listen to voice carefully to check whether it outputs sounds. If not, HDMI test fail.



6. 3.2.9 If test OK, please test **Display port.(for C1CNP0-A01)**

6. 3.2.10 Connect VGA card to LCD via Display cable test HDMI function.

(Please refer to step 6.3.2.4&6.3.2.5&6.3.2.6&6.3.2.7&6.3.2.8)




DISPLAY CON


6.4 Temperature test

6.4.1 Please copy Thermaltool(1.0.05) to Windows by yourself.


6.4.2 Please run ThermalTest.exe.



6.4.3 If test ok, show pass.













6.4.4 If test fail, show fail.



6.4.5 If test OK, please NTF test.

7.Appendix

NO#	Equipment Description	ASUS Part#	Supplier	Quantity	Remarks
1	Dell 30 inches (3008WFP) (Buying a local LCD by yourself)			1	
2	USB MOUSE			1	
3	PS/2 KEYBOARD			1	
4	ATX POWER SUPPLY(a minimum power of 500W)			1	
5	INTEL Celeron E1200			1	
6	Heat sink + FAN	22-240000160		1	
7	DDR2(667/800) 1G	04G0016169A9NE /22-T00642404		4	
8	TEST HDD			1	
9	SATA HDD Cable	14-000107070	ASUS	1	
10	PCIEX16 VGA CARD			1	
11	Dual link DVI cable (Buying a local DVI cable by yourself)			1	
12	HDMI extend cable (Buying a local HDMI cable by yourself)			1	
13	Display port cable (Buying a local HDMI cable by yourself)			1	
14	P5E MB	80- MBB7X0-*		1	