

| | | | |
|--------------------------|--|--------------------------------------|--------|
| ASUSTeK COMPUTER INC. | EN9400GT Standard Operation Procedure | Doc. No: | |
| | | Date: Mar. 24. 2010 Revision:1.11 | |
| | | Page: 12 | Grade: |

| Rev. | Modified Chapters | Modification Description | Issued Dept. | Issued by | Revised Date |
|------|-------------------|-------------------------------|--------------|-------------|--------------|
| 1.00 | | First release | GTC | Robin_Jiang | |
| 1.01 | | Add New P/N (C1CLS0) | GTC | Robin_Jiang | |
| 1.02 | | Add New P/N (C1CLNA&C1CLNF) | GTC | Robin_Jiang | |
| 1.03 | | Add New P/N (C1CLM5) | GTC | Robin_Jiang | |
| 1.04 | | Modify for new test structure | GTC | Robin_Jiang | |
| 1.05 | | Add New P/N (C1CLNK) | GTC | Robin_Jiang | |
| 1.06 | | Add New P/N(C1CLMA) | GTC | Robin_Jiang | May.11.2009 |
| 1.07 | | Add C1CLMA-A11&C1CLNF-A11 | GTC | Robin_Jiang | Jun.18.2009 |
| 1.08 | | Add New P/N C1CNE0 | GTC | Robin_Jiang | Aug.14.2009 |
| 1.09 | | Add New PCBA A11 For C1CLNK | GTC | Robin_jiang | Aug.21.2009 |
| 1.10 | | Unlock or lock bios | GTC | Robin_jiang | Sep.25.2009 |
| 1.11 | | Add New PCBA(C1CLM5-A11) | GTC | Ariel_wang | Mar.24.2010 |

| | | | | | |
|--------------|--|-----------|--|---------------|-------|
| Authorize by | | Review by | | Originator By | Robin |
|--------------|--|-----------|--|---------------|-------|

| | | |
|----------------------|--|---------------------|
| ASUSTeK COMPUTER INC | EN9400GT Standard Operation Procedure | Doc. No: |
| | | Date: Mar. 24. 2010 |
| | | Rev. : 1.11 Page: 1 |

1.Objectives

Create test procedure.

2.Scope

Model: EN9400GT

PN: C1CLM0 C1CLN0 C1CLN5 C1CLS0 C1CLNA
C1CLNF C1CLM5(A01&A11) C1CLNK C1CLMA C1CNE0

3.Test Item

3.1 Diagnostic test in DOS

3.2 3DMark05(**contain HDMI test**)

3.3 Temperature test

4.Relevant Document

None.

5.Definition : 1. If the model name contains P, please test HDCP function.

Ex: EAH***/HTDP/512M/A

2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI contains HDCP function.

| | | |
|----------------------|--|---------------------|
| ASUSTeK COMPUTER INC | EN9400GT Standard Operation Procedure | Doc. No: |
| | | Date: Mar. 24. 2010 |
| | | Rev. : 1.11 Page: 2 |

6. Operation Procedures:

6.1 Attention

- 6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.
- 6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.
- 6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.
- 6.1.4 Some test items should be tested under Windows environment. (Please install windows test environment by yourself).


6.2 Fixture connect

6.2.1 Install Intel P5 CPU & CPU Fan.


6.2.2 Install DDR2 667/800 1GB Memory to DIMM1~2.

6.2.3 Plug USB Mouse and PS/2 Keyboard into MB.

6.2.4 Plug VGA Card EN9400GT into PCIEX16.




C1CLM0




C1CLN0

6.2.5 Connect IDE HDD with IDE CON.




6.2.6 Plug 4PIN 12V (600W) power cable into CON12V.

6.2.7 Plug ATX Power (600W) on Power Connector.



6.3 Diagnostic test in DOS

6.3.1 Please connect LCD monitor & card's D-SUB CON via a D-SUB cable.
(Please connect to CRT port with CRT to test C1CLMA)



6.3.2 Press Power Switch then turn on power button.

6.3.3 Press "Del" to enter CMOS setup menu while boot screen is displaying.
EXIT -> Load Setup Defaults.



6.3.4 System will reboot, select DOS to run test program.

Path: VBAT\EN9400GT\BATCH\

Run the test program refer to the prompt.

6.3.5 Memory test

If you want to test memory, please run mats.exe.

Path: VBAT\EN9400GT\DIAG\

VBAT\EN9400GT\0171HX3\ (For C1CLMA, C1CLS0, C1CNE0 and C1CLNK-A11)

| | | |
|----------------------|--|---------------------|
| ASUSTeK COMPUTER INC | EN9400GT Standard Operation Procedure | Doc. No: |
| | | Date: Mar. 24. 2010 |
| | | Rev. : 1.11 Page: 5 |

6.3.6 BIOS flash

Please use the following command to flash bios and notice the size of character.

Path: VBAT\EN9400GT\BIOS

Command: `nvflash xxx.rom -4 -5 -6 -A -y`

Notice:


If you can not flash bios because of the bios locked, please use `nvflash.exe /r` to unlock bios. And then, please use `nvflash.exe /w` to lock bios after updating latest bios.

6.3.7 After finish DOS testing, please enter Windows environment to test 3DMark.

6.4 3DMark test(contain HDMI test)


6.4.1 Please install 3DMark program by yourself.

6.4.2 Please connect VGA card to LCD via HDMI cable.



6.4.3 Please install VGA card driver in Windows(You must use individual driver of this card).

6.4.4 Plug 4 Pin black cable into SPDIF_OUT of MB. Plug another 2 Pin white cable into SPDIF_IN of VGA card.




6.4.5 Plug SUPREME FX II card into PCIEX1 of MB.




6.4.6 Please install SUPREME FX II card driver in Windows and enter Windows to test HDMI.

6.4.7 Please run 3DMark05 base on this card (**please test 1 cycle**).

6.4.8 Press “Select” to enter Select test menu. You can choose “GT3” for default setting.



6.4.9 Press “Demo” to enter Demo menu. You can choose “Sounds” for default setting.



| | | |
|----------------------|--|---------------------|
| ASUSTeK COMPUTER INC | EN9400GT Standard Operation Procedure | Doc. No: |
| | | Date: Mar. 24. 2010 |
| | | Rev. : 1.11 Page: 8 |

6.4.10 Please pay attention to check if there is flickering, discolor, crash and so on.
If there's no problem, it can be judged OK!

6.4.11 Listen to voice carefully to check whether it outputs sounds. If not, HDMI test fail.




6.4.12 If test OK, please NTF test.


6.5 Temperature test

6.5.1 Please copy Thermaltool(1.0.05) to Windows by yourself.


6.5.2 Please run ThermalTest.exe.



6.5.3 If test ok, show pass.

















6.5.4 If test fail, show fail.



6.5.5 If test OK, NTF test.

7 Appendix

| NO# | Equipment Description | ASUS Part# | Supplier | Quantity | Remarks |
|-----|--|-------------------------------|----------|----------------|---|
| 1 | SAMSUNG 2232MW | | | 1 |  |
| 2 | PS/2 MOUSE | | | 1 |  |
| 3 | PS/2 KEYBOARD | | | 1 |  |
| 4 | ATX POWER SUPPLY(600W) | | | 1 |  |
| 5 | INTEL Celeron E1200 | | | 1 |  |
| 6 | Heat sink + FAN | 22-240000160 | | 1 |  |
| 7 | APACER 800MHz 512M or 800MHz 1G | | | 512M 2 or 1G 1 |  |
| 8 | TEST HDD | | | 1 |  |
| 9 | 40Pins IDE Cable ATA66 | | ASUS | 1 |  |
| 10 | PCIEX16 VGA CARD | | | 1 | |
| 11 | D-SUB extend cable (Buying a local D-SUB cable by yourself) | | | 1 |  |
| 12 | S CABLE(NVIDIA) | 14G010005113 /14G010005100 | | 1 |  |
| 13 | Dual link DVI cable (Buying a local DVI cable by yourself) | | | 1 |  |
| 14 | HDMI extend cable (Buying a local HDMI cable by yourself) | | | 1 |  |
| 15 | TV extend cable (Buying a local TV cable by yourself) | | | 1 |  |

| | | | | | | |
|----|---------------|-------------------------------|--|---|---|--|
| 16 | DVI-HDMI | 04G460002400 /04G460002450 | | 1 |  | |
| 17 | Power Cable | 14G000602510 /14G000602502 | | 1 |  | |
| 18 | SPDIF CABLE | 14G003200813 /14G003200810 | | 1 |  | |
| 19 | SUPREME FX II | 80-C1BHK5-0C01 | | 1 |  | |
| 20 | LCD "Y" Cable | 14-010230000 | | 1 |  | |
| 21 | P5E | 80-MBB7X0-G0A01 | | 1 | | |