

ASUSTeK COMPUTER INC.	Physx Management Procedure	Doc. No:	
		Date: AUG. 22, 2006	
		Revision:	
		Page: 5	Grade:

Rev.	Modification	Modify description	Issue div.	Originator
1.00		First Release	T.C.	

Authorize by		Review by		Originator By	
-----------------	--	--------------	--	------------------	--

ASUSTeK COMPUTER INC	Physx Management Procedure	Doc. No:
		Date: AUG. 22, 2006
		Rev.: 1.0 Page: 1

1. Objectives :

Create test procedure.

2. Scope :

Model :

Physx (C1CHF6)
(C1CHFA)

3. Relevant Document : None.

4. Definition : None.

ASUSTeK COMPUTER INC	Physx Management Procedure	Doc. No:
		Date: AUG. 22, 2006
		Rev. : 1.0 Page: 2

5. Operation Procedures:


5.1 Metter needing attention.

- 5.1.1 To avoid damage device or M/B and discharge after turn off A/C power.
- 5.1.2 While unplugging the card, do it in upright direction to avoid damage deviation to golden finger.
- 5.1.3 If it happens in problem, please inform to test supervisor. According to the ATX power specification, the +5V standby voltage is existing While AC 110V is connecting, for safely reason, Turn off main power when Test idling or during break time.

ASUSTeK COMPUTER INC	Physx Management Procedure	Doc. No:
		Date: AUG. 22, 2006
		Rev.: 1.0 Page: 3

5.2 Prepared Item :

- 5.2.1 Install Intel P5 CPU & CPU Fan.
- 5.2.2 Install DDR2 256MB Memory to DIMM1~2.
- 5.2.3 Plug PS/2 Mouse and Keyboard into PS/2 port.
- 5.2.4 Plug VGA Card EN6600 into PCIEX16.
- 5.2.5 Plug Physx Card into PCI slot.
- 5.2.6 Connect IDE HDD with IDE CON.



- 5.2.7 Plug 4PIN 12V power cable into CON12V.
- 5.2.8 Plug ATX Power on Power Connector.



ASUSTeK COMPUTER INC	Physx Management Procedure	Doc. No:
		Date: AUG. 22, 2006
		Rev.: 1.0 Page: 4

5.3 Test step :

5.3.1 Press Power Switch then presses the "Power Button" to power on.


5.3.2 Use a HDD with WindowsXP in.

First you should install the driver of VGA Card EN6600.

Then install Directx9.0c or even higher version.


Third Copy the Test program to the HDD and install them.

5.3.3 Reboot system and run the program.

a. Click  ,Test will run automatically in a CMD box.








Caution:Do not attempt to close the test box by click the "X" button.This will destroy the driver.Press "Enter" or "Ctrl+C" to Close or Abort the box.

b.Click the desktop Icon to run Smoke release231 test.



ASUSTeK COMPUTER INC	Physx Management Procedure	Doc. No:
		Date: AUG. 22, 2006
		Rev.: 1.0 Page: 5

6. Appendix :

NO#	Equipment Description	ASUS Part#	Supplier	Quantity	Remarks
1	LCD			1	
2	PS/2 MOUSE			1	
3	PS/2 KEYBOARD			1	
4	ATX POWER SUPPLY			1	
5	INTEL P5 CPU			1	
6	Heat sink + FAN	22-240000160		1	
7	DDR2	22-150001800		2	
8	TEST HDD(With WinXP)			1	
9	40Pins IDE Cable ATA66		ASUS	1	
10	EN6600 series	C1V DX*		1	