

# New Product SVC Guide [SM-A115A/U]

Rev 1.0

**SAMSUNG**

# Notice

This guide is intended solely for the Samsung Electronics internal training and may contain trade secret, industrial technology or privileged and confidential information otherwise protected under applicable law including the Unfair Competition Prevention and Trade Secret Protection Act. Any unauthorized dissemination, distribution, copying or use of the information contained in this guide is strictly prohibited and subject to legal action.

All functionality, features, specifications and other product information provided in this document including, but not limited to, the benefits, design, pricing, components, performance, availability, and capabilities of the product are subject to change without notice or obligation. Samsung reserves the right to make changes to this guide and the product described herein, at anytime, without obligation on Samsung Electronics to provide notification of such change.

# Contents

## 1. Specification of SM-Galaxy A11

## 2. H/W

### 2-1. New Concepts of H/W

### 2-2. Disassembly & Assembly

### 2-3. New Sensors & Test method

### 2-4. Parts Diagram (Module & ICs)

### 2-5. Troubleshooting

## 3. SVC Technical Information



# Specification

Item	Spec.		
AP Chipset	Vendor & Name	Cores & Architecture	Speed (Big/Little)
	Qualcomm SDM450	8 × Arm Cortex-A53 & 64 bit	1.8 Ghz
Memory	RAM	Storage	External Memory (Micro SD)
	2GB/3GB	32GB	Up to 2TB
Display	Size	Resolution	Type
	6.39 inch	HD+ ( 1560X720 )	Incell
CAMERA	Resolution (Main / Front)	Flash LED	Dual Camera
	13MP+2MP+5MP / 8MP	Rear only	-
Network	2G/3G	LTE	
	Support	4G LTE FDD, 4G LTE TDD	
Sensors	Accelerometer, Fingerprint, Light, Proximity		
Connectivity & LBS	Bluetooth 4.2 WIFI 802.11b/g/n/ac 2.4GHz/5.0GHz, WiFi-Direct		Support GPS , Glonass , Galileo
Battery Type & Capacity	Embedded battery	4,000 mAh	
Charging capacity & Adapter type	9V1.67A	Type C	
Water Resistance & OS Ver.	-	Android Q	
Ear Jack & Wireless charging	3.5 mm stereo	-	
Remarks			

# RAM & Storage size by region - NA

SKU CODE Rule	Model Name	Region	RAM	Storage	Color	Status
SM-A115AZZKAXXX	SM-A115AZ	AIO (Criket)	2	32	Black	single SIM
SM-A115AZZBAXXX			2	32	Blue	single SIM
SM-A115AZZWAXXX			2	32	White	single SIM
SM-A115AZZRAXXX			2	32	Red	single SIM
SM-A115U1ZKAXXX	SM-A115U1	OYM	2	32	Black	single SIM
SM-A115U1ZBAXXX			2	32	Blue	single SIM
SM-A115U1ZWAXXX			2	32	White	single SIM
SM-A115U1ZRAXXX			2	32	Red	single SIM
SM-A115UZKAXXX	SM-A115U	VZW	2	32	Black	single SIM
SM-A115UZBAXXX			2	32	Blue	single SIM
SM-A115UZWAXXX			2	32	White	single SIM
SM-A115UZRAXXX			2	32	Red	single SIM
SM-A115UZKAXXX	SM-A115U	TMK	2	32	Black	single SIM
SM-A115UZBAXXX			2	32	Blue	single SIM
SM-A115UZWAXXX			2	32	White	single SIM
SM-A115UZRAXXX			2	32	Red	single SIM
SM-A115UZKAXXX	SM-A115U	TMB	2	32	Black	single SIM
SM-A115UZBAXXX			2	32	Blue	single SIM
SM-A115UZWAXXX			2	32	White	single SIM
SM-A115UZRAXXX			2	32	Red	single SIM

# RAM & Storage size by region - NA

SKU CODE Rule	Model Name	Region	RAM	Storage	Color	Status
SM-A115UZKAXXX	SM-A115U	SPR	2	32	Black	single SIM
SM-A115UzbAXXX			2	32	Blue	single SIM
SM-A115UZWAXXX			2	32	White	single SIM
SM-A115UZRAXXX			2	32	Red	single SIM
SM-A115UZKAXXX	SM-A115U	USC	2	32	Black	single SIM
SM-A115UzbAXXX			2	32	Blue	single SIM
SM-A115UZWAXXX			2	32	White	single SIM
SM-A115UZRAXXX			2	32	Red	single SIM
SM-A115WZKAXXX	SM-A115W	XAC	2	32	Black	single SIM
SM-A115WzbAXXX			2	32	Blue	single SIM
SM-A115WZWAXXX			2	32	White	single SIM
SM-A115WZRAXXX			2	32	Red	single SIM
SM-S115DLZKAXXX	SM-S115DL	TFN	2	32	Black	single SIM
SM-S115DLzbAXXX			2	32	Blue	single SIM
SM-S115DLZWAXXX			2	32	White	single SIM
SM-S115DLZRAXXX			2	32	Red	single SIM

# RAM & Storage size by region

1. Now we have three kinds of EMCPs : 2+32G, 3+32G
2. SKU CODE Rules("SM-A115FZKDCIS" as an example):

- "SM-A115F" is the model name
- After model name, we use two letters (such as "ZK") to present the color, "SM-A115FZKDCIS" is black. More details refer to below matrix

Color	Code
Black	ZK
Blue	ZB
White	ZW
Red	ZR




- We use "D" or "A" to present double SIM or single SIM, "SM-A115FZKD" is a double SIM product.

SIM card info	Code
double SIM	D
single SIM	A

- The last three letters is country operator "SM-A115FZKDCIS"

# Disassembly & Reassembly


## Part list which must be changed after reassembly

Item	Code	Pictures (Images)
Fingerprint Module Tape (Whenever the rear cover is disassembled.)	GH81-18930A	
Front camera CU TAPE (When the front camera is changed.)	GH81-19061A	
A/S JDM-ETC FRONT CAM FOAM_SM-A115_SVC (When the front camera is changed.)	GH81-18785A	




# Disassembly & Reassembly

## Battery replacement

Type	Structure	Battery replace
 <p>The diagram illustrates the front assembly components. It shows a 'Display' (grey rectangle), a 'Bracket' (blue rectangle), and a 'Battery' (green rectangle). The 'Display' and 'Bracket' are grouped together with a dashed blue box and labeled 'Inseparable part (Front Assy)'. The 'Battery' is shown below the 'Bracket'.</p>	<p>Display and Bracket can not be separated.</p> <p>Battery replacement is required when Front Ass'y(Display) is replaced.</p> <p>If the Front Assy is supplied without battery, please order battery together.</p> <p>※ Do not reuse the battery.</p>	<p>It need to replace the battery when the display replace.</p>

# Disassembly & Reassembly

## Important management points




Ensure the camera located well in right place and BTB shall be buckled in place without deviation and avoid collapse.

- **The main camera and auxiliary camera must be replaced in pairs**
- **After replacing camera module, A/S engineer needs to check the camera as following steps:**
  - Step 1: Open the camera function and check whether camera can work normally.
  - Step 2: Download and install the Galaxy Diagnostic tool
  - Step 3: Open the Galaxy Diagnostic tool and set the Golden Value flag
  - Step 4: After opening the Golden Value flag, Arcsoft algorithm will call the Golden Value built in the S/W version and imaging.
- **Full function test should be do after any level repairing.**

# Disassembly & Reassembly

## Important management points

### ■ Back cover disassemble



### ■ After replacing camera module, A/S engineer needs to check the camera as following steps:



Step 1: Remove the SIM tray using the eject pin.

Step 2: Disassembly the back cover from the front ass'y using the disassemble stick.

Step 3: Set the temperature to **65 °C/ 5 minutes** using the mobile dryer and put the device

Step 4: Gently press the fingerprint key **using the disassemble stick or your finger** to remove the back cover


# Parts Layout





# Parts Layout

## PBA ( Bottom )



# Parts Layout

## PBA ( TOP )

J1701 Earphone Socket

J2103 Front CAM BTB Connector

J2304 SIM/SD Card Connector

U301 PMIC\_PMI632

PA2601 RF PA

U1602 OVP IC

ANT305/ANT306/ANT307/ANT311 Gr  
ounded shrapnel

ANT203/ANT204 MOTOR shrapnel

U2202 P-SENSOR

J2102 Rear CAM BTB Connector

U801 CPU-SDM450

U1501 memory



ANT1801/ANT1802/ANT1803/ANT1804  
Side key

U3401 NFC IC

U2001 BL Driver IC


Q101 NMOS

J101 TYPE\_C Connector



# Troubleshooting

## ■ No Power




# Troubleshooting

## ■ No Power

Power on voltage check				
Power Domain	Configurable Voltage	Signal Name	Measurement Location	TP
VPH_PWR	3.0-5.25V	VPH_PWR	C503	TP1
VDD_MEM	0.915V	VREG_S7_0P915	C535	TP2
VDD_CORE	0.8625V	VREG_S2_0P8625	C516	TP3
VDD_MODEM	0.8625V	VREG_S1_0P8625	C515	TP4
PM8953_Low-voltage LDOs	1.225V	VREG_S3_1P225	C521	TP5
PM8953_High-voltage LDOs	2.04V	VREG_S4_2P05	C523	TP6
APC	0.87v	VREG_S5_S6_0P8625	C537	TP7

## ■ Oscillate frequency measurement

Signal Name	Frequency MHZ	Measurement Location	TP
XTAL_19M_IN	19.2M	X201	TP8






# Troubleshooting

## ■ No Power


- Checking Power signal(Battery connector, PMU, Clock)



# Troubleshooting

## ■ No Power


- Checking Power signal(Battery connector, PMU, Clock)



# Troubleshooting


## ■ No Power

- Checking Power signal (Battery connector, PMU, Clock)



# Troubleshooting


## ■ No Charging



# Troubleshooting

■ **No Charging**

- The charging controlled by PMU chip PMI632 (U301).



# Troubleshooting

## ■ No Charging


- The charging controlled by PMU chip PMI632 (U301).

VBUS通路要求走3A电流，线宽至少3mm

[16] VBUS\_USB\_IN\_CON >>

LBC:  
Use C301= 4.7uF for Single Charging Config  
Use C301 = 2.2uF for Parallel Charging Config


TP3



# Troubleshooting

## ■ USB


1. I/O connector is used as the USB port.




# Troubleshooting

## ■ USB

1.1 I/O connector is used as the USB port.



## PEC CONNECTOR






# Troubleshooting

## ■ Sound Problem

### 2. Audio speaker

- The Speaker control signals are generated by CPU-SDM450(U801) and Smart PA(U1704) , the chip U801 、 U1704 and the speaker are to be checked out.




# Troubleshooting

## ■ Sound Problem

### 2.1 Audio speaker

- The Speaker control signals are generated by PM8953(U201) , the chip and the speaker are to be checked out.

Circuit Diagram




# Troubleshooting

## ■ Sound Problem

### 2. 2 Audio speaker

- The Speaker control signals are generated by PM8953(U201) , the chip and the speaker are to be checked out.

Circuit Diagram




# Troubleshooting

## ■ Sound Problem

### 3. Audio Main MIC

The MIC control signals are generated by PMU chip PM8953(U201), the PMU chip and the MIC are to be checked out.






# Troubleshooting

## ■ Sound Problem

### 4. Audio SUB MIC

The MIC control signals are generated by PM8953(U201), the PMU chip and the MIC are to be checked out.






# Troubleshooting

## ■ G-SENSOR

5. The G sensor is calibrated by using SW algorithm.






# Troubleshooting

## ■ G-SENSOR


5.1 The G sensor is calibrated by using SW algorithm.



# Troubleshooting

## ■ Proximity and light sensor


6. Proximity and Light Sensor is worked as below: Control the screen's on/off operation automatically while making phone calls, and adjust the screen brightness according to ambient light



# Troubleshooting

## ■ Proximity and light sensor


6.1 Proximity and Light Sensor is worked as below: Control the screen's on/off operation automatically while making ph one calls, and adjust the screen brightness according to ambient light.



# Troubleshooting

## ■ Vibrator


7. The Vibrator control signals are generated by PMI632(U301).



# Troubleshooting

## ■ Vibrator


7.1 The Vibrator control signals are generated by PMI632(U301).



# Troubleshooting

## ■ Main Camera

8. The Camera control signals are generated by PM8953 ( U201 ) and SDM450(U801)




## ■ Main Camera

# Troubleshooting

## ■ Rear auxiliary 5M Camera

9. The Camera control signals are generated by PM8953 ( U201 ) and SDM450(U801)






# Troubleshooting

## ■ Rear auxiliary 5M Camera


9.1 The Camera control signals are generated by PM8953 ( U201 ) and SDM450(U801)



# Troubleshooting

## ■ Rear auxiliary 2M Camera

10. The Camera control signals are generated by PM8953(U201) and SDM450(U801)






# Troubleshooting

## ■ Front Camera


11. The Camera control signals are generated by PM8953 ( U201 ) and SDM450(U801).



# Troubleshooting

## ■ Front Camera


11.1 The Camera control signals are generated by PM8953 ( U201 ) and SDM450(U801).



# Troubleshooting

## ■ Display Problem

12. The LCD control signals are generated by SDM450.






# Troubleshooting

## ■ Touch Problem

13.The Touch control signals are generated by SDM450. It is assembled with LCD.






# Troubleshooting

## ■ Touch Problem

13.The Touch control signals are generated by SDM450. It is assembled with LCD.



# SVC Technical Information

## Part list which must be changed after reassembly

Item	Code	Item	Code
Finger print tape	GH81-18930A		

## Calibration items for A115A/U

TSP Cal.	X	Force Touch Cal.	X	Optical Finger print Cal.	X	mmWave RF Cal.	X
Speaker Cal.	O	Digital Hall IC Cal.	X	TOF Camera Cal.	X	Multi Camera Cal.	O

※ Only USA device need Speaker Cal.  
Multi-camera calibration guide is provided separately.



Copyright © 2017 Samsung Electronics

This guide is protected under international copyright laws.

No part of this guide may be reproduced, distributed, translated, or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or storing in any information storage and retrieval system, without the prior written permission of Samsung Electronics.