
5. MAIN Electrical Parts List

Parts Code	Design Loc	Description
0404-001250	D5002,D6000	DIODE-SCHOTTKY
0404-001782	D3000	DIODE-SCHOTTKY
0406-001592	ZD3000,ZD3001,ZD3002	DIODE-TVS
0406-001592	ZD3003,ZD3004,ZD3005	DIODE-TVS
0406-001592	ZD6007,ZD6008,ZD6010	DIODE-TVS
0406-001678	ZD6004,ZD6005	DIODE-TVS
0406-001687	ZD6011,ZD6012	DIODE-TVS
0406-001690	ZD4006,ZD4007,ZD4008	DIODE-TVS
0406-001690	ZD4009,ZD4010,ZD4011	DIODE-TVS
0406-001690	ZD4012,ZD4013,ZD4014	DIODE-TVS
0406-001690	ZD4015,ZD4016,ZD4017	DIODE-TVS
0406-001690	ZD4018,ZD4019,ZD4020	DIODE-TVS
0406-001709	U7064,ZD6006,ZD6018	DIODE-TVS
0406-001715	ZD6019	DIODE-TVS
0406-001733	ZD5002	DIODE-TVS
0505-002088	TR5001,TR5002,TR7000	FET-SILICON
0505-003618	TR5000	FET-SILICON
0601-003541	LED5000	LED
0801-003602	U5007	IC
1001-001655	U5015,U5016	IC
1001-001849	U1004	IC
1001-001968	U6001	IC
1001-001969	U2008	IC
1001-001972	U1000,U1013,U2002	IC
1001-001972	U2004,U2005,U2009	IC
1001-002007	U2007	IC
1003-002415	U6010	IC
1003-002769	U3019	IC
1009-001066	U6000	IC
1105-002777	UCP400UP	IC-DRAM
1107-002396	UME6000	IC-FLASH MEMORY
1201-003790	U3012	IC
1201-003814	U1012	IC
1201-003964	U6009	IC
1201-003974	U1010	IC
1201-003979	U1001	IC
1201-003990	U1006,U1011	IC
1201-004006	PAM1000	IC

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

1203-006817	U7008	IC
1203-007000	U7007,U7009	IC
1203-007030	U3004,U7043	IC
1203-008250	U3018,U3021,U3023	IC
1203-008250	U5002,U5009,U5011	IC
1203-008251	U5010,U5013,U6008	IC
1203-008326	U7059	IC
1203-008379	U2000	IC
1203-008395	U3022,U5014	IC
1203-008459	U5012	IC
1203-008603	U3014	IC
1203-008689	U5006	IC
1203-008716	U6005	IC
1203-008717	U7010	IC
1203-008786	U5005	IC
1205-005262	U3007	IC
1205-005477	U3015	IC
1205-005493	U1007,U1008	IC
1205-005587	UCP400	IC
1209-002401	U3011	IC
1209-002403	U3010	IC
1404-001724	TH2000,TH4000,TH5003	THERMISTOR
1405-001177	VR3002,VR3003	VARISTOR
1405-001395	C3031,VR2001,VR2003	VARISTOR
1405-001395	VR3001,VR7000,VR7001	VARISTOR
1405-001398	VR2002	VARISTOR
1405-001404	V4000,V4001,V4002	VARISTOR
1405-001424	C2009,VR3005	VARISTOR
1405-001425	VR2000,VR2004	VARISTOR
2007-003025	R6030,R6032	R-CHIP
2007-007107	R2000,R4028	R-CHIP
2007-007313	R4009	R-CHIP
2007-007315	R3014	R-CHIP
2007-007741	R4033,R4037,R4048	R-CHIP
2007-007741	R4049,R4050,R4062	R-CHIP
2007-007741	R4064,R4065,R6001	R-CHIP
2007-007741	R6026,R6027,R7007	R-CHIP
2007-007798	R6028	R-CHIP
2007-008211	R3018	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-008312	R6005	R-CHIP
2007-008420	R4000,R4056,R5019	R-CHIP
2007-008531	L7001,R7001	R-CHIP
2007-008579	R1006,R1007	R-CHIP
2007-008774	R6007,R6029,R6031	R-CHIP
2007-008808	R6059	R-CHIP
2007-008816	R3004	R-CHIP
2007-009111	R6004	R-CHIP
2007-009155	R5002,R5013,R6003	R-CHIP
2007-009157	R3001,R3017,R5000	R-CHIP
2007-009157	R5015,R5016,R5018	R-CHIP
2007-009157	R5022,R5030,R5044	R-CHIP
2007-009158	R6024	R-CHIP
2007-009182	R5001	R-CHIP
2007-009212	R3000,R6014,R6019	R-CHIP
2007-009212	R6025,R6037,R6055	R-CHIP
2007-009223	R6022	R-CHIP
2007-009315	R5006	R-CHIP
2007-009352	R7000	R-CHIP
2007-009408	R3008,R3009,R4016	R-CHIP
2007-009408	R4017,R4018,R4019	R-CHIP
2007-009408	R4020,R4021,R4022	R-CHIP
2007-009408	R4023,R4024,R4025	R-CHIP
2007-009408	R4026,R4027,R4031	R-CHIP
2007-009408	R4032,R4052,R4053	R-CHIP
2007-009793	R5021	R-CHIP
2007-009801	R5017,R6000,R7005	R-CHIP
2007-009805	R1001,R1004,R1005	R-CHIP
2007-009805	R3003	R-CHIP
2007-009866	R5043	R-CHIP
2007-009920	R4002,R4003,R4004	R-CHIP
2007-009920	R4005,R4006,R4007	R-CHIP
2007-009954	R6023	R-CHIP
2007-009969	R6017	R-CHIP
2007-010029	R6020	R-CHIP
2007-010685	R4001,R4036,R4051	R-CHIP
2007-010685	R4063	R-CHIP
2007-010856	R5031	R-CHIP
2007-011043	R4008	R-CHIP

5. MAIN Electrical Parts List

2007-011648	R3006,R3007,R5050	R-CHIP
2007-011648	R6021,R7037,R7038	R-CHIP
2203-000233	C1033	C-CERAMIC,CHIP
2203-000585	C3106	C-CERAMIC,CHIP
2203-000627	C3072,C3083	C-CERAMIC,CHIP
2203-000725	C7038	C-CERAMIC,CHIP
2203-000854	C6035	C-CERAMIC,CHIP
2203-001072	C3078	C-CERAMIC,CHIP
2203-001239	C3073,C3080	C-CERAMIC,CHIP
2203-005344	C5029	C-CERAMIC,CHIP
2203-005682	C1018,C1041,C1051	C-CERAMIC,CHIP
2203-005682	C1054,C1059,C1062	C-CERAMIC,CHIP
2203-005682	C1066,C1079,C1115	C-CERAMIC,CHIP
2203-005682	C1125,C1136,C1143	C-CERAMIC,CHIP
2203-005682	C1161,C1162,C1167	C-CERAMIC,CHIP
2203-005682	C1169,C1190,C2027	C-CERAMIC,CHIP
2203-005682	C2034,C2039,C2045	C-CERAMIC,CHIP
2203-005682	C2048,C2049,C2054	C-CERAMIC,CHIP
2203-005682	C3050,C3051,C7003	C-CERAMIC,CHIP
2203-005682	L1041,L2024	C-CERAMIC,CHIP
2203-005717	C2055,C2079	C-CERAMIC,CHIP
2203-005719	C3088	C-CERAMIC,CHIP
2203-005725	C1024,C1106,C1111	C-CERAMIC,CHIP
2203-005725	C1112,C1113,C1134	C-CERAMIC,CHIP
2203-005725	C1138,C3054	C-CERAMIC,CHIP
2203-005727	C3025,C3026,C7041	C-CERAMIC,CHIP
2203-005729	C3038,C3039	C-CERAMIC,CHIP
2203-005731	C3023,C3028,C3032	C-CERAMIC,CHIP
2203-005731	C3043,C3044,C3096	C-CERAMIC,CHIP
2203-005731	C6021,C6042,C6043	C-CERAMIC,CHIP
2203-005731	C6048	C-CERAMIC,CHIP
2203-005732	C5055,C5058,C6017	C-CERAMIC,CHIP
2203-005732	C6019,C6049,C6058	C-CERAMIC,CHIP
2203-005734	L3003	C-CERAMIC,CHIP
2203-005736	C1000,C1001,C1007	C-CERAMIC,CHIP
2203-005736	C1008,C1010,C1012	C-CERAMIC,CHIP
2203-005736	C1034,C1037,C1038	C-CERAMIC,CHIP
2203-005736	C1053,C1057,C1058	C-CERAMIC,CHIP
2203-005736	C1072,C1075,C1081	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C1104,C1130,C1131	C-CERAMIC,CHIP
2203-005736	C1133,C1135,C1179	C-CERAMIC,CHIP
2203-005736	C1180,C1181,C1194	C-CERAMIC,CHIP
2203-005736	C1195,C2006,C2010	C-CERAMIC,CHIP
2203-005736	C2013,C2019,C2023	C-CERAMIC,CHIP
2203-005736	C2025,C2026,C2031	C-CERAMIC,CHIP
2203-005736	C2032,C2037,C2038	C-CERAMIC,CHIP
2203-005736	C2040,C2042,C2046	C-CERAMIC,CHIP
2203-005736	C2052,C2053,C2057	C-CERAMIC,CHIP
2203-005736	C2058,C2068,C2074	C-CERAMIC,CHIP
2203-005736	C2075,C2082,C2083	C-CERAMIC,CHIP
2203-005736	C2084,C2085,C3006	C-CERAMIC,CHIP
2203-005736	C3008,C3009,C3011	C-CERAMIC,CHIP
2203-005736	C3012,C3037,C3041	C-CERAMIC,CHIP
2203-005736	C3052,C3053,C3057	C-CERAMIC,CHIP
2203-005736	C3089,L1013,L1024	C-CERAMIC,CHIP
2203-005736	L1043,L1053,L1055	C-CERAMIC,CHIP
2203-005736	L2034	C-CERAMIC,CHIP
2203-005777	C1050,C3019	C-CERAMIC,CHIP
2203-005789	C1035,C1071,C1109	C-CERAMIC,CHIP
2203-005789	C1110,C1139,C1140	C-CERAMIC,CHIP
2203-005792	C1023,C1127	C-CERAMIC,CHIP
2203-005806	C4140,C5010,C5040	C-CERAMIC,CHIP
2203-006048	C6061	C-CERAMIC,CHIP
2203-006123	C2014,C2066	C-CERAMIC,CHIP
2203-006137	C3017	C-CERAMIC,CHIP
2203-006194	C2008,C3002,C3003	C-CERAMIC,CHIP
2203-006194	C3004,C3007,C3010	C-CERAMIC,CHIP
2203-006194	C3013	C-CERAMIC,CHIP
2203-006305	C5095,C5096	C-CERAMIC,CHIP
2203-006318	C1123	C-CERAMIC,CHIP
2203-006348	C6030	C-CERAMIC,CHIP
2203-006399	C1097,C1103,C3065	C-CERAMIC,CHIP
2203-006400	C1147,C1149,C2007	C-CERAMIC,CHIP
2203-006400	C3022	C-CERAMIC,CHIP
2203-006410	C1044,C1045,L1042	C-CERAMIC,CHIP
2203-006423	C1017,C1026,C1069	C-CERAMIC,CHIP
2203-006423	C1090,C1092,C1093	C-CERAMIC,CHIP
2203-006423	C1094,C1098,C1099	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-006423	C1100,C1105,C1118	C-CERAMIC,CHIP
2203-006423	C1119,C2035,C2051	C-CERAMIC,CHIP
2203-006423	C2063,C3035,C3046	C-CERAMIC,CHIP
2203-006423	C3047,C3048,C3058	C-CERAMIC,CHIP
2203-006423	C3101,C4000,C4001	C-CERAMIC,CHIP
2203-006423	C4004,C4010,C4011	C-CERAMIC,CHIP
2203-006423	C4012,C4013,C4014	C-CERAMIC,CHIP
2203-006423	C4015,C4017,C4062	C-CERAMIC,CHIP
2203-006423	C4086,C4123,C4138	C-CERAMIC,CHIP
2203-006423	C4139,C4157,C4158	C-CERAMIC,CHIP
2203-006423	C4161,C4162,C4165	C-CERAMIC,CHIP
2203-006423	C4172,C5016,C5035	C-CERAMIC,CHIP
2203-006423	C5042,C5073,C5075	C-CERAMIC,CHIP
2203-006423	C5092,C6001,C6002	C-CERAMIC,CHIP
2203-006423	C6004,C6007	C-CERAMIC,CHIP
2203-006426	C6023	C-CERAMIC,CHIP
2203-006556	C1016,C1025,C1027	C-CERAMIC,CHIP
2203-006556	C1030,C2005,C5091	C-CERAMIC,CHIP
2203-006562	C3018,C3024,C3067	C-CERAMIC,CHIP
2203-006562	C3084,C3099,C3104	C-CERAMIC,CHIP
2203-006562	C3109,C5041,C5044	C-CERAMIC,CHIP
2203-006562	C5064,C5065,C5069	C-CERAMIC,CHIP
2203-006562	C5079,C5081,C6029	C-CERAMIC,CHIP
2203-006562	C6053,C7011,C7013	C-CERAMIC,CHIP
2203-006562	C7015,C7017,C7023	C-CERAMIC,CHIP
2203-006562	C7025	C-CERAMIC,CHIP
2203-006604	C4177	C-CERAMIC,CHIP
2203-006611	C3034	C-CERAMIC,CHIP
2203-006642	C3071	C-CERAMIC,CHIP
2203-006648	C4016,C4018	C-CERAMIC,CHIP
2203-006707	C1091	C-CERAMIC,CHIP
2203-006839	C1086,C3097,C4167	C-CERAMIC,CHIP
2203-006839	C4176,C5000,C5043	C-CERAMIC,CHIP
2203-006839	C5087	C-CERAMIC,CHIP
2203-006846	C1021,C1055,C1060	C-CERAMIC,CHIP
2203-006872	C4088	C-CERAMIC,CHIP
2203-006896	C1124,C1126,C2064	C-CERAMIC,CHIP
2203-006979	C1082,C1084,C1095	C-CERAMIC,CHIP
2203-006979	C1096,C1101,C1102	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-006994	C3070	C-CERAMIC,CHIP
2203-007194	C1048,C3027,C7004	C-CERAMIC,CHIP
2203-007240	C4055,C4142	C-CERAMIC,CHIP
2203-007269	C7032,C7033	C-CERAMIC,CHIP
2203-007270	C6064,C7026	C-CERAMIC,CHIP
2203-007271	C1019,C5002,C5003	C-CERAMIC,CHIP
2203-007271	C5004,C5005,C5006	C-CERAMIC,CHIP
2203-007271	C5007,C5060,C5061	C-CERAMIC,CHIP
2203-007271	C5062,C5063,C5083	C-CERAMIC,CHIP
2203-007271	C5086,C6069,C7012	C-CERAMIC,CHIP
2203-007271	C7014,C7016,C7018	C-CERAMIC,CHIP
2203-007279	C1029,C6027	C-CERAMIC,CHIP
2203-007369	C3068,C6006	C-CERAMIC,CHIP
2203-007385	C5077	C-CERAMIC,CHIP
2203-007391	C1085,C1088,C3014	C-CERAMIC,CHIP
2203-007391	C3015,C3049	C-CERAMIC,CHIP
2203-007392	C5001	C-CERAMIC,CHIP
2203-007393	C2000,C2003,C3021	C-CERAMIC,CHIP
2203-007393	C3107,C4098,C5017	C-CERAMIC,CHIP
2203-007393	C5026,C5031,C5032	C-CERAMIC,CHIP
2203-007393	C6000,C6003	C-CERAMIC,CHIP
2203-007449	C1052,C1083,C1087	C-CERAMIC,CHIP
2203-007449	C3045,C3069,C3085	C-CERAMIC,CHIP
2203-007449	C3086,C3087,C3090	C-CERAMIC,CHIP
2203-007449	C3091,C3093,C3108	C-CERAMIC,CHIP
2203-007449	C3111,C3112,C4006	C-CERAMIC,CHIP
2203-007449	C4007,C4008,C4023	C-CERAMIC,CHIP
2203-007449	C4024,C4025,C4026	C-CERAMIC,CHIP
2203-007449	C4028,C4031,C4034	C-CERAMIC,CHIP
2203-007449	C4035,C4039,C4041	C-CERAMIC,CHIP
2203-007449	C4042,C4045,C4051	C-CERAMIC,CHIP
2203-007449	C4053,C4060,C4061	C-CERAMIC,CHIP
2203-007449	C4063,C4065,C4066	C-CERAMIC,CHIP
2203-007449	C4067,C4070,C4071	C-CERAMIC,CHIP
2203-007449	C4072,C4073,C4074	C-CERAMIC,CHIP
2203-007449	C4075,C4076,C4079	C-CERAMIC,CHIP
2203-007449	C4082,C4083,C4084	C-CERAMIC,CHIP
2203-007449	C4085,C4087,C4089	C-CERAMIC,CHIP
2203-007449	C4090,C4091,C4092	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007449	C4093,C4094,C4095	C-CERAMIC,CHIP
2203-007449	C4096,C4097,C4099	C-CERAMIC,CHIP
2203-007449	C4100,C4101,C4102	C-CERAMIC,CHIP
2203-007449	C4103,C4104,C4105	C-CERAMIC,CHIP
2203-007449	C4106,C4107,C4108	C-CERAMIC,CHIP
2203-007449	C4109,C4110,C4111	C-CERAMIC,CHIP
2203-007449	C4112,C4113,C4114	C-CERAMIC,CHIP
2203-007449	C4115,C4126,C4127	C-CERAMIC,CHIP
2203-007449	C4128,C4134,C4135	C-CERAMIC,CHIP
2203-007449	C4136,C4137,C4144	C-CERAMIC,CHIP
2203-007449	C4146,C4148,C4149	C-CERAMIC,CHIP
2203-007449	C4150,C4159,C4168	C-CERAMIC,CHIP
2203-007449	C4173,C5013,C5014	C-CERAMIC,CHIP
2203-007449	C5022,C5023,C5027	C-CERAMIC,CHIP
2203-007449	C5028,C5036,C5037	C-CERAMIC,CHIP
2203-007449	C5047,C5054,C5066	C-CERAMIC,CHIP
2203-007449	C5067,C5068,C5070	C-CERAMIC,CHIP
2203-007449	C5071,C5072,C5076	C-CERAMIC,CHIP
2203-007449	C5080,C5082,C5085	C-CERAMIC,CHIP
2203-007449	C5098,C5099,C6014	C-CERAMIC,CHIP
2203-007449	C6046,C6047,C6052	C-CERAMIC,CHIP
2203-007449	C6057,C7001,C7002	C-CERAMIC,CHIP
2203-007449	C7027,C7028,C7037	C-CERAMIC,CHIP
2203-007474	C3001,C3005,C3016	C-CERAMIC,CHIP
2203-007474	C7006,C7035	C-CERAMIC,CHIP
2203-007634	C6032	C-CERAMIC,CHIP
2203-007775	C3020,C3040,C3042	C-CERAMIC,CHIP
2203-007775	C5090,C7000	C-CERAMIC,CHIP
2203-007781	C7034	C-CERAMIC,CHIP
2203-007795	C3066	C-CERAMIC,CHIP
2203-007796	C6066,C7029	C-CERAMIC,CHIP
2203-007854	C3074,C3079	C-CERAMIC,CHIP
2203-008097	C1028,C1031	C-CERAMIC,CHIP
2203-008123	C4009,C4019,C4036	C-CERAMIC,CHIP
2203-008123	C4037,C4054,C4141	C-CERAMIC,CHIP
2203-008123	C5048,C5049,C5078	C-CERAMIC,CHIP
2203-008242	C3033,C5052,C7005	C-CERAMIC,CHIP
2203-008242	C7007,C7008,C7009	C-CERAMIC,CHIP
2203-008242	C7010,C7024	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-008394	L2031	C-CERAMIC,CHIP
2203-008527	C1032,C2002,C3102	C-CERAMIC,CHIP
2203-008527	C5008,C5038,C5039	C-CERAMIC,CHIP
2203-008527	C5045,C5074,C5097	C-CERAMIC,CHIP
2203-008527	C6062	C-CERAMIC,CHIP
2203-008860	C6031	C-CERAMIC,CHIP
2203-008876	C5053	C-CERAMIC,CHIP
2203-009048	C5009,C7030,C7031	C-CERAMIC,CHIP
2203-009328	C3000,C4124,C4125	C-CERAMIC,CHIP
2203-009618	C5012,C6063	C-CERAMIC,CHIP
2409-001369	TA3000	CAPACITOR
2703-002269	L1011	INDUCTOR-SMD
2703-002309	L3000,L3001	INDUCTOR-SMD
2703-002649	C1148,C2076,L2022	INDUCTOR-SMD
2703-002901	C1080,C2021,C2022	INDUCTOR-SMD
2703-002903	C4169,L2010,L2012	INDUCTOR-SMD
2703-002903	L2018,L2020	INDUCTOR-SMD
2703-002907	C2017,L1048,L1064	INDUCTOR-SMD
2703-002953	L1023,L1029	INDUCTOR-SMD
2703-002955	L1035,L1036,L1037	INDUCTOR-SMD
2703-002955	L1038	INDUCTOR-SMD
2703-002958	L2033,L3008,L3012	INDUCTOR-SMD
2703-002960	L2002	INDUCTOR-SMD
2703-003004	R3011,R3012	INDUCTOR-SMD
2703-003293	L3014,L3018	INDUCTOR-SMD
2703-004012	C1073,C1114,C1198	INDUCTOR-SMD
2703-004012	C2047,C2060,C2067	INDUCTOR-SMD
2703-004012	C2071,L1003,L1034	INDUCTOR-SMD
2703-004012	L1044,L1063,L1066	INDUCTOR-SMD
2703-004012	L1067,L2026	INDUCTOR-SMD
2703-004013	C1129,C1168,L1016	INDUCTOR-SMD
2703-004013	L1032,L1039,L2001	INDUCTOR-SMD
2703-004030	C1178	INDUCTOR-SMD
2703-004032	C1199,C2020,L1010	INDUCTOR-SMD
2703-004032	L1022,L1065,L2032	INDUCTOR-SMD
2703-004034	C1022,C1049,C1061	INDUCTOR-SMD
2703-004034	C1064,C1137,C1166	INDUCTOR-SMD
2703-004034	C2030,C2059,L1027	INDUCTOR-SMD
2703-004034	L2003,L2028,L2035	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-004035	C1121,C1155,L1014	INDUCTOR-SMD
2703-004035	L1019,L1059,L1060	INDUCTOR-SMD
2703-004035	L2008,L2009,L2021	INDUCTOR-SMD
2703-004035	L2023,L2027,L2030	INDUCTOR-SMD
2703-004035	L2036	INDUCTOR-SMD
2703-004036	C1009	INDUCTOR-SMD
2703-004037	C1108	INDUCTOR-SMD
2703-004038	C2033,C3030,L1008	INDUCTOR-SMD
2703-004259	L2004,L3011	INDUCTOR-SMD
2703-004289	L1045	INDUCTOR-SMD
2703-004290	C1116	INDUCTOR-SMD
2703-004328	C2041,L1018,L1021	INDUCTOR-SMD
2703-004328	L1040,L1068,L2017	INDUCTOR-SMD
2703-004328	L2019,L3013	INDUCTOR-SMD
2703-004366	L3004	INDUCTOR-SMD
2703-004367	C1128	INDUCTOR-SMD
2703-004369	L3005	INDUCTOR-SMD
2703-004408	L1000,L1054	INDUCTOR-SMD
2703-004684	L4000	INDUCTOR-SMD
2703-004763	L1062	INDUCTOR-SMD
2703-004862	C2015	INDUCTOR-SMD
2703-004901	L5006,L5007	INDUCTOR-SMD
2703-004947	L5001,L5003	INDUCTOR-SMD
2703-004976	C1013,C1173	INDUCTOR-SMD
2703-005007	L7006	INDUCTOR-SMD
2703-005058	L6012,L6017	INDUCTOR-SMD
2703-005067	L5013,L5014,L5015	INDUCTOR-SMD
2703-005070	L7005,L7007	INDUCTOR-SMD
2703-005101	L2000	INDUCTOR-SMD
2703-005201	L5002	INDUCTOR-SMD
2703-005224	L5004	INDUCTOR-SMD
2703-005225	L4004	INDUCTOR-SMD
2703-005339	L5005,L5012	INDUCTOR-SMD
2801-005154	OSC3000	CRYSTAL-UNIT
2801-005300	OSC5000	CRYSTAL-UNIT
2901-001786	F7005,F7006,F7007	FILTER-EMI
2901-001786	F7008,F7009,F7010	FILTER-EMI
2901-001786	F7011,F7012,F7013	FILTER-EMI
2901-001786	F7014	FILTER-EMI

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2901-001798	F7000,F7001,F7002	FILTER-EMI
2901-001798	F7003,F7004	FILTER-EMI
2903-001535	F1000	FILTER-CERAMIC
2904-002143	F1008	FILTER-SAW
2904-002147	F1005	FILTER-SAW
2904-002169	F3001	FILTER-SAW
2904-002190	F2003	FILTER-SAW
2904-002211	F2001	FILTER-SAW
2904-002257	F2005	FILTER-SAW
2904-002278	F2004	FILTER-SAW
2904-002314	U3005	FILTER-SAW
2904-002326	F2002	FILTER-SAW
2904-002350	F1006	FILTER-SAW
2910-000365	F1004	FILTER
2910-000367	U1009	FILTER
2911-000308	U3009	FILTER
2911-000411	F1007	FILTER
2911-000415	U2001	FILTER
3301-001534	L3010,L7011	CORE-FERRITE
3301-001789	L6005,L6006,L7008	CORE-FERRITE
3301-001789	L7009,L7010	CORE-FERRITE
3301-001885	L6007,L6014,L6018	CORE-FERRITE
3301-002223	L7003	CORE-FERRITE
3301-002236	L5009,L5010,L5011	CORE-FERRITE
3301-002236	L7002	CORE-FERRITE
3301-002238	L5008	CORE-FERRITE
3301-002242	L6008,L6009	CORE-FERRITE
3301-002248	L3002	CORE-FERRITE
3301-002286	L6000,L6001,L6013	CORE-FERRITE
3301-002286	L6016	CORE-FERRITE
3301-002331	L5000,U7061	CORE-FERRITE
3705-001937	RFS1000	CONNECTOR-COAXIAL
3709-001869	SIM4001	CONNECTOR-CARD
3709-001873	SIM4000	CONNECTOR-CARD
3711-007107	HEA7000	CONNECTOR-HEADER
3711-008182	HDC7000	CONNECTOR-HEADER
3711-008800	HDC6000	CONNECTOR-HEADER
3711-008824	HDC3001	CONNECTOR-HEADER
3711-008842	HEA7001	CONNECTOR-HEADER

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

3711-008847	BTC5000	CONNECTOR-HEADER
3711-008997	HDC3000	CONNECTOR-HEADER
3711-009073	HEA6000	CONNECTOR-HEADER
3712-001604	ANT6002,ANT6003	CONNECTOR
3712-001621	ANT2001,ANT2003	CONNECTOR
3712-001621	ANT2004,ANT2005	CONNECTOR
3712-001621	ANT3001,ANT3004	CONNECTOR
3712-001621	ANT3005,ANT3006	CONNECTOR
3712-001621	ANT6000,ANT6001	CONNECTOR
3712-001621	ANT6004,ANT6005	CONNECTOR
3712-001621	ANT6006	CONNECTOR
3712-001626	ANT2000,ANT2002	CONNECTOR
3712-001626	ANT2006,ANT2007	CONNECTOR
3712-001626	ANT2008,ANT2009	CONNECTOR
3712-001626	ANT3000,ANT3008	CONNECTOR
3712-001626	ANT3009,CON7000	CONNECTOR
3712-001626	CON7001	CONNECTOR
3712-001633	ANT3010,ANT3011	CONNECTOR
4709-002150	F3000	RF-MODULE
4709-002193	U1003	RF-MODULE
4709-002226	F1002	RF-MODULE
4709-002285	U3006	RF-MODULE
4709-002336	F1001	RF-MODULE
4709-002464	F2000	RF-MODULE
GH61-09798A	SUS2000	SUS
GH63-12525A	SC2002,SC2007	SHIELDCAN
GH63-12526A	SC2004	SHIELDCAN
GH63-12527A	SC2003	SHIELDCAN
GH63-12529A	SC2000	SHIELDCAN
GH98-38707A	SC2001	SHIELDCAN
GH98-39353A	SC2006	SHIELDCAN
GH98-39354A	SC2005	SHIELDCAN

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.