


8. Level 3 Repair


8-1. Components Layout

MAIN PBA (TOP SIDE)

Helpful-Man




MAIN PBA (BOTTOM SIDE)





8. Level 3 Repair

SUB PBA (TOP SIDE)




SUB PBA (BOTTOM SIDE)





SM-A022F/DS_REV1.0 RF Block Diagram

SM-A022F/G/M, M022F/G/M




Main2 ANT (HB)

	CIS	SEA	LA
FDD	1/ 3/ 5/ 7/ 8/ 20	1/ 3/ 5/ 7/ 8/ 20/ 28	1/ 2/ 3/ 4/ 5/ 7/ 8/ 12/ 17/ 20/ 28/ 66
TDD	38/ 40/ 41	38/ 40/ 41	
3G	1/ 5/ 8	1/ 5/ 8	1/ 2/ 4/ 5/ 8
2G	850/ 900/ 1800	850/ 900/ 1800	850/ 900/ 1800/ 1900

Main ANT LB/MB/HB

Main2 ANT HB



SM-A022F/G/M, M022F/G/M
Common

SIM5001

SIM5002

SIM5000

SIM5003

Helpful-Man

SC6000

UCP400

UME5000

SOC7000

BOTH5000

CON5000

PM1

PM2

PM3

PM4

PM5

PM6

PM7

PM8

PM9

PM10

PM11

PM12

PM13

PM14

PM15

PM16

PM17

PM18

PM19

PM20

PM21

PM22

PM23

PM24

PM25

PM26

PM27

PM28

PM29

PM30

PM31

PM32

PM33

PM34

PM35

PM36

PM37

PM38

PM39

PM40

PM41

PM42

PM43

PM44

PM45

PM46

PM47

PM48

PM49

PM50

PM51

PM52

PM53

PM54

PM55

PM56

PM57

PM58

PM59

PM60

PM61

PM62

PM63

PM64

PM65

PM66

PM67

PM68

PM69

PM70

PM71

PM72

PM73

PM74

PM75

PM76

PM77

PM78

PM79

PM80

PM81

PM82

PM83

PM84

PM85

PM86

PM87

PM88

PM89

PM90

PM91

PM92

PM93

PM94

PM95

PM96

PM97

PM98

PM99

PM100

PM101

PM102

PM103

PM104

PM105

PM106

PM107

PM108

PM109

PM110

PM111

PM112

PM113

PM114

PM115

PM116

PM117

PM118

PM119

PM120

PM121

PM122

PM123

PM124

PM125

PM126

PM127

PM128

PM129

PM130

PM131

PM132

PM133

PM134

PM135

PM136

PM137

PM138

PM139

PM140

PM141

PM142

PM143

PM144

PM145

PM146

PM147

PM148

PM149

PM150

PM151

PM152

PM153

PM154

PM155

PM156

PM157

PM158

PM159

PM160

PM161

PM162

PM163

PM164

PM165

PM166

PM167

PM168

PM169

PM170

PM171

PM172

PM173

PM174

PM175

PM176

PM177

PM178

PM179

PM180

PM181

PM182

PM183

PM184

PM185

PM186

PM187

PM188

PM189

PM190

PM191

PM192

PM193

PM194

PM195

PM196

PM197

PM198

PM199

PM200

PM201

PM202

PM203

PM204

PM205

PM206

PM207

PM208

PM209

PM210

PM211

PM212

PM213

PM214

PM215

PM216

PM217

PM218

PM219

PM220

PM221

PM222

PM223

PM224

PM225

PM226

PM227

PM228

PM229

PM230

PM231

PM232

PM233

PM234

PM235

PM236

PM237

PM238

PM239

PM240

PM241

PM242

PM243

PM244

PM245

PM246

PM247

PM248

PM249

PM250

PM251

PM252

PM253

PM254

PM255

PM256

PM257

PM258

PM259

PM260

PM261

PM262

PM263

PM264

PM265

PM266

PM267

PM268

PM269

PM270

PM271

PM272

PM273

PM274

PM275

PM276

PM277

PM278

PM279

PM280

PM281

PM282

PM283

PM284

PM285

PM286

PM287

PM288

PM289

PM290

PM291

PM292

PM293

PM294

PM295

PM296

PM297

PM298

PM299

PM300

PM301

PM302

PM303

PM304

PM305

PM306

PM307

PM308

PM309

PM310

PM311

PM312

PM313

PM314

PM315

PM316

PM317

PM318

PM319

PM320

PM321

PM322


PM323

PM324

PM325

8. Level 3 Repair

8-3. Flow chart of Troubleshooting.




Oscilloscope




Digital Multimeter



Power Supply



+ driver, ESD Safe Tweezer




8960 & Spectrum Analyzer



Soldering iron


8. Level 3 Repair

8-4-1. Power On




8. Level 3 Repair

8-4-2. Initial




8. Level 3 Repair

8-4-3. No Service




8. Level 3 Repair

8-4-4. SIM Part




8. Level 3 Repair

8-4-5. T-Flash Part




8. Level 3 Repair

8-4-6. Cable Charging Part




8. Level 3 Repair

8-4-7. Accel. Sensor




8. Level 3 Repair

8-4-8. Microphone Part - Main MIC




8. Level 3 Repair

8-4-9. Speaker Part




8. Level 3 Repair

8-4-10. Receiver Part




8. Level 3 Repair

8-4-11. BT/WIFI




8. Level 3 Repair

8-4-12. GPS




8. Level 3 Repair

8-4-13. Display




8. Level 3 Repair

8-4-14. 13M/2M REAR CAMERA




8. Level 3 Repair

8-4-15. 5M FRONT CAMERA




8. Level 3 Repair

8-4-16. Motor




8. Level 3 Repair

8-4-17. FM radio part




8. Level 3 Repair

8-4-18. GSM 850/900/1800/1900, WCDMA B1/2/4/5/8, LTE B1/2/3/4/5/8/12/17/20/28/66 PRx




8. Level 3 Repair

8-4-19. LTE B7/38/40/41 PRx




8. Level 3 Repair

8-4-20. WCDMA B1/2/4/5/8, LTE B1/2/3/4/5/8/12/17/20/28/66 DRx




8. Level 3 Repair

8-4-21. LTE B7/38/40/41 DRx



8. Level 3 Repair

8-4-22. GSM 850/900/1800/1900, WCDMA B1/2/4/5/8, LTE B1/2/3/4/5/8/12/17/20/28/66 Tx



8. Level 3 Repair

8-4-23. LTE B7/38/40/41 Tx

