


8. Level 3 Repair

8-3. Flow chart of Troubleshooting.



Oscilloscope




Digital Multimeter



Power Supply



+ driver, ESD Safe Tweezer




8960 & Spectrum Analyzer



Soldering iron


8. Level 3 Repair

8-4-1. Power On




8. Level 3 Repair

8-4-2. Initial




8. Level 3 Repair

8-4-3. No Service




8. Level 3 Repair

8-4-4. SIM Part



8. Level 3 Repair


8-4-5. T-Flash Part



8. Level 3 Repair


8-4-6. Cable Ca

8-4-6. Parte de carregamento do cabocharging Part




8. Level 3 Repair

8-4-7. OTG




8. Level 3 Repair

8-4-8-3. Hall Sensor




8. Level 3 Repair

8-4-8-5. Proximity / Light Sensor




8. Level 3 Repair

8-4-9-1. Microphone Part - Main MIC




8. Level 3 Repair

8-4-9-2. Microphone Part - Sub(2nd) MIC




8. Level 3 Repair

8-4-10. Speaker Part




8. Level 3 Repair

8-4-12. BT/WIFI



8. Level 3 Repair

8-4-13. GPS



8. Level 3 Repair

8-4-18. Quad Camera

